

ERC3 Actuator with Integrated Controller

Instruction Manual Fourteenth Edition

IAI Corporation



### Please Read Before Use

Thank you for purchasing our product.

This instruction manual explains the handling methods, structure and maintenance of this product, providing the information you need in order to use the product safely.

Before using the product, be sure to read this manual and fully understand the contents explained herein to ensure safe use of the product.

Please downloaded the user's manual from our website.

You can download it free of charge. User registration is required for the first time downloading. URL : www.iai-robot.co.jp/data\_dl/CAD\_MANUAL/

When using the product, print out of the necessary portions of the relevant manual, or please display it on your computer, tablet terminal, etc. so that you can check it immediately.

After reading the instruction manual, keep it in a convenient place so that whoever is handling the product can refer to it quickly when necessary.

### [Important]

- This instruction manual is an original document dedicated for this product.
- This product cannot be used in ways not shown in this instruction manual. IAI shall not be liable for any result whatsoever arising from the use of the product in any other way than what is noted in the manual.
- The information contained in this instruction manual is subject to change without notice for the purpose of product improvement.
- If any issues arise regarding the information contained in this instruction manual, contact our customer center or the nearest sales office.
- Use or reproduction of this instruction manual in full or in part without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the text are registered trademarks.





### Table of Contents

\_

Safety Guide	···1
Guideline for Control Method ······	8
Precautions in Operation ······	9
International Standards Compliances	· 13
Names of the Parts	· 14
Actuator Coordinate	·24
Starting Procedures	· 25

Chapter	<sup>-</sup> 1 S	pecifications Check ·······31	1
1.1	Product	Check	1
	1.1.1	Parts ·······34	1
	1.1.2	Teaching Tool ······32	2
	1.1.3	Instruction manuals related to this product	2
	1.1.4	How to read the model plate	3
	1.1.5	How to read the model	4
1.2	Specifica	ations······36	3
	1.2.1	Actuator ····································	3
		[1] High Output Setting	3
		[2] Maximum speed ·······38	3
		[3] MAX. Acceleration, Payload Capacity42	1
		[4] Driving System • Position Detector 53	3
		[5] Positioning Precision54	4
		[6] Current Limit Value and Pressing Force55	5
		[7] Option	9
	1.2.2	Built-in Controller ······60	)
		[1] Basic Specifications	)
		[2] I/O Specifications ····································	1
	1.2.3	Control Option ······63	3
		[1] PIO Converter (Model: RCB-DDD)63	3
		[2] Quick Teach (Model: RCM-PST- ) ······67	7
Chapter	2 In	istallation 71	1
2.1	Transpor	rtation	1
		[1] Handling of Actuator, PIO Converter and Quick Teach	1
		[2] Handling of Multi-Axes Type 72	2
		[3] Handling of Robot Mounted on Mechanical Equipment (System)	2
2.2	Installation	on and Storage Environment 73	3
		[1] Installation Environment 73	3
		[2] Storage • Preservation Environment 72	4
2.3	How to I	nstall ······75	ō
	2.3.1	Posture of Actuator Attachment	S
	2.3.2	Installation of Slider Type	[
		[1] Attachment of Actuator Body (Standard Type (Screw Cover Type)/	(
		[2] Load Attachment (Standard Type (Screw Cover Type)80	J
		[3] Attachment of Actuator Body (Standard Type (Stainless Steel	~
		Sneet Type), Cleanroom Type)······82	2
		[4] Load Attachment (Standard Type (Stainless Steel Sheet Type),	-
	0 0 0		2 7
	2.3.3	All Suction of Slider Type (Cleanfoorn Type)	1
		[1] Reference for vacuuming Capacity	1
		[2] vacuum Joint ······8/	(



	2.3.4	Installation of Rod Type	88 88
	235	[2] Load Allachment	93
	2.0.0	[1] Noise Flimination Grounding (Frame Ground)	.95
		[2] Precautions regarding wiring method	.99
		[3] Noise Sources and Elimination	.99
		[4] Cooling Factors and Installation	.99
Chapter	r3 W	/iring	01
3.1	Positione	er Mode 1 (Standard Type)······1	01
	3.1.1	Wiring Diagram (Connection of construction devices)1	01
	3.1.2	PIO Pattern Select and PIO Signal 1	02
		[1] PIO Pattern (Control Pattern) Selection1	02
		[2] PIO Patterns and Signal Assignment	03
	0.4.0	[3] List of PIO Signals1	04
	3.1.3	Circuit Diagram	05
		[1] Power Line and Emergency Stop Circuit	05
3.2		[Z] FIO Circuit ain Control Mode	00
0.2	321	Wiring Diagram (Connection of construction devices)	03
	3.2.2	PIO Pattern Selection and PIO Signal	110
		[1] PIO Pattern (Control Pattern) Selection	110
		[2] PIO pattern and Signal Allocation 1	110
		[3] List of PIO Signals 1	111
	3.2.3	Circuit Diagram 1	12
		[1] Power Line and Emergency Stop Circuit	112
		[2] Command Pulse Train Circuit	113
2.2	Desition	[3] PIO Circuit	114
3.3	2 2 1	Wiring Diagram (Connection of construction devices)	110
	332	PIO Pattern Selection and PIO Signal	117
	0.0.2	[1] PIO Pattern (Control Pattern) Selection	117
		[2] PIO Patterns and Signal Assignment 1	118
		[3] List of PIO Signals 1	20
	3.3.3	Circuit Diagram 1	22
		[1] Power Line and Emergency Stop Circuit1	22
		[2] PIO Converter to ERC3	25
2.4		[3] PIO Circuit	20
3.4		Wiring Diagram (Connection of construction devices)	32 32
	342	PIO Pattern Selection and PIO Signal	33
	0.4.2	[1] Operation pattern	33
		[2] Operation Patterns and Signal Assignments1	34
		[3] List of PIO Signals1	35
	3.4.3	Circuit Diagram 1	36
		[1] Power Line and Emergency Stop Circuit1	36
		[2] PIO Circuit 1	37
3.5	MEC Mo	de 2 (Operation Using PIO Converter)	39
	3.5.1	Wiring Diagram (Connection of construction devices)	39
	3.3.Z	FIO Pattern Selection and FIO Signal	40
		[2] Operation Patterns and Signal Assignments	40
		[3] List of PIO Signals ·······1	42
	3.5.3	Circuit Diagram	43
		[1] Power Line and Emergency Stop Circuit	43
		[2] PIO Converter to ERC3	46
		[3] PIO Circuit 1	47



3.6	MEC Mo	ode 3	(Solo Operation with Quick Teach)	149
	3.6.1	Wirir	ng Diagram (Connection of construction devices)	149
		[1]	RCM-PST-0 (24V DC power supply type)	149
		[2]	RCM-PST-1	150
		[3]	RCM-PST-2	151
3.7	Wiring N	1etho	d ·····	152
	3.7.1	Wirir	ng of Actuator·····	152
		[1]	PIO type power and I/O cable (Model : CB-ERC3P-PWBIO	152
		[2]	SIO type power and I/O cable (Model : CB-ERC3S-PWBIO	153
	3.7.2	Wirir	ng between PIO Converter and Quick Teach	154
	3.7.3	Wirir	ng between PIO Converter and Host Controller (e.g. PLC) ·······	155
	3.7.4	Wirir	ng of PIO Converter Power Line Connector ·····	159
	3.7.5	Puls	e Converter: AK-04 (Optional accessory)	160
	3.7.6	Teac	ching Port Connector Connection of ERC3 Main Unit	161
	3.7.7	Con	nection of SIO Connector of PIO Converter ·····	162
Chapte	r4 O	pera	tion	163
4.1	Basic Op	oerati	on	163
	4.1.1	Basi	c Operation Methods······	163
		[1]	Positioner Mode 1 (PIO Operation of ERC3) ······	163
		[2]	Pulse Train Control Mode (Pulse Train Operation of ERC3)	164
		[3]	Positioner Mode 2 (Extended Operation of ERC3)······	165
		[4]	MEC Mode 1	166
		[5]	MEC Mode 2	167
		[6]	MEC Mode 3	167
	4.1.2	Para	ameter Settings	168
4.2	Operatio	n in F		169
	4.2.1	Set		169
	4.2.2	Ope		174
		[1]	PIO Pattern Selection and Main Functions	174
		[2]	Overview of major Functions	175
		[3]	Power Supply and Emergency Stop Release (CP, MP, EMG, PEND).	170
		[4]	Brake release BK	1//
		[၁] (၉)	Operation Ready and Auviliany Signal	170
		[0]	Operation with the Desition No. Input =	1/0
		[/]	Operations of PIO Detterne 0 and 2	100
		<b>1</b> 01	Direct Desition Specification (2 point < Selonoid values type) =	102
		႞၀]	Direct Position Specification (S-point <solenoid td="" type)="" valve-="" –<=""><td>105</td></solenoid>	105
	123	One	ration in Positioner Mode 2 (Operation Using PIO Converter)	207
	4.2.0	[1]	PIO Pattern Selection and Main Functions	207
		[2]	Overview of major Functions	208
		[ <u>~]</u>	Power Supply and Emergency Stop Release	200
		[0]	(CP24 MPI MPO FMG(-))	209
		[4]	Time Constant for Control Signal Input	200
		[5]	Operation Ready and Auxiliary Signals	210
		[6]	Operation with the Position No. Input =	
		[~]	Operations of PIO Patterns 0 to 3	219
		[7]	Direct Position Specification (Solenoid Valve Mode 1) =	
		r. 1	Operation of PIO Pattern 4	236
		[8]	Direct Position Specification (Solenoid Valve Mode 2) =	
			Operations of PIO Pattern 5 in PIO Converter	248

# ERC**3** =

4.3	Operatio	n in P	Pulse Train Control Mode (How to Operate Pulse Train Control Type) $\cdots$	· 255
		[1]	Guideline for PIO Pattern Selection and Supportive Functions	·255
		[2]	Guideline for Supportive Functions	· 255
		[3]	Power Supply and Emergency Stop Release (CP, MP, EMG)	·256
		[4]	Brake Release BK	256
		[5]	Time Constant for Control Signal Input	· 257
		[6]	Operation Ready and Auxiliary Signals	257
		[7]	Pulse Train Input Operation	·261
		[8]	Settings of Basic Parameters Required for Operation	· 264
		[9]	Parameter Settings Required for Advanced Operations	·267
4.4	Operatio	n in N	IEC Mode 1 and 2 (Operation with PLC)	· 269
		[1]	Outline for Operation Patterns and Functions	·269
		[2]	Table for Operational Conditions (Position Table) and	
			Positioning Complete Signal	270
		[3]	Power Supply and Emergency Stop Release	·274
		i4i	Brake release BK	276
		[5]	Time Constant for Control Signal Input	276
		[6]	Operation when Operation Pattern is "2-Point Stop (2-Point	-
		[-]	Positioning)" ·····	277
		[7]	Operation when Operation Pattern is "3-Point Stop (3-Point	
		L . J	Positioning)" ·····	278
4.5	Operatio	n in N	IEC Mode 3 (Test Run with Quick Teach.) ······	· 281
	4.5.1	Oper	ation Panel Functions	·281
	452	Oper	ations	282
		[1]	Switches Used for Mode Selection (Auto 🗢 Manual)	. 282
		[2]	Switch Lised for Servo ON/OFE Operation	. 282
		[2]	Switch Used for Home-Return Operation	. 282
		[J] [4]	Switches Used for Manual Operation	. 282
		[ <sup>-</sup> ] [5]	Switch Lised for Brake Release	. 283
		[0]	Switches Used to Change Desitioning Point Number	200
		[0] [7]	Switches Used for Position Teaching	205
		[/]	Switches and Rotary Knobs Lised in Acceleration/Deceleration and	204
		[0]	Speed Settings	. 287
		[0]	Switches Lised in Test Run	. 287
		[3]	Switches Used in Alarm Reset	. 287
	153	Tost	Bun with Operation Panel	. 288
	4.3.3	IESU		200
Chantor	- E D	owor	action Eurotion	
Chapter	Э Р	ower-	-saving runction	007
- 4	( <i>F</i>	Autom		297
5.1	Positione	er Moo	de 1 and 2	297
5.2	Pulse Ira	ain Co	ontrol Mode·····	.300
5.3	MEC Mo	de 1,	2 and 3	.301
	5.3.1	Auto	matic Servo-off Function	· 301
	5.3.2	Full S	Servo Function ·····	· 303
Chapter	6 A	djustr	ment of Operation	305
6.1	Absolute	Rese	et and Absolute Battery······	· 305
	6.1.1	Abso	lute Reset ·····	· 305
		[1]	Absolute reset procedure from teaching tool	· 305
		[2]	Absolute reset using PIO	· 308
		[3]	Absolute Battery	310
6.2	High Out	tput S	etting and Gain Scheduling Function ·····	·313
	6.2.1	High	Output Setting ·····	313
	6.2.2	Gain	Scheduling Function ·····	· 313
	6.2.3	Settir	ng in Positioner Mode 1 & 2 and Pulse Train Control Mode	·313
	6.2.4	Settir	ng in MEC Mode 1 to 3······	· 314



6.3	I/O Parar	meter ·····	315
	6.3.1	Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode	316
		[1] I/O Parameter List	··· 316
		[2] Detail Explanation of Parameters	320
		[3] Servo Adjustment	··· 347
	6.3.2	MEC Mode 1, MEC Mode 2 and MEC Mode 3······	350
		[1] I/O Parameter List	350
		[2] Detail Explanation of Parameters	352
		[3] Servo Adjustment	360
Chantor	·7 Tr	roublesheating	. 262
	Action to	Be Taken upon Occurrence of Problem	. 363
7.1	Fault Dia	annosis	365
1.2	721	Impossible operation of controller ······	365
	722	Positioning and speed of poor precision (incorrect operation)	370
	7.2.3	Generation of noise and/or vibration	372
7.3	Alarm Le		373
7.4	Alarm Lis	st	374
Chapter	·8 A	ctuator Maintenance Check ······	· 387
8.1	Inspectio	on Items and Schedule ······	387
8.2	External	Visual Inspection ·····	388
8.3	Cleaning	]	388
8.4	Internal I	Inspections for Slider Type ·····	389
8.5	Internal (	Cleaning for Slider Type	389
8.6	Grease S	Supply ·····	390
	8.6.1	Grease Supply for Slider Type	390
		[1] Other Types than Cleanroom Type	390
	0 0 0	[2] Cleanroom Type	390
	8.6.2	How to Supply Grease on Slider Type	391
		[1] Standard Type (Screw Cover Type)	
	863	[2] Standard Type (Stanless Steel Sheet Type), Cleantoon Type	
	861	How to Supply Grease on Rod Type	306
	865	How to Replace and Adjust Stainless Steel Sheet	398
	0.0.0	[1] Preparation	398
		[2] Procedure for Replacement and Tuning	399
8.7	Motor Re	eplacement Process	·· 401
Chapter	·9 Ex	xternal Dimensions ······	· 403
9.1	ERC3-SA	A5C	··· 403
9.2	ERC3-SA	A7C	…404
9.3	ERC3D,	ERC3CR-SA5C Standard Type (Stainless Steel Sheet Type),	
	Cleanroo	от Туре	405
9.4	ERC3D,	ERC3CR-SA7C Standard Type (Stainless Steel Sheet Type),	
	Cleanroo	от Туре ·····	406
9.5	ERC3-R/	A4C ·····	407
9.6	ERC3-R/		408
Chanter	. 10	a na a dive	400
		ppendix d Output Deepense Defermence When DIO Converter is Used	• 409
10.1	May to S	a Output Response Periornance when PIO Converter is Used	··409
10.2	10 2 1	Connecting Example	/11
	10.2.1	Detailed Connection Diagram of Communication Lines	·· <u>/</u> 12
	10.2.2	Axis No Setting	
	10.2.4	Handling of e-CON connector (how to connect)	413
	10.2.5	SIO Converter	414
	10.2.6	Communications Cable	416



10.3	Conformity to Safety Category417	7
	[1] System Configuration	7
	[2] Wiring and setting of safety circuit	8
	[3] Examples of safety circuits ······420	0
	[4] TP adapter and Related Parts······426	6
10.4	When Connecting Power Supply with + Grounding	8
10.5	Example of Basic Positioning Sequence (PIO Patterns 0 to 3 in PIO Converter) ······429	9
	10.5.1 I/O Assignment 429	9
	10.5.2 Ladder Sequence·····430	0
	[1] Servo ON (Emergency Stop) Circuit ·······················430	0
	[2] Operation and Stop Circuit ······430	0
	[3] Pause Circuit ······43	1
	[4] Reset Circuit ······432	2
	[5] Home Return Circuit ······433	3
	[6] Decode Circuit of Positioning Complete Position No	4
	[7] Actuator Start Circuit ······434	4
	[8] Position 1 Operation Circuit ······43	5
	[9] Position 2 Operation Circuit ······436	6
	[10] Position 3 Operation Circuit ······43	7
	[11] Commanded Position No. Output Ready Circuit	8
	[12] Commanded Position No. Output Circuit ······ 43	9
	[13] Start Signal Output Circuit 43	9
	[14] Other Display Circuits (Zone 1, Position Zone, and Manual Mode) 44	0
10.6	Life ······44'	1
	10.6.1 How to Calculate Operation Life	1
	10.6.2 Operation Life ······442	2
Chapte	r 11 Warranty ······ 443	3
11.1	Warranty Period 443	3
11.2	Scope of the Warranty 443	3
11.3	Honoring the Warranty ······443	3
11.4	Limited Liability	4
11.5	Conditions of Conformance with Applicable Standards/Regulations, Etc.,	
	and Applications ······444	4
11.6	Other Items Excluded from Warranty	4
Change	e History 445	5



### Safety Guide

"Safety Guide" has been written to use the machine safely and so prevent personal injury or property damage beforehand. Make sure to read it before the operation of this product.

### **Safety Precautions for Our Products**

The common safety precautions for the use of any of our robots in each operation.

No.	Operation Description	Description
1	Model Selection	<ul> <li>This product has not been planned and designed for the application where high level of safety is required, so the guarantee of the protection of human life is impossible.</li> <li>Accordingly, do not use it in any of the following applications.</li> <li>1) Medical equipment used to maintain, control or otherwise affect human life or physical health.</li> <li>2) Mechanisms and machinery designed for the purpose of moving or transporting people (For vehicle, railway facility or air navigation facility)</li> <li>3) Important safety parts of machinery (Safety device, etc.)</li> <li>Do not use the product outside the specifications.</li> <li>Failure to do so may considerably shorten the life of the product.</li> <li>Do not use it in any of the following environments.</li> <li>1) Location where there is any inflammable gas, inflammable object or explosive</li> <li>2) Place with potential exposure to radiation</li> <li>3) Location with the ambient temperature or relative humidity exceeding the specification range</li> <li>4) Location where radiant heat is added from direct sunlight or other large heat source</li> <li>5) Location where there is any corrosive gas (sulfuric acid or hydrochloric acid)</li> <li>7) Location exposed to significant amount of dust, salt or iron powder</li> <li>8) Location subject to direct vibration or impact</li> <li>For an actuator used in vertical orientation, select a model which is equipped with a brake. If selecting a model with no brake, the moving part may drop when the power is turned OFF and may cause an accident such as an injury or damage on the work piece.</li> </ul>



No.	Operation Description	Description
2	Transportation	<ul> <li>When carrying a heavy object, do the work with two or more persons or utilize equipment such as crane.</li> <li>When the work is carried out with 2 or more persons, make it clear who is to be the "leader" and who to be the "follower(s)" and communicate well with each other to ensure the safety of the workers.</li> <li>When in transportation, consider well about the positions to hold, weight and weight balance and pay special attention to the carried object so it would not get hit or dropped.</li> <li>Transport it using an appropriate transportation measure. The actuators available for transportation with a crane have eyebolts attached or there are tapped holes to attach bolts. Follow the instructions in the instruction manual for each model.</li> <li>Do not step or sit on the package.</li> <li>Do not put any heavy thing that can deform the package, on it.</li> <li>When using a crane capable of 1t or more of weight, have an operator who has qualifications for crane operation and sling work.</li> <li>When using a crane or equivalent equipments, make sure not to hang a load that weighs more than the equipment's capability limit.</li> <li>Use a hook that is suitable for the load. Consider the safety factor of the hook in such factors as shear strength.</li> <li>Do not get on the load that is hung on a crane.</li> <li>Do not leave a load hung up with a crane.</li> </ul>
3	Storage and Preservation	<ul> <li>The storage and preservation environment conforms to the installation environment. However, especially give consideration to the prevention of condensation.</li> <li>Store the products with a consideration not to fall them over or drop due to an act of God such as earthquake.</li> </ul>
4	Installation and Start	<ul> <li>(1) Installation of Robot Main Body and Controller, etc.</li> <li>Make sure to securely hold and fix the product (including the work part). A fall, drop or abnormal motion of the product may cause a damage or injury. Also, be equipped for a fall-over or drop due to an act of God such as earthquake.</li> <li>Do not get on or put anything on the product. Failure to do so may cause an accidental fall, injury or damage to the product due to a drop of anything, malfunction of the product, performance degradation, or shortening of its life.</li> <li>When using the product in any of the places specified below, provide a sufficient shield.</li> <li>1) Location where electric noise is generated</li> <li>2) Location with the mains or power lines passing nearby</li> <li>4) Location where the product may come in contact with water, oil or chemical droplets</li> </ul>



No.	Operation Description	Description
4	Installation and Start	<ul> <li>(2) Cable Wiring</li> <li>Use our company's genuine cables for connecting between the actuator and controller, and for the teaching tool.</li> <li>Do not scratch on the cable. Do not bend it forcibly. Do not pull it. Do not coil it around. Do not insert it. Do not put any heavy thing on it. Failure to do so may cause a fire, electric shock or malfunction due to leakage or continuity error.</li> <li>Perform the wiring for the product, after turning OFF the power to the unit, so that there is no wiring error.</li> <li>When the direct current power (+24V) is connected, take the great care of the directions of positive and negative poles. If the connection direction is not correct, it might cause a fire, product breakdown or malfunction.</li> <li>Connect the cable connector securely so that there is no disconnection or looseness. Failure to do so may cause a fire, electric shock or malfunction of the product.</li> <li>Never cut and/or reconnect the cables supplied with the product for the purpose of extending or shortening the cable length. Failure to do so may cause the product to malfunction or cause fire.</li> </ul>
		<ul> <li>(3) Grounding</li> <li>The grounding operation should be performed to prevent an electric shock or electrostatic charge, enhance the noise-resistance ability and control the unnecessary electromagnetic radiation.</li> <li>For the ground terminal (PE) on the AC power cable of the controller and the grounding plate in the control panel, make sure for grounding work. For security grounding, it is necessary to select an appropriate wire thickness suitable for the load. Perform wiring that satisfies the specifications (electrical equipment standards and criteria). For detail, follow the description in [an instruction manual of each controller or controller built-in actuator].</li> <li>Conduct functional grounding on the FG terminal for a controller supplying 24V DC or a controller built-in type actuator. In order to minimize influence to mechanical operation given by electromagnetic interference (noise) to an electrical device or insulation failure, conduct grounding on a terminal or a conductor that is electrically stable. The reference impedance should be Type D (Former Class 3, ground resistance 100Ω or less).</li> </ul>



No.	Operation Description	Description
4	Installation and Start	<ul> <li>(4) Safety Measures</li> <li>When the work is carried out with 2 or more persons, make it clear who is to be the "leader" and who to be the "follower(s)" and communicate well with each other to ensure the safety of the workers.</li> <li>When the product is under operation or in the ready mode, take the safety measures (such as the installation of safety and protection fence) so that nobody can enter the area within the robot's movable range. When the robot under operation is touched, it may result in death or serious injury.</li> <li>Make sure to install the emergency stop circuit so that the unit can be stopped immediately in an emergency during the unit operation.</li> <li>Take the safety measure not to start up the unit only with the power turning ON. Failure to do so may start up the machine only with the emergency stop cancellation or recovery after the power failure. Failure to do so may result in an electric shock or injury due to unexpected power input.</li> <li>When the installation or adjustment operation is to be performed, give clear warnings such as "Under Operation; Do not turn ON the power!" etc. Sudden power input may cause an electric shock or injury.</li> <li>Take the measure so that the work part is not dropped in power failure or emergency stop.</li> <li>Wear protection gloves, goggle or safety shoes, as necessary, to secure safety.</li> <li>Do not insert a finger or object in the openings in the product. Failure to do so may cause an injury, electric shock, damage to the product or fire.</li> <li>When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by aravity.</li> </ul>
5	Teaching	<ul> <li>When the work is carried out with 2 or more persons, make it clear who is to be the "leader" and who to be the "follower(s)" and communicate well with each other to ensure the safety of the workers.</li> <li>Perform the teaching operation from outside the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well.</li> <li>When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency.</li> <li>When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly.</li> <li>Place a sign "Under Operation" at the position easy to see.</li> <li>When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.</li> <li>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</li> </ul>



No.	Operation Description	Description
6	Trial Operation	<ul> <li>When the work is carried out with 2 or more persons, make it clear who is to be the "leader" and who to be the "follower(s)" and communicate well with each other to ensure the safety of the workers.</li> <li>After the teaching or programming operation, perform the check operation one step by one step and then shift to the automatic operation.</li> <li>When the check operation is to be performed inside the safety protection fence, perform the check operation using the previously specified work procedure like the teaching operation.</li> <li>Make sure to perform the programmed operation check at the safety speed. Failure to do so may result in an accident due to unexpected motion caused by a program error, etc.</li> <li>Do not touch the terminal block or any of the various setting switches in the power ON mode. Failure to do so may result in an electric shock or malfunction.</li> </ul>
7	Automatic Operation	<ul> <li>Check before starting the automatic operation or rebooting after operation stop that there is nobody in the safety protection fence.</li> <li>Before starting automatic operation, make sure that all peripheral equipment is in an automatic-operation-ready state and there is no alarm indication.</li> <li>Make sure to operate automatic operation start from outside of the safety protection fence.</li> <li>In the case that there is any abnormal heating, smoke, offensive smell, or abnormal noise in the product, immediately stop the machine and turn OFF the power switch. Failure to do so may result in a fire or damage to the product.</li> <li>When a power failure occurs, turn OFF the power switch. Failure to do so may cause an injury or damage to the product, due to a sudden motion of the product in the recovery operation from the power failure.</li> </ul>

\_\_\_\_



No.	Operation Description	Description
8	Maintenance and Inspection	<ul> <li>When the work is carried out with 2 or more persons, make it clear who is to be the "leader" and who to be the "follower(s)" and communicate well with each other to ensure the safety of the workers.</li> <li>Perform the work out of the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well.</li> <li>When the work is to be performed inside the safety protection fence, basically turn OFF the power switch.</li> <li>When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency.</li> <li>When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly.</li> <li>Place a sign "Under Operation" at the position easy to see.</li> <li>For the grease for the guide or ball screw, use appropriate grease according to the instruction manual for each model.</li> <li>Do not perform the dielectric strength test. Failure to do so may result in a damage to the product.</li> <li>When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.</li> <li>The slider or rod may get misaligned OFF the stop position if the servo is turned OFF. Be careful not to get injured or damaged due to an unnecessary operation.</li> <li>Pay attention not to lose the removed cover or screws, and make sure to put the product back to the original condition after maintenance and inspection works.</li> <li>Use in incomplete condition may cause damage to the product or an injury.</li> </ul>
9	Modification and Dismantle	<ul> <li>Do not modify, disassemble, assemble or use of maintenance parts not specified based at your own discretion.</li> </ul>
10	Disposal	<ul> <li>When the product becomes no longer usable or necessary, dispose of it properly as an industrial waste.</li> <li>When removing the actuator for disposal, pay attention to drop of components when detaching screws.</li> <li>Do not put the product in a fire when disposing of it. The product may burst or generate toxic gases.</li> </ul>
11	Other	<ul> <li>Do not come close to the product or the harnesses if you are a person who requires a support of medical devices such as a pacemaker. Doing so may affect the performance of your medical device.</li> <li>See Overseas Specifications Compliance Manual to check whether complies if necessary.</li> <li>For the handling of actuators and controllers, follow the dedicated instruction manual of each unit to ensure the safety.</li> </ul>



### **Alert Indication**

The safety precautions are divided into "Danger", "Warning", "Caution" and "Notice" according to the warning level, as follows, and described in the instruction manual for each model.

Level	Degree of Danger and Damage	Symbol		
Danger	This indicates an imminently hazardous situation which, if the product is not handled correctly, will result in death or serious injury.		Danger	
Warning	This indicates a potentially hazardous situation which, if the product is not handled correctly, could result in death or serious injury.		Warning	
Caution	This indicates a potentially hazardous situation which, if the product is not handled correctly, may result in minor injury or property damage.		Caution	
Notice	This indicates lower possibility for the injury, but should be kept to use this product properly.	!	Notice	



### Guideline for Control Method

ERC3 has numerous operation patterns and options to meet many criteria for different applications. Check Chapter 4 Operation for more details.

When Quick Teach is used with Con mode only Jog Operation is available.

					Codes in brackets are model codes						
No	Type of	Cont	roller	Compulsory	Overview						
110.	Operation	I/O Type	Controller Type	Option							
1	Positioner Mode 1 (Standard Type)	PIO Type (NP/PN)	CON Mode (CN)	_	<ul> <li>Select from 3 types of PIO patterns for the operation method</li> <li>Number of maximum positioning points: 16 points</li> </ul>						
2	Pulse Train Control Mode	Pulse Train Control Type (PLN/PLP) <sup>(Note 1)</sup>	CON Mode (CN)	– Pulse Converter AK-04	<ul> <li>An operation by pulse train input is available.</li> <li>There are 2 types of operation methods (Positioning/Pressing)</li> <li>Applicable for open collector pulse train output</li> <li>There are 2 types of operation methods</li> </ul>						
					(Positioning/Pressing)						
3	Positioner Mode 2 (Expansion Type)	SIO Type (SE)	CON Mode (CN)	PIO Converter	<ul> <li>Select from 6 types of PIO patterns for the operation method</li> <li>Number of maximum positioning points: 512 points</li> <li>Capable for Simple Absolute Type application</li> </ul>						
4	MEC Mode 1	PIO Type (NP/PN)	MEC Mode (MC)	Quick Teach	<ul> <li>The same control as air cylinder is available</li> <li>Simple operation is available with Quick Teach (teaching pendant)</li> <li>There are 2 types of operation patterns (2-Point Positioning/3-Point Positioning)</li> </ul>						
5	MEC Mode 2	SIO Type (SE)	MEC Mode (MC)	PIO Converter Quick Teach	<ul> <li>The same control as air cylinder is available</li> <li>Simple operation is available with Quick Teach (teaching pendant)</li> <li>There are 2 types of operation patterns (2-Point Positioning/3-Point Positioning)</li> <li>Capable for Simple Absolute Type application</li> </ul>						
6	MEC Mode 3	SIO Type (SE)	MEC Mode (MC)	Quick Teach	<ul> <li>Individual operation is available by Quick Teach</li> <li>There are 2 types of operation patterns (2-Point Positioning/3-Point Positioning)</li> </ul>						

. . . . -1 - 1

The pulse train input is the differential input (Line Driver) type. For PLN, PIO is NPN type Note 1 and PLP is PNP type.

Note 2 It is also available to use any teaching tool other than Quick Teach.

A Caution : The selection of the controller type is determined by the selection of the model code. The type of built-in controller differs for each type. Since the hardware is different, it is not possible to select the type with parameters after the product is delivered out.



### Precautions in Operation

 It is set to "high output" when the machine is delivered from the factory. There is a limit in the duty for the high output setting. Even though the transportable weight and maximum speed decrease, an operation with the duty 100% becomes available if the high output setting is set invalid in the parameters.

See 1.2.1 Settings for Valid/Invalid of High Output Setting for more details.

#### 2. Set the operation patterns.

There are some operation (PIO) patterns prepared for each model classified by the built-in controller.

Set the operation pattern and parameters suitable for the operation method of each model. See Chapter 4 Operation for more details.

Caution : Please note it is very risky when the control sequence and PIO pattern setting do not match to each other. It may not only cause the normal operation disabled, but also may cause an unexpected operation.

3. Do not set speeds and accelerations/decelerations equal to or greater than the respective ratings.

If the actuator is operated at a speed or acceleration/deceleration exceeding the allowable value, abnormal noise or vibration, failure, or shorter life may result.

4. The allowable load moment for the slider type should be within the allowable range.

If the actuator is operated under a load equal to or greater than the allowable load moment, abnormal noise or vibration, failure, or shorter life may result. In an extreme case, flaking may occur.

- 5. The overhung for the slider type should be within the allowable range. Attaching a load beyond the allowable overhang length may generate vibration or abnormal noise.
- 6. Do not attempt to apply a rotary torque the rod type. Doing so may damage the internal component such as the rod stopper, and may result in an operation failure.



7. Back and forth operation in short distance may wear out the oil film of the grease.

If the actuator is moved back and forth continuously over a short distance of 30 mm or less, grease film may run out. As a guide, move the actuator back and forth repeatedly for around 5 cycles over a distance of 50 mm or more after every 5,000 to 10,000 cycles. Keep using the actuator with the grease worn out may cause malfunction. If it is extreme, flaking may occur on the guide.



- 8. Do not attempt to hit the slider or rod against an obstacle with high speed. It may destroy the coupling.
- 9. Make sure to attach the actuator properly by following this instruction manual. Using the product with the actuator not being certainly retained or affixed may cause abnormal noise, vibration, malfunction or shorten the product life.
- 10. Make sure to follow the usage condition, environment and specification range of the product. In case it is not secured, it may cause a drop in performance or malfunction of the product.
- 11. Use the dedicated teaching tool. Check 1.1.2 Teaching Tool for the PC software and teaching pendant available for this controller.
- Do not connect Quick Teach while a tool (teaching) is being connected to the 8-pin mini DIN connector on the ERC3 main unit. Communication between ERC3 and the tool (teaching or PC) becomes unable.
- 13. Do not connect Quick Teach while a tool is being connected to TP connector (8-pin mini DIN) on ERC3 side.

Since the communication with Quick Teach cannot be established, ERC3 cannot receive the high-output invalid command and runs with the high-output setting condition, resulting in a generation of the voltage drop error due to the capacity drop of the power supply unit inside Quick Teach.

14. Backup the data to secure for breakdown.

A non-volatile memory is used as the backup memory for this controller. All the registered position data and parameters are written into this memory and backed-up at the same time. Therefore, you will not usually lose the data even if the power is shut down. However, make sure to save the latest data so a quick recovery action can be taken in case when the controller is broken and needs to be replaced with another one.

How to Save Data

- (1) Save the data to CD-R or hard disk with using the PC software
- (2) Hard-copy the information of position tables and parameters on paper
- 15. Clock Setting in Calendar Function

When power is supplied to the PIO converter for the first time, "Error Code 069 Real Time Clock Vibration Stop Detected" May get generated. In the case this happens, set the current time with a teaching tool.

If the battery is fully charged, the clock data is retained for approximately 10 days after the power is turned OFF. Even though the time setting is conducted before the product is shipped out, the battery is not fully charged. Therefore, there may be a case that the clock data is lost even with fewer days than described above passed since the product is shipped out.

16. Pulse Train Control Type cannot be operated with the serial communication. It is able, however, to monitor the current position or the conditions of the status.



- 17. When using Pulse Train Control type, pay close attention to the pulse frequency; so the frequency will no exceed the actuator specification. In the pulse train control, the acceleration/deceleration speed is also controlled by the change of the command pulse frequency from the host controller. Be careful not to exceed the maximum acceleration/deceleration speed of the actuator. The use of the actuator with excessive acceleration/deceleration rate may cause a malfunction.
- 18. For CON Mode Type, an operation cannot be made unless the servo-on signal and pause signal are input.
  - (1) Servo ON Signal SON

Servo-on signal SON is selectable from either "Enable" or "Disable" by the parameter. This setting can be performed in Parameter No.21 "Servo ON input disable selection". [Refer to Chapter 7 Parameters.] If it is set to "Enable", the actuator would not operate unless turning this signal ON. If parameter No.21 is set to "1", SON is made disable. If it is set to "Disable", the servo becomes ON and the actuator operation becomes enabled as soon as the power supply to the controller is turned ON and the emergency stop signal is cancelled. The factory setting is "0" (Enable). Have the setting that suits the desired control logic.

(2) Pause Signal \*STP

The input signal of the pause signal \*STP is always ON considering the safety. Therefore, in general, the actuator would not operate if this signal is not ON.

It is available to make this signal to "Disable", if this signal is undesirable.

It is settable by parameter No.15 "Pause input disable".

[Refer to Chapter 7 Parameters.]

If parameter No.15 is set to "1" (Disable), the actuator can operate even if this signal is not ON.

This parameter is set to "0" (Enable) at delivery.



#### 19. Transference of PIO Signal between Controllers

Please note the following when conducting transference of PIO signal between controllers. To certainly transfer the signal between controllers with different scan time, it is necessary to have longer scan time than the one longer than the other controller. To ensure to end the process safely, it is recommended to have the timer setting more than twice as long as the longer scan time at least.

#### Operation Image

#### PLC

(e.g. scan time is 20msec)



As shown in the diagram, the input and output timings of two devices that have different scan time do not match, of course, when transferring a signal.

There is no guarantee that PLC would read the signal as soon as this controller signal turns on. In such a case, make the setting to read the signal after a certain time that is longer than the longer scan time to ensure the reading process to succeed on the PLC side.

It is the same in the case this controller side reads the signal.

In such a case, it is recommended to ensure 2 to 4 times of the scan time for the timer setting margin.

It is risky to have the setting below the scan time since the timer is also processed in the scan process.

In the diagram, PLC can only read the input once in 20msec even though this controller output once in 1msec.

Because PLC only conducts output process once in 20msec, this controller identifies the same output status for that while.

Also, if one tries to read the signal that is being re-written by the other, the signal may be read wrongly. Make sure to read the signal after the rewriting is complete. (It is recommended to have more than 2 scan periods to wait.) Make sure not to have the output side to change the output until the other side completes the reading. Also, a setting is made on the input area not to receive the signal less than a certain time to prevent a wrong reading of noise. This duration also needs to be considered.

#### 20. PLC Timer Setting

Do not have the PLC timer setting to be done with the minimum setting.

Setting to "1" for 100msec timer turns ON at the timing from 0 to 100msec while 10msec timer from 0 to 10msec for some PLC.

Therefore, the same process as when the timer is not set is held and may cause a failure such as the actuator cannot get positioned to the indicated position number in Positioner Mode. Set "2" as the minimum value for the setting of 10msec timer and when setting to 100msec, use 10msec timer and set to "10".



## International Standards Compliances

This product complies with the following overseas standard.

RoHS3 Directive	CE Marking
0	To be scheduled



### Names of the Parts

#### 1. Main Body

In this instruction manual, the right and left sides of the actuator is expressed in the way it is placed horizontally and is looked from the motor side as shown in the figure below.





Base

## ERC**3**

#### (3) Slider Cleanroom Type





### 2. Motor Unit



 Status Indicator LED Following show the controller operation status:

				ig ×: OFF ☆: Flashing						
LED			Status of PIO Output Signal							
SV	ALM	Operation status CON Mode Type MEC Mode								
(GN)	(RD)		*ALM Out	put <sup>(Note 1)</sup>						
		Control Power Supply ON	0	Ν						
×	×	Control Power Supply OFF	OF	=F						
		Servo OFF	OF	=F						
		Motor driving power supply OFF	OF	F						
×	0	Emergency Stop	0	Ν						
^		Alarm (Operation cancellation level or more)	OF	F						
0	×	Servo ON	0	Ν						
☆	×	During automatic servo-off	0	Ν						
0 (OR)		In initializing process at power being ON	OFF							

Note 1 The output signals with \* mark are the active low signals that turn ON in normal condition and turn OFF while in abnormal condition.

 Teaching Port It is the connector dedicated for the connection of a teaching tool such as PC software.

3) External I/F Connector It is I/F connector for controls with PIO and SIO.

## ERC**3**

#### 3. Option

(1) PIO Converter (Model: RCB-CV/CVG-\*\*)

The functions of CON mode type in ERC3 can be extended. See 4.2.3 Operation in Positioner Mode 2 for details.

Also, if ERC3 is Simple Absolute Type, the absolute battery is to be attached to this PIO Converter, thus it is mandatory.





- 1) PIO Connector (I/O) [Refer to 3.2.2 [2]] The PIO connector is used for control I/O signals.
- 2) Absolute Battery [Refer to Chapter 6] This is the battery to retain the encoder information for Simple Absolute Type. Affix it with fabric hook-and-loop fastener on the side of PIO Converter. If ERC3 is Simple Absolute Type, it is necessary that PIO Converter is a type that is applicable for Simple Absolute Type.
- SIO Connector (SIO) [Refer to 3.7.6] This is the connector for the communication cable connection with a teaching tool such as the PC software.
- 4) Brake Release Switch (RLS/NOM) For the actuator equipped with a brake, the switch is used to release the brake forcibly. RLS …… Brake release NOM …… Normal Operation (brake is activated)

🔨 Warning :	Always set the switch to "NOM" in normal operation.
	(Keep the chance to set the switch to RLS side as less as possible, and make
	sure to set it on NOM side in ordinary use.)
	The brake would not work even with the servo OFF condition if the switch is
	on the RLS side. In the vertical oriented mount, the work may drop and cause
	an injury or the work to be damaged.

5) Absolute Battery LED (BAT)

It shows the absolute reset status, complete or incomplete. It is equipped if applicable for Simple Absolute Type.

LED	Operation Status
OFF	Control Power Supply OFF
Green Light is turned ON.	Battery Fully Charged
Orange Light is turned ON.	Battery Charging Operation
Red Light is turned ON.	Battery Disconnected



6) Status Indicator LED (SYS)Following show the controller operation status:

O : Illuminating × : OFF ☆ : Flashing												
LE	ED		Status of PIO Output Signal									
				CON Mode Type								
SV (GN)	ALM (RD)	Operation status	SV Output (Servo ON)	*ALM Output (Note 1)	*EMGS Output (Note 1)(Note2)	*ALM Output (Note 1)						
				(Alarm)	(Emergency Stop Status)							
		Control Power Supply ON	OFF	ON	ON	ON						
××	×	Control Power Supply OFF	OFF	OFF	OFF	OFF						
		Servo OFF	OFF	OFF	_	OFF						
		Motor driving power supply OFF	OFF	OFF	-	OFF						
~	0	Emergency Stop	OFF	OFF	OFF	OFF						
Â	0	Alarm (Operation cancellation level or more)	OFF	OFF	-	OFF						
0	×	Servo ON	ON	ON	ON	ON						
☆	×	During automatic servo-off	OFF	ON	-	ON						
0 (	OR)	In initializing process at power being ON	OFF	OFF	_	OFF						

Note 1 The output signals with \* mark are the active low signals that turn ON in normal condition and turn OFF while in abnormal condition.

Note 2 \*EMGS output is not prepared for Pulse Train Control Type.

Note 3 Servo-motor Auto OFF [Refer to Chapter 5 Power-saving Function]

7) Absolute Reset LED (ABS)

It shows the absolute reset status, complete or incomplete. It is to be mounted to Simple Absolute Type.

LED	Operation Status
OFF	Control Power Supply OFF
Green Light is turned ON.	Absolute Reset Complete
Red Light is turned ON.	Absolute Reset Incomplete

- 8) Mode Changeover Switch for Status LEDs (SCT) The display modes (0 to 3) of LED 0 to 15 switch over every time the switch is pressed and the contents of display can be changed. The selection of the mode can be checked with the color of Status Display Mode LED.
- Status Display Mode LED (SYS) The mode selected with Status LED Mode Changeover Switch is expressed with the display colors.

LED	Mode	Contents of LED 0 to 15 Displays				
OFF	Mada 0	Command Current Ratio Level/				
OFF		Control Power Supply OFF				
Green Light is turned ON.	Mode 1	Alarm Code				
Yellow Light is turned ON.	Mode 2	Monitoring of PIO input signal				
Red Light is turned ON.	Mode 3	Monitoring of PIO output signal				



#### 10) Status LED (0 to 15)

• Display while Mode 0 (Command Current Ratio Level) being selected The command current ratio level of the motor rated current as 100% is displayed in a bar graph with green lights.

			0							0	LED	) Illur	ninat	ing, :	× : Le	ED O	FF
	Status of LEDs																
15	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	0
14	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	0	0
13	×	×	×	×	×	×	×	×	×	×	×	×	×	×	0	0	0
12	×	×	×	×	×	×	×	×	×	×	×	×	×	0	0	0	0
11	×	×	×	×	×	×	×	×	×	×	×	×	0	0	0	0	0
10	×	×	×	×	×	×	×	×	×	×	×	0	0	0	0	0	0
9	×	×	×	×	×	×	×	×	×	×	0	0	0	0	0	0	0
8	×	×	×	×	×	×	×	×	×	0	0	0	0	0	0	0	0
7	×	×	×	×	×	×	×	×	0	0	0	0	0	0	0	0	0
6	×	×	×	×	×	×	×	0	0	0	0	0	0	0	0	0	0
5	×	×	×	×	×	×	0	0	0	0	0	0	0	0	0	0	0
4	×	×	×	×	×	0	0	0	0	0	0	0	0	0	0	0	0
3	×	×	×	×	0	0	0	0	0	0	0	0	0	0	0	0	0
2	×	×	×	0	0	0	0	0	0	0	0	0	0	0	0	0	0
1	×	×	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	×	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Command Current Ratio [%]	0	to 6.24	to 12.24	to 18.74	to 24.99	to 31.24	to 37.49	to 43.74	to 49.99	to 56.24	to 62.49	to 68.74	to 74.99	to 81.24	to 87.49	to 93.74	to 100.00

• Display while Mode 1 (Alarm Code) being selected [refer to Chapter 7 for Alarm Codes] The alarm code issued in ERC3 is displayed in the hexadecimal system with the LED 0 to 15 used as 1 word of bit 0 to 15.

(Example) If Alarm Code "083" (absolute position movement command at home-return incomplete) is generated, the display is as shown below:

										0: LE	יווו עב	ruuns	aung,	* : LI	EDO	FF
LED	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Alarm Display	×	×	×	×	×	×	×	×	0	×	×	×	×	×	0	0
Alarm Code	ode 0					(	)		8				3			

### O: LED Illuminating, × : LED OFF



 Display while Mode 2 (PIO Input Signal Monitor) being selected It displays the status of PIO control input (PLC → PIO Converter) whether it is ON or OFF. [Refer to 2.1 [2]]

LED turned ON in green : input signal ON LED being OFF : input signal OFF

• Display while Mode 2 (PIO Output Signal Monitor) being selected It displays the status of PIO control input (PIO Converter → PLC) whether it is ON or OFF. [Refer to 2.1 [2]]

LED turned ON in green : output signal ON LED being OFF : output signal OFF

- 11) FG Terminal Block [Refer to 2.3.4 [1] (2)] This is the grounding terminal for protection from electric shock and noise. Make sure to conduct the Class D grounding (formerly Class 3 grounding: grounding resistance at 100 or less).
- 12) Power Supply Connector [Refer to 3.3.3 [1], 3.5.3 [1]] This is the connector for the connections of power supply, emergency stop input, driving cutoff and the emergency stop switch signal output for the teaching pendant.
- 13) ERC3 Connector [Refer to 3.3.3 [2], 3.5.3 [2]] This is the connector for the relay cable to connect ERC3 and PIO Converter.
- 14) Absolute Battery Connector [Refer to Chapter 6] It is the connector to plug in the enclosed battery if applicable for Simple Absolute Type.



(2) Quick Teach (Model: RCM-PST-\*\*)

You can operate ERC3 easily. Not only JOG operation and home-return operation, but also the settings and changes of stop positions (2 or 3 points), acceleration/deceleration, speed and try run (forward / backward / continuous operations) are available.

Check Chapter 4 Operation for the functions of each LED and operation switch.





1) Emergency Stop Connector [Refer to Chapter 2]

This is the input connector for the external emergency stop signals. There is a plug equipped with a jumper cable attached on at the delivery. Remove the jumper when a wiring for the external emergency stop is required. Connect a signal that turns ON in normal condition and OFF when in abnormal for the external emergency stop signal.

2) External 24V Connector

Use this connector to supply power when it is not equipped with 24V DC power supply unit or is to be used without the power supply unit being attached.

Power Supply  $24V DC \pm 10\% 2.5A$  or more When the excitation detection is operating after the power is turned ON (normally for 100ms) MAX. 2.5A



3) ERC3 Connector

When operating ERC3 directly with Quick Teach, plug the SIO type power supply and I/O cable.

When Quick Teach is used as the teaching pendant, plug the SIO communication cable.

Power for SIO Type • I/O Cable : Model CB-ERC3S-PWBIO

 $(\square\square$  shows the cable length, Example 020 = 2m, MAX. 10m)

SIO Communication Cable : Model CB-PST-SIO050 (Standard 5m)

4) Brake Release Switch

This is a switch to compulsorily release the brake of the actuator equipped with a brake. Release  $\cdots$  Brake release

Normal ····· Normal Operation (brake is activated)

/ Î Warning :	Always set the switch to "Normal" in normal operation.
	(Keep the chance to set the switch to release side as less as possible, and
	make sure to set it on normal side in ordinary use.)
	The brake would not work even with the servo OFF condition if the switch is
	on the release side. In the vertical oriented mount, the work may drop and
	cause an injury or the work to be damaged.

5) 24V DC Power Supply Unit

This is a 24V DC power supply unit to provide power to Quick Teach from AC power source. This can be used with being detached. It is necessary to provide power from external 24V connector when it is detached.

Quick Teach Model	Power Voltage	Rated Current	Peak Current	Remarks
RCM-PST-1 (100V Type)	Single-phase 100 to 115V AC ±10%	2.5A	3.2A	Cable 2m Equipped with 3-pin power socket plug
RCM-PST-2 (200V Type)	Single-phase 100 to 230V AC ±10%	2.1A		Cable 2m Equipped with ∳4.3-hole solderless ring tongue terminals



### Actuator Coordinate

The coordinate system of ERC3 is as shown below. 0 defines the home position, and items in () are for the home-reversed type (option). For MEC Mode, the home position is the origin point and positive side is the end point.

#### (1) Rod Type



(2) Slider Type





### **Starting Procedures**

#### 1. Positioner Mode 1

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "RC PC software".





### 2. Pulse Train Control Mode

This product allows positioning control by the pulse train.

It is necessary to have the positioning control function able to output the pulse train on the host controller (PLC).

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "RC PC software".

Are there all the delivered items?	No →	Contact us or our distributor.					
↓ Yes Installation and Wiring [Refer to Chapter 3] Perform the installation of and wiring for the controller.	2 and Chapter	Point Check Item [Refer to S • Is frame ground (FG) connec • Has the noise countermeasu ←Yes	Section 2.3.4] cted? ire been taken?				
Power Supply and Alarm Check Connect a teaching tool such as PC, turn th ON for unit. Select [Teaching Mode 1 Safety Speed Acti PIO Operation Invalid] in the teaching tool s PC.	e power Chec ls the buch as	t <b>k Item</b> ered light [ALM] on the status display OFF? ↓ Yes	Connect the teaching tool such as PC to confirm the content of alarm and have an appropriate treatment.				
Set 0 or 1 to Parameter No.25 (Pulse Train Set the Electronic Gear [Refer to Section 4.3 [8] (1)] Set the electronic gear ratio based on the amount of actuator operation per pulse in Parameters No.65 and 66.	Control Mode). → Check Item Is the minimum reso Is the fraction	m unit of operation set to the valu olution of the encoder? of the electronic gear ratio reduc ←Yes	e bigger than the ed to its lowest terms?				
Pulse Train Input Output Mode Setting [F Set the command pulse train input status fo Set Teach Mode to Monitor Mode 2 and disc Servo ON Input servo ON signal from PLC. ↓	Refer to Section 4.3 [8] r the parameter No.63 a connect the teaching too Check Item Does the status LED SV] on the panel?	(2)] nd No.64. I after the setting is complete. No → Confirm the content of tool such as PC to hav treatment.	alarm on the teaching an appropriate				
←Yes Safety Circuit Check Check that the emergency stop circuit (or motor drive-power cutoff circuit) operates normally to turn OFF the servo.  ↓ Yes							
Test Run Adjustment 1 [Operation Mode MANU] Check with a teaching tool such as the PC with no work being loaded, and check the operation range with JOG operation with the work being loaded.	Check Item Is there any risk of interfering with peripheral equipment? ↓ Yes	No → Check if there is any actuator mount.	problem in the way of				
Test Run Adjustment 2 → Ca [Operation Mode AUTO] Output the pulse train from PLC to the controller and check the system operation. Is an ab	n the positioning eration be performed mally? ↓ Yes it in condition without normal noise? ↓ Yes st Run Adjustment 3	No →       Check the electronic         Confirm the commanisetting.         No →         Confirm that there is actuator installation, to condition demands a voltage, and appropriate the second secon	gear ratio setting. d pulse train input mode no problem in the the actuator operation voltage more than rated ate pulse trains are input.				


#### 3. Positioner Mode 2

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "RC PC software".



2) Output the operation command from PLC to the controller and check the system operation.



### 4. MEC Mode 1

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "MEC PC software".

Check of Packed Items Are there all the delivered items?	$No \rightarrow$	Contact us or our distributo	r.						
↓ Yes									
Installation and Wiring [Refer to C Chapter 3] Perform the installation of and wiring	hapter 2 and $\rightarrow$ for the actuator.	Point Check Item [Refer t • Is frame ground (FG) con • Has the noise counterme ← Yes	to Section 2.3.4] nected? asure been taken?						
Power Supply and Alarm Check Connect a teaching tool such as PC ON for unit.	turn the power $$	Check Item Is the green light [SV] on the LED status display ON? ↓ Yes	Connect the teaching tool such as PC to confirm the content of alarm and have an appropriate treatment.						
Settings of Initial Setting, Target Position, etc. Establish the initial settings for such as stop positions (for 2-point stop and 3-point stop), whether to have the pressing operation, etc. Secondly, set the parameters such as target position, acceleration and deceleration in the operational condition table. Perform a home-return operation first when Direct Teaching is to be performed. Marning When installing the product vertically and using Direct Teach, and if servo is turned on/off repeatedly at the same position, the actuator may drop slightly with its weight. Be careful not to pinch the hand or damage the									
Safety Circuit Check Does the emergency stop circuit (dri the servo OFF?	ve cutoff circuit) work prop	perly and turn $\xrightarrow{No \rightarrow}$ Cher	ck the emergency stop circuit.						
↓ Yes									
<b>Test Run Adjustment 1</b> Check the operation without mounti work and set the safety speed inval the teaching tool such as PC, and the check the operation with a work mou	ng a → Any vibration id on abnormal noi unted.	No→ Check if there is installation of the the actuator use values. Adjust the servo Yes	any problem with the e actuator and the condition of exceeds the ranges of the rated if necessary.						
safety speed be enabl movements.	ed during initial								
Output the operation command from	n PLC to the controller an	d check the system operation.							



### 5. MEC Mode 2

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "MEC PC software".

Check of Packed Items Are there all the delivered items?	$No \rightarrow$	Contact us or our distri	butor.						
↓ Yes									
Installation and Wiring [Refer to C Chapter 3] Perform the installation of and wiring	hapter 2 and $\rightarrow$ for the actuator.	Point Check Item [Re           • Is frame ground (FG)           • Has the noise counter           ← Yes	fer to Section 2.3.4] connected? rmeasure been taken?						
Power Supply and Alarm Check Connect a teaching tool such as PC and turn the power ON.	to PIO Converter	Check Item Is the green [SV] turned ON in the ERC3 and PIO Converter Status Display LEDs? ↓ Yes	No → Connect the teaching tool such as PC to confirm the content of alarm and have an appropriate treatment.						
<ul> <li>Settings of Initial Setting, Target Position, etc.</li> <li>Establish the initial settings for such as stop positions (for 2-point stop and 3-point stop), whether to have the pressing operation, etc.</li> <li>Secondly, set the parameters such as target position, acceleration and deceleration in the operational condition table.</li> <li>Perform a home-return operation first when Direct Teaching is to be performed.</li> <li>Warning When installing the product vertically and using Direct Teach, and if servo is turned on/off repeatedly at the same position, the actuator may drop slightly with its weight. Be careful not to pinch the hand or damage the</li> </ul>									
Safety Circuit Check Does the emergency stop circuit (dri the servo OFF?	ve cutoff circuit) work prop	perly and turn $\underbrace{No \rightarrow}$	Check the emergency stop circuit.						
↓ Yes									
Test Run Adjustment 1 Check the operation without mounti work and set the safety speed inval the teaching tool such as PC, and the check the operation with a work mount Counting To ensure safety, it is not safety in the safety of the safety	ng a don abnormal noi abnormal noi anted.	or se? No → Check if the installation or the actuator values. Adjust the set	re is any problem with the of the actuator and the condition of use exceeds the ranges of the rated ervo if necessary.						
safety speed be enabl movements.	ed during initial								
Output the operation command from	n PLC to the controller an	d check the system operation.							



### 6. MEC Mode 3

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "MEC PC software".

Check of Packed Items Are there all the delivered items?	$No \rightarrow$	Contact us or our distributor.
↓Yes		
Installation and Wiring [Refer to Chapter Perform the installation of and wiring for the actuator according to the instructions in the for the actuator and this Instruction Manual.	2 and Chapter 3] → e quick teach and Instruction Manual	<ul> <li>Point Check Item [Refer to Section 2.3.4]</li> <li>Is the safety grounding conducted?</li> <li>Has the noise countermeasure been taken?</li> </ul>
		↓Yes
Power Supply and Alarm Check Turn ON the power. The motor power (servo) automatically turns ON by supplying the power.	Check Item Is the error display LED flashing in red? No↓	Confirm that the emergency stop switch has been cancelled. If it is cancelled and there is a teaching tool such as PC connected, check the detail of the alarm and have an appropriate treatment.
Safety Circuit Check Check if the emergency stop circuit is opera condition.	ated in normal $\longrightarrow$ Che	eck the emergency stop circuit.
↓Yes		
<b>Setting of stop position [1.7]</b> Set the target position on the operation pan	el.	
Ļ		
<b>Test Run Adjustment [1.8]</b> Have the settings of velocity and acceleratio operation panel. Set the speed low first. After confirming the problem, set the speed to the desired settin	Is it in condition re is no any vibration ar g. abnormal noise	without $No \rightarrow$ nd ?
	↓Yes ←	Check if there is a problem in the actuator attachment, or the usage of the
	_	actuator is beyond the specification.
Now it is ready for operation.		

# 1.1 Product Check

### ERC**3**

### Chapter 1 Specifications Check

### 1.1 Product Check

### 1.1.1 Parts

This product is comprised of the following parts if it is of standard configuration. If you find any fault in the contained model or any missing parts, contact us or our distributor.

### (1) ERC3 Main Body

( )						
No.	Part Name ERC3 Main Body		Model	Remarks		
1			Refer to "How to read the model plate", "How to read the model".			
Acces	sories			•		
2	Power Supply	Except for SE Type	CB-ERC3P-PWBIO	□□□ shows the cable length		
2	• I/O Cable	SE Type	CB-ERC3S-PWBIO	(Example) □□□ : 020 = 2 [m]		
3	First Step Guid	e				
4	Safety Guide					
5	Pulse Converte	भ (Option)	AK-04	It is necessary when pulse control is to be conducted and host controller is the open collector type.		

### (2) PIO Converter (Option: SE: Serial Communicate Type)

( )	<u> </u>	51 /	
No.	Part Name	Model	Remarks
1	PIO Converter Main Body	Refer to "How to read the model plate", "How to read the model".	
Acces	sories		
2	I/O Flat Cable	CB-PAC-PIO	□□□ shows the cable length (Example) □□□ : 020 = 2 [m]
3	Power Connector	FMC1.5/7-ST-3.5 (Supplier : PHOENIX CONTACT)	Recommended cable size AWG16 to 18 (1.25 to 0.75mm <sup>2</sup> )
4	Absolute Battery (For Simple Absolute Type)	AB-7	
5	Safety Guide		

### (3) Quick Teach (Option: SE: Serial Communicate Type (Specially for MEC Mode Type))

No.	Part Name	Model	Remarks
1	Main Body	Refer to "How to read the model plate", "How to read the model".	
Acces	sories		
2	2-pin plug connector for external 24V power input	733-102-CC (Supplier : WAGO)	Recommended cable size AWG20 (0.5mm <sup>2</sup> )
3	2-pin plug connector for EMG	FMC1.5/2-ST-3.5 (Supplier : PHOENIX CONTACT)	Recommended cable size AWG16 to 24 (0.2 to 1.25mm <sup>2</sup> ) Short-circuited when delivered
4	Safety Guide		



### 1.1.2 Teaching Tool

The teaching tool is necessary to perform setup operations such as position and parameter settings through teaching or other means. The teaching tools listed below are available for ERC3. However, the available teaching tools differ for MEC Mode Type and CON Mode Type. Prepare an appropriate one considering the controller type.

		(O: Available	×: Unavailable)				
			Controller Type				
No.	Part Name	Model	CON Mode Type (Model: CN)	MEC Mode Type (Model: MC)			
1	Quick Teach	RCM-PST-0	×	0			
2	PC Software (Includes RS232C Exchange Adapter + Peripheral Communication Cable)	RCM-101-MW	0	×			
3	PC Software (Includes USB Exchange Adapter + USB Cable + Peripheral Communication Cable)	RCM-101-USB	0	×			
4	MEC PC Software	-	×	0			
5	Touch Panel Teaching TB-01	TB-01/01D/01DR	0	0			
6	Touch Panel Teaching TB-02	TB-02/02D	0	0			
7	Touch Panel Teaching TB-03	TB-03	0	0			

### 1.1.3 Instruction manuals related to this product

No.	Name	Manual No.
1	ERC3 Controller Instruction Manual	ME0297
2	PC Software RCM-101-MW/ RCM-101-USB Instruction Manual	ME0155
3	MEC PC Software Instruction Manual	ME0248
4	Touch Panel Teaching TB-01 Applicable for Position Controller Instruction Manual	ME0324
5	Touch Panel Teaching TB-02 Applicable for Position Controller, ELECYLINDER Instruction Manual	ME0355
6	Touch Panel Teaching TB-03 Applicable for Position Controller, ELECYLINDER Instruction Manual	ME0376
7	Instruction Manual for the serial communication [for Modbus]	ME0162



MADE IN JAPAN



Note 1 Identification for IAI use only : This may be marked for the purpose of IAI. It is not an ID to describe the model code.

Note 2 The pulse train input is the differential input (Line Driver) type. For PLN, PIO is NPN type and PLP is PNP type.



2 : Single-phase 100 to 230V AC (200V AC power supply type)

Note 1 Identification for IAI use only : This may be marked for the purpose of IAI. It is not an ID to describe the model code.



### 1.2 Specifications

### 1.2.1 Actuator

### [1] High Output Setting

(1) Enabling/Disabling of High Output Setting

This actuator can select whether to enable / disable the high output setting by the parameters.

At the delivery, the high output setting is activated for all the controllers.

Controller Type	Parameter	Setting	Set Value
	No.152	Enabled	1 (At the delivery)
CON Mode Type	High Output Setting	Disabled	0
	No.28	Enabled	1 (At the delivery)
MEC Mode Type	High Output Setting	Disabled	0

- The maximum speed, acceleration, and transportable weight differ when high output setting is enabled and disabled. [Refer to [3] Mechanical Specifications]
- 2) An operation with the duty 100% is available if the high output setting is inactivated. The actuator cannot operate with 100% when it is activated.

Duty ratio is the rate of operation expressed in % that presents the time of the actuator being operated in 1 cycle of operation.

$$D = \frac{T_{M}}{T_{M}+T_{R}} \times 100 \,[\%] \qquad \begin{bmatrix} D & : Duty \\ T_{M} & : Operation time (pressing operation included) \\ T_{R} & : Stop time \end{bmatrix}$$



Caution: Please note that the high output setting becomes invalid automatically if Quick Teach is connected.



(2) Duty Ratio for High Output Setting

When high output setting is enabled, duty is restrained respective to the surrounding temperature to control heat generation by the motor unit. For the actuators of slider type standard design (stainless sheet type), the duty ratio is different from that for the cleanroom type and other types.

Perform an operation with the duty ratio below the allowable range shown in the graph below.



#### •Slider Type Standard Type (Screw Cover Type), Rod Type

Surrounding temperature [°C]



Standard Type (Stainless Sheet Type ), Cleanroom Type



Surrounding temperature [°C]

Make sure to have 1	C	ycle within	the	time	described	below:
---------------------	---	-------------	-----	------	-----------	--------

1	
Model Name	Time of one cycle $(T_M+T_R)$
SA5/RA4	15min. or less
SA7/RA6	10min. or less

Caution: Do not attempt to perform an operation with the duty ratio above the allowable range. An operation with the duty ratio beyond the allowable range could shorten the life of the capacitor used in the build-in controller by the generation of heat on the motor.



#### [2] Maximum speed

The maximum speed of the actuator is limited by the limit of the maximum ball screw revolution. The maximum speed in the actuators of slider type (screw cover type) is partly different from that in the stainless sheet type.

#### (1) Slider Standard Type (Screw Cover Type)

#### • When high output setting is enabled

Speed limits (Unit: mm/s)																						
						Maximum Speed																
Size	NIOLOF	Lead	Horizontal	Snood		Stroke [mm]																
	туре	luuul	/ ventical	Speed	50	100	150	200	0 2	50	300	350	40	00	450	500	550	600	650	700	750	800
		2	Horizontal	2 75					2	25						200	165	140	115	100	85	75
		3	Vertical	3.75					2	25						200	165	140	115	100	85	75
		6	Horizontal	7.5					4	-50						400	330	280	235	200	175	150
SA5C	42P	0	Vertical	7.5					4	-50						400	330	280	235	200	175	150
SAJU		10	Horizontal	15		900					805	665	560	475	405	350	300					
		12	Vertical	15	900					805	665	560	475	405	350	300						
		20	Horizontal	25		1120					1115	935	795	680	585	510						
		20	Vertical	25		1120							1115	935	795	680	585	510				
		1	Horizontal	5							2	10							185	160	140	120
		4	Vertical	5		210								185	160	140	120					
		Q	Horizontal	10		490						440	375	320	280	245						
SA70	56D	0	Vertical	10		490							440	375	320	280	245					
SAIC	JUF	16	Horizontal	20		980						880	750	645	565	495						
		10	Vertical	20		840									750	645	565	495				
		24	Horizontal	30		1200							1130	975	850	745						
		24	Vertical	50					1200										1130	975	850	745

#### • When high output setting is disabled

#### Maximum speed limits (Unit: mm/s)

					10070			004		5,0			<u> </u>							
	Matan		l la nime natal								Ma	ximuı	n Spe	eed						
Size	NIOLOF	Lead	Horizontal	Speed							S	Stroke	e [mm	ı]						
	туре	fuuul	/ ventical	Speed	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
		2	Horizontal	2 75						150						140	115	100	85	75
		3	Vertical	3.75						150						140	115	100	85	75
		6	Horizontal	7.5						300						280	235	200	175	150
S450	12D	0	Vertical	7.5						300						280	235	200	175	150
0400	421	12	Horizontal	15						600						560	475	405	350	300
		12	Vertical	15						600						560	475	405	350	300
		20	Horizontal	25						1000						935	795	680	585	510
		20	Vertical	25						1000						935	795	680	585	510
		~	Horizontal	5								125								120
		4	Vertical	5								125								120
		8	Horizontal	10								250								245
SA7C	56D	0	Vertical	10								250								245
	501	16	Horizontal	20								4	50							
		10	Vertical	20								4(	00							
		24	Horizontal	30								6	75							
		24	Vertical	50								60	00							



#### (2) Slider Standard Type (Stainless Steel Sheet Type), Slider Cleanroom Type

• When high output setting is enabled

						Spe	ed l	imits	s (Ur	nit: m	nm/s	)								
			11	N.411							Ма	ximu	m Sp	eed						
Size	Niotor	Lead	Horizontal	Spood							5	Stroke	e [mm	ן]						
	Type	[[[]]]		Speed	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
		2	Horizontal	2 75					225					195	165	140	120	105	90	80
		3	Vertical	3.75					225					195	165	140	120	105	90	80
		6	Horizontal	7.5					450					395	335	285	245	215	185	165
SVEC	120	0	Vertical	7.5					450					395	335	285	245	215	185	165
SAJU	426	12	Horizontal	15					900					795	665	570	490	425	375	330
		12	Vertical	15					900					795	665	570	490	425	375	330
		20	Horizontal	25						1120						1045	900	785	690	610
		20	Vertical	25						1120						1045	900	785	690	610
		1	Horizontal	Б						2′	10						185	160	145	125
		4	Vertical	5						2′	10						185	160	145	125
		0	Horizontal	10						400						430	375	325	290	255
SA70	56D	0	Vertical	10						490						430	375	325	290	255
SAIC	JUF	16	Horizontal	20						980						865	750	655	580	515
		10	Vertical	20						84	10						750	655	580	515
		24	Horizontal	30						12	00						1155	1010	890	790
		24	Vertical	50						12	00						1155	1010	890	790

#### • When high output setting is disabled

Maximum speed limits (Unit: mm/s)

			11	N 41-1							Ма	ximui	n Spe	eed						
Size	Motor	Lead	Horizontal	Minimum							S	Stroke	e [mm	ן]						
	туре	[mm]	/ ventical	Speed	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
		2	Horizontal	3 75						150						140	120	105	90	80
		5	Vertical	3.75						150						140	120	105	90	80
		6	Horizontal	7.5						300						285	245	215	185	165
SAFC	120	0	Vertical	7.5						300						285	245	215	185	165
SAJU	42F	12	Horizontal	15						600						570	490	425	375	330
		12	Vertical	15						600						570	490	425	375	330
		20	Horizontal	25						10	00						900	785	690	610
		20	Vertical	25						10	00						900	785	690	610
		4	Horizontal	Б								12	25							
		4	Vertical	5								12	25							
		0	Horizontal	10								25	50							
SA70	56D	0	Vertical	10								25	50							
SAIC	50F	16	Horizontal	20								45	50							
		10	Vertical	20								4(	00							
		24	Horizontal	30								67	75							
		24	Vertical	- 50								60	00							



### (3) Rod Type

· When high output setting is enabled

				Speed limits	s (Unit: n	nm/s)				
	Matan	المعط	Llevizentel (	Minimum			Maximu	m Speed	250 170 345 345 695 695	
Size	Type	[mm]	Vertical	Speed			Stroke	e [mm]		
	туре	[11111]	ventical	Opeed	50	100	150	200	250	300
		2	Horizontal	2 75		22	25		170	120
		3	Vertical	3.75		22	25		170	120
		6	Horizontal	7.5		45	50		345	240
DA4C	420	0	Vertical	7.5		45	50		345	240
RA4C	42F	12	Horizontal	15		70	00		695	485
		12	Vertical	15		70	00		695	485
		20	Horizontal	25			80	00		
		20	Vertical	25			80	00		
		4	Horizontal	5			210			200
		4	Vertical	5			1	75		
		0	Horizontal	10			420			400
PAGC	560	0	Vertical	10			420			400
RAOC	50F	16	Horizontal	20			7(	00		
		10	Vertical	20			56	60		
		24	Horizontal	30			80	00		
		24	Vertical	- 50			60	00		

#### • When high output setting is disabled

Speed limits (Unit: mm/s)

	Matan	اممط	Llevizentel (	Mississer			Maximur	m Speed		
Size	Type	Lead [mm]	Norizontal /	Niinimum Speed			Stroke	e [mm]		
	Type	[11111]	ventical	Opeed	50	100	150	200	250	300
		2	Horizontal	2 75			150			120
		3	Vertical	3.75			150			120
		c	Horizontal	7.5			300			240
	400	0	Vertical	7.5			300			240
RA4C	42P	10	Horizontal	15			600			485
		12	Vertical	15			600			485
		20	Horizontal	25			66	67		
		20	Vertical	25			66	67		
		Λ	Horizontal	F			12	25		
		4	Vertical	5			12	25		
		0	Horizontal	10			25	50		
PAGC	560	0	Vertical	10			25	50		
RAUC	50F	16	Horizontal	20			45	50		
		10	Vertical	20			4(	00		
		24	Horizontal	30			67	75		
		24	Vertical	50			60	00		





[3] MAX. Acceleration, Payload Capacity

If the payload capacity is smaller than as specified, the acceleration/deceleration can be raised beyond the applicable level.

(1) Slider Type

Standard Type (Screw Cover Type), Standard Type (Stainless Steel Sheet Type), Cleanroom Type

• When high output setting is enabled

		Lood	Horizontal /	Payle	oad capac	ity by acce	eleration/d	eceleratio	n [kg]
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G
				0	20	20	16	16	13
				25	20	20	16	16	13
				50	20	20	16	16	12
				75	20	20	16	16	12
			Harizantal	100	20	18	14	12	10
			Horizontai	125	20	17	14	9.5	8
				150	20	17	11	8	7
				175	20	10	10	4.5	3.5
				200	20	9	3	_	_
		2		225	15	_	_	_	_
		3		0	12	12	12	-	_
				25	12	12	12	_	_
				50	12	12	12	-	-
				75	12	12	12	-	-
			Vortical	100	12	10.5	10.5	-	-
			ventical	125	12	10.5	10.5	_	-
				150	9.5	8	8	_	-
				175	7	7	6	-	-
				200	6	4	2	_	-
SAFC	420			225	4.5	_	_	_	_
SAJU	426			0	18	18	13	12	11
				50	18	18	13	12	11
				100	18	18	13	12	11
				150	18	18	13	12	11
			Horizoptal	200	18	18	13	12	11
			TIONZONIA	250	18	17	13	12	9
				300	16	16	12	11	7
				350	14	14	8	8	6
				400	10.5	10	7	4.5	4
		6		450	7.5	7	4	2.5	1
		0		0	6	6	6	-	-
				50	6	6	6	-	-
				100	6	6	6	-	-
				150	6	6	6	-	_
			Vertical	200	6	6	6	-	-
			vertical	250	6	5	4.5	-	_
				300	4.5	4	3.5	_	_
				350	4	3.5	3	_	_
				400	2.5	2	1.5	-	-
				450	1	0.5	_	_	_



		Lood	Harizantal /	Payle	oad capac	ity by acce	eleration/d	eceleratior	n [kg]
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G
				0	9	9	9	9	8
				100	9	9	9	9	8
				200	9	9	9	9	8
				300	9	9	9	9	7
			Harizoptal	400	9	9	8	8	6
			HUHZUHIAI	500	9	9	8	5.5	5.5
				600	9	9	8	5.5	4
				700	9	7	6	4	2.5
				800	-	5.5	3.5	2	1
		10		900	-	5	2.5	1	-
		12		0	2.5	2.5	2.5	-	_
				100	2.5	2.5	2.5	-	_
				200	2.5	2.5	2.5	-	_
				300	2.5	2.5	2.5	-	_
			Vertical	400	2.5	2.5	2.5	-	_
			ventical	500	2.5	2.5	2	-	_
				600	2.5	2	1.5	-	_
				700	2.5	1	0.5	-	_
				800	-	0.5	0.5	-	-
SA5C	12P			900	_	0.5	_	-	_
0/100	721			0	6.5	6.5	5	5	4
				160	6.5	6.5	5	5	4
				320	6.5	6.5	5	5	4
				480	6.5	6.5	4	4	4
			Horizontal	640	6.5	6.5	3.5	3.5	3
			TionZontai	800	5.5	5.5	3.5	3	1
				960	-	5.5	2.5	2	1
				1120	_	5.5	1	1	1
				1280	-	-	-	-	_
		20		1440	_	_	_	-	_
				0	1	1	1	-	_
				160	1	1	1	-	_
				320	1	1	1	-	_
				480	1	1	1	-	_
			Vertical	640	1	1	1	-	_
				800	1	1	1	-	_
				960	_	0.5	0.5	-	_
				1120	_	0.5	0.5	-	_
				1280	_	_	_	-	_
				1440	—	—	—	-	—

		Lead	Horizontal /	Paylo	oad capac	ity by acce	eleration/d	eceleration	n [kg]
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G
				0	45	45	45	40	35
				35	45	45	45	40	35
				70	45	42	42	35	35
			l la sima su ta l	105	42	40	40	35	35
			Horizontai	140	42	40	25	25	22
				175	38	18	_	_	_
				210	35	_	_	_	_
				245	-	_	-	_	_
		4		0	22	22	22	_	_
				35	22	22	22	_	_
				70	22	22	22	_	_
			\ /ti1	105	20	20	19	_	_
			vertical	140	15	12	11	_	_
				175	10	4.5	_	_	_
				210	6.5	_	_	_	_
0470	500			245	_	_	_	_	_
SAIC	205			0	43	40	40	40	40
				70	43	40	40	40	40
				140	40	40	40	38	35
			Llavimontal	210	40	36	35	30	24
			Horizontai	280	40	23	11	8	2
				350	35	4	2	2	_
				420	25	_	_	_	_
				490	15	_	_	_	_
		ð		0	15	14	13	_	_
				70	15	14	13	-	-
				140	15	14	13	_	_
			Vertical	210	11	9	9	_	_
			vertical	280	8	7	6	_	_
				350	5	3.5	1.5	_	_
				420	2.5	-	-	-	-
				490	1.5	-	-	_	-



		Lood	Horizontal /	Paylo	oad capac	ity by acce	eleration/d	eceleratior	ו [kg]
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G
				0	35	35	35	26.5	26.5
				140	35	35	35	26.5	26.5
				280	35	28	28	22	18
			Harizoptal	420	30	23	12.5	11	10
			HUHZUHLAI	560	22	15	9.5	7.5	5.5
				700	20	11	5.5	3.5	2
				840	-	4	2.5	-	-
		16		980	-	2	-	-	-
		10		0	7	6	4	_	_
				140	7	6	4	_	_
				280	7	6	4	_	_
			Vartical	420	5	5	4	_	_
			ventical	560	5	4	3	_	_
				700	3.5	2.5	1.5	-	-
SA7C	560			840	-	1	-	-	-
SAIC	50F			980	-	-	-	-	-
				0	20	17	15	13	11
				200	20	17	15	13	11
				400	20	14	14	13	10
			Horizontal	600	20	14	10	8	8
				800	10	10	8	6	2.5
				1000	Ι	8	4	2	1
		24		1200	Ι	4	2	—	-
		24		0	3	3	3	—	-
				200	3	3	3	—	-
				400	3	3	3	-	-
			Vertical	600	3	3	3	_	-
				800	-	3	2.5	-	-
				1000	-	2	-	-	-
				1200	_	1	_	-	_

Caution: Do not set speeds and accelerations/decelerations equal to or greater than the respective ratings. Doing so may result in vibration, failure or shorter life. If any acceleration/deceleration equal to or greater than the rated acceleration/deceleration is set, a creep phenomenon or slipped coupling may occur.

1.2 Specifications 1.2.1 Actuator



### • When high output setting is disabled

Туре	Motor Type	Lead [mm]	Horizontal / Vertical	Velocity [mm/s]	Acceleration/ Deceleration [G]	Load capacity [kg]
				0		12
				19	-	12
				38		12
			Horizontal	75	0.2	12
				113	-	12
		3		150	-	12
				0		6
				19		6
			Vertical	38	0.2	6
				120		6
				150		4
				0		12
				38		12
			llerimentel	100	0.0	12
			Horizontai	150	0.3	12
				200	-	12
		6		300	-	12
				0		3
				38	Acceleration/ Deceleration [G]       Load [         0.2	3
			Vertical	80	0.2	3
SAFC	420			250	-	3
SASC	426			300		2.5
				0		6
				75		6
			Horizontal	150	0.3	6
				400		6
		10		600		2
		12		0		1.5
				75		1.5
			Vertical	125	0.2	1.5
				450		1.5
				600		1
				0	-	3.5
				125	-	3.5
			Horizontal	250	0.3	3.5
				667	-	3.5
		20		1000		1
		20		0	-	1
				125	-	1
			Vertical	208	0.2	1
				750		1
				1000		0.5



Туре	Motor Type	Lead [mm]	Horizontal / Vertical	Velocity [mm/s]	Acceleration/ Deceleration [G]	Load capacity [kg]
				0		20
				10		20
				50		20
			Horizontal	100	0.2	20
				120		20
		4		125		20
				0		10
				10		10
			Vertical	35	0.2	10
				90		10
				125		2
				0		20
				30		20
			Horizontal	100	03	20
			TIONZONIA	150	0.0	20
				180		20
		8		250		3.5
		0		0		5
				$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	5	
			Vertical	30	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	5
			Vortiour	150	0.2	5
SA7C	56P			200		1
				250		0.5
				0		10
				50		10
			Horizontal	100	0.3	10
				300		10
		16		450		2
				0		2.5
				50		2.5
			Vertical	100	0.2	2.5
				300		2.5
				400		0.5
				0		6
			Llevimentel	15	0.0	6
			Horizoniai	150	0.3	0
				400		0
		24		0/5		1 5
				U 75		1.0
			Vortical	10	0.2	1.5
			vertical	150	0.2	1.0
				400		1.5
				000		0.5



### (2) Rod Type

When high output setting is enabled

		Lood	Horizontal /	Payle	oad capac	ity by acce	eleration/d	eceleratior	n [kg]
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G
				0	40	40	40	40	35
				25	40	40	40	40	35
				50	40	40	40	40	35
				75	40	40	40	40	35
				100	40	40	40	40	35
			Horizontai	125	40	40	40	40	35
				150	40	40	40	30	25
				175	36	36	35	25	20
				200	36	28	28	19.5	14
		0		225	36	16	14	10	6
		3		0	18	18	17	_	_
				25	18	18	17	-	-
				50	18	18	17	-	-
				75	16	16	16	_	_
			Vertical	100	16	15	15	_	_
			ventical	125	16	12	10	-	_
				150	10	8	5.5	_	-
				175	10	5.5	5	_	_
				200	7	5	4.5	-	_
DA4C	420			225	4	3.5	2	-	_
RA4C	426			0	40	40	31.5	30	25
				50	40	40	31.5	30	25
				100	40	40	31.5	24.5	21
				150	40	40	24.5	17.5	17.5
			Horizoptol	200	40	40	21	14	12.5
			HUHZUHLAI	250	35	24.5	17.5	14	11
				300	28	21	12.5	12.5	8
				350	24.5	17.5	9.5	5.5	5.5
				400	17.5	9.5	7	4	2.5
		e		450	17.5	5.5	2	_	-
		0		0	12	12	10	_	_
				50	12	12	10	_	_
				100	12	12	10	_	_
				150	11	11	7	_	_
			Vertical	200	8	8	5.5	-	_
			vertical	250	7	7	4	_	-
				300	5.5	5.5	4	-	-
				350	4	3.5	3.5	_	-
				400	3.5	2.5	2	_	_
				450	_	1	1	_	-



		Lood	Harizantal (	Payload capacity by acceleration/deceleration [kg]						
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G	
				0	25	25	14	14	12	
				100	25	25	14	14	12	
				200	25	25	11	8	8	
			Horizoptol	300	25	25	11	7	5.5	
			HUHZUHLAI	400	17.5	16.5	8	4	3.5	
				500	-	15	5.5	2	2	
				600	-	10	3.5	-	-	
		10		700	-	6	2	-	-	
		12		0	4.5	4.5	3.5	_	_	
				100	4.5	4.5	3.5	_	_	
			200	4.5	4.5	3.5	-	_		
			Vortical	300	4	4	3.5	-	_	
			Vertical	400	3.5	3.5	2.5	_	_	
PA4C	420			500	Ι	3.5	2	—	-	
NA4C	426			600	Ι	2	1	—	-	
				700	Ι	1	1	—	-	
				0	12	12	8	6	4.5	
				160	12	12	8	6	4.5	
			Horizoptal	320	12	12	8	5	3	
			TIONZONIA	480	7	7	6	4.5	3	
				640	-	6	4	3	2	
		20		800	-	4	3	_	-	
		20		0	2	1.5	1.5	_	_	
				160	2	1.5	1.5	_	-	
			Vertical	320	2	1.5	1.5	-	-	
			vertical	480	1	1	1	-	-	
				640	-	1	1	_	_	
				800	_	0.5	0.5	-	_	

		lead		Payload capacity by acceleration/deceleration [kg]						
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	0.7G	1.0G	
				0	70	70	60	60	50	
				35	70	70	60	60	50	
				70	70	70	60	60	50	
			Horizontal	105	70	70	55	45	40	
				140	70	50	30	20	15	
				175	50	15	Ι	-	-	
		1		210	20	-	Ι	-	-	
		4		0	25	25	25	-	-	
				35	25	25	25	-	-	
				70	25	25	25	-	-	
			Vertical	105	15	15	15	-	-	
				140	11.5	10	8	-	-	
				175	6	3	-	-	-	
PAGC	56P			210	-	-	-	_	-	
1000	501		Horizontal	0	60	55	45	40	40	
				70	60	55	45	40	40	
				140	60	55	40	40	40	
				210	60	50	40	28	26	
				280	60	32	20	15	11	
				350	50	14	4.5	1	-	
		8		420	15	-	-	-	-	
		0		0	17.5	17.5	17.5	-	-	
				70	17.5	17.5	17.5	-	-	
				140	11	11	11	-	-	
			Vertical	210	7.5	7.5	7	-	-	
				280	6	5.5	4.5	-	-	
				350	3	2.5	2	-	-	
				420	2	-	-	-	-	



		Lood	Horizontal /	Payload capacity by acceleration/deceleration [kg]						
Туре	Motor Type	[mm]	Vertical	Velocity [mm/s]	0.1G	0.3G	0.5G	deceleratio 0.7G 28 28 24 13 2.5	1.0G	
				0	45	40	30	28	26	
				140	45	40	30	28	26	
			Horizontal	280	45	34	30	24	18	
			Horizontai	420	45	22	17	13	10	
				560	Ι	9.5	5	2.5	1.5	
		16		700	Ι	2	Ι	—	-	
		10		0	8	8	8	—	-	
				140	8	8	8	-	-	
			Vortical	280	6.5	5.5	5.5	-	_	
			ventical	420	5.5	4	3		_	
DAGO	FCD			560	_	2	1	-	_	
RAOC	206			700	_	_		-	_	
				0	25	25	17	12	8	
				200	25	25	17	12	8	
			Horizontal	400	20	20	14	10	8	
				600	-	13	7	5	3.5	
		24		800	-	3	1	-	_	
		24		0	3	3	2	-	1	
				200	3	3	2	-	1	
			Vertical	400	3	2	2	_	-	
				600	_	2	2	_	_	
				800	_	_	_	_	_	
	l	1	1	000		1		1		



### • When high output setting is disabled

Туре	Motor Type	Lead [mm]	Horizontal / Vertical	Velocity [mm/s]	Acceleration/ Deceleration [G]	Load capacity [kg]
				0		40
				19		40
			l la vizza e da l	38		40
			Horizontal	75	0.2	40
				113		40
		3		150		40
			-	0		18
				19		18
			Vertical	38	0.2	18
			-	50		18
				150		4
				0		40
				38		40
			Horizontal	100	0.0	40
			TIONZONIA	150	0.5	40
		6		200		40
		0		300		12
				0		12
			Vertical	38	0.2	12
RA4C	42P		vertical	80	0.2	12
				300		2.5
				0	-	25
				75	0.3	25
			Horizontal	150		25
				300	-	12
		12		600		2.5
				0	-	4.5
			Vertical	75	0.2	4.5
			Vortiour	125	0.2	4.5
				600		0.5
				0	-	12
				125	-	12
			Horizontal	200	0.3	12
				500	-	7
		20		667		6
				0	-	2
			Vertical	125	0.2	2
			, cruodi	208	0.2	2
				667		0.5

FRF3	_
ERCO	-

Туре	Motor Type	Lead [mm]	Horizontal / Vertical	Velocity [mm/s]	Acceleration/ Deceleration [G]	Load capacity [kg]
				0		55
				10		55
				20		55
			Honzontai	50	0.2	55
		4		100		55
		4		125		25
				0		25
			Vortical	10	0.2	25
			ventical	35	0.2	25
				125		2
				0		50
				30		50
			Horizontal	100	03	50
			TIONZONIA	150	0.0	50
		8		160		50
		Ŭ		250		3.5
				0		17.5
			Vertical	10	0.2	17.5
			Vortiour	30	0.2	17.5
RA6C	56P			200		1
				0		40
			Horizontal	50		40
				100	0.3	40
					40	
		16		450		2
				0		5
				50		5
			Vertical	100	0.2	5
				150		5
				400		0.5
				75		25
			Horizontol	15	0.2	25
			Horizoniai	100	0.5	25
				675		20
		24		075		1.0 3
				75	1	3 2
			Vertical	150	0.2	3 2
			vertical	225	0.2	3 2
				600	1	0.5
				000		0.5



[4] Driving System • Position Detector

### (1) Slider Type

Standard Type (Screw Cover Type), Standard Type (Stainless Steel Sheet Type), Cleanroom Type

Type Motor Typ		Lood	No. of Encoder	Ball Screw Type			
туре	wotor type	Lead	Pulses (Note 1)	Туре	Diameter	Accuracy	
		3			φ10mm		
SA5C	420	6		Pollod		C10	
	427	12		Rolled			
		20	800				
		4	000			C10	
SA70	560	8		Dellad	140		
SAIC	50F	16		Rolled	Rolled $\phi$ 12mm		
		24					

Note 1 This is a number of pulses entered in the controller.

### (2) Rod Type

Type Motor Type		Lood	No. of Encoder	Ball Screw Type			
туре	wow inde	Leau	Pulses (Note 1)	Туре	Diameter	Accuracy	
		3					
RA4C	420	6		Pollod	φ10mm	C10	
	426	12		Rolled			
		20	800				
		4	800				
DAGO	560	8		Dellad	140	010	
RAOC	206	16		Rolled	φı∠mm	C10	
		24					

Note 1 This is a number of pulses entered in the controller.



[5] Positioning Precision

#### (1) Slider Type

Standard Type (Screw Cover Type), Standard Type (Stainless Steel Sheet Type), Cleanroom Type

Туре	Lead	Item	Performance
	2 6 1 2	Positioning repeatability	±0.02mm
SA5C	3, 0, 12	Lost motion	0.1mm or less
	20	Positioning repeatability	±0.03mm
		Lost motion	0.1mm or less
	4, 8, 16	Positioning repeatability	±0.02mm
SA7C		Lost motion	0.1mm or less
SAIC	24	Positioning repeatability	±0.03mm
	24	Lost motion	0.1mm or less

The values shown above are the accuracy at the delivery from the factory. It does not include the consideration of time-dependent change as it is used.

### (2) Rod Type

Туре	Lead	Item	Performance
	2 6 12	Positioning repeatability	±0.02mm
RA4C	3, 0, 12	Lost motion	0.1mm or less
	20	Positioning repeatability	±0.03mm
		Lost motion	0.2mm or less
	1 0 16	Positioning repeatability	±0.02mm
DAGO	4, 8, 16	Lost motion	0.1mm or less
RAUC	24	Positioning repeatability	±0.03mm
	24	Lost motion	0.2mm or less

The values shown above are the accuracy at the delivery from the factory. It does not include the consideration of time-dependent change as it is used.

## 1.2 Specifications 1.2.1 Actuator

### ERC**3**

- [6] Current Limit Value and Pressing Force
- (1) Slider Type

Standard Type (Screw Cover Type), Standard Type (Stainless Steel Sheet Type), Cleanroom Type

• SA5C

Pressing Force [N]									
Boll Corow Lood [mm]		Curr	ent Lin	nit Valu	e [%]				
Ball Screw Lead [mm]	m] 20 30 40 50 106 159 211 264	60	70						
3	106	159	211	264	317	370			
6	53	79	106	132	159	185			
12	26	40	53	66	79	93			
20	16	24	32	40	48	56			



Caution: (1) The relation of the current limit and the pressing force is a reference assuming when the speed is 20mm/s.

- (2) There will be a little variance in the actual pressing force. If the value of current limit is small, the variance for the pressing force becomes big.
   (2) Use the predict with the current limit within the pressing if a dia the second seco
  - (3) Use the product with the current limit within the range specified in the graph. If used below 20%, the pressing force would not be stable. An operation may not be made in some cases. An operation cannot be made also when it is beyond 70%. If use in such a condition, it may extremely shorten the product life by the degradation of insulator in the motor coil due to heat generation.
- (4) When the approaching speed (setting in the position table) to the pressing start position is 20mm/s or less, the pressing operation will be made with the approaching speed. In this case, also, the pressing force would not be stable. In such cased, check in advance that the actuator can be used with no problem before start using.

• SA7C

Pressing Force [N]

Poll Serow Load [mm]	Current Limit Value [%]								
Ball Screw Lead [mm]	20	30	40	50	60	70			
4	239	358	478	597	717	836			
8	119	179	239	299	358	418			
16	60	90	119	149	179	209			
24	40	60	79	99	119	139			



- Caution: (1) The relation of the current limit and the pressing force is a reference assuming when the speed is 20mm/s.
  - (2) There will be a little variance in the actual pressing force. If the value of current limit is small, the variance for the pressing force becomes big.
  - (3) Use the product with the current limit within the range specified in the graph. If used below 20%, the pressing force would not be stable. An operation may not be made in some cases. An operation cannot be made also when it is beyond 70%. If use in such a condition, it may extremely shorten the product life by the degradation of insulator in the motor coil due to heat generation.
  - (4) When the approaching speed (setting in the position table) to the pressing start position is 20mm/s or less, the pressing operation will be made with the approaching speed. In this case, also, the pressing force would not be stable. In such cased, check in advance that the actuator can be used with no problem before start using.

### (2) Rod Type

• RA4C

Pressing Force [N]						
Boll Scrow Lood [mm]	Current Limit Value [%]					
Ball Screw Lead [mm]	20	30	40	50	60	70
3	106	159	211	264	317	370
6	53	79	106	132	159	185
12	26	40	53	66	79	93
20	16	24	32	40	48	56



Caution: (1) The relation of the current limit and the pressing force is a reference assuming when the speed is 20mm/s.
 (2) There will be a little variance in the actual pressing force. If the value of current limit is small, the variance for the pressing force becomes big.
 (3) Use the product with the current limit within the range specified in the graph. If used below 20%, the pressing force would not be stable. An operation may not be made in some cases. An operation cannot be made also when it is beyond 70%. If use in such a condition, it may extremely shorten the product life by the degradation of insulator in the motor coil due to heat generation.
 (4) When the approaching speed (setting in the position table) to the pressing start position is 20mm/s or less, the pressing operation will be made with the approaching speed. In this case, also, the pressing force would not be stable. In such cased, check in advance that the actuator can be used with no problem before start using.

• RA6C

Pressing Force [N]

	<u> </u>					
Poll Sorow Load [mm]	Current Limit Value [%]					
Bail Sciew Lead [IIIII]	20	30	40	50	60	70
4	312	469	625	781	937	1094
8	156	234	312	391	469	547
16	78	117	156	195	234	273
24	52	78	104	130	156	182



Caution: (1)	The relation of the current limit and the pressing force is a reference assuming when the speed is 20mm/s
(2)	There will be a little variance in the actual pressing force. If the value of current limit is small, the variance for the pressing force becomes big.
(3)	Use the product with the current limit within the range specified in the graph. If used below 20%, the pressing force would not be stable. An operation may not be made in some cases. An operation cannot be made also when it is beyond 70%. If use in such a condition, it may extremely shorten the product life by the degradation of insulator in the motor coil due
	to heat generation.
(4)	When the approaching speed (setting in the position table) to the pressing start position is 20mm/s or less, the pressing operation will be made with the approaching speed. In this case, also, the pressing force would not be stable. In such cased, check in advance that the actuator can be used with no problem before start using.





### [7] Option

(1) With Brake (Model: B)

This is a function that is necessary when the actuator is mounted in the vertical orientation. This prevents a drop of work piece or fixture attached on the actuator when the power or servo is turned OFF.

(2) Home Reversed Type (Model: NM)

In the standard type, the home position is set on the motor end. This is a specification when an indication is desired for the operation direction to be matched with the coordination system of the device that the actuator is to be installed.

Caution: The home position is already adjusted when the product is shipped out from our factory. When a change is desired to the home-reversed type after delivery, it is necessary that you return the product to us for an adjustment. Contact our sales office or an agent near you.

(3) Simple Absolute Type (Model: ABU)

It is not necessary to have a home-return operation every time the power is turned ON. PIO Converter of Simple Absolute Type is required for this function, and it is available only when the I/O type of the actuator is the serial communication type (Model Code: SE). [Refer to Chapter 6]

(4) Flange (Model: FL)

It is an option for Rod Type. This is a metal component for flange to fix the unit on the rod side. [Refer to 2.3 How to Install]



(5) Foot Brackets (Model: FT)

It is an option for Rod Type. It is a metal part to be attached on the bottom of the actuator to affix with screws from top side. [Refer to 2.3 How to Install]





### 1.2.2 Built-in Controller

[1] Basic Specifications

Item		m	Description					
Power-supply Voltage		ge	24V DC ±10%					
Load Current		-	High output setting is enabled (Set in delivery) : 3.5A (MAX. 4.2A)					
(including current consumption for control)		sumption for control)	High output setting is disabled : 2.2A					
Power	Supply	/ for Electr	romagnetic Brake (Note 1)	24V DC ±10% 0.15A (MAX.)				
(In the	e case	of the ac	ctuator with a brake)					
Heat	Gener	ration		High output setting is enabled (Set in delivery) : 8.0W				
				High output setting is disabled : 5.0W				
Rush	Curre	nt (Note 2)		8.3A				
Trans	ient P	ower Cu	toff Durability	MAX. 500µs				
Motor	<sup>-</sup> Contr	rol Syste	m	Weak field-magnet vector control				
Applic	cable E	Encoder		Incremental Encoder Resolution 800pulse/rev				
Actua	tor Ca	able Leng	gth	MAX. 10m				
Seria	Comr	municati	on Interface	RS485: 1CH (based on Modbus Protocol RTU/ASCII)				
(SIO	Port)			Speed : 9.6 to 230.4Kbps				
			DIO T					
Exter	nal Inte	Interface PIO Type		Signal I/O dedicated for 24V DC (selected from NPN/PNP) ··· Input 6 points max.,				
				output 4 points max.				
			Fieldhue Ture	Nationaliashia				
Dete	0			Not applicable				
Data	Setting	g and inp tion Mon		PC Software, leaching Pendant				
Data	Reten	tion wen	nory	There is no limitation in number of writing)				
Oper	ation N	lode	SE/ND/DN	Positioner Mode				
(I/O T	vpe)	nouc		Pulsa Train Control Mode				
Nicoral		D		Puise main control Mode				
Mode		Positions	s in Positioner	Standard 8 points, MAX. 16 points (Note) Number of positions differs depending on the selection in PIO pattern.				
Pulse Train	·	Input Pulse Command Pulse		Differential System (Line Driver System) : MAX.200kpps Cable length MAX. 10m				
Interfa	ace			Open Collector System : Not applicable (Note 3)				
	(			1/50 < A/B < 50/1				
	ľ	Magnific	ations	Setting Range of A and B (set to parameter) : 1 to 4096				
	1			Nono				
Feedback Pulse Output		tod on motor unit)	2 colors LED: Sorve ON (CN) / Sorve OEE (OEE) / Emergency Stop (PD) /					
	LED Display (Mounted on motor unit)			Alarm generated (RD) / Automatic servo-off (Flashing in green)				
Electr	romag	netic Bra	ake Compulsory	Not equipped on main unit, equipped on PIO Converter (option)				
Relea	ase Sw	VIICN						
Drotor			e const Flastria Chaola	SUUV DC TUMIS2 or more				
Protection Function against Electric Snock		gainst Electric Shock						
Cooling Method		\ir Temperature						
			85% PH or loss (non condensing)					
÷			Turniuity Environment	Refer to Installation Environment				
lote 4	Surrounding Storage Temperature		torage Temperature	0 to 60°C (0 to 50°C if stored for 1 month or more )				
ר (≻	Surrounding Storage Humidity		Storage Humidity	85%RH or less (non-condensing)				
ner	Lisade Altitude		e	1000m or lower above sea level				
onr	Protection Class		ass	IP20				
nvir	Vibra	Vibration Durability		Frequency 10 to 57Hz / Swing width : 0.075mm				
ш				Frequency 57 to 150Hz / Acceleration : 9.8m/s <sup>2</sup>				
				XYZ Each direction Sweep time: 10 min. Number of sweep: 10 times				
Impact			150mm/s <sup>2</sup> , 11mm/s Semi-sine wave pulse to each of the directions X, Y and Z					
Weigl	Weight			Refer to specifications for actuator for it is integrated with controller				
External Dimensions		s						

Note 1 It is the power source to be supplied when compulsorily releasing the brake.

Note 2 Rush current passes for about 5ms after the power is injected (at 40°C).

- The rush current value varies depending on the impedance of the power line.
- Note 3 If the pulse train applies the open collector output, prepare AK-04 (option) separately to convert to the differential type.

Note 4 The environmental specifications include the actuator main unit.



### [2] I/O Specifications

(1) PIO Interfaces

		Input section	Output section		
ion	Input Voltage	24V DC ±10%	Rated Load Voltage	24V DC ±10%	
Specificat	Input Current	5mA / 1 circuit	MAX. current 50mA / 1 point		
	ON/OFF voltage	ON voltage IN.DC18V OFF voltage MAX.DC6V	Residual Voltage	2V or less	
	Leak Current	MAX. 1mA/1 point			
Insulation Type	Non-isolated	from external output signal	Non-isolated from external input signal		
NPN	# Input Terminal	100kΩ 100kΩ 100kΩ 100kΩ 100kΩ Internal Power Source	Internal Power Source	External Power Supply 24V	
PNP	External Power Supply 24V	100kΩ     Internal       5.6kΩ     20kΩ       #     #	Internal Power Internal Power Source	Supply 24V 15Ω Output Terminal <sup>777</sup>	
Connection Cable	PIO type power and I/O cable [Refer to 3.1.3 [2]]				

### NPN Type





1.2 Specifications 1.2.2 Built-in Controller

### ERC**3** -

### (2) Pulse Train Input Interface



(3) Pulse converter : AK-04 (Please purchase separately)

Use this by connecting to the host controller pulse train output when the host controller output pulse is open collector type.

It converts the command pulse of the open collector type to the differential type.

Item	Specifications			
Input Power	24V DC ±10% (MAX. 50mA)			
Supply				
Input Pulse	Open collector (Collector current MAX. 12 mA)			
Input Frequency	60Kpps or less			
Output Pulse	Differential output equivalent to 26C31 (MAX.10mA)			
Weight	10g or less (Cable connector excluded)			
Accessories	37104-3122-000FL (e-CON connector) 2 Units Cover color: YW Applicable wire AWG24			
	(Less than 0.2 to $0.3$ mm <sup>2</sup> , finished O.D. $\phi$ 1.0 to			
	1.211111)			



### Caution

- 1) Use the pulse converter in the surrounding temperature range between 0 and  $40^{\circ}$ C.
- 2) The temperature increase of about 30°C occurs during operation. Accordingly, neither install several pulse converters in close contact nor install them within a duct. Do not install the pulse converter near other heating devices.
- 3) If more than one pulse converters are installed, set a pulse converter apart from another by 10mm or more.

To avoid noise, connect it within 50mm of the pulse train output terminal.


#### 1.2.3 Control Option

#### [1] PIO Converter (Model: RCB-DDD)

(1) Basic Specifications

Item		Item	Description			
Numb	per of Cor	trolled Axes	1 axis			
Powe	r-supply \	/oltage	24V DC ±10%			
Load current when actuator is			High output setting is enabled (Set in delivery) :4.3A (MAX.5.0A)			
conne (inclu contro	ected ding curre ol)	ent consumption for	High output setting is disabled :3.0A			
Power (In the	Supply for le case of t	Electromagnetic Brake <sup>(Note 1)</sup> he actuator with a brake)	24V DC ±10% 0.15A (MAX.)			
Heat	Generatio	, n	1.3W			
In-rus conne	h current ected <sup>(Note 2</sup>	when actuator is	8.4A			
Trans	ient Powe	er Cutoff Durability	MAX. 500µs			
Serial (SIO	l Commur Port)	nication Interface	RS485: 1CH (based on Modbus Protocol RTU/ASCII) Speed : 9.6 to 230.4Kbps Control available with serial communication			
Exter Interfa	nal ace	PIO Type	Signal I/O dedicated for 24V DC (selected from NPN/PNP) ···· Input 16 points max., output 16 points max. Cable length MAX. 10m			
		Fieldbus Type	Not applicable			
Data Setting and Input		nd Input	PC Software, Teaching Pendant Position data and parameters to be saved in the non-volatile memory inside the built-in controller in the actuator via this unit (There is no limitation in number of writing) However, the clock data is to be stored in this unit (retained by capacitor power: approx. 10 days)			
Actua	itor I/O Ty	ре	SIO Type (Model: SE) An operation with Positioner Mode is available			
Numb Mode	per of Pos	itions in Positioner	MAX. 512 points (Note) Number of positioning points differs depending on the selected PIO pattern			
LED I	Display	Standard Type	Controller status display			
		Simple Absolute Type	Display of absolute battery status and absolute reset status			
		With Monitor	Monitor display with switching Command Current Ratio / Alarm Code / PIO Input Status / PIO Output Status			
Electr Relea	romagneti ise Switch	່ດ Brake Compulsory າ	NOM (Normal Operation) / RLS (Brake release) Changeover			
Insula	ation Resi	stance	500V DC 10M $\Omega$ or more			
Prote Shoc	ction Fun k	ction against Electric	Class I basic insulation			
Cooli	ng Metho	d	Natural air-cooling			
	Surround	ing Air Temperature	0 to 40°C			
	Surround	ing Humidity	85%RH or less (non-condensing)			
	Surround	ing Environment	[Refer to installation Environment]			
ent	Surround	ng Storage Temperature	-20 to 70°C (Excluding battery)			
nm	Surround	ing Storage Humidity	85%RH or less (non-condensing)			
/iro	Usage Altitude		1000m or lower above sea level			
En	Protection	n Class	IP20 Exercise and 10 to EZU = / Quiene width + 0.025mm			
Vibration Durability		Durability	Frequency 10 to 5/HZ / Swing Wath : 0.0/5mm			
			XYZ Each direction Sweep time: 10 min, Number of sweep: 10 times			
	Impact		150mm/s <sup>2</sup> , 11mm/s Semi-sine wave pulse to each of the directions X. Y and Z			
Weig	nt .		Standard: 103g, Simple Absolute Type: 287g (including 190g for battery)			
Exter	nal Dimer	nsions	25W × 90H × 98D			

Note 1 It is the power source to be supplied when compulsorily releasing the brake.

Note 2 Rush current passes for about 5ms after the power is injected (at 40°C).

The rush current value varies depending on the impedance of the power line.



(2) External Dimensions(2) For Incremental Type (Standard)





For Simple Absolute Type (Option)





#### (3) PIO Input and Output Interface



#### NPN Type





Same power source as that supplied to PIO Converter



Caution: Use the same power source as that supplied to PIO Converter for the power supply to the common line. It would not operate normally if the power source is different.



#### [2] Quick Teach (Model: RCM-PST-D)

(1) Basic Specifications

		RCM-PST-0	RCM-PST-1	RCM-PST-2				
	Item	24V DC power supply type	Equipped with 100V AC power	Equipped with 200V AC power				
		(Main unit of teaching pendant)	supply unit					
Power Supply Unit Model			RCM-PS-1	(Equipped with 2m cable with				
		-	(Equipped with 2m cable with	φ4.3-hole solderless ring tongue				
			SF power socket plug)	terminals)				
Nui Axe	mber of Controlled		1 axis					
			Single-phase	Single-phase				
Po	ver-supply Voltage	24V DC ±10%	100 to 115V AC ±10% 50/60Hz	100 to 230V AC ±10% 50/60Hz				
Loa	d current when			0.67A				
act	uator is connected	2.2A	1.3A	(when 100V AC is used)				
(inc	luding current	(High output setting is disabled)	(when 100V AC is used)	0.36A				
He	at generation when			(when 200V AC is used)				
act	uator is connected	2W	11	W				
In-r	ush current when	8.3A	MAX. 30A	MAX. 15A				
Cu	rent leakage when							
act	uator is connected	-	MAX. 5mA	MAX. 0.75mA				
Tra	nsient Power Cutoff	_	MAX 10ms	MAX 10ms				
Durability		_						
Emergency Stop		External signal input						
Dat	a Setting and Input	Pressing button switches and dials on the operation panel						
Dat	a Retention Memory	(There is no limitation in number of writing)						
Nui Pos	mber of Settable sitions	2 or 3-point						
Op Fur	eration nctions/LED Display	Servo ON/OFF, try run function as JOG, power ON/OFF, error display, etc. [Refer to Section 4.5.1]						
Ele	ctromagnetic Brake							
Co	npulsory Release	Normal / Release (Compulsory release) changeover						
SW	lich							
Dro								
ada	ainst Electric Shock							
Co	oling Method	Natural air-cooling						
	Surrounding Air	0 to 40°C						
	Temperature							
	Surrounding Humidity	10 to 85%RH (non-condensing)						
L L	Surrounding Environment	[Refer to installation Environmen	t]					
men	Surrounding Storage Temperature	-20 to 70°C						
Iviror	Surrounding Storage	90%RH (non-condensing)						
ш	Usage Altitude	1000m or lower above sea level						
1	Protection Class							
	Vibration Durability	Frequency 5 to 9Hz / Swing widt	h: 1.75mm (continuous), 3.5mm	(intermittent)				
1		Frequency 9 to 150Hz / Accelera	ation 4.9m/s <sup>2</sup> (continuous), 9.8m/	s <sup>2</sup> (intermittent)				
We	ight	120g	540g	535g				
External Dimensions		65W × 157H × 21.6D	65W × 157	7H × 64.4D				

Note 1 Rush current passes for about 5ms after the power is injected (at 40°C).

The rush current value varies depending on the impedance of the power line.

Note 2 High output setting operation cannot be made with a quick teach other than RCM-PST-0. High output setting (Parameter No.152) automatically becomes invalid if a quick teach is connected.



(2) External Dimensions © RCM-PST-0







1.2 Specifications 1.2.3 Control Option



RCM-PST-1/RCM-PST-2





1.2 Specifications 1.2.3 Control Option

# 2.1 Transportation

### Chapter 2 Installation

#### 2.1 Transportation

FRE

- [1] Handling of Actuator, PIO Converter and Quick Teach
  - Unless otherwise specified, the actuators are wrapped individually when the product is shipped out. Also, PIO Converter and Quick Teach are packaged separately.
  - (1) Handling the Packed Unit
  - Do not damage or drop. The package is not applied with any special treatment that enables it to resist an impact caused by a drop or crash.
  - Transport a heavy package with at least more than two operators. Consider an appropriate method for transportation.
  - Keep the unit in horizontal orientation when placing it on the ground or transporting. Follow the instruction if there is any for the packaging condition.
  - Do not step or sit on the package.
  - Do not put any load that may cause a deformation or breakage of the package.
  - (2) Handling the Actuator After Unpacking
  - Do not carry an actuator by a cable or attempt to move it by pulling the cable.



- When carrying the actuator main unit, hold the base part for the slider type and the frame of the body for the rod type.
- When carrying the actuator, exercise caution not to bump it against nearby objects or structures.
- Do not give any excessive force to any of the sections in the actuator.
- Handle with care on the operation panel of the quick teach since it is easy to get scratched.



#### [2] Handling of Multi-Axes Type

This is the case that this product is delivered with other actuators being combined. Multi-axes type will be delivered in a package with an outer case fixed to a wooden base. Sliders are fixed so they would not accidently move while in transportation. The end of the actuator is also fixed to avoid it swinging by external vibration.

- (1) Handling the Packed Unit
- Do not damage or drop. The package is not applied with any special treatment that enables it to resist an impact caused by a drop or crash.
- Transport a heavy package with at least more than two operators. Consider an appropriate method for transportation.
- When suspending the package using ropes, pass the ropes from underneath the reinforcement frames at the bottom of the base. When lifting with a forklift, also place the forks underneath the base.
- Do not apply an impact on the package or let it bounce when putting it down.
- Do not step or sit on the package.
- Do not put any load that may cause a deformation or breakage of the package.
- (2) Handling the Actuator After Unpacking
- Affix the slider and rod so they would not move while transporting.
- If any end of the actuator is overhanging, secure it properly to avoid significant movement due to external vibration. If the actuator assembly is transported without the ends being secured, do not apply an impact of 0.3G or more.
- In the case that the actuator needs to be carried up with ropes or another method, be sure to use an appropriate cushioning to avoid the robot being deformed or put on an excessive pressure. And also, be sure to keep the robot in a stable and horizontal posture. Make a tool to utilize the attachment holes and tapped holes on the actuator and attach it if necessary.
- Do not attempt to apply load to the actuator or connector box. Also, avoid the cables being pinched or caused an excessive deformation.
- [3] Handling of Robot Mounted on Mechanical Equipment (System) In below, explains how to handle the actuator when transporting it in the whole mechanical equipment (system) that the actuator is built in.
  - Affix the slider and rod so they would not move while transporting.
  - If any end of the actuator is overhanging, secure it properly to avoid significant movement due to external vibration. If the actuator assembly is transported without the ends being secured, do not apply an impact of 0.3G or more.
  - When suspending the mechanical equipment (system) with ropes, avoid applying force to the actuator, connector box, etc. Also, avoid the cables being pinched or caused an excessive deformation.

2.1 Transportation

2.2 Installation and Storage Environment



#### 2.2 Installation and Storage Environment

This product is capable for use in the environment of pollution degree  $2^{1}$  or equivalent.

- \*1 Pollution Degree 2 : Environment that may cause non-conductive pollution or transient conductive pollution by frost (IEC60664-1)
- [1] Installation Environment

In general, the installation environment should be one in which an operator can work without protective gear.

Also provide sufficient work space required for maintenance inspection.

- (1) Actuator
  - Do not use this product in the following environment.
- Where the actuator receives radiant heat from strong heat sources such as heat treatment furnaces
- Where the surrounding temperature exceeds the range of 0 to 40°C
- Where the temperature changes rapidly and condensation occurs
- Where the relative humidity exceeds 85% RH
- Where the actuator receives direct sunlight
- · Where the actuator is exposed to corrosive or combustible gases
- Where the surrounding air contains a large amount of powder dust, salt or iron (at level exceeding what is normally expected in an assembly plant)
- Where the actuator is subject to splashed water, oil (including oil mist or cutting fluid) or chemical solutions
- · Where the actuator receives impact or vibration

Provide sufficient shielding measures for usage in locations shown below.

- Where noise generates due to static electricity, etc.
- Where the actuator is subject to a strong electric or magnetic field
- · Where the actuator is subject to ultraviolet ray or radiation

Where the space required for maintenance inspection



(2) PIO Converter • Quick Teach

Do not use this product in the following environment.

- Where the surrounding temperature exceeds the range of 0 to 40°C
- Where the temperature changes rapidly and condensation occurs
- · Where the relative humidity exceeds 85% RH
- Relative humidity less than 10%RH (Quick Teach)
- · Where the actuator is exposed to corrosive or combustible gases
- Where the surrounding air contains a large amount of powder dust, salt or iron
- · Where the actuator receives impact or vibration
- · Where the actuator receives direct sunlight
- Where the actuator is subject to splashed water, oil or chemical solutions

Provide sufficient shielding measures for usage in locations shown below.

- Where noise generates due to static electricity, etc.
- Where the actuator is subject to a strong electric or magnetic field
- Location with the mains or power lines passing nearby



#### [2] Storage • Preservation Environment

#### (1) Actuator

The storage • preservation environment should be similar to the installation environment. In addition, make sure condensation will not occur when the actuator is to be stored or preserved for a long period of time. Unless specified, we do not include drying agents when shipping the actuator. If you are storing the actuator in an environment where condensation might occur, you must treat the entire shipping box, or treat the actuator itself after unpacking, to prevent condensation. The unit can withstand temperatures up to 60°C during a short storage/preservation period, but only up to 50°C if the storage/preservation period is longer than one month.

The actuator should be lying flat during storage • preservation.

If the actuator is to be stored in a packed state, follow the specified actuator position if indicated.

#### (2) PIO Converter • Quick Teach

Storage and preservation environment follows the installation environment. However, the surrounding temperature should be from -20 to 70°C and the relative humidity to be 85%RH at maximum. Especially in a long-term storage, consider to avoid condensation of surrounding air. Unless specified, we do not include drying agents when shipping the actuator. If you are storing the actuator in an environment where condensation might occur, you must treat the entire shipping box, or treat the actuator itself after unpacking, to prevent condensation.

Chapter 2 Installation



#### 2.3 How to Install

#### 2.3.1 Posture of Actuator Attachment

#### O : Possible $\Delta$ : Daily inspection is mandatory × : Not possible

Туре	Horizontal Installation	Vertical Installation	Sideway Installation	Ceiling Mount Installation
Slider Standard Type (Screw Cover Type) (SA5C, SA7C)	0	0	0	0
Slider Standard Type (Stainless Steel Sheet Type) (SA5C, SA7C)	0	0	Δ	Δ
Slider Cleanroom Type (SA5C, SA7C)	0	0	Δ	Δ
Rod Type (RA4C, RA6C)	0	0	0	0

Attachment Orientation



Chapter 2 Installation

## ERC**3**

Caution:

- 1. When the unit is installed vertically oriented, attempt to put the motor up unless there is a special reason. Putting the motor on the lower side would not cause a problem in an ordinary operation. However, it may rarely cause a problem, when it is not operated for a long period, depending on the surrounding environment (especially high temperature), caused by the grease being separated and the base oil flowing into the motor unit.
- 2. If the actuator is installed in horizontally oriented wall mount for the slider standard type (screw cover type) SA5C and SA7C, it is easy for a foreign object to get inside the actuator from the opening on the side of the actuator. And also it becomes easy to splash the grease applied on the guide and ball screw from the opening on the side surface.
- 3. Although the slider standard type (stainless steel type) and cleanroom types SA5C and SA7C are available for the installations in horizontally oriented wall mount and in ceiling mount, it is necessary to have daily inspections. If the actuator is installed sideways or ceiling mount, the stainless sheet may be slacked or displaced. Keeping use of the actuator in such conditions may cause such failures as breakage of the stainless steel sheet. In case the sheet is slacked or displaced, adjust the attachment of it. Refer to "8.6.5 How to Replace and Adjust Stainless Steel Sheet"

Chapter 2 Installation

## ERC**3**

#### 2.3.2 Installation of Slider Type

The installation for the screw cover type, is different from that for the stainless sheet type (cleanroom type).

[Refer to [1] and [2] for the screw cover type. Refer to [3] and [4] for the stainless sheet type (cleanroom type).]

[1] Attachment of Actuator Body (Standard Type (Screw Cover Type))

The attachment surface should be a machined surface or a flat surface that possesses an equivalent accuracy, and the flatness should be 0.05mm or less. Also, the platform should have a structure stiff enough to install the unit so it would not generate vibration or other abnormality. Also consider enough space necessary for maintenance work such as actuator replacement and inspection.

There are datum surfaces for attachment on the base.

The flatness of the slider movement is designed to be 0.05mm/m at maximum to the datum surface.

On the rear side of the actuator, there are tapped holes and through holes for attachment and reamed hole and oblong hole for positioning. See the appearance drawings for the details of the position and diameters. [Refer to Chapter 9]

Utilize the reamed holes when repeatability in the attachment after detaching is required. However, when small tunings such as the perpendicularity is required, consider such things like to use one reamed hole.



#### (1) Datum Surface

There are datum surfaces for attachment on the base.







#### (For reference) Shown below is the section of platform when attaching using the datum.



Actuator Type	A Dimension for Reference [mm]
SA5C, SA7C	1.5 to 4.5 or less

## 2.3 How to Install

## ERC**3**

(2) Mounting Method 1 (When utilizing tapped holes)

Follow the table below for the torque to tighten the attachment screws.

Actuator	Tanning	Tightening Torque [N•m]		
Туре	Diameter	In the case that steel is used for the bolt seating surface:	In the case that aluminum is used for the bolt seating surface:	
SA5C	M4	3.59	1.76	
SA7C	M5	7.27	3.42	

Regarding attachment screws

- It is recommended to use high-tensile bolts with ISO-10.9 or more.
- The length of thread engagement should be 1.8 times more than the nominal diameter, and pay attention not to stick the screw out inside the actuator.

/ Caution: Pay attention to the bolt length. If a bolt with inappropriate length is used	d, it may
cause an abnormality or drop in the accuracy on the driving part, damage	ge on tapped
holes or accident or failure due to insufficient strength on the actuator a	ttachment.

(3) Mounting Method 2 (When using through holes)

Detach the screw cover and install with hex socket head cap screws from inside the actuator. Do not lose the screws for the screw cover attachment.

Be careful not to make a dent or scratch on the ball screw by dropping a screw or tool on it. After installation is finished, put the screw cover back on.

Attach the actuator with the hex socket head cap screw described in the table and with the specified tightening torque.

Actuator Type	Mounting Holes	Mounting Screw	Tightening Torque [N•m]
SA5C	φ4.5 through hole φ8 counter boring depth 4.5	M4	1.76
SA7C	φ6 through hole φ9.5 counter boring depth 5.5	M5	3.42

Regarding attachment screws

- It is recommended to use high-tensile bolts with ISO-10.9 or more.
- For the effective engagement length between the bolt and female thread, provide at least the applicable value specified below:

Female thread is made of steel material  $\rightarrow$  Same length as the nominal diameter Female thread is made of aluminum  $\rightarrow$  1.8 times of nominal diameter

Caution: Pay attention when selecting screws. If a bolt out of the instruction is used, it may cause an abnormality or drop in the accuracy on the driving part, damage on tapped holes or unexpected accident or failure due to insufficient strength on the actuator attachment or interference on the driving area.



#### [2] Load Attachment (Standard Type (Screw Cover Type)

• There is a restriction on the moment and load overhang length when attaching a load to the slider.

Actuator	Static allowable moment [N•m]			Dynamic allowable moment <sup>(Note 1)</sup> [N•m]			Allowable overhung load
Туре	Ma	Mb	Мс	Ma	Mb	Мс	length L [mm]
SA5C	29.4	42	60.5	8.52	12.2	17.5	Ma direction: 150 Mb or Mc direction: 150
SA7C	70	100	159.5	17.7	25.2	40.3	Ma direction: 150 Mb or Mc direction: 150

#### Allowable moment and overhang load length

Note 1 Provided under assumption that the operation life is 5,000km.



Direction of moment

For the calculation of Ma and Mc moments, consider the position indicated with an arrow as the datum point.



Caution: An operation beyond the allowable moment and overhang load length would not only generate abnormal noise and vibration, but also may shorten the life of actuator extremely.

Direction of allowable overhang



- There are tapped holes on the slider top for the load attachment. Also, there are two reamed holes. Utilize the reamed holes when repeatability in the attachment after detaching is required. Also, when a tuning of such accuracy as the perpendicularity is required, use only one of the reamed holes.
- Shown below is the detail of the attachment area. Attach a load with the bolts listed in the table below with the specified tightening torque. Pay special attention to the bolt length.



Reamer Hole Pitch : ±0.02

Actuator Type	А	В	С	D	E	Tapping Diameter	Tightening Torque [N•m]
SA5C	50	20.5	41	φ4H7, depth 6	M4, depth 8	M4	1.76
SA7C	72	32	64	φ5H7, depth 10	M5, depth 10	M5	3.42

Regarding attachment screws

- Use of high-tension bolts meeting at least ISO-10.9 is recommended.
- Make sure to have the length of at least 1.8 times to the bolt diameter below for the effective length of screw engagement for the tightening of a bolt and a female screw.



[3] Attachment of Actuator Body (Standard Type (Stainless Steel Sheet Type), Cleanroom Type)

The attachment surface should be a machined surface or a flat surface that possesses an equivalent accuracy, and the flatness should be 0.05mm or less. Also, the platform should have a structure stiff enough to install the unit so it would not generate vibration or other abnormality. Also consider enough space necessary for maintenance work such as actuator replacement and inspection.

There are datum surfaces for attachment on the base.

The flatness of the slider movement is designed to be 0.05mm/m at maximum to the datum surface.

On the rear side of the actuator, there are tapped holes and through holes for attachment and reamed hole and oblong hole for positioning. See the appearance drawings for the details of the position and diameters. [Refer to Chapter 9]

Utilize the reamed holes when repeatability in the attachment after detaching is required. However, when small tunings such as the perpendicularity is required, consider such things like to use one reamed hole.



Shown in the figure above is the cleanroom type. There is no vacuum joint of the stainless steel sheet type.

#### (1) Datum Surface

There are datum surfaces for attachment on the base.



Positions of Datum Surfaces (View from shaft end of opposite side of motor)

Shown in the figure above is the cleanroom type. There is no vacuum joint of the stainless steel sheet type.



(For reference) Shown below is the section of platform when attaching using the datum.



Actuator Type	A Dimension for Reference [mm]
SA5C	2 to 4.5 or less
SA7C	2 to 5.5 or less



(2) Mounting Method 1 (When utilizing tapped holes)

Follow the table below for the torque to tighten the attachment screws.

Actuator	Topping	Tightening Torque [N•m]		
Туре	Diameter	In the case that steel is used for the bolt seating surface:	In the case that aluminum is used for the bolt seating surface:	
SA5C	M4	3.59	1.76	
SA7C	M5	7.27	3.42	

Regarding attachment screws

- It is recommended to use high-tensile bolts with ISO-10.9 or more.
- The length of thread engagement should be 1.8 times more than the nominal diameter, and pay attention not to stick the screw out inside the actuator.
- Caution: Pay attention to the bolt length. If a bolt with inappropriate length is used, it may cause an abnormality or drop in the accuracy on the driving part, damage on tapped holes or accident or failure due to insufficient strength on the actuator attachment.
- (3) Mounting Method 2 (When using through holes)

Detach the screw cover and install with hex socket head cap screws from inside the actuator. Do not lose the screws for the screw cover attachment.

Be careful not to make a dent or scratch on the ball screw by dropping a screw or tool on it. After installation is finished, put the screw cover back on.

Attach the actuator with the hex socket head cap screw described in the table and with the specified tightening torque.

Actuator Type Mounting Holes		Mounting Screw	Tightening Torque [N•m]
SA5C	φ4.5 through hole φ8 counter boring depth 5.5	M4	1.76
SA7C	φ6 through hole φ9.5 counter boring depth 11	M5	3.42

Regarding attachment screws

- It is recommended to use high-tensile bolts with ISO-10.9 or more.
- For the effective engagement length between the bolt and female thread, provide at least the applicable value specified below:

Female thread is made of steel material  $\rightarrow$  Same length as the nominal diameter Female thread is made of aluminum  $\rightarrow$  1.8 times of nominal diameter

Caution: Pay attention when selecting screws. If a bolt out of the instruction is used, it may cause an abnormality or drop in the accuracy on the driving part, damage on tapped holes or unexpected accident or failure due to insufficient strength on the actuator attachment or interference on the driving area.



[4] Load Attachment (Standard Type (Stainless Steel Sheet Type), Cleanroom Type)There is a restriction on the moment and load overhang length when attaching a load to the slider.

Actuator	Static a	lowable [N•m]	moment	Dyna mome	amic allov ent <sup>(Note 1)</sup>	vable [N•m]	Allowable overhung load
Туре	Ма	Mb	Мс	Ма	Mb	Мс	length L [mm]
SA5C	18.6	26.6	47.5	5.81	8.3	14.8	Ma direction: 150 Mb or Mc direction: 150
SA7C	50.4	71.9	138.0	20.7	29.6	56.7	Ma direction: 230 Mb or Mc direction: 230

#### Allowable moment and overhang load length

Note 1 Provided under assumption that the operation life is 5,000km.



Direction of moment



For the calculation of Ma and Mc moments, consider the position indicated with an arrow as the datum point.



Caution: An operation beyond the allowable moment and overhang load length would not only generate abnormal noise and vibration, but also may shorten the life of actuator extremely.



- There are tapped holes on the slider top for the load attachment. Also, there are two reamed holes. Utilize the reamed holes when repeatability in the attachment after detaching is required. Also, when a tuning of such accuracy as the perpendicularity is required, use only one of the reamed holes.
- Shown below is the detail of the attachment area. Attach a load with the bolts listed in the table below with the specified tightening torque. Pay special attention to the bolt length.



Reamer Hole Pitch :  $\pm 0.02$ 

#### Regarding attachment screws

- Use of high-tension bolts meeting at least ISO-10.9 is recommended.
- Make sure to have the length of at least 1.8 times to the bolt diameter below for the effective length of screw engagement for the tightening of a bolt and a female screw.

Actuator Type	А	В	С	D	E	Tapping Diameter	Tightening Torque [N•m]
SA5C	26	19	30	φ4H7, depth 6	M4, depth 9	M4	1.76
SA7C	39	32	50	φ5H7, depth 10	M5, depth 10	M5	3.42



## ERC**3**

### 2.3.3 Air Suction of Slider Type (Cleanroom Type)

- Cleanroom type can have the performance to comply with Cleanroom Class 10  $(0.1 \,\mu \,\text{m})$  by vacuuming the air at the two vacuum joints. The table below shows the reference of vacuum capacity at the maximum speed for each model.
- Have the pipe layout to make the vacuum performance at the two points get even.
- Have all the base attachment holes and Positioning hole at the bottom of the unit closed when using the unit. If there is a through hole on the body, it can drop the cleanliness.

A studtor turo	Lead	Vacuum Capacity
Actuator type	[mm]	NI/min (L/min)
	3	15 (16)
8450	6	30 (32)
SAUC	12	50 (54)
	20	80 (86)
	4	30 (32)
8470	8	40 (43)
SAIC	16	70 (75)
	24	90 (97)

#### [1] Reference for Vacuum Capacity

#### [2] Vacuum Joint

A quick joint structure is applied to the vacuum joint so an air tube available in the market can be easily joined.

Actuator type	Air Tube Outer Diameter
SA5C	φ6
SA7C	φ8



#### 2.3.4 Installation of Rod Type

[1] Installation of Actuator Type Unit

There are two ways to install, one is to use the T-shaped slots on the frame and other to install vertically with using the flange surface. The installed surface should be a machined surface or a flat surface which possesses an equivalent accuracy to it, and the flatness should be 0.05mm at the maximum.

See the appearance drawings for the details of the actuator dimensions. [Refer to Chapter 9]



(1) Mounting Method 1 (When using T slots on frame)

There are T-shaped slots on the frame for installation. Attach the unit directly with using these T slots or use foot brackets (option).

Square nuts (4 pieces) for T-shaped slot are enclosed in standard.

• Direct Installation



Square nut	
3.2 7 M4	
For RA4C	For RA6C

Actuator Type	Mounting Screw	А	В	Tightening Torque [N•m]
RA4C	M4	17	7	1.76
RA6C	M6	25	11.6	5.36

Regarding attachment screws

Caution: Pay attention to the bolt length. It may cause an unexpected accident or failure due to an insufficient attachment strength if the screws are too long or short.





• When Using Foot Brackets (Option) When installing the unit with using the foot brackets, use the T slots as for the direct installation and affix with hex socket head cap screws.



Actuator Type	А	В	С	D	Е	Recommended attachment screw	Tightening Torque [N•m]
RA4C	71	57	20	10	φ6.6 through hole	M6	5.36
RA6C	95	79	25	12	$\phi 9$ through hole	M8	11.48

Regarding attachment screws

- Use of high-tension bolts meeting at least ISO-10.9 is recommended.
- For the effective engagement length between the bolt and female thread, provide at least the applicable value specified below:
   Female thread is made of steel material → Same length as the nominal diameter

Female thread is made of aluminum  $\rightarrow$  1.8 times of nominal diameter



(2) Mounting Method 2 (Installation using flange surface)Direct Installation



Actuator Type	А	В	Tightening Torque [N•m]
RA4C	34	M6, depth 12	5.4
RA6C	50	M8, depth 16	11.5

Regarding attachment screws

- Use of high-tension bolts meeting at least ISO-10.9 is recommended.
- Make sure to have the length of at least 1.8 times to the bolt diameter for the effective length of screw engagement for the tightening of a bolt and a female screw.



## ERC**3**

• When Using Flange Bracket (Option)

When installing the unit with using the flange bracket, use the tapped holes as for the direct installation and affix with hex socket head cap screws.



								Tightening T	「orque [N•m]
Actuator Type	A	В	С	D	Е	F	Screw	If the platform to attach actuator is steel	If the platform to attach actuator is aluminum
RA4C	44.5	75	10	34	60	φ6.6 through hole	M6	12.34	5.36
RA6C	63.5	99	12	50	82	∮9 through hole	M8	29.97	11.48

Regarding attachment screws

- Use of high-tension bolts meeting at least ISO-10.9 is recommended.
- For the effective engagement length between the bolt and female thread, provide at least the applicable value specified below:

Female thread is made of steel material  $\rightarrow$  Same length as the nominal diameter Female thread is made of aluminum  $\rightarrow$  1.8 times of nominal diameter



Caution:

• When installing on the flange, do not apply external force to the unit. It may cause an operation error or damage with the external force.





#### [2] Load Attachment

Utilize the threaded part on the rod tip to attach the load. Screw in the load or use the enclosed nut. The enclosed nut can also be used as a stopper to stop from loosened after the load is screwed in.



Maximum nut tightening torque of metal part on rod tip (Note 1)

- RA4 31.9N•m
- RA6 88.8N•m
- Note 1 Listed above are the maximum nut tightening torques in the basis of the metal part on the tip of the rod. Tighten the nut with the appropriate torque below those values considering the condition of the load attachment. In case the load is a material other than steel, such as aluminum, or the area of the tightening contact surface is small, consider the limit interface pressure of the material of the load and set the appropriate torque below the limit value.



Caution:

• Do not attempt to apply the radial load to the tip of the rod. An operation with the radial load being applied may cause an abnormal noise or vibration resulted in generation of an alarm. Also, it may shorten the actuator life extremely.



• Pay attention not to rotate the rod when attaching a load. Make sure to hold 2 faces on the top with a wrench so the tightening torque would not be applied to the rod.

The allowable static rotation torque should be  $0.5N \cdot m$ 



 $\oplus$ Between 2 flat faces



## ERC**3**

#### 2.3.5 Noise Prevention and How to Attach Electrical Devices

[1] Noise Elimination Grounding (Frame Ground)

(1) When controlling ERC3 directly from the host controller (PLC)





Do not share the ground wire with or connect to other equipment. Ground each controller.

ERC3 possesses a built-in controller in the actuator body. The frame ground line for this controller is equipped in the PIO type power and I/O cable. Connect this to the ground terminal using a relay terminal block.

For the grounding line after the relay terminal apply a low carbon steel wire with the diameter 1.6mm (AWG14: 2mm<sup>2</sup>) or more.



(2) When controlling with using PIO converter



Do not share the ground wire with or connect to other equipment. Ground each controller.

There is a terminal for frame grounding on the front panel of PIO Converter. Connect it to the grounding terminal. Use a low carbon steel wire with the diameter 1.6mm (AWG14: 2mm<sup>2</sup>) or more for grounding.

- (3) How to ground Quick Teach
  - 1) RCM-PST-0 (24V DC power supply type)

It is not necessary to ground the quick teach since its frame ground is connected to the actuator with the connection cable. Have a ground on the platform to install the actuator the actuator main unit. For grounding, make sure to conduct Class D Grounding (former Class 3 Grounding: grounding resistance  $100\Omega$  or less).



Grounding resistance at  $100\Omega$  or less

#### Caution:

In case it is necessary to use a terminal block in an electromagnetic control box, cut off the 3P plug to connect the line.

In that case, do not attempt to share the ground line with other devices or join with others. For the wiring, follow the cable colors described below.

Electric wire color	Signal Name	Description
BR	L	Dowor oupply
BL	N	Power supply
YW & GN	PE	Ground wire



2.3 How to Install



#### 3) RCM-PST-2



Electric wire color	Signal Name	Description
BR	L	Dowor ourphy
BL	N	Power supply
YW & GN	PE	Ground wire

Copper Wire : Connect to a ground cable with diameter 1.6mm (AWG14: 2mm<sup>2</sup>) or more.

Earth Terminal Grounding resistance at  $100\Omega$  or less

MIDDLE BACK POS POS

NO DOS DOS SAVE TOSS TUD FWD BACK Coss BUN STOP

DA\D

8888 8888

FWD




- [2] Precautions regarding wiring method
  - 1) Wire is to be twisted for the power supply.
  - 2) Separate the signal and encoder lines from the power supply and power lines.
- [3] Noise Sources and Elimination

Carry out noise elimination measures for electrical devices on the same power path and in the same equipment. The following are examples of measures to eliminate noise sources.

- 1) AC solenoid valves, magnet switches and relays [Measure] Install a Surge absorber parallel with the coil.
- 2) DC solenoid valves, magnet switches and relays [Measure] Mount the windings and diodes in parallel. Select a diode built-in type for the DC relay.



- [4] Cooling Factors and Installation
  - 1) PIO Converter

Design and Build the system considering the size of the controller box, location of the controller and cooling factors to keep the surrounding temperature around the controller below 40°C.





2) Quick Teach

- RCM-PST-0 (24V DC power supply type) As shown in the figure on the right, Quick Teach can be hanged on a wall using the hook hole for wall mount on the back of it if a pan head screw is prepared on a wall.
- RCM-PST-1/RCM-PST-2 (Equipped with power supply unit)

Shown below is the figure describing the dimensions for when the unit is permanently installed in an electromagnetic control box.





# Chapter 3 Wiring

- 3.1 Positioner Mode 1 (Standard Type)
- 3.1.1 Wiring Diagram (Connection of construction devices) I/O type of the model code is NP or PN.







# 3.1.2 PIO Pattern Select and PIO Signal

#### [1] PIO Pattern (Control Pattern) Selection

There are three ways of control methods for ERC3 controllers. Set the most suitable PIO pattern to Parameter No.25 "PIO Pattern Select".

Refer to 4.2.2 Operation in Positioner Mode 1 for the details of PIO patterns.

Туре	Value set in parameter No.25	Mode	Overview
PIO Pattern 0	0 (at the delivery)	8-point type	<ul> <li>Number of positioning points : 8 points</li> <li>Position command : binary code</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> </ul>
PIO Pattern 1	1	3-point type (Solenoid valve type)	<ul> <li>Number of positioning points : 3 points</li> <li>Position command : Individual number signal ON</li> <li>Zone signal output : None</li> </ul>
PIO Pattern 2	PIO 2 16-point type		<ul> <li>Number of positioning points : 16 points</li> <li>Position command : binary code</li> <li>Position zone signal output<sup>*2</sup> or Zone signal output<sup>*1</sup> : 1 point <sup>(Note 1)</sup></li> </ul>

Note 1 The position zone signal output can be switched to the zone signal with Parameter No.149.

- \*1 Zone signal output : Zone range is to be set to either Parameter No.1, 2 and it is always available after the home-return operation is complete.
- \*2 Position zone signal output : This feature is associated with the specified position number. The zone range is set in the position table. The zone range is enabled only when the position is specified but disabled if another position is specified.



[2] PIO Patterns and Signal Assignment

The signal assignment of cable by the PIO pattern is as shown below. Follow the following table to connect the external equipment (such as PLC).

				Parameter No.25 (PIO Pattern) Selection		
		Cotogony	<b>BIO</b> Eurotiona	0	1	2
		Calegory	PIO Functions	8-point type	3-point (solenoid valve) type	16-point type
			Number of positioning points	8 points	3 points	16 points
D' N			Home return signal	0	×	×
PIN NO.	wire Color	Input	Jog signal	×	×	×
			Teaching signal	×	~	×
			(Current position writing)	~	~	~
			Brake release	0	0	0
			Moving signal	×	×	×
		Output	Zone signal	0	×	0
			Position zone signal	×	×	×
A1	Drain	F	rame ground		FG	
B1	BR	Contro	l power unit +24V		CP	
A2	-		-		_	
B2	RD	Contr	ol power unit 0V	CP_GND		
A3	RD 1	В	rake release	BK		
B3	OR	Motor	power unit +24V	MP		
A4	OR 1	Emer	gency-stop input		EMG	
B4	YW	Moto	or power unit 0V		MP_GND	
A5	-		_	-		
B5	GN		_	_		
A6	-		_	_		
B6	BR 1		_	_		
A7	BL		-	_		
B7	PL		-		_	
A8	GY		-		_	
B8	WT		-		_	
A9	BR 2		INO	PC1	ST0	PC1
B9	RD 2		IN1	PC2	SI1	PC2
A10	OR 2	Input	IN2	PC4	S12	PC4
B10	YW 2	•	IN3	HOME	-	PC8
A11	GN 2		IN4	CSIR	RES	CSIR
B11	BL 2		IN5	*512	*SIP	*512
A12	PL2			PEND	PE0	PEND
в12	GY 2	Outerst	0011	HEND	PE1	HEND
A13	WT 2	Output	OUT2	ZONE1	PE2	PZONE/ ZONE1
B13	BK		OUT3	*ALM	*ALM	*ALM

(Note) Signal with "\*" expresses the signal of active low.

(Reference) Signal of Active Low

Signal with "\*" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.



[3] List of PIO Signals The table below lists the functions of PIO signals. Refer to the section shown in Relevant Sections for the details of the control of each signal.

Category	Signal Abbreviation	Signal Name	Function Description	Relevant Sections
	EMG	Emergency Stop Input	It shuts the motor power supply.	4.2.2 [3]
	BK	Brake Forcible Release	The brake will forcibly be released.	4.2.2 [4]
	CSTR	Start Signal	The actuator will start to move to the position set by the command position number.	4.2.2 [7]
	PC1 to PC8	Command Position Number	Input of the position number to move (binary input)	4.2.2 [7]
Input	*STP	Pause	When this signal turns OFF while the actuator is moving the actuator will decelerate to stop. The remaining movement is retained and will resume when the signal is turned ON again.	4.2.2 [7]
	HOME	Home Return	The controller will perform home return operation when this signal is turned ON.	4.2.2 [6]
	ST0 to ST6	Start Signal	The actuator moves to the position corresponding to the start signal when this signal is on in Electromagnetic Valve Mode.	4.2.2 [8]
	PEND	Position Complete	Turns ON in the positioning width range after actuator operation. The INP signal will turn OFF if the position deviation exceeds the in-position range. PEND and INP can be switched over by the parameter.	4.2.2 [6] [7]
	HEND	Home Return Completion	This signal will turn ON when home return has been completed. It will be kept ON unless the home position is lost.	4.2.2 [6] [7]
	ZONE1	Zone Signal 1	Turns ON if the current actuator position is within the range set to the parameter No.1, 2.	<sup>,</sup> 4.2.2 [6]
Output	PZONE	Position Zone	This is a function belonging to the commanded position number, and the zone range is to be set in the position table and is effective only when that position is indicated. This signal turns ON when the current position comes into the range set in the position data.	4.2.2 [6]
	*ALM	Alarm	Turns ON when the controller is in normal condition, and turns OFF when an alarm is generated.	4.2.2 [6]
	PE0 to PE2	Current Position Number	In the electromagnetic valve mode, this signal will turn ON when the actuator completes moving to the target position.	4.2.2 [8]



#### 3.1.3 Circuit Diagram

Sample circuit diagrams are shown below.

[1] Power Line and Emergency Stop Circuit



Note 1 The load current for the emergency stop signal EMG to turn ON/OFF at contact CR is 24V DC and 10mA.

Note 2 This is a switch to compulsorily release the brake of the actuator equipped with a brake. It is convenient when in maintenance or adjustment work if it is installed. It is necessary to have at least 24V DC and 150mA for the switch contact capacity.

Note 3 The controller automatically identifies that the teaching tool is connected and activates the emergency stop switch of the teaching pendant.

Note 4 Apply contact CR when having external cutoff of driving source.

The motor drive power line MP that turns ON/OFF at CR is as load current for the as shown below.

Load current	When ERC3 high output setting activated: 3.5A (4.2A max.)
Loau current	ERC high output setting invalid: 2.0A
During in-rush	8.3A

#### Caution:

- Do not attempt to shut the 0V circuit of MP\_GND and CP\_GND with the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- The emergency stop switch of the teaching pendant cannot be reflected to the emergency stop circuit of the whole system.
- In case the power source for each controller is different, join the 0V of each power supply together.



[2] PIO Circuit

1) PIO Pattern 0 ..... 8-point Type



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

• For the connection of I/O, use the enclosed cable for those connections including the power supply and emergency stop circuit.

Model : CB-ERC3P-PWBIO  $\Box \Box \Box$  indicates the cable length L. Example. 020 = 2m)



Pin No.	Wire Color	Signal Abbreviation	Width	Pin No.	Wire Color	Signal Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	_	-	-	B2	RD	CP_GND	(0.3mm-)
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	I	_	-	B5	GN	-	
A6	-	-	-	B6	BR 1	-	
A7	BL	-		B7	PL	-	
A8	GY	_		B8	WT	-	A1A/C 29
A9	BR 2	PC1	AVA/C 20	B9	RD 2	PC2	AVVGZO
A10	OR 2	PC4	AVVGZO	B10	YW 2	HOME	(0.0011111)
A11	GN 2	CSTR	(0.0011111)	B11	BL 2	*STP	
A12	PL 2	PEND		B12	GY 2	HEND	
A13	WT 2	ZONE1		B13	BK	*AI M	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.

#### 2) PIO Pattern 1 ····· Solenoid Valve Type



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

• Use the attached cable for the I/O connection. Model : CB-ERC3P-PWBIO ( ... indicates the cable length L. Example. 020 = 2m)



(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated. 3.1 Positioner Mode 1 (Standard Type)

#### 3) PIO Pattern 2······ 16-point Type

FRE



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

Use the attached cable for the I/O connection.
 Model : CB-ERC3P-PWBIO (000 indicates the cable length L. Example. 020 = 2m)



Pin No.	Color	Abbreviation	Width	Pin No.	Color	Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	1	-	-	B2	RD	CP_GND	(0.3mm <sup>-</sup> )
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	-	-	-	B5	GN	-	
A6	-	—	-	B6	BR 1	_	
A7	BL	—		B7	PL	-	
A8	GY	_		B8	WT	-	
A9	BR 2	PC1		B9	RD 2	PC2	AWG28
A10	OR 2	PC4	AWG28	B10	YW 2	PC8	(0.08mm <sup>2</sup> )
A11	GN 2	CSTR	(0.08mm <sup>2</sup> )	B11	BL 2	*STP	
A12	PL 2	PEND		B12	GY 2	HEND	
A13	WT 2	PZONE/ ZONE1		B13	BK	*ALM	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.



# 3.2 Pulse Train Control Mode

3.2.1 Wiring Diagram (Connection of construction devices) I/O type of the model code is PLN or PLP.



Note 1  $\square$  indicates the cable length. (Example) 030 = 3m



# 3.2.2 PIO Pattern Selection and PIO Signal

#### [1] PIO Pattern (Control Pattern) Selection

There are two types of control method for the pulse train control. Set an appropriate PIO pattern suited to the use to Parameter No.25 "PIO Pattern Select". Refer to 4.3 Operation in Pulse Train Control Mode for the details of PIO patterns.

Туре	Value set in parameter No.25	Mode	Overview
PIO Pattern 0	0 (at the delivery)	Positioning mode	Positioning with Pulse Train
PIO Pattern 1	1	Pressing mode	<ul> <li>Positioning with Pulse Train</li> <li>Pressing operation with torque control available</li> </ul>

#### [2] PIO pattern and Signal Allocation

The signal assignment of cable by the PIO pattern is as shown below. Follow the following table to connect the external equipment (such as PLC).

				Parameter No.25 (F	PIO Pattern) Selection	
Pin No.	Wire Color	Category	PIO Function	0	1	
				Positioning mode	Pressing mode	
A1	Drain	Frame	e ground	ŀ	-G	
B1	BR	Control pov	ver unit +24V	(	CP	
A2	_		-		_	
B2	RD	Control po	ower unit 0V	CP	GND	
A3	RD 1	Brake	release	I	ЗК	
B3	OR	Motor pow	ver unit +24V	Γ	MP	
A4	OR 1	Emergeno	cy-stop input	E	MG	
B4	YW	Motor po	wer unit 0V	MP	_GND	
A5	_		-	_		
B5	GN		-	-		
A6	_		-	_		
B6	BR 1		_	-		
A7	BL		_	/PP		
B7	PL		-	PP		
A8	GY		-	/NP		
B8	WT		-	NP		
A9	BR 2		IN0	SON	SON	
B9	RD 2		IN1	TL	TL	
A10	OR 2	Input	IN2	HOME	HOME	
B10	YW 2	input	IN3	RES RES/DCLR		
A11	GN 2		IN4			
B11	BL 2		IN5	_	—	
A12	PL 2		OUT0	SV	SV	
B12	GY 2	Output	OUT1	INP	INP/TLR	
A13	WT 2	Output	OUT2	HEND	HEND	
B13	BK		OUT3	*ALM	*ALM	

Signal with "\*" expresses the signal of active low.

#### (Reference) Signal of Active Low

Signal with "\*" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.



# ERCJ

#### [3] List of PIO Signals

The table below lists the functions of PIO signals. Refer to the section shown in Relevant Sections for the details of the control of each signal.

Category	Signal Abbreviation	Signal Name	Function Description	Relevant Sections
	EMG	Emergency Stop Input	It shuts the motor power supply.	4.3 [3]
	BK	Brake Forcible Release	The brake will forcibly be released.	4.3 [4]
	PP	Differential Pulse Train		
	/PP	Input (+)	Input the pulse train from the best controller	4 2 [7]
	NP	Differential Pulse Train		4.3 [7]
	/NP	Input (-)		
	SON	Servo ON	Servo is ON while this signal is turned ON.	4.3 [6]
Input	TL	Torque Limit Select	Applies torque limit to the motor with the signal on and the value set to the parameter.	4.3 [7]
p.a.t	HOME	Home Return	The controller will perform home return operation when this signal is turned ON.	4.3 [6]
			When Parameter No. 25 = 0 (Positioning mode) An alarm will be reset when this signal is turned ON.	4.3 [6]
	RES	Reset	When Parameter No. 25 = 1 (Pressing mode) Alarm reset is conducted with this signal being ON when TL signal is not ON.	4.3 [6]
	DCLR	Deviation Counter Clear	Have the deviation counter reset with this signal being ON.	4.3 [7]
	SV	Servo ON Status	This signal will remain ON while the servo is ON.	4.3 [6]
	INP	Positioning Completion	It is turned ON when the remaining movement pulse amount in the deviation counter is in the positioning width range.	4.3 [6]
Output	TLR	Torque Under Control	Turns ON when torque reaches the limit while in torque restriction (TL signal is ON).	4.3 [7]
	HEND Home Return Completion		This signal will turn ON when home return has been completed. It will be kept ON unless the home position is lost.	4.3 [6]
	*ALM	Alarm	Turns ON when the controller is in normal condition, and turns OFF when an alarm is generated.	4.3 [6]

Signal with "\*" expresses the signal of active low. It is ON when the power is applied to the controller, and turns OFF when the signal is output.

Caution: Torque restriction by TL Signal is available even if Parameter No.25 = 0. Thus, it is possible to have a positioning move with the torque restricted in such cases as when pushing out a breakable work piece. However, when it comes to a situation that the actuator cannot move, it may create a big deviation (servo lag pulses) as it may occur for the pressing control. If TL Signal is turned off under this condition, the operation may be started with the maximum torque at the same time, and make a sudden move. If it is not to be used, set User Parameter No.61 Torque Restriction Command Input to invalid (= 1). If Parameter No.25 = 0, the deviation counter cannot be cleared since there is no DCLR Signal. Move to the opposite side or turn the servo OFF if a movement cannot

be made any more.



#### 3.2.3 Circuit Diagram

Sample circuit diagrams are shown below. [1] Power Line and Emergency Stop Circuit



- Note 1 The load current for the emergency stop signal EMG to turn ON/OFF at contact CR is 24V DC and 10mA.
- Note 2 This is a switch to compulsorily release the brake of the actuator equipped with a brake. It is convenient when in maintenance or adjustment work if it is installed. It is necessary to have at least 24V DC and 150mA for the switch contact capacity.
- Note 3 The controller automatically identifies that the teaching tool is connected and activates the emergency stop switch of the teaching pendant.

#### Caution:

- Do not attempt to shut the 0V circuit of MP\_GND and CP\_GND with the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- The emergency stop switch of the teaching pendant cannot be reflected to the emergency stop circuit of the whole system.
- In case the power source for each controller is different, join the 0V of each power supply together.



- [2] Command Pulse Train Circuit
  - (1) When Host Unit is Differential System



(2) When Host Unit is Open Collector System

AK-04 (please purchase separately) is required for pulse train input.



Caution: Use the same power source for the host open collector input and output, AK-04.



[3] PIO Circuit

#### (1) PIO Pattern 0 ····· Positioning mode



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

 For the connection of I/O, use the enclosed cable for those connections including the emergency stop and pulse train input circuit.
 Model : CB-ERC3P-PWBIO (IDED INDICATES THE CABLE LENGTH L. Example. 020 = 2m)

L BA

Pin No.	Wire Color	Signal Abbreviation	Width	Pin No.	Wire Color	Signal Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	-	—	-	B2	RD	CP_GND	(0.31111-)
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	I	_	-	B5	GN	_	
A6	I	_	-	B6	BR 1	_	
A7	BL	_		B7	PL	_	
A8	GY	-		B8	WT	-	AVA/C 29
A9	BR 2	SON1	AVA/C 29	B9	RD 2	TL	AWGZO
A10	OR 2	HOME	AVVGZO	B10	YW 2	RES	(0.0011111)
A11	GN 2	-	(0.0011111)	B11	BL 2	-	
A12	PL 2	SV		B12	GY 2	INP	
A13	WT 2	HEND		B13	BK	*ALM	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.



Pin No.	Wire Color	Signal Abbreviation	Width	Pin No.	Wire Color	Signal Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	-	-	_	B2	RD	CP_GND	(0.3mm-)
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	-	-	_	B5	GN	-	
A6	-	-	_	B6	BR 1	-	
A7	BL	-		B7	PL	-	
A8	GY	-		B8	WT	-	
A9	BR 2	SON1		B9	RD 2	TL	A1A/C 29
A10	OR 2	HOME	AWG28	B10	YW 2	RES/ DCLR	(0.08mm <sup>2</sup> )
A11	GN 2	-	(0.0011111)	B11	BL 2	-	
A12	PL 2	SV		B12	GY 2	INP/ TLR	
A13	WT 2	HEND		B13	BK	*ALM	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.



- 3.3 Positioner Mode 2 (Extension Type by PIO Converter)
- 3.3.1 Wiring Diagram (Connection of construction devices) The model code for I/O type of ERC3 is SE (SIO type).



**Teaching Pendant** 

Note 1  $\Box \Box \Box$  indicates the cable length. (Example) 030 = 3m



# 3.3.2 PIO Pattern Selection and PIO Signal

#### [1] PIO Pattern (Control Pattern) Selection

PIO Converter can extend the positioner function of ERC3, and enables to have 6 types of control methods. Set the suitable PIO pattern to Parameter No.25 "PIO Pattern Select". Check the 4.2.3 Operation in Positioner Mode 2 for the details of PIO Patterns.

Туре	Value set in parameter No.25	Mode	Overview
PIO Pattern 0	0 (at the delivery)	Positioning mode (Standard type)	<ul> <li>Number of positioning points : 64 points</li> <li>Position command : binary code</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>
PIO Pattern 1	1	Teaching mode (Teaching type)	<ul> <li>Number of positioning points : 64 points</li> <li>Position command : binary code</li> <li>Position zone signal output<sup>*2</sup> : 1 point (Note 1)</li> <li>Writing current position data to position table enabled by PIO signal</li> </ul>
PIO Pattern 2	2	256-point mode (Number of positioning points : 256-point type)	<ul> <li>Number of positioning points : 256 points</li> <li>Position command : binary code</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>
PIO Pattern 3	3	512-point mode (Number of positioning points : 512-point type)	<ul> <li>Number of positioning points : 512 points</li> <li>Position command : binary code</li> <li>Zone signal output : None</li> </ul>
PIO Pattern 4	4	Solenoid valve mode 1 (7-point type)	<ul> <li>Number of positioning points : 7 points</li> <li>Position command : Individual number signal ON</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point (Note 1)</li> </ul>
PIO Pattern 5	5	Solenoid valve mode 2 (3-point type)	<ul> <li>Number of positioning points : 3 points</li> <li>Position command : Individual number signal ON</li> <li>Completion signal : Signal equivalent to LS (limit switch) enabled</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point (Note 1)</li> </ul>

Note 1 The position zone signal output can be switched over to the zone signal output with the setting of Parameter No.149.

*1	Zone signal output	:	Zone range is to be set to either Parameter No.1, 2 and it is
			always available after the home-return operation is complete.
*2	Position zone signal output	2	This feature is associated with the specified position number.
			The zone range is set in the position table. The zone range is enabled only when the position is specified but disabled if another position is specified.



#### [2] PIO Patterns and Signal Assignment

The signal assignment of cable by the PIO pattern is as shown below. Follow the following table to connect the external equipment (such as PLC).

		Category		Parameter No.25 (PIO Pattern) Selection			
			PIO Functions	0	1	2	
		• •		Positioning mode	Teaching mode	256-point mode	
			Number of positioning points	64 points	64 points	256 points	
			Home return signal	0	0	0	
Pin No.	Color	Input	Jog signal	×	0	×	
	COO		Teaching signal (Current position writing)	×	0	×	
		Output	Brake release	0	×	0	
			Moving signal	0	0	×	
			Zone signal	0	X	×	
			Position zone signal	0	0	0	
1A	BR-1	_		_	•	•	
2A	RD-1	-		-			
3A	OR-1	_		-			
4A	YW-1	-		_			
5A	GN-1		IN0	PC1	PC1	PC1	
6A	BL-1		IN1	PC2	PC2	PC2	
7A	PL-1		IN2	PC4	PC4	PC4	
8A	GY-1		IN3	PC8	PC8	PC8	
9A	WT-1		IN4	PC16	PC16	PC16	
10A	BK-1		IN5	PC32	PC32	PC32	
11A	BR-2		IN6	-	MODE	PC64	
12A	RD-2	Input	IN7	-	JISL	PC128	
13A	OR-2		IN8	-	JOG+	-	
14A	YW-2	-	IN9	BKRL	JOG-	BKRL	
15A	GN-2		IN10	-	-	-	
16A	BL-2		IN11	HOME	HOME	HOME	
17A	PL-2	-	IN12	*SIP		^STP	
18A	GY-Z	<u> </u>					
19A		4	IN 14 IN 15	RES SON	RES SON	RES SON	
20A 1B	DR-2						
2B	PD-3	-	OUT1				
2D 3B	OR-3	4		$PM4(\Delta I M4)$	$PM4(\Delta I M4)$	$PM4(\Delta I M4)$	
4B	YW-3	-	0012		PM8(ALM8)		
5B	GN-3	4	OUT4	PM16	PM16	PM16	
6B	BI -3	-	OUT5	PM32	PM32	PM32	
7B	PL-3		OUT6	MOVE	MOVE	PM64	
8B	GY-3	1	OUT7	ZONE1	MODES	PM128	
9B	WT-3	Output	OUT8	PZONE/ZONE2	PZONE/ZONE1	PZONE/ZONE1	
10B	BK-3	1 .	OUT9	_	-	_	
11B	BR-4	1	OUT10	HEND	HEND	HEND	
12B	RD-4		OUT11	PEND	PEND/WEND	PEND	
13B	OR-4	1	OUT12	SV	SV	SV	
14B	YW-4		OUT13	*EMGS	*EMGS	*EMGS	
15B	GN-4		OUT14	*ALM	*ALM	*ALM	
16B	BL-4		OUT15	LOAD/TRQS, *ALML	*ALML	LOAD/TRQS, *ALML	
17B	PL-4	-	-				
18B	GY-4	-		-			
19B	WT-4	-		_			
20B	BK-4	-		_			

Signal with "\*" expresses the signal of active low.

PM1 to PM8 are the binary code output signals of an alarm while it is being generated. [Refer to 4.2.3 [5]] PZONE (position zone signal) can be switched over to ZONE (zone signal) with the setting of Parameter No.149.

#### (Reference) Signal of Active Low

Signal with "\*" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.

				Parameter No.25 (PIO Pattern) Selection				
		Catanan		3	4	5		
		Category	PIO Functions	= 10 1 1 1	Solenoid valve	Solenoid valve		
				512-point mode	mode 1	mode 2		
			Number of positioning	540 14		0.11		
			points	512 points	7 points	3 points		
	Wire		Home return signal	0	0	×		
Pin No.	Color	Input	Jog signal	×	×	×		
	-		Teaching signal					
			(Current position writing)	×	×	×		
			Brake release	0	0	0		
			Moving signal	×	×	×		
		Output	Zone signal	×	0	0		
		· ·	Position zone signal	Х	0	0		
1A	BR-1	_						
2A	RD-1	_		_				
3A	0R-1	_		_				
4A	YW-1	_		_				
5A	GN-1		INO	PC1	ST0	ST0		
64	BI -1		IN1	PC2	ST1	ST1(J0G+)		
74	PL-1		IN2	PC4	ST2	ST2 (Note 1)		
84	GY-1	_	IN3	PC8	ST3			
04	W/T_1	-	INIA	PC16	ST4			
104	BK_1	-	IN4 IN5	PC32	ST5			
11Δ	BR-2	-	ING	PC64	ST6			
124				D128	510	_		
12/		Input		PC256	_			
140				PC230				
14/	CN 2	-		DRILL	DIVINE	DRINL		
16A		1				-		
174	DL-Z			*STD	*STD	_		
104	FL-2	-		OSTR	SIF	-		
10A		_						
19A	PK 2	-	IN 14 IN 15	RES SON	RE3	RE3		
20A	DR-2					30N		
		-		PIVIT(ALIVIT)	PEU DE1			
20		-						
3D 4D		-	0012		FEZ			
4D		-	0013	PIVIO(ALIVIO)	PEJ DE4			
	GIN-3	-	0014	PIVI IO	PE4			
	DL-3	-	0013	PIVIJZ	FEU	-		
	PL-3	-	0016	P1VI04				
		Output		PIVI 120				
90	VV 1-3	Output		PIVIZOO	PZUNE/ZUNEZ	PZUNE/ZUNEZ		
10B	BK-3	_	0019					
118	BR-4	-		HEND	HEND	HEND		
12B	RD-4	_	00111	PEND	PEND	-		
13B	0R-4	_		SV	SV	SV		
14B	YVV-4	-	00113	^EMGS	^EMGS	^EMGS		
15B	GN-4	-	OUT14	*ALM	*ALM	*ALM		
16B	BL-4		OUT15	LOAD/TRQS,	LOAD/TRQS,	*ALML		
470			-	"ALML	"ALML	<u> </u>		
1/B	PL-4	-		-				
18B	GY-4	-		-				
19B	VV I-4	-	-					
20B	ВК-4	-						

Signal with "\*" expresses the signal of active low.

PM1 to PM8 are the binary code output signals of an alarm while it is being generated. [Refer to 4.2.3 [5]] PZONE (position zone signal) can be switched over to ZONE (zone signal) with the setting of Parameter No.149.

Note 1 It is invalid before home-return operation.

#### (Reference) Signal of Active Low

Signal with "\*" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.



[3] List of PIO Signals The table below lists the functions of PIO signals. The detail of each signal is provided in this chapter. Refer to the relevant sections shown in the list below.

Category	Signal Abbreviation	al Signal Name Function Description		Relevant Sections
	CSTR	PTP Strobe (Start signal)	The actuator will start to move to the position set by the command position number.	4.2.3 [6]
	PC1 to PC256	Command Position Number	Input (in binary) a number of the position that is desired to move.	4.2.3 [6]
	BKRL	Brake Forcible Release	The brake will forcibly be released.	4.2.3 [5]
	*STP	Pause	When this signal is turned OFF while in move, the actuator decelerates and then stops. The remaining movement is in a hold while the actuator is stopped and will resume when the signal turns back ON.	4.2.3 [6]
	RES	Reset	An alarm will be reset when this signal is turned ON. Also, when it is turned ON in the pause mode (*STP is turned OFF), the remaining movement amount can be cancelled.	4.2.3 [5]
	SON	Servo ON	The servo remains ON while this signal is ON, or OFF while this signal is OFF.	4.2.3 [5]
	HOME Home Return		The controller will perform home return operation when this signal is turned ON.	4.2.3 [5]
Input	MODE	Teaching Mode	The operating mode will change to the teaching mode when this signal is turned ON. It cannot be switched over unless all of CSTR, JOG+ and JOG- since the actuator is in a stop condition (excluding the pause condition).	4.2.3 [6]
	JISL	Jog/Inching Selector	Jog Operation can be performed with JOG+ and JOG- while this signal is OFF. Inching Operation is performed with JOG+ and JOG- when it is ON.	4.2.3 [6]
	JOG + JOG -	Jog	JOG operation is performed to the positive direction when JOG+ Signal is ON and to negative when JOG- Signal is ON while JISL Signal is turned OFF. Inching operation will be performed to the positive direction when JOG+ Signal is ON and to negative when JOG- Signal is ON while JISL Signal is turned ON.	4.2.3 [6]
	PWRT	Current Position Write	While in Teaching Mode, if the command position number (PC1 to PC32) is indicated and this signal is turned ON for 26ms or more, the current position is written to the indicated position number.	4.2.3 [6]
	ST0 to ST6	Start Signal	With the start signal of each position, while in Electromagnetic Valve Mode, the actuator moves to the position corresponding to the start signal if this signal is turned ON.	4.2.3 [7], [8]



Category	ory Signal Signal Name Function Description		Function Description	Relevant Sections
	PEND/INP	Position Complete	Turns ON in the positioning width range after actuator operation. The INP signal will turn OFF if the position deviation exceeds the in-position range. PEND and INP can be switched over by the parameter.	4.2.3 [6], [7]
	PM1 to PM256	Completion Position No.	The position No. reached after the positioning completion, is output (binary output).	4.2.3 [6]
	HEND	Home Return Completion	This signal will turn ON when home return has been completed. It will be kept ON unless the home position is lost.	4.2.3 [5]
	ZONE1 ZONE2	Zone	Turns ON if the current actuator position is within the range set to the parameter.	4.2.3 [5]
	PZONE	Position Zone	This signal will turn ON when the current actuator position enters the range specified the position data after position movement. Even though it can be used together with ZONE1, PZONE will become only available for operation by the set position number.	4.2.3 [5]
	*ALM Alarm Turns ON when the controller is in normal condition, an OFF when an alarm is generated.		Turns ON when the controller is in normal condition, and turns OFF when an alarm is generated.	4.2.3 [5]
	ALM1 to ALM8	Alarm Code	The detail of the alarm is output with binary code when an alarm more than the operation cancel level is issued.	4.2.3 [5]
Output	MOVE Moving		Turns ON during the actuator is moving (including home-return operation and pressing operation).	4.2.3 [6]
	SV	SV Servo ON This signal will remain ON while the servo is ON.		4.2.3 [5]
	*EMGS	Emergency Stop Output	This signal remains ON while the controller is under the emergency stop reset condition and turns OFF when the emergency stop condition is enabled. (Regardless of alarms.)	4.2.3 [5]
	MODES	Teaching Mode Output	This signal will turn ON while the teaching mode is enabled by the input of the MODE signal and will turn OFF when the mode changes to the normal mode.	4.2.3 [6]
	WEND	Writing Complete	This is a signal effective while in Teaching Mode, and is turned ON when the writing by PWRT signal is complete, and turned OFF at the same time as PWRT signal is turned OFF.	4.2.3 [6]
	PE0 to PE6	Current Position Number	In the solenoid valve mode, this signal will turn ON when the actuator completes moving to the target position.	4.2.3 [7]
	LS0 to LS2	Limit Switch Output	Turns ON when the current actuator position is within the range of positioning width $(\pm)$ of the target position. It is output even before the movement command and the servo is OFF if the home-return operation is completed.	4.2.3 [8]
	*ALML	Light Error Output	Outputs when a message level alarm is generated. (It is necessary to set parameter) It is ON in the normal condition, and turned OFF when an alarm is issued.	4.4

Signal with "\*" expresses the signal of active low. The controller executes the command when the input signal is OFF. The output should normally be ON in a condition that the power is supplied and OFF in the signal output.



3.3.3 Circuit Diagram

Sample circuit diagrams are shown below.

[1] Power Line and Emergency Stop Circuit (1) Built-in Drive Cutoff Relay Type Emergence



 Note 2 For CR1, select the one with coil current 0.1A or less.
 Note 3 This circuit is equivalent to Safety Category 1. The load current for the emergency stop signal EMG (-) to turn ON/OFF at contact CR1 is 24V DC and 20mA.

### Caution:

- Do not attempt to cut the 0V circuit of GND whit the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- In case the power source for each controller is different, join the 0V of each power supply together.



Load current	ERC3 high output setting valid: 3.5A (MAX. 4.2A)					
	ERC3 high output setting invalid: 2.0A					
During in-rush	8.3A					
Refer to 10.3 for the compliance with Safety Categories.]						

## Caution:

FRE

- Do not attempt to cut the 0V circuit of GND whit the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- In case the power source for each controller is different, join the 0V of each power supply together.



# Pin Assignment on Power Supply Connector

ERCJ



#### [2] PIO Converter to ERC3



Note 1  $\Box \Box \Box$  indicates the cable length. (Example) 030 = 3m

# ERCJ

## [3] PIO Circuit



1) PIO Pattern 0..... Positioning mode (Standard type)

"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.





#### 2) PIO Pattern 1 ······ Teaching mode (Teaching type)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.



#### 3) PIO Pattern 2 ...... 256-point mode (Number of positioning points : 256-point type)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.



ERCÃ

#### 4) PIO Pattern 3 ..... 512-point mode (Number of positioning points : 512-point type)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

Use the attached cable for the I/O connection.
 Model : CB-PAC-PIO (and (and indicates the cable length L. Example. 020 = 2m)



FRFé



# 5) PIO Pattern 4 ..... Solenoid Valve Mode 1 (7-point type)

ERCÃ

"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.





6) PIO Pattern 5..... Solenoid Valve Mode 2 (3-point type)

FRFé

"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

Use the attached cable for the I/O connection.
 Model : CB-PAC-PIO (and indicates the cable length L. Example. 020 = 2m)





# 3.4 MEC Mode 1 (Operation with PLC)

#### 3.4.1 Wiring Diagram (Connection of construction devices) I/O type of the model code is NP or PN. It is available to have a try run and teaching with Quick Teach.



a power supply unit (100V type / 200V type), remove the power supply unit. The emergency stop input terminal is treated with short-circuit by a jumper. Remove the jumper if necessary and connect devices such as an emergency stop switch (always closed and open in emergency stop).

Note 2  $\Box \Box \Box$  indicates the cable length. (Example) 030 = 3m



# 3.4.2 PIO Pattern Selection and PIO Signal

#### [1] Operation pattern

There are 2 types of operation patterns available. The selection of the operation patterns is to be set in the initial setting process using a teaching tool such as the PC software. See the instruction manual of each teaching tool for more details. This setting cannot be made for Quick Teach.

Explained below is the outline of the operational specifications for each pattern.

Operation pattern		Description	How to connect motorized Air cylinder circuit	
Stopping at 2 points (2-point positioning)	Movement by 1 input between 2 points [Single-solenoid mode]	You can move the actuator between 2 points using the same control you would normally use with an air cylinder. You can set the positions of the end point and start point. You can specify the moving speed and acceleration/deceleration. You can also specify push-motion Operation. The actuator moves to the end point when the ST0 turns ON, and returns to the start point when the signal turns OFF.	PLC Detection of start position Detection of end position LS1 Move signal 1 ST0 Power Supply	PLC PLC Detection of start position LS1 Move signal 1 ST0 P(Air)
Stopping at 3 points	Movement by 2 input between 2 points [Double-solenoid mode]	You can move the actuator between 2 points using the same control you would normally use with an air cylinder. You can set the positions of the end point and start point. You can set the position of an intermediate point and perform positioning to the intermediate point. You can specify the moving speed and acceleration/deceleration. You can also specify push-motion Operation. The actuator moves to the end point when the ST1 turns ON, and moves to the start point when the ST0 turns ON.	PLC Detection of start position LS0 Detection of end position LS1 Move signal 1 ST0 Move signal 2 ST1 Power Supply	Air cylinder PLC Detection of start position LS1 Move signal 1 Move signal 2 Stolencid A A B Solencid B Solencid A B Solencid B RR P (Air ylinder RR P (Air ylinder (Air ylin
(3-point positioning)	Movement by 2 input between 3 points [3-point positioning]	Intermediate movement mode, both ON] When both the ST0 and ST1 are turned ON, the actuator will position to and stop at an intermediate point. When both the ST0 and ST1 are turned OFF, the actuator will stop in the middle of movement. [Intermediate movement mode, both OFF] When both the ST0 and ST1 are turned OFF, the actuator will position to and stop at an intermediate point. When both the ST0 and ST1 are turned ON, the actuator will stop in the middle of movement.	PLC Detection of star position Detection of an position Detection of difference of the position LS2 Move signal 1 Move signal 2 ST1 Power Supply	PLC Air cylinder Detection of start position USU Detection of and position USU Move signal 1 ST1 Move signal 2 ST1 P(Air) P(Air) P(Air)



#### [2] Operation Patterns and Signal Assignments

The signal assignment of cable by the operation pattern is as shown below. Follow the table below to connect external equipment (such as a PLC).

	Wire Color			Operation pattern			
Dia			Stopping at 2 points Stopping at 3 points				
Pin		(	Category	(2-point positioning) (3-point positioning)			
INO.		Color	Movement by 1 input	Movement by 2 input	Movement by 2 input		
				between 2 points	between 2 points	between 3 points	
				[Single-solenoid mode]	[Double-solenoid mode]	[3-point positioning]	
A1	Drain	Fra	ame ground	FG			
B1	BR	Control	power unit +24V	СР			
A2	-		_		-		
B2	RD	Contro	l power unit 0V		CP_GND		
A3	RD 1	Brake	forcible release		BK		
B3	OR	Motor p	ower unit +24V		MP		
A4	OR 1	Emerg	ency-stop input	EMG			
B4	YW	Motor power unit 0V		MP_GND			
A5	-	_		_			
B5	GN	_		-			
A6	_	_			_		
B6	BR 1	_		_			
A7	BL		-				
B7	PL		-	_			
A8	GY		-		-		
B8	WT		-		-		
A9	BR 2		IN0	ST0	ST	ГО	
B9	RD 2		IN1	-	ST	Γ1	
A10	OR 2	Innut	IN2	RES	RE	ES	
B10	YW 2	input	IN3	-	-	-	
A11	GN 2		IN4	-	-	-	
B11	BL 2		IN5	-	-	-	
A12	PL 2	OUT0		LS0/PE0	LS0/	PE0	
B12	GY 2	Output	OUT1	LS1/PE1	LS1/	PE1	
A13	WT 2	Output	OUT2	HEND	LS2/	PE2	
B13	BK	OUT3		*ALM	*AI	_M	

Signal with "\*" expresses the signal of active low.

#### (Reference) Signal of Active Low

Signal with "\*" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.


ERCÕ

[3] List of PIO Signals The table below lists the functions of PIO signals. Refer to Section 4.4 [6] and [7] for the details of the control for each signal.

					Function			
o: 1					Stopping at 2 points	Stopping	at 3 points	
Signai	be Signal Name		Signals	(2-point positioning)	(3-point p Movement by 2 input	Ositioning)		
.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			elghale	between 2 points	between 2 points	between 3 points		
					[Single-solenoid mode]	[Double-solenoid mode]	[3-point positioning]	
					Positioning starts towards	Positioning starts towards	Positioning starts towards	
				Move Signal	level is detected	when the ON level is	when the ON level is	
		ST0		1	Positioning starts towards	detected.	detected.	
					the start point when the OFF level is detected	Moving to end point with ST0 = OFF and ST1 = ON	Moving to end point with ST0 = OFF and ST1 = ON	
					/	Moving to start point with	Moving to start point with	
						ST0 = ON and ST1 = OFF	ST0 = ON and ST1 = OFF	
						Caution	[Intermediate Point	
						Set to [Both ON for	Movement = Both ON]	
						intermediate movement	point with ST0 = ON and	
Input						settings. Have the	ST1 = ON	
		OT1		Move Signal		interlock activated so ST0	Stop during operation with	
		311		2		ON at the same time. A	ST1 = OFF	
						positioning at the		
						intermediate point is	[Intermediate Point Movement = Both OFF]	
						turned ON.	Moving to intermediate	
							point with ST0 = OFF and	
							Stop during operation with	
				/		ST0 = ON and ST1 = ON		
	RES		Reset	An alarm will be reset wher	n this signal is turned ON.			
		Not	LS0	Detection				
			1.01	End Point	The same operation as of t	he sensor of the air cylinder	r is performed.	
		used	LOI	Detection	It is turned ON when the cu	irrent position is within the p	positioning width for each	
			1.52	Point				
	n			Detection				
	ncti		550	Start Point				
	Fu		PE0	Complete				
Output	sing			End Point	It turns ON when the press	ing or the neetiening is con	anlata	
Output	res	Use	PE1	Positioning	It turns ON when the press (It also turns ON even with	a miss-operation.)	ipiete.	
	Ъ			Complete	It turns OFF with a moveme	ent signal to another point.		
			550	Point				
			PE2	Positioning				
				Complete	This signal is turned ON wh	on the home return energy	on is completed. This signal	
		HEND	)	Home Return	will not exist when 3-point s	stop (3-point positionina) is	selected as the operation	
				Completion	pattern.			
		*ALM		Alarm Output	This signal is turned ON wh	nen the controller is in the n	ormal condition and turned	
L	Signa				OFF when the controller is	in the alarm condition.		



#### 3.4.3 Circuit Diagram

Sample circuit diagrams are shown below. [1] Power Line and Emergency Stop Circuit



- Note 1 The load current for the emergency stop signal to turn ON/OFF at contact CR is 24V DC and 10mA.
- Note 2 This is a switch to compulsorily release the brake of the actuator equipped with a brake. It is convenient when in maintenance or adjustment work if it is installed. It is necessary to have at least 24V DC and 150mA for the switch contact capacity.

Note 3 The controller automatically identifies that the teaching tool is connected and activates the emergency stop switch of the teaching pendant.

- Note 4 Apply contact CR when having external cutoff of driving source.
  - The motor drive power line MP that turns ON/OFF at CR is as load current for the as shown below.

Load current	When ERC3 high output setting activated: 3.5A (4.2A max.)
Loau current	ERC high output setting invalid: 2.0A
During in-rush	8.3A

#### Caution:

- Do not attempt to shut the 0V circuit of MP\_GND and CP\_GND with the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- The emergency stop switch of the teaching pendant cannot be reflected to the emergency stop circuit of the whole system.
- In case the power source for each controller is different, join the 0V of each power supply together.

3.4 MEC Mode 1 (Operation with PLC)

# ERCJ

[2] PIO Circuit

1) Stopping at 2 points (2-point positioning)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

For the connection of I/O, use the enclosed cable for those connections including the power supply and emergency stop circuit.
 Model: CR ERC3P PW(PIORER (REF indicates the cable length I = Example, 020 - 2m)

Model : CB-ERC3P-PWBIO  $\square \square$  ( $\square \square$  indicates the cable length L. Example. 020 = 2m)

L B A Display of Mode Code

Pin No.	Wire Color	Signal Abbreviation	Width	Pin No.	Wire Color	Signal Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	-	-	_	B2	RD	CP_GND	(0.3mm-)
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	-	-	_	B5	GN	-	
A6	-	-	_	B6	BR 1	-	
A7	BL	-		B7	PL	-	
A8	GY	-		B8	WT	-	A)A/C 29
A9	BR 2	ST01	AVA/C 29	B9	RD 2	-	AVVGZO
A10	OR 2	RES	$(0.08 \text{mm}^2)$	B10	YW 2	-	(0.0011111)
A11	GN 2	_	(0.0011111)	B11	BL 2	_	
A12	PL 2	LS0/PE0		B12	GY 2	LS1/PE1	
A13	WT 2	HEND		B13	BK	*ALM	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.



# 2) Stopping at 3 points (3-point positioning)

Movement by 2 input between 2 points (Double-solenoid mode) Movement by 2 input between 3 points (3-point positioning)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

Use the attached cable for the I/O connection.
 Model : CB-ERC3P-PWBIO (IDED INDICATES THE CABLE LENGTH L. Example. 020 = 2m)



Pin No.	Wire Color	Signal Abbreviation	Width	Pin No.	Wire Color	Signal Abbreviation	Width
A1	Drain	FG	AWG22 (0.3mm <sup>2</sup> )	B1	BR	СР	AWG22
A2	1	-	-	B2	RD	CP_GND	(0.3mm <sup>-</sup> )
A3	RD 1	BK	AWG28	B3	OR	MP	AWG19
A4	OR 1	EMG	(0.08mm <sup>2</sup> )	B4	YW	MP_GND	(0.75mm <sup>2</sup> )
A5	-	-	-	B5	GN	-	
A6	-	-	-	B6	BR 1	-	
A7	BL	-		B7	PL	-	
A8	GY	_		B8	WT	-	AVA/C 28
A9	BR 2	ST0		B9	RD 2	ST1	AVVGZO
A10	OR 2	RES	AWG28	B10	YW 2	-	(0.0011111)
A11	GN 2	_	(0.001111)	B11	BL 2	_	
A12	PL 2	LS0/PE0		B12	GY 2	LS1/PE1	
A13	WT 2	LS2/PE2		B13	BK	*AI M	

(Note) Wire color No.1 is colored with short-dotted line and No.2 with long-dotted line. For the successive long-dotted line, at first four long dots are indicated and with some interval, again four long dots are indicated.



#### MEC Mode 2 (Operation Using PIO Converter) 3.5

3.5.1 Wiring Diagram (Connection of construction devices) The model code for I/O type of ERC3 is SIO type (model code: SE).



- If Quick Teach is equipped with a power supply unit (100V type / 200V type), remove the Note 1 power supply unit. The emergency stop input terminal is treated with short-circuit by a jumper. Remove the jumper if necessary and connect devices such as an emergency stop switch (always closed and open in emergency stop).
- $\square$  indicates the cable length. (Example) 030 = 3m Note 2



# 3.5.2 PIO Pattern Selection and PIO Signal

#### [1] Operation pattern

There are 2 types of operation patterns available. The selection of the operation patterns is to be set in the initial setting process using a teaching tool such as the PC software. See the instruction manual of each teaching tool for more details. This setting cannot be made for Quick Teach.

Explained below is the outline of the operational specifications for each pattern.

Operation p	attern	Description	How to connect motorized cylinder	Air cylinder circuit (Reference)
Stopping at 2 points (2-point positioning)	Movement by 1 input between 2 points [Sindle-solenoid mode]	You can move the actuator between 2 points using the same control you would normally use with an air cylinder. You can set the positions of the end point and start point. You can specify the moving speed and acceleration/deceleration. You can also specify push-motion Operation. The actuator moves to the end point when the ST0 turns ON, and returns to the start point when the signal turns OFF.	ERC3 PLC Dedicated Cable Dedicated Cable PIO Nove signal 1 Move signal 1 PIO Converter Power supply	PLC Detection of start position LST Move signal 1 STO R1 P(Air)
Stopping at 3 points	Movement by 2 input between 2 points [Double-solenoid mode]	You can move the actuator between 2 points using the same control you would normally use with an air cylinder. You can set the positions of the end point and start point. You can set the position of an intermediate point and perform positioning to the intermediate point. You can specify the moving speed and acceleration/deceleration. You can also specify push-motion Operation. The actuator moves to the end point when the ST1 turns ON, and moves to the start point when the ST0 turns ON.	PLC Dedicated LS0 Dedicated cable Dedicated cable PIO PIO PIO PIO PIO PIO PIO Pio Power supply	PLC Detection of start position LS1 Move signal 2 Solenoid A A Solenoid A A B Solenoid B Solenoid A A B Solenoid B ST Move signal 2 ST B Solenoid A B Solenoid B ST P (Atr) Solenoid B ST P (Atr) Solenoid A B Solenoid B ST P (Atr) Solenoid B St P (Atr) St P (Atr)
(3-point positioning)	Movement by 2 input between 3 points [3-point positioning]	[Intermediate movement mode, both ON] When both the ST0 and ST1 are turned ON, the actuator will position to and stop at an intermediate point. When both the ST0 and ST1 are turned OFF, the actuator will stop in the middle of movement. [Intermediate movement mode, both OFF] When both the ST0 and ST1 are turned OFF, the actuator will position to and stop at an intermediate point. When both the ST0 and ST1 are turned ON, the actuator will stop in the middle of movement.	ERC3 PLC Detection of and position LS Detection of intermediate point LS Move signal 1 ST0 Move signal 2 ST1 Plo Converter Move signal 2 ST1 Power supply	PLC Air cylinder Detection of start position Usi Detection of and position LS1 Move signal 1 Move signal 2 Move signal 2 P(Air) P(Air) P(Air)



#### [2] Operation Patterns and Signal Assignments

The signal assignment of cable by the operation pattern is as shown below. Follow the following table to connect the external equipment (such as PLC).

				Operation pattern			
				Stopping at 2 points	s Stopping at 3 points		
Pin	Wire	C	ategory	(2-point positioning)	(3-point positioning)		
No.	Color	Ũ	atogoly	Movement by 1 input	Movement by 2 input	Movement by 2 input	
				between 2 points	between 2 points	between 3 points	
				[Single-solenoid mode]	[Double-solenoid mode]	[3-point positioning]	
1A	BR-1		_		-		
2A	RD-1		-		-		
3A	OR-1		-		-		
4A	YW-1		-	070	-		
5A	GN-1		INO	ST0	S	ГО	
6A	BL-1		IN1	-	S	<u>[1</u>	
/A	PL-1		IN2	RES	RI	<u>-S</u>	
8A	GY-1		IN3	-		-	
9A	VV I-1		IN4	_	-	_	
10A	BK-1		IN5	-	-	-	
11A 10A	BR-2		ING	-	-	-	
12A	RD-2	Input		-	-	-	
13A	UR-2	-	INO				
14A	YVV-Z		IN9	-	-	-	
15A	GN-Z			-		-	
10A	DL-2			-		-	
17A				-		-	
10A	WT-2		IN 13 IN 14	_		-	
204	BK-2		IN14	_			
1B	BR-3		OUTO	LS0/PE0	1.50	ΈFΟ	
2B	RD-3		OUT1	LS1/PE1	LS1	PF1	
3B	OR-3		OUT2	HEND	1.52	/PF2	
4B	YW-3		OUT3	*AI M	*A	M	
5B	GN-3		OUT4		-	-	
6B	BL-3		OUT5		-	-	
7B	PL-3		OUT6		-	-	
8B	GY-3	0	OUT7		-	-	
9B	WT-3	Output	OUT8		-	-	
10B	BK-3		OUT9		-	_	
11B	BR-4		OUT10		-	-	
12B	RD-4		OUT11		-	-	
13B	OR-4		OUT12		-	-	
14B	YW-4		OUT13		-	-	
15B	GN-4		OUT14		-	-	
16B	BL-4		OUT15		-	-	
17B	PL-4			-			
18B	GY-4			-			
19B	WT-4		_				
20B	BK-4			-			

Signal with "\*" expresses the signal of active low.

(Reference) Signal of Active Low

Signal with <sup>"\*\*</sup>" expresses the signal of active low. A signal of active low is a signal that the input signal is processed when it is turned OFF, output signal is ordinary ON while the power is ON, and turns OFF when the signal is output.



[3] List of PIO Signals The table below lists the functions of PIO signals. Refer to Section 4.4 [6] and [7] for the details of the control for each signal.

					Function			
					Stopping at 2 points	Stopping	at 3 points	
Signal	Signal Signal Name		Contents of	(2-point positioning)	(3-point p	ositioning)		
Туре			9.10.100110		Movement by 1 input	Movement by 2 input	Movement by 2 input	
				Detween 2 points	Detween 2 points	between 3 points		
					[Single-solenoid mode]		[3-point positioning]	
					the end point when the ON	the corresponding point	the corresponding point	
				Move Signal	level is detected.	when the ON level is	when the ON level is	
		S10		1	Positioning starts towards	detected.	detected.	
					the start point when the	Moving to end point with	Moving to end point with	
					OFF level is detected.	ST0 = OFF and ST1 = ON	ST0 = OFF and ST1 = ON	
					/	Moving to start point with	Moving to start point with	
						510 - ON and 511 - OFF		
						∕ Caution	[Intermediate Point	
						Set to Both ON for	Movement = Both ON]	
						intermediate movement	Moving to intermediate	
Input						method] in the initial	point with ST0 = ON and	
						settings. Have the	Stop during operation with	
		ST1		Move Signal		and ST1 cannot be turned	ST0 = OFF and	
				2		ON at the same time. A	ST1 = OFF	
						positioning at the		
						intermediate point is	[Intermediate Point	
						performed if both are	Moving to intermediate	
						turrieu ON.	point with ST0 = OFF and	
							ST1 = OFF	
							Stop during operation with	
	-	RES		Reset	/ An alarm will be reset wher	this signal is turned ON		
		T.E.O		Start Point				
		Not used	LS0	Detection				
			1 91	End Point	The same operation as of t	he sensor of the air cylinder	r is performed.	
			LUI	Detection	It is turned ON when the current position is within the positioning w		positioning width for each	
				Intermediate	position detection output.			
	_		L92	Point				
	tior			Start Point				
	nnc		PE0	Positioning				
	Ē			Complete				
Output	sinç			End Point	It turns ON when the press	ing or the positioning is com	anlata	
Output	es	معلا	PE1	Positioning	It turns ON when the press	a miss-operation )	ipiele.	
	Ę,	030		Complete	It turns OFF with a movement	ent signal to another point.		
				Intermediate		p		
			PE2	Point				
				Complete				
					This signal is turned ON wh	en the home return operation	on is completed. This signal	
		HEND		Home Return	will not exist when 3-point s	stop (3-point positioning) is	selected as the operation	
				Completion	pattern.			
		*ALM		Alarm Output	This signal is turned ON wh	nen the controller is in the n	ormal condition and turned	
				Signal	UFF when the controller is	in the alarm condition.		

# ERCJ

#### 3.5.3 Circuit Diagram

Sample circuit diagrams are shown below.

- [1] Power Line and Emergency Stop Circuit
  - (1) Built-in Drive Cutoff Relay Type



DC and 20mA.

#### Caution:

- Do not attempt to cut the 0V circuit of GND whit the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- In case the power source for each controller is different, join the 0V of each power supply together.



Note 2 For CR1, select the one with coil current 0.1A or less. ct CR2 and the load

No	te 3 The mo	otor driving power line MPI that is to be turned O	N/OFF at contac
	current	of the emergency stop signal EMG(-) are follows	s;
	Load current	ERC3 high output setting valid: 3.5A (MAX. 4.2A)	
		ERC high output setting invalid: 2.0A	
	During in-rush	8.3A	

[Refer to 10.3 for the compliance with Safety Categories.]

#### Caution:

ERL

- · Do not attempt to cut the 0V circuit of GND whit the emergency stop. Doing so may burn the internal circuit. If an absolute shutoff of the power supply is required, conduct it on the primary side of DC power supply (alternating current side).
- In case the power source for each controller is different, join the 0V of each power supply together.



## Pin Assignment on Power Supply Connector

ERCŐ



[2] PIO Converter to ERC3



Note 1  $\square$  indicates the cable length. (Example) 030 = 3m

# ERC**3**

- [3] PIO Circuit
  - 1) Stopping at 2 points (2-point positioning) ...... Movement by 1 input between 2 points (Single-solenoid mode)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

Use the attached cable for the I/O connection.
 Model : CB-PAC-PIO (000) (000) indicates the cable length L. Example. 020 = 2m)





# 2) Stopping at 3 points (3-point positioning)

Movement by 2 input between 2 points (Double-solenoid mode) Movement by 2 input between 3 points (3-point positioning)



"\*" in codes above shows the signal of the active low. Processing occurs when an input signal of the type is turned OFF. An output signal of the type is normally ON in the power-on status and turned OFF at signal output.

• Use the attached cable for the I/O connection. Model : CB-PAC-PIO





- 3.6 MEC Mode 3 (Solo Operation with Quick Teach)
- 3.6.1 Wiring Diagram (Connection of construction devices)
  - I/O type of the model code is SE.
- [1] RCM-PST-0 (24V DC power supply type)



Note 1  $\square$  indicates the cable length. (Example) 030 = 3m



[2] RCM-PST-1



#### Caution:

In case it is necessary to use a terminal block in an electromagnetic control box, cut off the 3P plug to connect the line.

In that case, do not attempt to share the ground line with other devices or join with others. For the wiring, follow the cable colors described below.

Electric w color	ire	Signal Name	Description
BR		L	Doworoupply
BL		Ν	Power supply
YW & G	N	PE	Ground wire





[3] RCM-PST-2



Note 1  $\Box \Box \Box$  indicates the cable length. (Example) 030 = 3m

### Caution:

In case it is necessary to use a terminal block in an electromagnetic control box, do not attempt to share the ground line with other devices or join with others.

Electric wire color	Signal Name	Description
BR	L	Bower oupply
BL	N	Power supply
YW & GN	PE	Ground wire





# 3.7 Wiring Method

#### 3.7.1 Wiring of Actuator

Use a dedicated connection cable of IAI for connection.

[1] PIO type power and I/O cable (Model : CB-ERC3P-PWBIO□□□) □□□ indicates the cable length L. (Example 030 = 3m), MAX. 10m



Chapter 3 Wiring

ME0297-14E

r = 45mm or more

PLC (Host System)



[2] SIO type power and I/O cable (Model : CB-ERC3S-PWBIO□□□) □□□ indicates the cable length L. (Example 030 = 3m), MAX. 10m





• Cable bending radius

It is a robot cable, which can be used for moving parts.



B12

A13

B13

N.C

N.C

N.C



# 3.7.2 Wiring between PIO Converter and Quick Teach

SIO communication cable (Model: CB-PST-SIO050) Cable length = 5m





## 3.7.3 Wiring between PIO Converter and Host Controller (e.g. PLC)

The connection of I/O for PIO Converter is to be conducted with the dedicated I/O cable. The cable length is shown in the model code of PIO Converter. Check the model code of PIO Converter. Selection can be made from 3m or 5m as well as standard 2m. 10m is also applicable at maximum if purchased separately. [Refer to 1.1.5 How to read the model] Also, the end of the cable harness to be connected to the host controller (PLC, etc.) is just cut and no treatment is conducted so the wiring layout can be performed freely.



For the signal assignment of each wire, refer to the following considering the operation mode.

1) Positioner Mode 2 ······· 3.3.3 [3] PIO Circuit

2) MEC Mode 2..... 3.5.3 [3] PIO Circuit





- Use dedicated cables of IAI indicated in this instruction manual. Contact us if you wish to have a change to the specifications of the dedicated cables.
- Make sure to turn the power off in the process of power line or cable connection or disconnection.
- Do not attempt to cut a dedicated cable with connectors on both ends to extend, shorten or re-joint it.
- Hold the dedicated cable to avoid mechanical force being applied to the terminals and connectors.
- Use a cable pipe or duct to have an appropriate protection when there is a possibility of mechanical damage on a dedicated cable.
- In case a dedicated cable is to be used at a moving part, make sure to lay out the cable without applying any force to pull the connector or extreme bend on the cable. Do not attempt to use the cable with a bending radius below the allowable value.
- Make certain that the connectors are plugged properly. Insufficient connection may cause an operation error, thus it is extremely risky.
- Do not lay out the cables to where the machine runs over them.
- Pay attention to the cable layout so it would not hit peripherals during an operation. In case it does, have an appropriate protection such as a cable track.
- When a cable is used hanging on the ceiling, prevent an environment that the cable swings with acceleration or wind velocity.
- Make sure there is not too much friction inside the cable storage equipment.
- Do not apply radiated heat to power line or cables.
- Have a sufficient radius for bending, and avoid a bend concentrating on one point.







Follow the instructions below when using a cable track.

- If there is an indication to the cable for the space factor in a cable track, refer to the wiring instruction given by the supplier when storing the cable in the cable track.
- Avoid the cables to get twined or twisted in the cable track, and also to have the cables move freely and do not tie them up. (Avoid tension being applied when the cables are bent.)

Do not pile up cables. It may cause faster abrasion of the sheaths or cable breakage.





## 3.7.4 Wiring of PIO Converter Power Line Connector

The wires of the power supply and the emergency stop circuit are to be connected to the enclosed connector (plug). Strip the sheath of the applicable wires for 10mm and insert them to the connector. Push a protrusion beside the cable inlet with a small slotted screwdriver to open the inlet. After inserting a cable, remove the screwdriver from the protrusion to fix the cable.



#### Power Supply Connector

- I onel eapply connector							
Connector Name	Power Supply Connector						
Cable Side	FMC1.5/7-ST-3.5	Enclosed in standard package					
Controller Side	MC1.5/7-G-3.5						

Pin No.	Signal Name	Contents of Signals	Applicable cable diameter
1	EMG(-)	Emergency-stop input	KIV AWG20 (0.5mm <sup>2</sup> )
2	GND	$Power Input(24) (PC \pm 10\%)$	$K_{\rm N}$ (1.2 mm <sup>2</sup> )
3	CP24V	Power Input (24V DC ±10%)	KIV AVVG10 (1.2511111-)
4	MPO	Motor drive newer supply line	$K_{\rm N}$ (1.25mm <sup>2</sup> )
5	MPI	Notor drive power supply line	KIV AVVG10 (1.2511111-)
6	S2	Teaching pendant	$K_{\rm N}$ (0.5 mm <sup>2</sup> )
7	S1	Signal of emergency stop push button	KIV AVVG20 (0.5mm²)



### 3.7.5 Pulse Converter: AK-04 (Optional accessory)

This pulse converter is necessary when pulse train control is required and the output pulse of the host controller is the open collector type. It converts the command pulse of the open collector type to the differential type.

Use the enclosed e-CON connector for wiring.

The available cable wire size is AWG22 to 26 (less than 0.2 to 0.3mm<sup>2</sup>) equivalent to KIV, finished out diameter  $\phi 1.0$  to 1.2mm.

[Refer to 10.2.4 Handling of e-CON connector]



### Caution

- 1) Pay attention not to insert wrongly because it is the same e-CON connector as input and output. Putting the power on with the insertion being wrong will burn AK-04.
- 2) Use the pulse converter in the surrounding temperature range between 0°C and 40°C.
- 3) The temperature increase of about 30°C occurs during operation. Accordingly, neither install several pulse converters in close contact nor install them within a duct. Do not install the pulse converter near other heating devices.
- 4) If more than one pulse converters are installed, set a pulse converter apart from another by 10mm or more.
- 5) Make the wiring between the host controller (PLC, etc.) and AK-04 as short as possible. Long one is easy to pick the noise. Also make the wiring between AK-04 to ERC3 as short as possible.

Place AK-04 close to the host controller.

A recommended installation sample is shown in the figure below.

• Make the cable length between the host controller and pulse converter as short as possible.



• Keep pulse converters separated for 10mm or more from each other.





3.7.6 Teaching Port Connector Connection of ERC3 Main Unit

Teaching Port is for the connection of teaching tools (except for Quick Teach) only. Connect the connector of a teaching tool in the way the insertion mark comes to the bottom side.

It is able to put in/take OFF the connector while ERC3 power is ON.



Caution: Removing the teaching pendant while the power is ON causes a transient emergency stop. Thus, the actuator in operation will be stopped. Do not disconnect the teaching pendant during the operation.



### 3.7.7 Connection of SIO Connector of PIO Converter

SIO Connector of PIO Converter can be used not only for the connection of teaching tools including Quick Teach, but also for serial communication with a host controller (PLC, touch panel or PC). For the operation of those devices, refer to the instruction manual for each device.

[Refer to Instruction manuals related to this product]

Connect the connector of a teaching tool in the way the insertion mark comes to the left side. It is able to put in/take OFF the connector while ERC3 power of PIO Converter is ON.



3.7 Wiring Method

Caution: Removing the teaching pendant while the power is ON causes a transient emergency stop. Thus, the actuator in operation will be stopped. Do not disconnect the teaching pendant during the operation.

# Chapter 4 Operation

## 4.1 Basic Operation

ERC3 has 6 types of operation method when combined with peripheral devices. In addition, each operation method has several operation patterns to meet various ways of use. Please note, though, that these patterns are to be determined by selecting the model code when in order, thus have an operation with a control logic that corresponds to the model code. [Refer to Guideline for Control Method]

## 4.1.1 Basic Operation Methods

#### [1] Positioner Mode 1 (PIO Operation of ERC3) Three types of operation patterns and 16 points of positioning at the maximum are available.



- 1) Set target positions (coordinate values), velocities, accelerations, and decelerations by the required number of positioning points in the position table by using a teaching tool such as PC software.
- 2) Enter the binary data of position numbers subject to positioning on the PLC and turn ON the start signal.
- 3) The actuator is placed at the proper coordinate value according to the positioning information in the specified position number.
- 4) After the positioning is completed, the completion signal is output.

The above procedure describes the basic operation method in the positioner mode 1.



[2] Pulse Train Control Mode (Pulse Train Operation of ERC3) An operation by pulse train input is available. There are 2 patterns of operation modes, positioning and pressing.



- 1) Set the pulse train format and the electric gear ratio (the distance of actuator movement in mm against 1 pulse) to the parameters in the ERC3 with using a teaching tool such as PC software.
- 2) Send pulses based on the moving distance of the actuator to the ERC3 from the PLC (positioning unit).
- 3) The ERC3 multiplies the entered number of pulses by the electrical gar ratio to get the moving distance. The actuator is moved by the moving distance from the current position. The velocity varies depending on the entered pulse rate (frequency).
- 4) After the positioning is completed, the completion signal is output.

The above procedure describes the basic operation method in the pulse train control mode.

4.1 Basic Operation



[3] Positioner Mode 2 (Extended Operation of ERC3)

By using the optional PIO Converter, a selection from six types of operation patterns and 512 points at the maximum of positioning are available. Also, the unit can be applicable for Single Absolute Type.



- 1) Set target positions (coordinate values), velocities, accelerations, and decelerations by the required number of positioning points in the position table by using a teaching tool such as PC software.
- 2) Enter the binary data of position numbers subject to positioning on the PLC and turn ON the start signal.
- 3) The actuator is placed at the proper coordinate value according to the positioning information in the specified position number.
- 4) If the positioning is completed, the binary data of the position number is output. The completion signal is also output.

The above procedure describes the basic operation method in the positioner mode 2.



#### [4] MEC Mode 1

A simple operation with Quick Teach is available and a control same as for the air cylinder is available.

There are two operation patterns, 2-point positioning and 3-point positioning.



- 1) Using a teaching tool such as the MEC PC software, select an operation pattern, and set the target position (coordinate values), speed and acceleration/deceleration data that suits to the selected pattern.
- 2) Turn the start signal ON for the one desired to have a positioning from the host such as PLC.
- 3) The actuator is placed at the proper coordinate value according to the positioning information in the specified operation condition table.
- 4) If the positioning is completed, the completion signal is also output.

The above procedure describes the basic operation method in the MEC mode 1.

4.1 Basic Operation

# ERC**3**

# [5] MEC Mode 2

The operation method is the same as for MEC Mode 1. It becomes applicable for Simple Absolute Type by using PIO Converter.



# [6] MEC Mode 3

Independent operation is available with Quick Teach, and enables to have such operations as a test run of actuators.



- 1) By selecting the number of stop positions, teaching can be conducted with JOG operation.
- Acceleration/deceleration and speed settings can be performed with an easy operation.
- 3) An operation can be made with using the operation functions (forward/backward/continuous operations) of Quick Teach.



### 4.1.2 Parameter Settings

Parameter data should be set to be suit to the system or application. Parameters are variables to be set to meet the use of the controller in the similar way as settings of the ringtone and silent mode of a cell phone and settings of clocks and calendars.

(	Exam	ple)
١.	LAUIT	pic,

anipie)	
Soft Stroke Limit	: Set a proper operation range for definition of the stroke end,
	prevention of interferences with peripherals and safety.
Zone Output	: Set to require signal outputs in an arbitrary position zone within the
	operation zone.

Parameters should be set to meet the use of the controller prior to operation. Once set, they may not set every operation.

Refer to Chapter 6, 6.3 for the parameter types and the details.

4.2 Operation in Positioner Mode 4.2.1 Set of Position Table

FRE

# 4.2 Operation in Positioner Mode

#### 4.2.1 Set of Position Table

[It is not necessary to set up for Pulse Train Control Mode. Refer to Section 4.4 [2] for MEC Mode.]

The values in the position table can be set as shown below. The number of position will be displayed according the selected pattern. If specifying the speed, acceleration, and deceleration is not required, only the position data needs to be written. The speed, acceleration, and deceleration are automatically set to the data defined by the relevant parameters. Therefore, setting the speed, acceleration, and deceleration data often used to the relevant parameters makes input easy.

1)	2)	3)	4)	5)	6)	7)	8)	9)	10)	11)	12)	13)	14)	15)	
No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode	Vibration suppress No.	Comment
0	0.00	100.00	0.30	0.30	0.00	0.00	0.10	0.00	0.00	0	0	0	0	0	
1	100.00	100.00	0.30	0.30	0.00	0.00	0.10	0.00	0.00	0	0	0	0	0	
2	150.00	200.00	0.30	0.30	50.00	0.00	30.00	0.00	0.00	0	0	0	0	0	
3	200.00	400.00	1.00	1.00	0.00	0.00	0.10	0.00	0.00	0	0	0	0	1	
4	200.00	200.00	0.30	0.30	0.00	0.00	0.10	250.00	230.00	0	0	0	0	2	
5	500.00	50.00	0.10	0.10	0.00	0.00	0.10	0.00	0.00	0	0	0	0	0	
6															
7															

1) Position No. .... The number is specified by PLC at start.

Caution: In an operation mode that indicates the position number in a binary number, do not use Position No.0 if there is a margin in the positions. At the first servo ON after power ON, the completed position No. output is 0 even if the actuator is not located at position No.0. The actuator enters into the same state as that at positioning to position No.0. The completed position No. output is 0 during movement of the actuator. To use position No.0, get the command history by using the sequence program to check completed position No.0 based on the history.

Position [mm] ……… Positioning coordinate value. Enter it as the distance from the home position.
 For pitch feed (relative movement = incremental feed), enter the pitch width.

A value with – indicates that the actuator moves toward the home position. A value without – indicates that the actuator moves to be away from the home position.

 3) Velocity [mm/s] …… Set the velocity in the operation. Do not attempt to input a value more than the maximum velocity or minimum velocity <sup>(Note 1)</sup>. (Note 1) For the minimum speed, you can either check in "1.2.1 Actuator" or figure out from the formula below. Min. Speed [mm/s] = Lead Length [mm] / No. of Encoder Pluses / 0.001 [s]



- 4) Acceleration [G] ······ Set the acceleration at start.
- 5) Deceleration [G] ..... Set the deceleration at stop.



<ul> <li>Caution: (1) Set the velocity, acceleration and deceleration so that they do not exceed the rating values described in the brochure or the instruction manual of the actuator. Failure to follow this may cause the life of the actuator to be shortened extremely.</li> <li>(2) If shocks and/or vibrations appear on the actuator and/or the work, lower the acceleration and/or the deceleration. In such cases, do not continue the use of the actuator, otherwise the product life may be shortened extremely fast.</li> <li>(3) If the carriage weight is extremely lighter than the rating carriage weight, acceleration/deceleration larger than their rating values to shorten the cycle time. Please contact IAI for the settings in such situation. Inform us of the weight, shape and mounting method of the work and the installation conditions of the actuator.</li> </ul>
) Pressing [%] Setting proper data here allows pressing to be done. Set a pressing torque (limit current value) in %. If the value is set to 0, the normal positioning operation is performed. The speed for the pressing operation is set in Parameter No.34. If the setting of 3) is lower than the pressing velocity, the pressing process will be conducted with the velocity of 3).
Caution: If the pressing velocity is changed, the pressing force may differ from that specified in "1.2.1 Actuator". When the pressing velocity is changed, make sure to measure the actual pressing force before start using.

7) Threshold [%] ······· Unavailable. Do not set up.
4.2 Operation in Positioner Mode 4.2.1 Set of Position Table



8) Positioning width [mm] ····· In PIO Patterns 0 to 4 in Positioner Mode 1 (for ERC3 unit) and Positioner Mode 2 (when PIO Converter is used), the positioning complete signal is output when the remaining movement amount gets into the area that is set in them when positioning is conducted.

For pressing, actuator will first move to the position of the coordinate set in 2) at the set velocity, acceleration, and deceleration. It will then, performs pressing movement by the data set here.

For the positioning width, make its width at least 4 times larger than the minimum unit of the movement (movement amount of 1 pulse of the encoder) of the used actuator.

It is not the output range of the complete signal for the positioning command if PIO pattern 5 of PIO converter. Despite the specified position number, the relevant output signal LS\* is turned ON when the actuator reaches the setting range. The operation is accomplished as if a sensor were installed to detect the actuator. PIO pattern 5 does not correspond to the pressing operation.

[Example for Positioner Mode 2, PIO Pattern 5 of PIO Converter] The figure below shows the position table and the position at which each of the LS signals is turned ON. If the actuator passes any of the positioning width in the operation by another position number or manual operation in the servo-off state, the relevant LS signal is always turned ON.



- 9) Zone + [mm] ········ Set the coordinate value on the positive side at which position zone output signal PZONE is turned ON. PZONE is set to ON in the zone between this value and the coordinate value on the negative side set in 10). The feature follows the specified position number. It is valid only when the position is specified but invalid in another position operation.
- 10) Zone [mm]...... Set the coordinate value on the negative side at which position zone output signal PZONE is turned ON.



## 11) Acceleration/deceleration mode ......Select a proper acceleration/deceleration pattern depending on the load.

Set Value	Acceleration/ Deceleration Pattern	Operation			
0	Trapezoid	Velocity			
1	S-motion (Refer to Caution at S-shaped Motion)	Velocity Time Set the S-motion rate with parameter No.56.			
2	First-Order Lag Filter	Velocity Time Set the delay time constant with parameter No.55.			

Caution at S-shaped Motion:

- Since it requires a speed change during the operation, even if having the position command that S-shaped motion is set while the actuator is moving, S-shaped motion control cannot be performed and will be the trapezoid control. Make sure to make a command while the actuator.
- 2) Do not use S-shaped acceleration/deceleration control if the setting of the acceleration time or the deceleration time exceeds 2 seconds. It will not provide the right operation.
- 3) Do not pause on the move during acceleration or deceleration. It will change the speed (acceleration) and may cause a danger.
- 12) Incremental ········ Set to 1 for pitch feed (relative movement = incremental feed). The value set for the position in 1) indicates the pitch feed distance. With the value set to 0, positioning is defined to the position in 1) based on the absolute coordinate system.

Caution:	In the pitch feed, do not perform a command with a pitch smaller than the minimum encoder resolution (lead/encoder pulse number) or that less than positioning accuracy repeatability.
	There would be no deviation to occur even with the command because it is an operation command to the same position as the positioning complete condition, but the positioning control cannot be performed properly. Pitch feed cannot be conducted with PIO Pattern 5 (Solenoid Valve Mode 2) of PIO Converter. Set it to "0". Setting this to 1 causes the position data error to occur.



13) Transported load … Register 4 types of load weights with using the teaching tool, and choose the number from the registered numbers (0 to 3) that is to be used.

From the numbers (load weights) registered in this section, the smart tuning calculates the optimum speed and acceleration/deceleration.

[Refer to the instruction manual of each teaching tool for how to register the load weights and smart tuning.]

Setting	Name
0	Transported Load No.0
1	Transported Load No.1
2	Transported Load No.2
3	Transported Load No.3

14) Stop mode ………… Automatic servo OFF is enabled after a certain period from the completion of positioning for power saving.

A proper period can be selected from three parameters.

Setting	Operation after completion of operation	parameter No.
0	Servo ON not changed	-
1	Automatic servo OFF after certain period	36
2	Automatic servo OFF after certain period	37
3	Automatic servo OFF after certain period	38
4	Full servo control	_
5	Full-servo control for a certain time and then automatically turning servo OFF	36
6	Full-servo control for a certain time and then automatically turning servo OFF	37
7	Full-servo control for a certain time and then automatically turning servo OFF	38

Caution: •	No retaining torque is provided in automatic servo OFF. Pay sufficient attention to the setting because the actuator may be moved by external force applied to it. Do not use the automatic servo OFF if the next moving command is relative distance specification (pitch feed). Failure to follow it may cause position shift to occur. Do not use the automatic servo OFF in pressing. If used, the pressing force is lost. Automatic Servo OFF would not function in the operation with teaching mode of PC software.
------------	--

15) Vibration suppress No.....Unavailable. Do not set up.



#### 4.2.2 Operation in Positioner Mode 1

In Positioner Mode 1, it is available to select 3 types of PIO patterns with the parameters. This PIO Pattern cannot be switched over after the system is finished to be established or during the actuator operation. Choose the optimum pattern beforehand considering the system operation specifications and prepare the cables and sequence design.

#### [1] PIO Pattern Selection and Main Functions

	O : Valid function						
	PIO Pattern (Parameter No.25)	0 1		2			
	Mode	8-point type	Solenoid valve type	16-point type			
	Number of positioning points	8	3	16			
	Operation with the Position No. Input	0	×	0			
	Position No. direct command operation	×	0	×			
suc	Positioning	0	0	0			
unctic	Velocity change during the movement	0	×	0			
orf	Pressing (tension)	0	0	0			
Maj	Pitch Feeding (relative moving feed)	0	0	0			
	Home return signal input	0	×	×			
	Pause	0	0	0			
	Brake release signal input	0	0	0			
	Zone signal output	0	×	O <sup>Note 1</sup>			
	Position zone signal output	×	×	O <sup>Note 1</sup>			

Note 1 The position zone signal output (set in delivery) can be switched to the zone signal with Parameter No.149. This cannot be used together with the zone signal.



#### [2] Overview of major Functions

Major functions	Description
Number of positioning points	Number of positioning points which can be set in the position table.
Operation with the Position No. Input	Normal operation started by turning the start signal ON after position No. is entered with binary data.
Position No. direct command operation	Operation enabled by turning the signal directly corresponding to a position No. ON
Positioning	Positioning enabled at an arbitrary position by the data set in the position table
Velocity change during the movement	Velocity change enabled by activating another position No. during movement
Pressing (tension)	Operation by an arbitrary pressing (tensile) force set in the position table enabled
Pitch Feeding (relative moving feed)	Pitch feed by an arbitrary moving distance set in the position table enabled
Home return signal input	Input signal exclusively used for home return. Set to ON to start home return
Pause	The operation can be interrupted or continued by setting this signal to ON or OFF, respectively.
Brake release signal input	The brake (option) can only be released while the input is set to ON.
Zone signal output	The output signal is set to ON while the actuator is entered within the zone defined by the coordinate values set as parameters.
Position zone signal output	This is a function that is included to the indicated position number, and its zone range is to be set in the position table, and is valid when that position is indicated and is invalid when in other position command. The output signal is set to ON while the actuator is entered within the zone defined by the coordinate values set in the position table.



- [3] Power Supply and Emergency Stop Release (CP, MP, EMG, PEND)
  - [Refer to 3.1.3 Circuit Diagram]
  - 1) Supply the control power (CP, CP\_GND), first.
  - Secondly, turn ON the motor power source (MP, MP\_GND) and the emergency stop signal EMG at the same time. Do not attempt to turn ON the emergency stop signal EMG prior to the motor power source. The controllers get into the servo-on status by the emergency stop signal EMG being ON.

For Pattern 0 and 2, the positioning complete signal PEND turns ON at the same time. Also for an actuator equipped with a brake, the brake is released by the servo being turned ON.

3) If the emergency stop signal EMG turns OFF, the servo also turns OFF. Have the motor power (MP, MP\_GND) cut off at the same time. Do not attempt to cut off the motor power (MP, MP\_GND) prior to the emergency stop signal EMG being turned OFF. By turning the servo OFF, the positioning complete signal PEND also turns OFF. For an actuator equipped with a brake, the brake gets to the operating condition.



- T (before detecting excitation) = SON signal identification (6ms) + Excitation detection time (T1 + T2) × Number of retry (10 times Max.) + Servo ON delay time (T3)
- T (after detecting excitation) = SON signal identification (6ms) + Servo ON delay time (T3)
- T1 : Parameter No.30 It differs depending on the setting of excitation detection type. Set Value =  $0 \rightarrow 160ms$ Set Value = 1,  $2 \rightarrow 220ms$
- T2 : Parameter No.29 Setting of excitation phase signal detection time It is set to 10ms in the initial setting.
- T3 : Fixed to 20ms
- (Note) Excitation detection operation of the motor is conducted at the first servo-on after the power is turned ON.
  - PEND would not turn ON if the pause signal \*STP is OFF.



- [4] Brake release BK······ [Refer to 3.1.3 Circuit Diagram]
  - This is a signal to compulsorily release the brake of the actuator equipped with a brake. The brake in the actuator is a non-excitation operation type electromagnetic brake. In a normal operation, it automatically releases the brake with the servo ON and gets to the brake operating status with the servo OFF.

Releasing the brake may be required to move the slider and/or the rod by hand in case of installation of the actuator in the machine or direct teach<sup>\*1</sup>. In such cases, turn this signal ON. The brake can be released while signal is turned ON.

\*1 Direct teaching : This operation is intended to get coordinate values to the position by moving the slider and/or the rod by hand.

- Warning: (1) Take sufficient care to release the brake. Inappropriate brake release may cause people to be injured and/or the actuator, the work and/or the machine to be damaged.
  - (2) After the brake is released, always make the brake applied again. Any operation with the brake remaining released is extremely dangerous. The slider or rod may drop to cause people to be injured and/or the actuator, the work and/or the machine to be damaged.
  - (3) Make certain that this signal is turned OFF (brake is activated) when the power is supplied to the controller. Leaving the power ON may cause a drop of the slider or rod, results in an injury or damage of the actuator unit, work piece or devices.
- [5] Time Constant for Control Signal Input

For the input signal for control of this controller, it is set to 6ms of input time constant to prevent an error operation due to chattering or noise from the next page and later. Therefore, input each input signal for 6ms or more <sup>(Note)</sup> continuously. The signal cannot be identified if it is less than 6ms.





#### [6] Operation Ready and Auxiliary Signals

(1) Home Return (HOME, HEND, PEND)

	Input	Output		
FIO Signal	HOME	HEND	PEND	
Pattern 0	0	0	0	
Pattern 1	× (Note1)	×	×	
Pattern 2	× (Note1)	0	0	

O : Available, ×: Unavailable

(Note 1) For Patterns 1 and 2, a home-return operation with HOME Signal cannot be performed.

- Refer to 4.2.2 [8] Direct Position Specification (3-point <Solenoid valve> type) = PIO Pattern 1 for how to home return for Pattern 1
- Refer to 4.2.2 [7] Operation with the Position No. Input = Operations of PIO Patterns 0 and 2 for how to home return for Pattern 2

The HOME signal is intended for automatic home return. The HOME signal is caught at the rising edge (ON edge) to start the home return. At completion of the home return, home return completion signal HEND is turned ON. The home-return complete signal HEND is kept ON unless the memory of origin point is lost for a reason such as alarm. During the home-return operation, the positioning complete signal PEND is OFF.



<sup>[</sup>Operation of Actuator]



- 1) With the HOME signal being ON, the actuator moves toward the mechanical end at the home return speed. The movement speed is 20mm/s.
- 2) The actuator is turned at the mechanical end and stopped at the home position. The moving distance is the value set by Parameter No.22 "Home return offset level".

Caution: In the home reverse specification, the actuator moves in the reverse direction. Make sure to refer to Chapter 6, 6.3.1 [2] (15) when a change to Parameter No.22 "Home return offset level" is required.



#### (2) Zone Signal and Position Zone Signal (ZONE1, PZONE)

	Output		
PIO signal	ZONE1	PZONE	
Pattern 0	0	×	
Pattern 1	×	×	
Pattern 2	O (Note 1)	O (Note 1)	
	PIO signal Pattern 0 Pattern 1 Pattern 2	PIO signal Out   Pattern 0 O   Pattern 1 ×   Pattern 2 O <sup>(Note 1)</sup>	

O : Available, x: Unavailable

Note 1 ZONE1 and PZONE cannot be used both at the same time. The setting at the delivery is set to the position zone signal output. It can be switched to the zone signal with Parameter No.149. Select the most appropriate one considering the purpose of use.



The relevant signal can be turned ON while the actuator passes or stops in the zone range in either of the following 2 types:

- 1) Zone signal ZONE1 ..... The output signal is turned ON at the position set by the proper parameter.
- 2) Position zone signal PZONE ...... The output signal is turned ON at the position set in the position table.

The feature can play a role as the sensor for judging whether the completion position is good or not at completion of pressing, setting the continuous operation zone in pitch feed or interlocking operations of other units in the setting zone.

#### I. Zone signal ZONE1

Set the zone range to the relevant parameter.

- 1) Parameter No.1 : Zone boundary 1+
- 2) Parameter No.2 : Zone boundary 1-

The zone signal ZONE is kept effective also during the emergency stop unless the memory of the origin is lost due to alarm.



II. Position zone signal PZONE

No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	50.00	30.00	0	0	0	0
2	100.00	250.00	0.20	0.20	0	0	0.10	70.00	60.00	0	0	0	0
3	50.00	250.00	0.20	0.20	50	0	20.00	60.00	65.00	0	0	0	0
	Setting of zone range												

Zone ranges should be set in the position table.

While the operation corresponding to a position number is executed, the zone range set for the position number is valid. It is kept effective also during the emergency stop unless the actuator is operated or the memory of the origin is lost due to alarm.

#### III. Setting values and signal output range

The zone output range varies depending on the difference between the value set for the positive side of the zone and that for the negative side.

- 1) Value set for positive side > value set for negative side: The output signal is set to ON in the range and OFF out of the range.
- Value set for positive side < value set for negative side: The output signal is set to OFF in the range and ON out of the range.

#### [Example]



the minimum resolution (actuator lead length/800).



#### (3) Alarm, Alarm Reset (\*ALM, RES)

Model name		Input	Output
	FIO Signal	RES	*ALM
	Pattern 0	×	0
ERC3 Main Body	Pattern 1	0	0
	Pattern 2	×	0

O : Available, ×: Unavailable

- 1) Alarm signal \*ALM is set to ON in the normal status but turned OFF at the occurrence of an alarm <sup>(Note 1)</sup> at a level equal to or higher than the operation release level.
- 2) Turning reset signal RES ON under occurrence of an alarm at the operation release level allows the alarm to be released. The action is taken at the rising edge (ON edge). There is no reset signal in Patterns 0 and 2. Release with using a teaching tool such as the PC software, or turn OFF the control power supply.

Note 1 For the details and how to deal when an alarm is generated, refer to Chapter 8 Troubleshooting.

Caution: The alarm reset should be done after the cause of the alarm is confirmed and removed. If alarm reset and restart are repeated many times without removal of the cause, a severe failure such as motor burnout may occur.

4.2 Operation in Positioner Mode 4.2.2 Operation in Positioner Mode 1



[7] Operation with the Position No. Input = Operations of PIO Patterns 0 and 2

Described in this section is how to operate in PIO Pattern 0 and 2 of ERC3 unit. These patterns provide normal controller operation methods in which the ROBO cylinder is operated by turning the start signal ON after a position No. is entered.

Positioning, pitch feeding and pressing operations differ only in the settings in the position table and are the same in how to control the sequence.

#### (1) Positioning [Basic] (PC1 to PC\*, CSTR, PEND, HEND)

Madal nama		Inp	but	Output		
woder name		PC1 to PC*	CSTR	PEND	HEND	
EDC2 Main Rody	PIO pattern 0	PC1 to 4	0	0	0	
ERCS Main Body	PIO pattern 2	PC1 to 8	0	0	0	
O : Available, ×: Unavailable						

[Caution] If the start signal CSTR is turned ON without performing a home-return operation after the power is turned ON, it automatically performs the home-return operation, and then conducts a positioning operation to the position number indicated at that time.

Also, there is no home-return signal in PIO Pattern 2. For such operations as interlocking, refer to "Home-Return Operation without Home-Return Signal" described later.

#### Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	70.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0

Deceleration

7) 8)

4)

8)

Position 2

Mo comp

Moving comp.

5) 6)

Positioning

Completion

Signal Output

Positioning

Completion Signal Output



- Control method
  - First enter command position No. PC1 to PC\* with binary data. Next turn start signal CSTR ON. Then the actuator starts acceleration depending on the data in the specified position table for positioning to the target position.
  - At operation start, positioning complete signal PEND is turned OFF. Always turn the CSTR signal OFF. Unless CSTR Signal is turned OFF, the positioning complete signal PEND would not turn ON at the completion of positioning.
  - 3) The positioning complete signal PEND turns ON when positioning is complete.
  - 4) Positioning complete signal PEND is turned ON if the remaining moving distance enters into the positioning width. PEND signal that is turned ON will remain ON unless the start signal CSTR turns ON again, or the servo is turned OFF. It would not turn OFF even if it goes out of the positioning width. (Note 1)
  - Note 1 If INP (setting number: 1) is selected in Parameter No.39, PEND becomes INP (In-position) Signal, and will turn OFF when it goes out of the positioning width.



#### Caution:

- (1) Set the period taken from entering position No. to turning CSTR ON to 6ms or larger. In spite of 6ms timer process in the PLC, commands may be input to the controller concurrently to cause positioning to another position. Take the scanning time in the PLC into account to set a period as 2 to 4 times as the scanning time.
- (2) At the completion of positioning, positioning complete signal PEND is not turned ON if start signal CSTR remains ON. If this occurs, turn CSTR OFF then PEND is turned ON immediately. Therefore, create the sequence program so that turning PEND OFF makes CSTR turned OFF and the PLC waits for the state in which PEND is turned ON.
- (3) If a positioning is performed at the same position as the stop (complete) position number, PEND turns OFF once.
- (4) If the setting of the positioning width wide, the actuator continues to move to the target position even after PEND turns ON.
  - [Important] Home-Return Operation without Home-Return Signal = Home-Return for Pattern 2 If a positioning operation is performed by the indicated position number without having a home-return operation, the actuator automatically performs a home-return operation, and then starts positioning operation by the indicated position number. There is no home-return command in Pattern 2. Have a home return in this way.

4.2 Operation in Positioner Mode 4.2.2 Operation in Positioner Mode 1



If there is a problem in this operation, have an interlocking to the start signal by the home-return complete signal HEND since there is the home-return signal HOME in PIO Pattern 1. There is no home-return signal in PIO Pattern 2. Therefore, it is necessary to set 0.00mm to one of the position numbers as a position for positioning, and perform positioning to that position. The actuator

position numbers as a position for positioning, and perform positioning to that position. The actuator performs positioning to the home position and the home-return complete signal HEND turns ON. Interlock the setting so positioning cannot be conducted at other positions by the home-return complete signal HEND.

Binary data			0 : ON	• : OFF
Command position No.	PC8	PC4	PC2	PC1
0	•	•	•	•
1	•	•	•	0
2	•	•	0	•
3	•	•	0	0
4	•	0	•	•
5	•	0	•	0
6	•	0	0	•
7	•	0	0	0
8	0	•	•	•
9	0	•	•	0
10	0	•	0	•
11	0	•	0	0
12	0	0	•	•
13	0	0	•	0
14	0	0	0	•
15	0	0	0	0

# 4.2 Operation in Positioner Mode 4.2.2 Operation in Positioner Mode 1



### (2) Speed change during the movementSample use





The unit inserts nozzles into containers, injects liquid, and moves the nozzles upward so that they may not be contact with the liquid surfaces.

No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	150.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	0.00	50.00	0.20	0.20	0	0	100.00	0.00	0.00	0	0	0	0
3	0.00	100.00	0.20	0.20	0	0	0.10	0.00	5.00	0	0	0	0

#### Control method

The speed of the actuator can be changed while it moves. Positions are used by the number of speeds. The method of controlling the operation to each position is the same as that described in (1) Positioning.

The example below describes the case of 2 speeds:

- In this example, the speed is changed while the actuator moves from the position of 150mm to the position of 0mm. At first, set the positioning to the target position at the first speed in position No.2. In the positioning width, set the distance from the speed change position to the target position. The value is set to 100mm in the example. Thus, for position No.2, positioning complete signal PEND is turned ON at the position before the target position by 100mm.
- 2) Set the positioning to the target position at the second speed in position No.3.
- 3) Start position No.2. Then start position No.3 successively when PEND in position No.2 is turned ON. In normal positioning, position data specified later has always a priority over position data specified earlier. Thus, the operation in position No.3 is started on the way of the operation in position No.2.

In this example, the target positions No.2 and 3 are equal with each other. They may not be the same. However, setting the target positions to be equal with each other allows the distance from the speed change position to the target position to be known easily. To increase in the number of speed change steps, add a position number and operation

sequence, set the speed change position in the positioning width and operate the actuator continuously.



## (3) Pitch Feeding (relative movement = incremental feed)■ Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	100.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	25.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	1	0	0
	itian NI.	- O a ata	mitch fo							•			

(Position No.2 sets pitch feed.)

- Control method
  - 1) The method of controlling pitch feed is the same as that described in (1) Positioning except the setting of the position table. Repeat the positioning of a specific position No.
  - 2) For pitch feed, the position set in the position table indicates the pitch. Set the pitch (relative moving distance = incremental moving distance) in column "Position".
  - 3) If the operation command is issued, the actuator moves from the current stop position by "Position" in the position table. To perform continuous movement, repeat the operation. Any accumulation error does not occur because the home position (coordinate value 0) is specified as the base point.

Caution	In the pitch feed, do not perform a command with a pitch smaller than the
	minimum encoder resolution (lead/encoder pulse number) or that less than
	positioning accuracy repeatability.
	There would be no deviation to occur even with the command because it is an
	operation command to the same position as the positioning complete condition,
	but the positioning control cannot be performed properly.





(Position No.2 sets pressing operation.)

- Control method
  - The method of controlling the pressing operation is the same as that described in (1) Positioning except the setting of the position table. Any setting of "Pressing" in the position table allows the pressing operation to be done. "Positioning width" is assumed as pressing operation distance.
  - 2) The actuator moves at the setting speed and rating torque to the position of the coordinate set in "Position" in the similar way as normal positioning. The operation is executed with the value set in "Positioning width" for the amount of movement in the pressing operation, and the torque (current limit) set in % in "Pressing" for the pressing operation as the upper limit.
  - 3) The control method is the same as that in [1] Positioning. However, the processing of positioning complete signal PEND is different from that in [1] Positioning. PEND is output when the shaft is stopped by pressing (pressing complete). If the work is not subject to pressing (miss-pressing), the actuator moves by the value set in "Positioning width" to stop but PEND is not turned ON.

4.2 Operation in Positioner Mode 4.2.2 Operation in Positioner Mode





#### Judging completion of pressing operation

The operation monitors the torque (current limit value) in percent in "Pressing" of the position table and turns pressing complete signal PEND ON when the load current satisfies the condition shown below during pressing. PEND is turned ON at satisfaction of the condition if the work is not stopped.

the work is not stopped. (Accumulated time in which current reaches pressing value [%]) – (accumulated time in which current is less than pressing value [%])  $\geq$  255ms (Parameter No.6)





(5) Tension Operation



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	100.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	80.00	250.00	0.20	0.20	50	0	-50.00	0.00	0.00	0	0	0	0
3													



#### Control method

The method of controlling the tension operation is the same as that described in (4) Pressing operation. The control method is explained below by using the sample position table shown above.

- Position No.2 indicates the settings of tension operation. The settings of "Position" and "Positioning width" show the tension start position and the tension quantity, respectively. Attach – (minus sign) to the tension quantity. Specify the upper limit of the torque required for tension in percent (limited current value) in "Pressing". The speed, acceleration, and deceleration are the conditions of positioning to the coordinate value (80mm) set in "Position".
- Position No.1 indicates the tension start preparation position. Specify a value larger than the coordinate value at which the tension provided by position No.2 ends (80 – 50 = 30mm) in "Position".
- 3) First define the positioning in position No.1. Next, the operation in position No.2 moves the actuator to the position of 80mm at the setting speed and rating torque and change to the tension operation. The actuator moves by 50mm in the negative direction in the tension operation. The upper limit of the tensile force is the torque set in percent.
- 4) In the similar way as pressing, the positioning complete signal is output when the shaft is stopped by tension (pressing complete). If the actuator cannot be stopped during movement within the setting positioning width (miss-pressing), it moves by the setting distance to stop but PEND is not turned ON.





	No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
	0													
	1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
	2	50.00	250.00	0.20	0.20	30	0	20.00	0.00	0.00	0	0	0	0
	3	50.00	250.00	0.20	0.20	50	0	20.00	0.00	0.00	0	0	0	0
Γ	4													

#### Control method

After pressing, the pressing pressure can only be changed in the pressing state. The method of controlling multi-step pressing is the same as that described in (4) Pressing operation.

- 1) Set the weak pressing (30%) in position No.2 and perform the pressing operation.
- If pressing complete signal PEND is turned ON, start the pressing operation with pressing pressure (50%) greater than the first pressure set in position No.3. The position data in position No.3 should be the same as that in position No.2 except the setting in "Pressing".
- 3) To add a pressing step with another pressing pressure, add a sequence consisting of a position number and a pressing operation.

ME0297-14E



#### Control method

FRFé

Pause is possible during movement. The pause signal is an input signal always set to ON. So, it is normally used to remain ON. Use this as an interlock in such a case interference gets into the moving direction while the actuator is operating.

- If pause signal \*STP is turned off during operation of the actuator, the actuator is decelerated to a stop. The deceleration is defined by the value set in the position table.
- 2) The positioning complete signal PEND would not turn ON while in pause.
- If pause signal \*STP is returned to ON, the actuator continues the remaining movement. The acceleration is the value set in the position table.



Caution: Turning \*STP OFF with the actuator being in the positioning complete state causes PEND to be turned OFF. Note that this situation may not occur when a sequence program is created.



[8] Direct Position Specification (3-point <Solenoid valve> type) = PIO Pattern 1 The start signal is provided for every position number. Only turning ON the relevant input signal according to the table shown below allows the operation based on the data in the target position number to be performed. The operation mode is called the solenoid valve mode because solenoid valves can directly drive air cylinders.

Also, the complete position number is output for each position number once positioning is complete.

Positioning, pressing, and pitch feed are possible. Their control methods are the same as those of other patterns.

#### (1) Positioning [Basic] (ST0 to ST2, PE0 to PE2)

Model name	Position No.	Input	Output
	0	ST0	PE0
ERC3 Main Body	1	ST1	PE1
	2	ST2	PE2

[Caution] • Speed change is not allowed during movement.

• There is no home-return signal. The actuator automatically performs the home-return operation with the first start signal ST\* after the power is turned ON, and then performs an operation regarding the data in the indicated position number. For the details refer to "Home-Return Operation" described later.

#### Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0	0.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
1	70.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0

#### Control method

- 1) When start signal ST\* is turned ON, the actuator starts acceleration based on the data in the specified position table for positioning to the target position.
- Current Position No. PE\* of the commanded position turns ON once the positioning is complete.
- 3) Once the current position No. PE\* signal turns ON, turn OFF ST\* Signal.
- 4) Current Position No. PE\* turns ON if the remaining movement amount is in the range of the positioning width. PE\* signal that is turned ON will remain ON unless the start signal ST\* turns ON again, or the servo is turned OFF. It would not turn OFF even if it goes out of the positioning width. <sup>(Note 1)</sup>
- Note 1 If INP (setting number: 1) is selected in Parameter No.39, PE\* becomes INP (In-position) Signal, and will turn OFF when it goes out of the positioning width. (Note) It can be switched over with Parameter No.39.



#### [Important] Home return

In the first positioning operation after the power is supplied, home-return operation is automatically performed, and then positioning operation with the data of the indicated position number starts. There is no home-return command in Pattern 1. Have a home return in this way.



If there is a problem in this operation, set 0.00mm to one of the position numbers as a position for positioning, and perform positioning to that position. The actuator performs positioning to the home position and PE\* of the indicated position turns ON. Interlock the setting so positioning cannot be conducted at other positions by this PE\* Signal.

4.2 Operation in Positioner Mode 4.2.2 Operation in Positioner Mode 1

## ERC**3**

## (2) Pitch Feeding (relative movement = incremental feed)■ Sample use



(Position No.2 sets pitch feed.)

#### Control method

- 1) The method of controlling pitch feed is the same as that described in [1] Positioning except the setting of the position table. Repeat the positioning of a specific position No.
- 2) For pitch feed, the position set in the position table indicates the pitch. Set the pitch (relative moving distance = incremental moving distance) in column "Position".
- 3) If the operation command is issued, the actuator moves from the current stop position by "Position" in the position table. To perform continuous movement, repeat the operation. Any accumulation error does not occur because the home position (coordinate value 0) is specified as the base point.

## ERC**3**

#### Caution:

- (1) If ST\* Signal is turned ON at the same position number to repeat pitch feeding after positioning is complete, PE\* Signal turns OFF at the operation start like the positioning in (1), and then turns back ON once the positioning is complete.
- (2) If the actuator reaches the software limit (stroke end) in pitch feed, the actuator is decelerated to be stopped and current position No. PE\* is turned ON at the stop position.
- (3) PE\* Signal turns ON when the actuator gets into the positioning width. Accordingly, they may be turned ON under operation of the actuator if a large positioning width is set.
- (4) SInterlock should be taken so that two or more ST\* signals are set to ON simultaneously.
  - Entering the ST\* signal of another position during positioning is invalid. If the ST\* signal of another position is turned ON during positioning, the operation is terminated after the completion of the positioning being operated.
  - Entering the ST\* signal of another position with the ST\* signal of the current position remaining ON after the completion of positioning allows the positioning to the other position to be executed.
- (5) If Parameter No.27 "Move command type" is set to "0" (factory setting), turning ST\* OFF during positioning caused the operation to be interrupted.
- (6) Note that, when Parameter No.27 "Move command type" is set to "1", starting (ST\* ON) pitch feed repeatedly during pause causes the actuator to be moved successively by the number of starts. If this situation is supposed, cancel the remaining moving distance by turning reset signal RES ON in the pause state or take interlock so that start signals are not turned on during pause.
- (7) The pressing operation is enabled by using the pitch feed function.
- (8) In the pitch feed, do not perform a command with a pitch smaller than the minimum encoder resolution (lead / encoder pulse number) or that less than positioning accuracy repeatability.

There would be no deviation to occur even with the command because it is an operation command to the same position as the positioning complete condition, but the positioning control cannot be performed properly.





No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	100.00	250.00	0.20	0.20	50	0	50.00	0.00	0.00	0	0	0	0

(Position No.2 sets pressing operation.)

- Control method
  - The method of controlling the pressing operation is the same as that described in (1) Positioning except the setting of the position table. Any setting of "Pressing" in the position table allows the pressing operation to be done. "Positioning width" is assumed as pressing operation distance.
  - 2) The actuator moves at the setting speed and rating torque to the position of the coordinate set in "Position" in the similar way as normal positioning. The operation is executed with the value set in "Positioning width" for the amount of movement in the pressing operation, and the torque (current limit) set in % in "Pressing" for the pressing operation as the upper limit.
  - ③ Current Position No. PE\* is output when the axis stops by pressing operation (pressing complete). Also, even when not pressing a work piece (pressing error), a movement is made for the setting of "positioning width", and then turns ON.







#### Judging completion of pressing operation

PIO converter monitors the torque (current limiting value) set in % in "Pressing" in the position table, and turns ON the pressing complete signal PE\* when the load current reaches the following condition. PE\* is turned ON at satisfaction of the condition if the work is not stopped.

Accumulated time in which current reaches pressing value [%]) – (accumulated time in which current is less than pressing value [%])  $\ge$  255ms (Parameter No.6)







ST\*: Start position

#### Control method

ERTŐ

The control logic for the pulling operation is as same as the one for (3) Pressing Operation. The control method is explained below by using the sample position table shown above.

- Position No.2 indicates the settings of tension operation. The settings of "Position" and "Positioning width" show the tension start position and the tension quantity, respectively. Attach – (negative sign) to the tension quantity. Specify the upper limit of the torque required for tension in percent (limited current value) in "Pressing". The speed, acceleration, and deceleration are the conditions of positioning to the coordinate value (80mm) set in "Position".
- Position No.1 indicates the tension start preparation position. Specify a value larger than the coordinate value at which the tension provided by position No.2 ends (80 – 50 = 30mm) in "Position".
- 3) First define the positioning in position No.1. Next, the operation in position No.2 moves the actuator to the position of 80mm at the setting speed and rating torque and change to the tension operation. The actuator moves by 50mm in the negative direction in the tension operation. The upper limit of the tensile force is the torque set in percent.
- 4) Like the pressing operation, Current Position No. PE\* is output when the axis stops by pressing operation (pressing complete). Also, even when not stopping during a move in the set range (pressing error), a movement is made for the setting of "Positioning width", and then turns ON.





No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	50.00	250.00	0.20	0.20	30	0	20.00	0.00	0.00	0	0	0	0
3	50.00	250.00	0.20	0.20	50	0	20.00	0.00	0.00	0	0	0	0
4													

#### Control method

It is available to change only the pressing pressure after performing the pressing operation once and while keeping the pressing.

The method of controlling multi-step pressing is the same as that described in (4) Pressing operation.

- 1) Set the weak pressing (30%) in position No.2 and perform the pressing operation.
- 2) If pressing complete signal PE2 is turned ON, start the pressing operation with pressing pressure (50%) greater than the first pressure set in position No.3. In this particular operation, turn ON ST3 after completion of ST2, and turn OFF ST2 when PE2 is turned OFF. In usual case, do not turn ON two or more ST\* signals simultaneously. The position data in position No.3 should be the same as that in position No.2 except the setting in "Pressing".





(6) Pause and Operation Interruption (ST\*, \*STP, RES, PE\*)

Pause is possible during movement. In this mode, the following two methods are possible for pause.

1) Use of pause signal \*STP

Turning reset signal RES ON during the pause allows the remaining moving distance to be cancelled to interrupt the operation.

- 2) Use of start signal ST\* This method is valid when Parameter No.27 "Move command type" is set to "0" (factory setting). The actuator can only be moved while the ST\* signal is set to ON and stopped if ST\* is turned OFF. Since setting the ST\* signal to OFF is assumed as interrupt of operation, the remaining moving distance may not be cancelled.
- I. Use of pause signal \*STP



Control method

The pause signal is an input signal always set to ON. So, it is normally used to remain ON. Use this function for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- If pause signal \*STP is turned OFF during operation of the actuator, the actuator is decelerated to a stop. The deceleration is defined by the value set in the position table. During pause, current position No. PE\* is not turned ON.
- 2) If pause signal \*STP is returned to ON, the actuator continues the remaining movement. The acceleration is the value set in the position table.
- 3) Turning reset signal RES ON during pause (\*STP being OFF) allows the remaining movement to be canceled to interrupt the operation.





Note 1 Refer to Chapter 8 Troubleshooting for details of alarms.

#### II. Use of start signal ST\*

FRFé



#### Control method

It is available to pause the operation if turning OFF the start signal ST\* during the operation. Use the control method for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- 1) If the ST\* signal is turned OFF during movement, the actuator is paused. The deceleration is the value set in the position table.
- ST\* Signal being turned OFF is identified as a cancel of positioning. PE\* would not turn ON.
- If the ST\* signal is turned ON again, the remaining movement is continued. The acceleration is the value set in the position table.




# ERC**3**

4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter) To perform an operation of Position Mode 2, PIO Converter (option) is necessary. By using PIO Converter, an operation with extended function of ERC3 is available. It is available to select 6 types of PIO patterns with the parameters. This PIO Pattern cannot be switched over after the system is finished to be established or during the actuator operation.

Choose the optimum pattern beforehand considering the system operation specifications and prepare the cables and sequence design.

					(	ວ : Valid fu	Inction
	PIO Pattern (Parameter No.25)	0	1	2	3	4	5
	Mode	Positioning mode	Teaching mode	256-point mode	512-point mode	Solenoid valve mode 1	Solenoid valve mode 2
	Number of positioning points	64	64	256	512	7	3
	Operation with the Position No. Input	0	0	0	0	×	×
	Position No. direct command operation	×	×	×	×	0	0
	Positioning	0	0	0	0	0	0
functions	Velocity change during the movement	0	0	0	0	×	×
	Pressing (tension)	0	0	0	0	0	×
	Pitch feeding (relative moving feed)	0	0	0	0	0	×
ljor	Home return signal input	0	0	0	0	0	×
Ma	Pause	0	0	0	0	0	$\Delta^{(Note 1)}$
	Jog moving signal	×	0	×	×	×	×
	Teaching signal input (Current position writing)	×	0	×	×	×	×
	Brake release signal input	0	×	0	0	0	0
	Moving signal output	0	0	×	×	×	×
	Zone signal output	0	×	×	×	0	0
	Position zone signal output	0	0	0	×	0	0

### [1] PIO Pattern Selection and Main Functions

(Note 1) The pause signal is not provided. [Refer to 4.2.3 [8] (5).]

#### (Reference)

Zone signal output signal: The zone range is set to the Parameters No.1 and 2 and No.23<br/>and 24, and becomes always effective after the home return is<br/>complete.Position zone signal: This feature is associated with the specified position number. The<br/>zone range is set in the position table. The zone range is enabled

zone range is set in the position table. The zone range is enabled only when the position is specified but disabled if another position is specified.



### [2] Overview of major Functions

Major functions	Description
Number of positioning points	Number of positioning points which can be set in the position table.
Operation with the Position No.	Normal operation started by turning the start signal ON after
Input	position No. is entered with binary data.
Position No. direct command	Operation enabled by turning the signal directly
operation	corresponding to a position No. ON
Positioning	Positioning enabled at an arbitrary position by the data set in the position table
Velocity change during the movement	Velocity change enabled by activating another position No. during movement
Pressing (tension)	Operation by an arbitrary pressing (tension) force set in the position table enabled
Pitch feeding	Pitch feed by an arbitrary moving distance set in the position
(relative moving feed)	table enabled
Home return signal input	Input signal exclusively used for home return. Set to ON to start home return
Pause	The operation can be interrupted or continued by setting this signal to ON or OFF, respectively.
Jog moving signal	The actuator can only be moved while the input is set to ON.
Teaching signal input	Setting the input signal to ON allows the coordinate value in
(Current position writing)	the stop state to be written to the position table.
Brake release signal input	The brake (option) can only be released while the input is set to ON.
Moving signal output	The output signal is set to ON while the actuator is moved.
Zone signal output	The output signal is set to ON while the actuator is entered
	within the zone defined by the coordinate values set as parameters.
Position zone signal output	The output signal is set to ON while the actuator is entered within the zone defined by the coordinate values set in the position table.

# ERC**3**

- [3] Power Supply and Emergency Stop Release (CP24, MPI, MPO, EMG(-)) [Refer to 3.3.3 Circuit Diagram]
  - (1) Built-in Drive Cutoff Relay Type (Model: RCB-CV-DDD)
    - 1) Supply the power (CP24, GND), first.
      - Secondly, turn ON the motor power source and the emergency stop signal at the same time. Do not attempt to turn ON the emergency stop signal prior to the motor power source.

Jumper MPI and MPO in advance (is already jumpered at the delivery). By releasing the emergency stop (turning ON EMG(-) Signal), built-in relay turns ON and power is supplied to the driving source.

- 3) Once the emergency stop signal EMG(-) is turned OFF, a cutoff of the motor power supply by the built-in relay is conducted at the same time as the servo being turned OFF. Do not attempt to cut off the motor power supply (MPI and MPO) in advance to the emergency stop signal EMG(-) being turned OFF.
- (2) External Drive Cutoff Relay Type (Model: RCB-CVG-DDD)
  - 1) Supply the power (CP24, GND), first.
  - Secondly, turn ON the motor power source and the emergency stop signal at the same time. Do not attempt to turn ON the emergency stop signal prior to the motor power source.

Connect a contact for the cutoff relay between MPI and MPO and turn it ON at the same time as releasing the emergency stop (turning EMG(-) Signal ON).

- 3) If the emergency stop signal EMG turns OFF, the servo also turns OFF. Have the motor power (MPI, MPO) cut off at the same time. Do not attempt to cut off the motor power (MPI, MPO) prior to the emergency stop signal EMG being turned OFF.
- [4] Time Constant for Control Signal Input

For the input signal for control of this controller, it is set to 6ms of input time constant to prevent an error operation due to chattering or noise from the next page and later. Therefore, input each input signal for 6ms or more <sup>(Note)</sup> continuously. The signal cannot be identified if it is less than 6ms.



4.2 Operation in Positioner Mode 4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



- [5] Operation Ready and Auxiliary Signals
  - (1) Emergency stop status EMGS

	Output
PIO signal	*EMGS
Common to Patterns	0
0 to 5	U

O : Available, ×: Unavailable

- 1) The emergency stop status EMGS is turned ON when in normal condition and turned OFF when EMG(-) terminal on "3.3.3 Circuit Diagram" is 0V (emergency stop condition or disconnected).
- 2) It turns back ON once the emergency stop condition is released and EMG(-) terminal goes up to 24V DC.

Have an appropriate safety treatment such as interlock with this signal for the host controller (PLC, etc.).

[Caution] EMGS is different from the emergency stop output caused by a controller alarm.

(2) Servo ON (SON, SV, PEND)

= ( = , ,				
	Input	Output		
FIO Signal	SON	SV	PEND	
Other than pattern 5	0	0	0	
Pattern 5	0	0	×	

O : Available, ×: Unavailable

- 1) Servo ON signal SON is the input signal making the servo motor of the actuator operable.
- 2) If the servo-on is performed to enable operation, the SV output signal is turned ON. Concurrently positioning completion signal PEND is turned ON.
- 3) With the power being supplied, then controller cannot be operated while the SV signal remains OFF. If the SON signal is turned OFF under operation of the actuator, the actuator is decelerated and stopped with the maximum torque. After the stop, the servo OFF occurs to enter the motor into the free running state.

For an actuator equipped with a brake, the brake gets to the operating condition.



- T1 : Parameter No.30 It differs depending on the setting of excitation detection type. Set Value = 0  $\rightarrow$  160ms Set Value = 1, 2  $\rightarrow$  220ms
- T2 : Parameter No.29 Setting of excitation phase signal detection time It is set to 10ms in the initial setting.
- T3 : Fixed to 20ms
- (Note) Excitation check operation is performed at the first servo-on process after the power is turned ON, or when the home return is completed for the simple absolute type to identify the magnetic poles of the motor.
  - PEND would not turn ON in the pause condition.



#### (3) Home Return (HOME, HEND, PEND, MOVE)

	Input		Output	
FIO Signal	HOME	HEND	PEND	MOVE
Patterns 0 to 1	0	0	0	0
Patterns 2 to 4	0	0	0	×
Pattern 5	× <sup>(Note 1)</sup>	0	×	Х

O : Available, x: Unavailable

Note 1 Pattern 5 cannot make a home return with HOME signal. Refer to 4.2.3 [8] (1) for how to perform a home-return operation.

The HOME signal is intended for automatic home return. The HOME signal is caught at the rising edge (ON edge) to start the home return. At completion of the home return, home return completion signal HEND is turned ON. The home-return complete signal HEND is kept ON unless the memory of origin point is lost for a reason such as alarm. During the home return operation, positioning completion signal PEND and moving signal MOVE are set to OFF and ON, respectively.



#### [Operation of Actuator]



- With the HOME signal being ON, the actuator moves toward the mechanical end at the 1) home return speed. The movement speed is 20mm/s.
- 2) The actuator is turned at the mechanical end and stopped at the home position. The moving distance is the value set by Parameter No.22 "Home return offset level".

Caution: In the home reverse specification, the actuator moves in the reverse direction. Make sure to refer to Chapter 7 Parameter when a change to Parameter No.22 "Home return offset level".



PIO signal	Output					
FIO Signal	ZONE1	ZONE2 <sup>(Note 2)</sup>	PZONE (Note 2)			
Pattern 0	0	0	0			
Pattern 1	O (Note 2)	×	0			
Pattern 2	O (Note 2)	×	0			
Pattern 3(Note 1)	×	×	×			
Pattern 4	0	0	0			
Pattern 5	0	0	0			

O : Available, ×: Unavailable

- Note 1 Pattern 3 does not possess the zone signal output function.
- Note 2 In Parameter No.149 Zone Output Switchover, ZONE can be selected instead of PZONE.



The relevant signal can be turned ON while the actuator passes or stops in the zone range in either of the following 2 types:

- 1) Zone signal (ZONE1, ZONE2)....The output signal is turned ON at the position set by the proper parameter.
- 2) Position zone signal PZONE ...... The output signal is turned ON at the position set in the position table.

The feature can play a role as the sensor for judging whether the completion position is good or not at completion of pressing, setting the continuous operation zone in pitch feed or interlocking operations of other units in the setting zone.

## I. Zone signal (ZONE1, ZONE2)

Set the zone range to the relevant parameter.

- 1) Parameter No.1 : Zone boundary 1+
- 2) Parameter No.2 : Zone boundary 1-
- 3) Parameter No.23: Zone boundary 2+
- 4) Parameter No.24 : Zone boundary 2-

The zone signal ZONE is kept effective also during the emergency stop unless the memory of the origin is lost due to alarm.

4.2 Operation in Positioner Mode 4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



II. Position zone signal PZONE

No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	50.00	30.00	0	0	0	0
2	100.00	250.00	0.20	0.20	0	0	0.10	70.00	60.00	0	0	0	0
3	50.00	250.00	0.20	0.20	50	0	20.00	60.00	65.00	0	0	0	0
	Setting of zone range												

Zone ranges should be set in the position table.

While the operation corresponding to a position number is executed, the zone range set for the position number is valid. It is kept effective also during the emergency stop unless the actuator is operated or the memory of the origin is lost due to alarm.

#### III. Setting values and signal output range

The zone output range varies depending on the difference between the value set for the positive side of the zone and that for the negative side.

- 1) Value set for positive side > value set for negative side: The output signal is set to ON in the range and OFF out of the range.
- Value set for positive side < value set for negative side: The output signal is set to OFF in the range and ON out of the range.



 (2) The zone detection range would not turn ON unless the value exceeds that of the minimum resolution (actuator lead length/800).



(5) Alarm, Alarm Reset (\*ALM, RES)

	Input	Output
FIO Signal	RES	*ALM
Common to Patterns 0 to 5	0	0

O : Available, x: Unavailable

- 1) Alarm signal \*ALM is set to ON in the normal status but turned OFF at the occurrence of an alarm <sup>(Note 1)</sup> at a level equal to or higher than the operation release level.
- 2) Turning reset signal RES ON under occurrence of an alarm at the operation release level allows the alarm to be released. The action is taken at the rising edge (ON edge).

Note 1 Check the Chapter 8 Troubleshooting for details of alarms.

▲ Caution:	<ol> <li>Reset signal RES has two features, or alarm reset under occurrence of an alarm and operation interruption (cancellation of remaining moving distance) under temporary stop.</li> <li>For the operation interruption under temporary stop, refer to the description of the operation in each pattern.</li> <li>The alarm reset should be done after the cause of the alarm is confirmed and removed. If alarm reset and restart are repeated many times without removal of the cause, a severe failure such as motor</li> </ol>
	times without removal of the cause, a severe failure such as motor burnout may occur.



(6) Binary Output of Alarm Data Output (\*ALM, PM1 to 8)

<b>DIO</b> signal	Out	tput
PIO Signal	*ALM	PM1 to 8
Common to Patterns 0 to 3	0	0
Pattern 4 <sup>(Note 1)</sup>	0	×
Pattern 5 <sup>(Note 1)</sup>	0	×

O : Available, ×: Unavailable

(Note 1) Patterns 4 and 5 do not have this function.

- 1) If an alarm at a level equal to or higher than the operation release level occurs, completed position number output signals PM1 to PM8 output the alarm information in the binary code format.
- 2) The PLC can read the binary code of alarm signal \*ALM as the strobe signal to refer to alarm information.

						O: ON ●: OFF
*ALM	ALM8 (PM8)	ALM4 (PM4)	ALM2 (PM2)	ALM1 (PM1)	Binary Code	Description: Alarm code is shown in ( ).
0	•	•	•	•	-	Normal
•	•	•	0	•	2	Software reset during servo ON (090) Position number error during teaching (091) PWRT signal detected during movement (092) PWRT signal detected before completion of home return (093)
•	•	•	0	0	3	Move command during servo OFF (080) Position Command in Incomplete Home Return (082) Absolute position move command when home return is not yet completed (083) Movement Command during Home Return Operation (084) Position No. error during movement (085) Move command while pulse train input is effective (086) Command deceleration error (0A7)
•	•	0	•	•	4	Mismatched PCB (0F4)
	•	0	•	0	5	
•	•	0	0	•	6	Parameter data error (0A1) Position data error (0A2) Position command data error (0A3) Unsupported motor/encoder type (0A8)
•	•	0	0	0	7	Excitement detection error (0B8) Home return timeout (0BE)

(Note) \*ALM Signal is an active low signal. It is ON when the power is applied to the controller, and turns OFF when the signal is output.



O: ON ●: OFF

*ALM	ALM8 (PM8)	ALM4 (PM4)	ALM2 (PM2)	ALM1 (PM1)	Binary Code	Description: Alarm code is shown in ( ).							
•	0	•	•	•	8	Actual speed excessive (0C0)							
•	0	•	•	0	9	Overcurrent (0C8) Overvoltage (0C9) Overheat (0CA) Control power source voltage error (0CC) Drop in control supply voltage (0CE) Drive source error (0D4)							
•	0	•	0	0	11	Command counter overflow (0A4) Command counter overflow in Incomplete home return (0D5) Deviation Overflow (0D8) Software stroke limit over error (0D9) Pressing motion range over error (0DC)							
•	0	0	●	•	12	Servo error (0C1) Overload (0E0)							
•	0	0	•	0	13	Encoder receipt error (0E5) Absolute encoder error detection 1 (0ED) Absolute encoder error detection 2 (0EE) Absolute encoder error detection 3 (0EF)							
•	0	0	0	•	14	CPU Error (0FA) Logic Error (0FC)							
•	0	0	0	0	15	Nonvolatile memory write verify error (0F5) Nonvolatile memory write timeout (0F6) Nonvolatile memory data destroyed (0F8)							

(Note) \*ALM Signal is an active low signal. It is ON when the power is applied to the controller, and turns OFF when the signal is output.



(7) Brake release BKRL

	Input
FIO Signal	BKRL
Pattern 0	0
Pattern 1 <sup>(Note 1)</sup>	×
Patterns 2 to 5	0

O : Available, ×: Unavailable

(Note 1) Pattern 1 does not have this feature

The brake can be released while BKRL signal is set to ON. If a brake is installed in the actuator, the brake is automatically controlled by servo ON/OFF. Releasing the brake may be required to move the slider and/or the rod by hand in case of installation of the actuator in the machine or direct teach<sup>\*1</sup>. This operation can be performed not only by the brake release switch on the front panel of the PIO converter, but also by the brake release signal BKRL.

\*1 Direct teach : This operation is intended to get coordinate values to the position by moving the slider and/or the rod by hand.

<ul> <li>Warning: (1) Take sufficient care to release the brake. Inappropriate brake release may cause people to be injured and/or the actuator, the work and/or the machine to be damaged.</li> <li>(2) After the brake is released, always make the brake applied again. Any operation with the brake remaining released is extremely dangerous. The slider or rod may drop to cause people to be injured and/or the actuator, the work and/or the machine to be damaged.</li> <li>(3) Make certain that this signal is turned OFF (brake is activated) when the power is supplied to the controller.</li> </ul>			
	Narning:	(1) (2) (3)	Take sufficient care to release the brake. Inappropriate brake release may cause people to be injured and/or the actuator, the work and/or the machine to be damaged. After the brake is released, always make the brake applied again. Any operation with the brake remaining released is extremely dangerous. The slider or rod may drop to cause people to be injured and/or the actuator, the work and/or the machine to be damaged. Make certain that this signal is turned OFF (brake is activated) when the power is supplied to the controller.

Chapter 4 Operation



### [6] Operation with the Position No. Input = Operations of PIO Patterns 0 to 3

This is the operation method for PIO Patterns 0 to 3. This is a standard operation method when using PIO Converter that operates by turning the start signal ON after inputting the position number.

The control methods of positioning, pitch feed, and pressing are the same as those described before.

(	1)	Positionina	[Basic]	(PC1 to	PC**.	CSTR.	PM1 t	o PM**.	PEND.	MOVE)
۰.	• •	i oonaoning		(1.0.10	,			•••••	,	

	Input		Output					
FIO signal	PC1 to PC** CSTR		PM1 to PM**	PEND	MOVE			
PIO pattern 0	PC1 to 32	0	PM1 to 32	0	0			
PIO pattern 1	PC1 to 32	0	PM1 to 32	0	0			
PIO pattern 2	PC1 to 128	0	PM1 to 128	0	×			
PIO pattern 3	PC1 to 256	0	PM1 to 256	0	×			

O : Available, ×: Unavailable

(Note) Operation without home return leads the operation based on the data of the specified position No. after automatic home return. If one or more problems are found, interlock by home return complete signal HEND is required.

#### Sample use

ERCÕ



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	70.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0



- Control method
  - 1) First enter command position No. PC1 to PC\*\* with binary data. Next turn start signal CSTR ON. Then the actuator starts acceleration depending on the data in the specified position table for positioning to the target position.
  - At operation start, positioning complete signal PEND is turned OFF. Always turn the CSTR signal OFF. Without it, the completed position number is not output and the positioning complete signal is not turned ON at the completion of positioning.
  - 3) When the positioning is completed, the positioning complete position numbers are output from complete position No.PM1 to PM\*\* with binary data and also positioning complete signal PEND is turned ON.
  - 4) Moving signal MOVE is turned ON as soon as the operation is started and turned OFF at the completion of positioning.
  - 5) Positioning complete signal PEND is turned ON if the remaining moving distance enters into the positioning width. PEND signal that is turned ON will remain ON unless the start signal CSTR turns ON again, or the servo is turned OFF. It would not turn OFF even if it goes out of the positioning width. (Note 1)
  - Note 1 A switchover is available to INP (Setting 1) in Parameter No.39. PEND becomes an in-position signal that turns OFF out of the positioning width.



Note 1 The completion position No. output is set to 0 during movement of the actuator.

### Caution:

- (1) Set the period taken from entering position No. to turning CSTR ON to 6ms or larger. In spite of 6ms timer process in the PLC, commands may be input to the controller concurrently to cause positioning to another position. Take the scanning time in the PLC into account to set a period as 2 to 4 times as the scanning time. Set the value similarly if the PLC reads the complete position.
- (2) At the completion of positioning, positioning complete signal PEND is not turned ON if start signal CSTR remains ON. If this occurs, turn CSTR OFF then PEND is turned ON immediately. Therefore, create the sequence program so that turning PEND OFF makes CSTR turned OFF and the PLC waits for the state in which PEND is turned ON.
- (3) At the positioning to the position same as that specified in the stop (complete) position number, PEND is turned OFF once but moving signal MOVE is not turned ON. Therefore, use PEND to turn CSTR OFF.
- (4) MOVE turns ON at the start of an operation and PEND turns OFF at almost the same time. MOVE turns OFF when there is no more movement command existing. Therefore, in the normal stop, PEND turns ON after MOVE is turned OFF, however, when the positioning width setting is wide, PEND would turn ON even during an operation of the actuator.

# ERC**3**

#### Binary data

O : ON ● : OFF

Command position No.	PC256	PC128	PC64	PC32	PC16	PC8	PC4	PC2	PC1
Completed position No.	PM256	PM128	PM64	PM32	PM16	PM8	PM4	PM2	PM1
0	•	•	•	•	•	•	•	•	•
1	•	•	•	•	•	•	•	•	0
2	•	•	•	•	•	•	•	0	•
3	•	•	•	•	•	•	•	0	0
4	•	•	•	•	•	•	0	•	•
5	•	•	•	•	•	•	0	•	0
6	•	•	•	•	•	•	0	0	•
7	•	•	•	•	•	•	0	0	0
8	•	•	•	•	•	0	•	•	•
9	•	•	•	•	•	0	•	•	0
10	•	•	•	•	•	0	•	0	•
		:		:	:	:	:		:
509	0	0	0	0	0	0	0	•	0
510	0	0	0	0	0	0	0	0	•
511	0	0	0	0	0	0	0	0	0



# (2) Speed change during the movementSample use





The unit inserts nozzles into containers, injects liquid, and moves the nozzles upward so that they may not be contact with the liquid surfaces.

No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	150.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	0.00	50.00	0.20	0.20	0	0	100.00	0.00	0.00	0	0	0	0
3	0.00	100.00	0.20	0.20	0	0	0.10	0.00	5.00	0	0	0	0

#### Control method

The speed of the actuator can be changed while it moves. Positions are used by the number of speeds. The method of controlling the operation to each position is the same as that described in (1) Positioning.

The example below describes the case of 2 speeds:

- In this example, the speed is changed while the actuator moves from the position of 150mm to the position of 0mm. At first, set the positioning to the target position at the first speed in position No.2. In the positioning width, set the distance from the speed change position to the target position. The value is set to 100mm in the example. Thus, for position No.2, positioning complete signal PEND is turned ON at the position before the target position by 100mm.
- 2) Set the positioning to the target position at the second speed in position No.3.
- 3) Start position No.2. Then start position No.3 successively when PEND in position No.2 is turned ON. In normal positioning, position data specified later has always a priority over position data specified earlier. Thus, the operation in position No.3 is started on the way of the operation in position No.2.

In this example, the target positions No.2 and 3 are equal with each other. They may not be the same. However, setting the target positions to be equal with each other allows the distance from the speed change position to the target position to be known easily. To increase in the number of speed change steps, add a position number and operation sequence, set the speed change position in the positioning width and operate the actuator continuously.

# ERC**3**

# (3) Pitch Feeding (relative movement = incremental feed) ■ Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	100.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	25.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	1	0	0
í		•											

(Position No.2 sets pitch feed.)

#### Control method

- 1) The method of controlling pitch feed is the same as that described in (1) Positioning except the setting of the position table. Repeat the positioning of a specific position No.
- 2) For pitch feed, the position set in the position table indicates the pitch. Set the pitch (relative moving distance = incremental moving distance) in column "Position".
- 3) If the operation command is issued, the actuator moves from the current stop position by "Position" in the position table. To perform continuous movement, repeat the operation. Any accumulation error does not occur because the home position (coordinate value 0) is specified as the base point.

Caution: In the pitch feed, do not perform a command with a pitch smaller than the minimum encoder resolution (lead/encoder pulse number) or that less than positioning accuracy repeatability. There would be no deviation to occur even with the command because it is an operation command to the same position as the positioning complete condition, but the positioning control cannot be performed properly.

4.2 Operation in Positioner Mode 4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



Caution: (1) If the actuator reaches the software limit corresponding to the stroke end in the pitch feed operation, the actuator stops at the position and positioning complete signal PEND is turned ON.

(2) Note that, in pitch feed just after pressing operation (to be in the pressing state), the start position is not the stop position at the completion of pressing but the coordinate value entered in "Position" of the pressing position data. The movement to the base point is added to the first pitch feed.



- (3) If the position number for pitch feed is started (CSTR ON) during normal positioning, the actuator moves to the position of the coordinate resulting from adding the pitch feed distance to the target coordinate of the positioning. Repeating the start of pitch feed several times allows the pitch feed distance to be added to the target position by the number of repeats. Do not use the pitch feed function in such a way, because the PLC cannot confirm the complete position.
- (4) Note that, if pitch feed is started (CSTR ON) repeatedly during pause, the actuator moves continuously by the distance based on the number of starts. In such a case, cancel the remaining moving distance by turning reset signal RES to ON in the pause state or take interlock so that the start signal is not turned ON during pause.
- (5) At software limit (stroke end) in pitch feed, the actuator is decelerated to be stopped and positioning complete output PEND is output.
- (6) MOVE turns ON at the start of an operation and PEND turns OFF at almost the same time. MOVE turns OFF when there is no more movement command existing. Therefore, in the normal stop, PEND turns ON after MOVE is turned OFF, however, when the positioning width setting is wide, PEND would turn ON even during an operation of the actuator.
- (7) Pressing is enabled by using the pitch feed function. However, do not make control of changing to pitch feed on the way of normal positioning (before PEND turning ON). Pressing is interrupted by using the pitch feed function as soon as start signal CSTR is turned ON. The PLC cannot manage the position of the actuator any more.



- (4) Pressing operation
- Sample use



No.	Position [mm]	Velocity [mm/s]	ration [G]	ration [G]	Pressing [%]	old [%]	width [mm]	Zone+ [mm]	Zone- [mm]	Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	100.00	250.00	0.20	0.20	50	0	50.00	0.00	0.00	0	0	0	0
		- · ·											

(Position No.2 sets pressing operation.)

- Control method
  - The method of controlling the pressing operation is the same as that described in (1) Positioning except the setting of the position table. Any setting of "Pressing" in the position table allows the pressing operation to be done. "Positioning width" is assumed as pressing operation distance.
  - 2) The actuator moves at the setting speed and rating torque to the position of the coordinate set in "Position" in the similar way as normal positioning. Then the operation changes to pressing. The amount of movement during the pressing operation is the set value in "Positioning Width" and the pressing operation is executed with the torque (current limit value) in % set in "Pressing" in PIO Patterns 1 to 3 as the upper limit.
  - 3) The control method is the same as that in (1) Positioning. However, the processing of positioning complete signal PEND is different from that in (1) Positioning. PEND is output when the shaft is stopped by pressing (pressing complete). If the work is not subject to pressing (miss-pressing), the actuator moves by the value set in "Positioning width" to stop but PEND is not turned ON.



- Note 1 Set the period taken from entering the position number to turning CSTR ON to 6ms or longer. Because 6ms timer process on the PLC is also entered to the controller, positioning at another position may occur. Take the PLC scan time into account.
- Note 2 The completion position No. output is set to 0 during movement of the actuator.





#### Judging completion of pressing operation

The operation monitors the torque (current limit value) in percent in "Pressing" of the position table and turns pressing complete signal PEND ON when the load current satisfies the condition shown below during pressing. PEND is turned ON at satisfaction of the condition if the work is not stopped.

the work is not stopped. (Accumulated time in which current reaches pressing value [%]) – (accumulated time in which current is less than pressing value [%])  $\geq$  255ms (Parameter No.6)



Chapter 4 Operation



(5) Tension Operation



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	100.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	80.00	250.00	0.20	0.20	50	0	-50.00	0.00	0.00	0	0	0	0
3													



### Control method

The method of controlling the tension operation is the same as that described in (4) Pressing operation. The control method is explained below by using the sample position table shown above.

- Position No.2 indicates the settings of tension operation. The settings of "Position" and "Positioning width" show the tension start position and the tension quantity, respectively. Attach – (minus sign) to the tension quantity. Specify the upper limit of the torque required for tension in percent (current limit value) in "Pressing". The speed, acceleration, and deceleration are the conditions of positioning to the coordinate value (80mm) set in "Position".
- 2) Position No.1 indicates the tension start preparation position. Specify a value larger than the coordinate value at which the tension provided by position No.2 ends (80 50 = 30 mm) in "Position".



- 3) First define the positioning in position No.1. Next, the operation in position No.2 moves the actuator to the position of 80mm at the setting speed and rating torque and change to the tension operation. The actuator moves by 50mm in the negative direction in the tension operation. The upper limit of the tensile force is the torque set in percent.
- 4) In the similar way as pressing, the positioning complete signal is output when the shaft is stopped by tension (pressing complete). If the actuator cannot be stopped during movement within the setting positioning width (miss-pressing), it moves by the setting distance to stop but PEND is not turned ON.





No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	50.00	250.00	0.20	0.20	30	0	20.00	0.00	0.00	0	0	0	0
3	50.00	250.00	0.20	0.20	50	0	20.00	0.00	0.00	0	0	0	0
4													

### Control method

After pressing, the pressing pressure can only be changed in the pressing state. The method of controlling multi-step pressing is the same as that described in (4) Pressing operation. The control method is explained below by using the sample position table shown above.

- 1) Set the weak pressing (30%) in position No.2 and perform the pressing operation.
- If pressing complete signal PEND is turned ON, start the pressing operation with pressing pressure (50%) greater than the first pressure set in position No.3. The position data in position No.3 should be the same as that in position No.2 except the setting in "Pressing".
- 3) To add a pressing step with another pressing pressure, add a sequence consisting of a position number and a pressing operation.



ľ	7)	Teaching	by PIO	(MODE.	MODES.	PWRT	WEND	, JISL	JOG+	JOG-

			Input			Out	put				
FIO Signal	MODE	JISL	JOG+	JOG-	PWRT	MODES	WEND				
Other than pattern 1	×	×	×	×	×	×	×				
Pattern 1	0	0	0	0	0	0	0				
O: Existence of signal, ×: No signal											

(Note) It is the function available only in Pattern 1.

#### Teaching by PIO is enabled.

It is possible to select the teaching mode, move the actuator to the target position with jog or inching operation, and write the coordinate value into any position number.

#### I. Teaching Mode Selecting

- 1) To select the teaching mode, set teaching mode signal MODE to ON. If the teaching mode is selected, mode status signal MODES is turned ON.
  - While the actuator is operating, MODE signal input is invalid. Therefore, after the operation is completed, the MODES signal is turned ON.
  - With the MODES signal being ON, the CSTR signal is changed to teaching signal PWRT. Therefore, it is not possible to operate the actuator by specifying a position No.
- To cancel the teaching mode to return to the normal operation mode, set the MODE signal to OFF. If the MODE signal is turned OFF, the MODES signal is turned OFF to return to the normal operation mode.



- II. Jog/inching switch and jog input
  - Jog/inching switching signal JISL indicates whether the jog operation<sup>Note 1</sup> or inching operation<sup>Note 2</sup> is performed by the jog input signal.
    - JISL signal OFF ..... Jog operation
    - JISL signal ON ..... Inching operation
  - 2) There are two jog input signals, or JOG+ for operation in the positive direction and JOG- for operation in the negative direction.
- Note 1 Jog operation: The actuator is moved while the jog input signal is set to ON.
  - JOG+… While JOG+ is set to ON, the actuator is moved in the positive direction. If JOG+ is turned OFF, the actuator is decelerated and then stopped.
    - JOG- … While JOG- is set to ON, the actuator is moved in the negative direction. If JOG- is turned OFF, the actuator is decelerated and then stopped.
  - Velocity ...... Value set in Parameter No.26 "PIO jog speed".
  - Acceleration/Deceleration Rating acceleration/deceleration of actuator
  - Pause Signal \*STP ······ Enabled
- Note 2 Inching operation: Once the jog input signal is turned ON, the actuator is moved by a certain distance.
  - JOG+… Once JOG+ is turned ON, the actuator is moved by a certain distance in the positive direction.
  - JOG- … Once JOG- is turned ON, the actuator is moved by a certain distance in the negative direction.
  - Moving distance ...... Value set in Parameter No.48 "PIO inching distance".

  - Acceleration/Deceleration..... Rating acceleration/deceleration of actuator
    - Pause Signal \*STP ……… Enabled

4.2 Operation in Positioner Mode

4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



 Warning: (1) In home return incomplete state, software limit cannot stop the actuator. Take interlock and prohibit the operation or perform the operation carefully.
 (2) If the JISL signal is changed during inching operation, the inching being operated is continued. If JISL is changed during job operation, the jog is stopped.

III. Writing current data to position table

- 1) The feature is valid only when the teaching mode is selected (with the MODES signal being ON).
- 2) Specify the position number to which the current data is written in the binary data format in command position No.PC1 to PC32. Turn current value writing signal PWRT ON.
- The coordinate value of the current position is written into the position table for the controller. If position data is written previously, only the coordinate value in "Position" is only rewritten.

If nothing is written, the values set in the parameters below are written as the speed, acceleration/deceleration, positioning width, acceleration/deceleration mode and stop mode. Other data is set to "0".

- Velocity ······ Parameter No.8 "Default speed"
- Acceleration ······ Parameter No.9 "Default acceleration/deceleration"
- Deceleration ······ Parameter No.9 "Default acceleration/deceleration"
- Positioning width ..... Parameter No.10 "Default positioning width (in-position)"
- Acceleration/deceleration mode ··· Parameter No.52 "Default acceleration/deceleration mode"
- Stop mode ..... Parameter No.53 "Default stop mode"
- 4) At the completion of writing, controller write complete signal WEND is output. Then turn the PWRT signal OFF.
- 5) When the PWRT signal is turned "OFF" the WEND signal is also turned "OFF". Turn OFF PWRT after confirming WEND is turned ON.





# ERC**3**

#### Caution:

- (1) Set the period taken from entering position No. to turning the PWRT ON to 6ms or longer. In spite of 6ms timer process in the PLC, commands may be input to the controller concurrently to cause writing to another position. Take the scanning time in the PLC into account, set a period as 2 to 4 times as the scanning time.
- (2) Turning the PWRT signal ON in the state in which home return is not completed (the HEND signal is set to ON) causes alarm 093 "PWRT signal detected before completion of home return" to occur.
- (3) Turning PWRT signal OFF before turning WEND signal ON disturbs the proper data writing.
- (4) Writing processing with position table screen remaining open on a teaching tool such as PC cannot lead the data on the screen to be updated. To update and confirm writing data, take the following actions:
  - 1) PC software ···· Left-click the 💋 button.
  - 2) Teaching Pendant or Touch Panel Teaching ·· Change to user adjustment screen, input "4" in adjustment No. and return to the position table screen after software reset.

Check the relevant Instruction Manual for details of operation.

### (8) Pause and Operation Interruption (\*STP, RES, PEND, MOVE)

	Inp	out	Output			
PIO Signal	*STP	RES	PEND	MOVE		
Pattern 0 to 1	0	0	0	0		
Pattern 2 to 3	0	0	0	×		



O: Available, ×: Unavailable

4.2 Operation in Positioner Mode 4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



Control method

Pause is possible during movement. In addition, the remaining moving distance can be cancelled to interrupt the operation.

The pause signal is an input signal always set to ON. So, it is normally used to remain ON. Use this function for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- 1) If pause signal \*STP is turned OFF during operation of the actuator, the actuator is decelerated to a stop. The deceleration is defined by the value set in the position table.
- 2) During pause, moving signal MOVE is set to OFF but positioning complete signal PEND is not turned ON.
- If pause signal \*STP is returned to ON, the actuator continues the remaining movement. The acceleration is the value set in the position table.
- 4) Turning reset signal RES ON during pause (\*STP being OFF) allows the remaining movement to be canceled to interrupt the operation.



occur when a sequence program is created.

Note 1 Check the Chapter 7 Troubleshooting for details of alarms.



[7] Direct Position Specification (Solenoid Valve Mode 1) = Operation of PIO Pattern 4 The start signal is provided for every position number. Only turning ON the relevant input signal according to the table shown below allows the operation based on the data in the target position number to be performed. The operation mode is called the solenoid valve mode because solenoid valves can directly drive air cylinders.

At the completion of positioning, every completed position number is output as well as the positioning complete signal.

Positioning, pressing, and pitch feed are possible. Their control methods are the same as those of other patterns.

#### (1) Positioning [Basic] (ST1 to ST6, PE1 to PE6, PEND)

Position No.	Input	Out	tput
0	ST0	PE0	PEND
1	ST1	PE1	PEND
2	ST2	PE2	PEND
3	ST3	PE3	PEND
4	ST4	PE4	PEND
5	ST5	PE5	PEND
6	ST6	PE6	PEND

[Caution] • Speed change is not allowed during movement.

• If start signal ST\* is issued without home return, the home return operation is automatically done before the operation based on the data of the specified position number. When this specification is not desired, interlock by home return complete signal HEND is required.

#### Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0	0.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
1	70.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0



- Control method
  - 1) When start signal ST\* is turned ON, the actuator starts acceleration based on the data in the specified position table for positioning to the target position.
  - 2) For PIO converter, when the positioning is finished, the positioning complete signal PEND turns ON at the same time as Current Position No. PE\* of the commanded position.
  - 3) For PIO converter, turn OFF ST\* Signal once PEND Signal is turned ON.
  - 4) Current position No. PE\* and positioning completion signal PEND are turned ON if the remaining moving distance is entered into the positioning width zone. Once Current Position No. PE\* and PEND Signal are turned ON, they remain ON unless the start signal ST\* is turned ON or the servo is turned OFF. They would not turn off even out of the positioning width range. <sup>(Note 1)</sup>
  - Note 1 A switchover is available to INP (Setting 1) in Parameter No.39. PEND becomes an in-position signal that turns OFF out of the positioning width.



<u>∕</u> Caution:	(1)	If the ST* signal is turned ON for the position after completion of positioning, both the PE* and PEND signals remain ON (except the pitch feed operation).
	(2)	Both the PE* and PEND signals are set to ON in the positioning width zone. Accordingly, they may be turned ON under operation of the actuator if a large positioning width is set.
	(3)	<ol> <li>Interlock should be taken so that two or more ST* signals are set to ON simultaneously.</li> <li>Entering the ST* signal of another position during positioning is invalid. If the ST* signal of another position is turned ON during positioning, the operation is terminated after the completion of the positioning being operated.</li> <li>Entering the ST* signal of another position with the ST* signal of the current position remaining ON after the completion of positioning allows the positioning to the other position to be executed.</li> </ol>
	(4)	If Parameter No.27 "Move command type" is set to "0" (factory setting), turning ST* OFF during positioning caused the operation to be interrupted.

4.2 Operation in Positioner Mode 4.2.3 Operation in Positioner Mode 2 (Operation Using PIO Converter)



# (2) Pitch Feeding (relative movement = incremental feed)■ Sample use



(Position No.2 sets pitch feed.)

- Control method
  - 1) The method of controlling pitch feed is the same as that described in (1) Positioning except the setting of the position table. Repeat the positioning of a specific position No.
  - 2) For pitch feed, the position set in the position table indicates the pitch. Set the pitch (relative moving distance = incremental moving distance) in column "Position".
  - 3) If the operation command is issued, the actuator moves from the current stop position by "Position" in the position table. To perform continuous movement, repeat the operation. Any accumulation error does not occur because the home position (coordinate value 0) is specified as the base point.



# erc3

#### Caution:

- (1) Because pitch feed is repeated, turning ON the ST\* signal of the same position after completion of positioning causes both the PE\* and PEND signals to be turned OFF at operation start and turned ON again at completion of positioning in the same way as (1) Positioning.
- (2) If the actuator reaches the software limit (stroke end) in pitch feed, the actuator is decelerated to be stopped and current position No. PE\* and positioning complete signal PEND are turned ON at the stop position.
- (3) Both the PE\* and PEND signals are set to ON in the positioning width zone. Accordingly, they may be turned ON under operation of the actuator if a large positioning width is set.
- (4) Interlock should be taken so that two or more ST\* signals are set to ON simultaneously.
  - Entering the ST\* signal of another position during positioning is invalid. If the ST\* signal of another position is turned ON during positioning, the operation is terminated after the completion of the positioning being operated.
  - Entering the ST\* signal of another position with the ST\* signal of the current position remaining ON after the completion of positioning allows the positioning to the other position to be executed.
- (5) If Parameter No.27 "Move command type" is set to "0" (factory setting), turning ST\* OFF during positioning caused the operation to be interrupted.
- (6) Note that, when Parameter No.27 "Move command type" is set to "1", starting (ST\* ON) pitch feed repeatedly during pause causes the actuator to be moved successively by the number of starts. If this situation is supposed, cancel the remaining moving distance by turning reset signal RES ON in the pause state or take interlock so that start signals are not turned ON during pause.
- (7) The pressing operation is enabled by using the pitch feed function.
- (8) In the pitch feed, do not perform a command with a pitch smaller than the minimum encoder resolution (lead / encoder pulse number) or that less than positioning accuracy repeatability.

There would be no deviation to occur even with the command because it is an operation command to the same position as the positioning complete condition, but the positioning control cannot be performed properly.



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	100.00	250.00	0.20	0.20	50	0	50.00	0.00	0.00	0	0	0	0

(Position No.2 sets pressing operation.)

- Control method
  - The method of controlling the pressing operation is the same as that described in (1) Positioning except the setting of the position table. Any setting of "Pressing" in the position table allows the pressing operation to be done. "Positioning width" is assumed as pressing operation distance.
  - 2) The actuator moves at the setting speed and rating torque to the position of the coordinate set in "Position" in the similar way as normal positioning. The operation is executed with the value set in "Positioning width" for the amount of movement in the pressing operation, and the torque (current limit) set in % in "Pressing" for the pressing operation as the upper limit.
  - 3) The control method is the same as that in (1) Positioning. However, the processing of positioning complete signal PEND is different from that in (1) Positioning. PEND is output when the shaft is stopped by pressing (pressing complete). If the work is not subject to pressing (miss-pressing), the actuator moves by the value set in "Positioning width" to stop but PEND is not turned ON. The current position No. PE\* is turned ON at the completion of pressing and even in miss-pressing.





#### Judging completion of pressing operation

The torque (current limit value) set in % in "Pressing" in the position table, and turns ON the pressing complete signal PEND when the load current reaches the following condition. PEND is turned ON at satisfaction of the condition if the work is not stopped. It is the same for PE\*.

(Accumulated time in which current reaches pressing value [%]) – (accumulated time in which current is less than pressing value [%])  $\geq$  255ms (Parameter No.6)



Chapter 4 Operation


(4) Tension Operation





No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	100.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	80.00	250.00	0.20	0.20	50	0	-50.00	0.00	0.00	0	0	0	0
3													





# Control method

The control logic for the pulling operation of PIO converter is as same as the one for (3) Pressing operation. The control method is explained below by using the sample position table shown above.

- Position No.2 indicates the settings of tension operation. The settings of "Position" and "Positioning width" show the tension start position and the tension quantity, respectively. Attach – (negative sign) to the tension quantity. Specify the upper limit of the torque required for tension in percent (limited current value) in "Pressing". The speed, acceleration, and deceleration are the conditions of positioning to the coordinate value (80mm) set in "Position".
- Position No.1 indicates the tension start preparation position. Specify a value larger than the coordinate value at which the tension provided by position No.2 ends (80 – 50 = 30mm) in "Position".



- 3) First define the positioning in position No.1. Next, the operation in position No.2 moves the actuator to the position of 80mm at the setting speed and rating torque and change to the tension operation. The actuator moves by 50mm in the negative direction in the tension operation. The upper limit of the tensile force is the torque set in percent.
- 4) In the similar way as pressing, the positioning complete signal is output when the shaft is stopped by tension (pressing complete). If the actuator cannot be stopped during movement within the setting positioning width (miss-pressing), it moves by the setting distance to stop but PEND is not turned ON. The current position No. PE\* is turned ON at the completion of pressing and even in miss-pressing.

 Caution: (1) The speed during tension operation is set in Parameter No.34. The pressing operation speed is 20mm/s. Do not set any value larger than the value in the list. If the speed setting in the position table is below this set value, pressing is performed with the set speed.
 (2) The tension ready position should be the tension start position or forward. If not, the moving direction varies depending on the start position to be dangerous.

The tension operation from a coordinate (less than 30mm = 80 - 50 in the above example) located before the end position (30mm) changes to the pressing operation from the current position to the tension end position. Note that the tension operation after positioning to the position of 80mm does not take place.



(3) The work is pulled also after completion of the tension. The work is drawn back or pulled further if the work is moved. When the work is drawn back before the approach position, alarm code 0DC "pressing operation range over error" occurs to stop the work. When the work is moved in the tension direction and the load current becomes less than the current limit value (pressing in percent), PEND is turned OFF. The work reaches the tension moving distance set in "Positioning width" to cause miss-pressing.



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0													
1	0.00	250.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	50.00	250.00	0.20	0.20	30	0	20.00	0.00	0.00	0	0	0	0
3	50.00	250.00	0.20	0.20	50	0	20.00	0.00	0.00	0	0	0	0
4													

#### Control method

For PIO converter, it is available to change only the pressing pressure after performing the pressing operation once and while keeping the pressing.

The method of controlling multi-step pressing is the same as that described in (3) Pressing operation.

- 1) Set the weak pressing (30%) in position No.2 and perform the pressing operation.
- 2) If pressing complete signal PEND is turned ON, start the pressing operation with pressing pressure (50%) greater than the first pressure set in position No.3. In this particular operation, turn ON ST3 after completion of ST2, and turn OFF ST2 when PEND is turned OFF. In usual case, do not turn ON two or more ST\* signals simultaneously. The position data in position No.3 should be the same as that in position No.2 except the setting in "Pressing".
- 3) To add a pressing step with another pressing pressure, add a sequence consisting of a position number and a pressing operation.



(6) Pause and Operation Interruption (ST\*, \*STP, RES, PE\*, PEND)

Pause is possible during movement. In this mode, the following two methods are possible for pause.

1) Use of pause signal \*STP

Turning reset signal RES ON during the pause allows the remaining moving distance to be cancelled to interrupt the operation.

- 2) Use of start signal ST\* This method is valid when Parameter No.27 "Move command type" is set to "0" (factory setting). The actuator can only be moved while the ST\* signal is set to ON and stopped if ST\* is turned OFF. Since setting the ST\* signal to OFF is assumed as interrupt of operation, the remaining moving distance may not be cancelled.
- I. Use of pause signal \*STP



Control method

The pause signal is an input signal always set to ON. So, it is normally used to remain ON. Use this function for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- If pause signal \*STP is turned OFF during operation of the actuator, the actuator is decelerated to a stop. The deceleration is defined by the value set in the position table.
- During pause, current position No. PE\* and positioning complete signal PEND are not turned ON.
- If pause signal \*STP is returned to ON, the actuator continues the remaining movement. The acceleration is the value set in the position table.
- 4) Turning reset signal RES ON during pause (\*STP being OFF) allows the remaining movement to be canceled to interrupt the operation.



ME0297-14E



II. Use of start signal ST\*

FRE



Control method

For PIO converter, it is available to pause the operation if turning OFF the start signal ST\* during the operation.

Use the control method for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- 1) If the ST\* signal is turned OFF during movement, the actuator is paused. The deceleration is the value set in the position table.
- 2) Turning the ST\* signal OFF causes the positioning to be interrupted and deemed complete signal PEND to be turned ON.
- If the ST\* signal is turned ON again, the remaining movement is continued. The acceleration is the value set in the position table.





[8] Direct Position Specification (Solenoid Valve Mode 2)= Operations of PIO Pattern 5 in PIO Converter

The start signal is provided for every position number. By only turning ON the input signal corresponding to the 3-point positioning position, an operation becomes available with the data of the target position number. The operation mode is called the solenoid valve mode because solenoid valves can directly drive air cylinders. At invasion of the actuator into the positioning width set for each position, the output signal is turned ON in the operation of any position number or manual operation of the actuator in servo OFF status as if a sensor were installed.

Positioning and speed change during operation are possible. Their control methods are the same as those of other patterns.

Caution: This pattern does not allow pressing and pitch feed.

(1) Home return (ST0, HEND)

For PIO converter, the PIO input and output for the position numbers before the home return operation is changed as shown below;

Position No.	Input	Output
0	ST0	LS0
1	$ST1 \Rightarrow JOG+$	LS1
2	$ST2 \Rightarrow Disable$	$LS2 \Rightarrow Disable$

After a home-return operation, while the start signal ST0 is ON, home-return operation and the start signal ST1 work as the function of JOG+. By using this function, move the actuator to a position at which home return can be done safely. The speed of ST1 is the home return speed. After the home return is fully prepared, turn the ST0 signal ON to start the home return. At the completion of the home return, home return complete signal HEND is turned ON. Turn the ST0 signal OFF if HEND is turned ON. HEND remains ON unless the home is lose due to occurrence of an alarm.

If a certain home positioning precision is required, Set "Position" of position No.0 to 0 mm and the ST0 signal is not changed by the HEND signal to remain ON. After the home return is completed, positioning is provided for position No.0. [Refer to (3) Positioning in this section.]





[Operation of Slider Type/Rod Type Actuator]



1) With the ST0 signal being ON, the actuator moves toward the mechanical end at the home return speed.

The movement speed is 20mm/s.

2) The actuator is turned at the mechanical end and stopped at the home position. The moving distance is the value set by Parameter No.22 "Home return offset level".

Caution: In the home reverse specification, the actuator moves in the reverse direction. Make sure to refer to 6.3.1 [2] (15) when a change to Parameter No.22 "Home return offset level" is required.

(2) Features of LS signals (LS0 to 2)

The LS\* signals are not complete signals for positioning commands such as those for other PIO patterns. Despite the specified position No., the corresponding LS\* signal is turned ON when the actuator is entered into the setup value range as if the actuator were detected by a sensor installed.

(Example) The figure below shows the position table and the position at which each of the LS signals is turned ON. If the actuator passes any of the positioning widths in the operation by another position number or manual operation in the servo OFF state, the relevant LS signal is always turned ON.



4.2 Operation in Positioner Mode



# (3) Positioning [Basic] (ST0 to ST2, LS0 to LS2)

1.50
LOU
LS1
LS2

[Caution] Pressing and pitch feed are unavailable.

#### Sample use



No.	Position [mm]	Velocity [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0	0.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
1	70.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0

#### Control method

- When start signal ST\* is turned ON, the actuator starts acceleration based on the data in the specified position table for positioning to the target position. Turning the ST\* signal OFF on the way causes the actuator to be decelerated and stopped. So, make the ST\* signal remain ON until the actuator reaches the target position.
- 2) At the completion of positioning, position detection output LS\* of the specified position is turned ON.
- 3) Position detection output LS\* is turned ON if the remaining moving distance enters into the positioning width. LS\* is set to ON if the current position is located within the positioning width zone or OFF if the current position is located out of the positioning width zone (the same situation occurs in the servo OFF status).
- 4) Leave the ST\* signal to be ON until the actuator is moved to another position and turn OFF it at the next ST\* signal. If the ST\* signal is turned OFF at the LS\* signal, the actuator is decelerated to a stop in the positioning width and thus the actuator may not reach the target position. In continuous operation, turn ON the next ST\* signal by setting the positioning width within the required precision range or setting the period taken from detection of the LS\* signal to reaching the target position.



 $\Delta t$ : Time required to certainly reach the target position after the position sensing output LS1 or 2 is turned ON.

[Example of stop position when the ST\* signal is turned OFF by the LS\* signal] If the positioning width is set at a position before the original deceleration start position, the actuator cannot reach the target position.





# (4) Speed change during the movement

Sample use





The unit inserts nozzles into containers, injects liquid, and moves the nozzles upward so that they may not be contact with the liquid surfaces.

No.	Position [mm]	Velicoty [mm/s]	Accele- ration [G]	Decele- ration [G]	Pressing [%]	Thresh- old [%]	Positioning width [mm]	Zone+ [mm]	Zone- [mm]	Acceleration/ Deceleration mode	Incre- mental	Transported load	Stop mode
0	0.00	100.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0
1	0.00	50.00	0.20	0.20	0	0	100.00	0.00	0.00	0	0	0	0
2	150.00	200.00	0.20	0.20	0	0	0.10	0.00	0.00	0	0	0	0

#### Control method

The speed of the actuator can be changed while it moves. The operation control method is the same as that in (3) Positioning. This pattern prioritizes the start signal specified later over the previous signal. Accordingly if another position No. is started during operation, then the new operation begins. This can be used to change the speed.

- In this example, the speed is changed while the actuator moves from the position of 150mm to the position of 0mm. At first, set the positioning to the target position at the first speed in position No.1. In the positioning width, set the distance from the speed change position to the target position. The value is set to 100mm in the example. Thus, for position No.1, position sensing signal LS1 is turned ON at the position before the target position by 100mm.
- 2) Set the positioning to the target position at the second speed in position No.0.
- 3) Then start position No.1 (ST1 signal) and use position sensing output signal LS1 of position No.1 to start position No.0 (ST0 signal). Since this pattern prioritizes the signal specified later over the previous signal, the operation of No.1 is changed to the operation of No.0 during the operation of No.1.
- 4) Use position sensing signal LS0 of position No.0 to turn the ST1 signal OFF.

In this example, the target positions No.0 and 1 are equal with each other. They may not be the same. However, setting the target positions to be equal with each other allows the distance from the speed change position to the target position to be known easily.

Depending on the timing when the actuator accepts the input signal, the speed change may be delayed a little. Changing the positioning width can adjust the timing.





FRL



#### (5) Pause and Operation Interruption (ST\*, LS\*)

Turning start signal ST\* OFF allows the actuator to be paused while it is moved. To restart it, turn the same ST\* signal ON.



Control method

If start signal ST\* is turned OFF during movement, the actuator can be paused. Use the control method for interlock in case where an object is invaded into the moving direction of the actuator being moved.

- 1) If the ST\* signal is turned OFF during movement, the actuator is decelerated to a stop. The deceleration is the value set in the position table.
- 2) If the ST\* signal is turned ON again, the remaining movement is continued. The acceleration is the value set in the position table.



 $\bigcirc$  · Valid function



# 4.3 Operation in Pulse Train Control Mode (How to Operate Pulse Train Control Type)

In Pulse Train Mode, the actuator can be operated by the pulse train output of the host controller (PLC) positioning control function.

An operation in Pulse Train Control Mode is available when ERC3 is the pulse train control type (model code: PLN/PLP).

It is available to select 2 types of PIO patterns with different supportive functions by parameters. This operation mode is not to be changed after the system is complete to be established or during an operation. Select the PIO pattern considering the system operation specifications in advance and design the wiring layout and operational sequence.

Caution:	In Pulse Train Control Mode, the input pulse.	e operation is performed corresponding to the
	Input Pulse Value	$\Rightarrow$ Moving distance
	Input pulse frequency	$\Rightarrow$ Velocity
	Change in Input Pulse Frequency	$y \Rightarrow$ Velocity change and acceleration/deceleration
	Do not use the actuator above the movement amount, acceleration Doing so may cause an abnorm	he specifications for the commands of the and deceleration from the host controller (PLC). al noise or malfunction.

#### [1] Guideline for PIO Pattern Selection and Supportive Functions

	PIO Pattern (Parameter No.25)	0	1
	Mode	Positioning mode	Pressing mode
υD	Dedicated home return signal	0	0
i i č	Brake control function	0	0
nct o	Torque limiting function		0
Sup Fu	Position-command primary filter function	0	0

## [2] Guideline for Supportive Functions

Function	Description
Dedicated home return signal	When this function (signal) is used, home return can be performed without using a complex sequence or an external sensor, etc.
Brake control function	Since the controller controls the brake, there is no need to program a separate sequence.
Torque limiting function	The torque can be limited (a desired limit can be set by a parameter) using an external signal. When the torque reaches the specified level, a signal will be output. This function (signal) permits pressing and press fitting operations.
Position-command primary filter function	Soft start and stop can be achieved even when the actuator is operated in the command-pulse input mode where acceleration and deceleration are not considered.

FRE



This is a signal to compulsorily release the brake of the actuator equipped with a brake. The brake in the actuator is a non-excitation operation type electromagnetic brake. In a normal operation, it automatically releases the brake with the servo ON and gets to the brake operating status with the servo OFF.

There may be a case that the brake needs to be released to move the slider or rod manually by hand when installing the unit to the system or having a direct teach<sup>\*1</sup>. In such cases, turn this signal ON. The brake can be released while signal is turned ON.

\*1 Direct teach : This operation is intended to get coordinate values to the position by moving the slider and/or the rod by hand.

Narning:	(1)	Take sufficient care to release the brake. Inappropriate brake release may cause people to be injured and/or the actuator, the work and/or the machine to be damaged. After the brake is released, always make the brake applied again. Any operation with the brake remaining released is extremely dangerous. The slider or rod may drop to cause people to be injured and/or the actuator,
	(3)	the work and/or the machine to be damaged. Make certain that this signal is turned OFF (brake is activated) when the power is supplied to the controller. Leaving the power ON may cause a drop of the slider or rod, results in an injury or damage of the actuator unit, work piece or devices.



[5] Time Constant for Control Signal Input

The input signals of this controller incorporate an input time constant to prevent malfunction due to chattering, noise, etc. Make sure to input the signals continuously for 6ms or more. (Note) Command pulse train inputs (PP•/PP, NP•/NP) do not have input time constants. Also, it is necessary to input 16ms or more for CSTP Signal.



# [6] Operation Ready and Auxiliary Signals

#### (1) Servo ON (SON, SV, INP)

	Input	Out	tput	
FIO Signal	SON	SV	INP	

- 1) Servo ON signal SON is the input signal making the servo motor of the actuator operable.
- 2) If the servo-on is performed to enable operation, the SV output signal is turned ON. Concurrently positioning completion signal INP is turned ON.
- 3) With the power being supplied, then controller cannot be operated while the SV signal remains OFF. If the SON signal is turned OFF under operation of the actuator, the actuator is decelerated and stopped with the maximam torque. After the stop, the servo OFF occurs to enter the motor into the free running state.

If the actuator is equipped with a brake, the brake gets in the operational condition. The brake (option) is of release-in-excitation type. Therefore, making the servo ON will release the brake while making it OFF will lock the brake.

If the deviation clear is set to valid (setting: 0, setting at delivery: 1 = invalid) in Parameter No.58 at this time, the deviation counter gets reset.

- Servo OFF status
- 1. Once the actuator stops, no retaining torque will be supplied.
- 2. The pulse train input, HOME (home return signal), TL (torque-limiting selection signal) and CSTP (external forced stop signal) are all ignored.
- 3. Output signals SV (ready signal), HEND (home return complete signal) and TLR (torque limiting signal) are all cleared (turned OFF).
- INP (Positioning Completion Signal) The INP (Positioning Completion Signal) is OFF when the servo is OFF.



- + 12) × Number of time (T3)
- T (after detecting excitation) = SON signal identification (6ms) + Servo ON delay time (T3)
- T1 : Parameter No.30 It differs depending on the setting of excitation detection type. Set Value = 0  $\rightarrow$  160ms Set Value = 1, 2  $\rightarrow$  220ms
- T2 : Parameter No.29 Setting of excitation phase signal detection time It is set to 10ms in the initial setting.
- T3 : Fixed to 20ms
- (Note) Excitation detection operation of the motor is conducted at the first servo-on after the power is turned ON.



#### (2) Home Return (HOME, HEND)

	Input	Output
PIO signal	HOME	HEND

The HOME signal is intended for automatic home return.

When the HOME signal is turned ON, the command will be processed at the leading edge (ON edge) of the signal and the actuator will perform home return operation automatically. Once the home return is completed, the HEND (home return completion) signal will turn ON. Set the home (enter "0") in the current value register of the host controller (PLC) using the current value preset function, etc., when the HOME signal turns ON.

#### Caution:

- (1) The HOME signal is given priority over any pulse train command. Even when the actuator is moving with a pulse train command, it will start home return once the HOME signal is turned ON.
- (2) The HOME signal is processed only at the leading edge (ON edge) of the signal.
- (3) If the SON signal is turned OFF or an alarm is detected during home return, the home return operation will stop. If the servo is turned OFF, the home return command will be cancelled even when the HOME signal remains ON. To perform home return again, therefore, turn the HOME signal OFF and then turn it ON again.
- (4) The actuator can be operated without using this function. If this function is not used, however, management of position data will solely be dependent on the host controller (monitoring soft stroke limit is effective in the home return complete status). Therefore, take the necessary measures to prevent an over-stroke, such as not sending pulse commands with travel distances exceeding the effective stroke or providing external limit switches for stroke end detection, etc., to forcibly stop the actuator.
- (5) By turning the servo OFF or having the deviation counter cleared, HEND turns OFF. Perform home return again.

[Operation of Actuator]



1) With the HOME signal being ON, the actuator moves toward the mechanical end at the home return speed.

The movement speed is 20mm/s.

2) The actuator is turned at the mechanical end and stopped at the home position. The moving distance is the value set by Parameter No.22 "Home return offset level".

Caution: In the home reverse specification, the actuator moves in the reverse direction. Make sure to refer to 6.3.1 [2] (15) when a change to Parameter No.22 "Home return offset level" is required.



#### (3) Alarm, Alarm Reset (\*ALM, RES)

	Input	Output
PIO signal	Input RES	*ALM

- 1) Alarm signal \*ALM is set to ON in the normal status but turned OFF at the occurrence of an alarm <sup>(Note 1)</sup> at a level equal to or higher than the operation release level.
- 2) Turning reset signal RES ON under occurrence of an alarm at the operation release level allows the alarm to be released. The action is taken at the rising edge (ON edge).

Note 1 Check the Chapter 7 Troubleshooting for details of alarms.

▲ Caution: The alarm reset should be done after the cause of the alarm is confirmed and removed. If alarm reset and restart are repeated many times without removal of the cause, a severe failure such as motor burnout may occur.



- [7] Pulse Train Input Operation
  - (1) Command Pulse Input (PP•/PP, NP•/NP)

In the differential type, it is able to have 200kpps of pulse train input at maximum. If the host controller is an open collector pulse output type, it is able to input the pulse of 60kpps at the maximum by connecting AK-04 (option).

6 types of command pulse train can be selected. Set the pulse train format in Parameter No.63 and active high/low in Parameter No.64. [Refer to 4.3 [8] Settings of Basic Parameters Required for Operation]

Caution:

- (1) The directions in which the actuator moves upon receiving forward and reverse pulses conform to the "pulse count direction" set in Parameter No.62.
- (2) As for the forward/reverse directions, pay attention to the host controller setting or PP•/PP and NP•/NP connections.
- (3) Set the actuator acceleration/deceleration on the host controller side.
- (4) The actuator acceleration/deceleration should not exceed the rated
  - acceleration/deceleration of the applicable actuator. [Refer to 1.2.1 Actuator.]
    \* The rotating direction of the motor is defined so that the CCW direction as viewed from the end of the load shaft represents the forward direction. (For a standard type actuator, the move is to the motor end.)

	Command Pulse String Mode	Input Terminal	In Normal Rotation	In Reverse Rotation
	Normal Rotation Pulse String PP•/PP			
	Reverse Rotation Pulse String	NP•/NP		
	The normal rotation reverse rotation puls	pulse string sl se string show	hows the motor rotation amount i s the motor rotation amount in re	in normal direction, and verse direction.
Logic	Pulse Train	PP•/PP	·	
jative	Symbol	NP•/NP	Low	High
Neg	The command pulse rotation direction.	e shows the m	otor rotation amount and the com	nmand symbol shows the
	A/B Phase	PP•/PP		
	Pulse String NP•/N			<u>+</u> +++
	It is the pulse input of amount and the dire	of A/B-phase c ction of revolu	of 90° phase difference multiplied tion.	by 4, and indication of the
	Normal Rotation Pulse String	PP•/PP		
gic	Reverse Rotation Pulse String	NP•/NP		
ive Lo	Pulse Train	PP•/PP		
Posit	Symbol	NP•/NP	High	Low
	A/B Phase	PP•/PP		
	Puise String	NP•/NP		





#### Caution:

- Set the acceleration/deceleration speed not to exceed the maximum acceleration/deceleration speed of the actuator. An operation with exceeding condition may cause a malfunction.
- Consider the electric gear ratio of the host side and that of the controller side via the following calculation.
- (2) Position complete INP

PIO signal	Output
	INP

This signal will turn ON when the remaining travel pulses (accumulated pulses) on the deviation counter enters the positioning width.

When the servo is ON, this signal turns ON when the accumulated pulses on the deviation counter are within the number of pulses set in Parameter No.10 "Default positioning width". This signal is OFF while the servo is OFF.

#### Caution:

- This signal will turn ON when the servo turns ON (because positioning is executed at the current position where the servo is ON).
- Since this signal turns ON only with the deviation (servo lag pulses), it could turn ON even during an operation (even if positioning is not completed) when operating in low speed and getting into the positioning width range if the setting of Parameter No.10 "Positioning width initial setting" is too wide. Also, even when the deviation is in this range, the signal turns OFF when there is a change to the command pulse in 1ms. Therefore, if operating with a command of 1kpps or less, INP may repeatedly turn ON and OFF.



#### (3) Torque Limit Select (TL, TLR)

	Input	Output		
PIO signal	Input Output TL INP→TL ction available only in Patter	INP→TLR		
(Note ) TLR is the functi	function available only in Pattern			

The torque limit signal TL is a signal that limits the torque for the motor. While this signal is ON, the actuator thrust can (motor torque) can be limited at the torque that was set in Parameter No.57 "Torque limit".

While TL Signal is ON, the positioning complete signal INP becomes the torque limiting signal TLR and turns ON when the motor torque gets to the torque limit value set in Parameter No.57.

The TL signal is disabled during home return or forced stop.

Â	Caution:	

Do not turn the TL signal OFF while the TLR signal is ON.

Large deviation (servo lag pulses) may be created while in torque limit (TL Signal is ON). (For example, the actuator may receive a load just like it receive a pressing force in pressing operation and therefore become no longer operable). If TL Signal is turned OFF under this condition, the operation may be started with the maximum torque at the same time, and make a sudden move. After turning TLR signal ON, perform an operation in the reversed way to confirm TLR signal turns OFF. If the condition is difficult for the reversed movement, turn the servo OFF or clear the deviation counter (by turning DCLR ON).

#### (4) Deviation Counter Clear DCLR

	Input	
PIO signal	RES→DCLR	

It is a function that can be selected only in Pattern 1

This is the signal to clear the deviation counter that stores the specified pulse until its process is completely finished (positioning is completed) once a command pulse is input. While TL Signal is ON, the reset signal RES becomes the deviation counter clear signal DCLR.

It is used when the deviation is desired to be cleared after the pressing by TL signal is complete (TLR signal ON). Once the deviation is cleared, TLR signal turns OFF and the condition can be made as it is positioned at the point where the pressing is complete.

Caution: DCLR signal is a signal that is processed at the startup (ON edge). Therefore, input the pulse train while DCLR signal is on and the actuator will operate. Turn this signal ON only when the deviation counter is to be cleared.



## [8] Settings of Basic Parameters Required for Operation

It is a mandatory parameter to perform an operation.

The parameters listed in the table below may only be set if the actuator performs only positioning operation.

Parameter No.	Parameter Name	Details
65	Electronic Gear Numerator	This parameter determines the unit travel distance of the
66	Electronic Gear Denominator	actuator per command pulse train input 1 pulse.
63	Command Pulse Mode	Specifies the command pulse train input mode.
64	Command Pulse Mode Input Polarity	Sets the type of active high/low of the specified pulse train

#### (1) Electronic Gear Setting

This parameter determines the unit travel distance of the actuator per command pulse train input 1 pulse.

User Parameter No.65/66	Electronic Gear Numerator/Denominator

Name	Symbol	Unit	Input Range	Initial Value (For reference)
Electronic Gear Numerator	CNUM	_	1 to 4096	2048
Electronic Gear Denominator	CDEN	-	1 to 4096	125

Determine the movement amount and calculate value for the electronic gear setting by following the formula below:

Linear Axis Unit Travel Distance = Min. Travel Distance Unit (1, 0.1, 0.01mm etc.) / pulse Rotary Axis Unit Travel Distance = Min. Travel Distance Unit (1, 0.1, 0.01deg. etc.) / pulse

Electronic Gear Formula: In the case of Linear Axis

Electronic Gear <u>Numerator (CNUM)</u> Electronic Gear Denominator (CDEN) = No. of Encoder Pulses<sup>(Note 1)</sup> [pulse/rev] Actuator Lead Length [mm/rev] × Unit Travel Distance [mm/pulse]

Note 1 The encoder pulse of ERC3 is 800pulse/rev.

Formula for velocity:

The velocity of the actuator can be figured out with the following formula. Velocity = Unit Travel Distance  $\times$  Input Pulse Frequency [Hz]



Examples of electronic gear calculations:

FRE

When operating ERC3 with 3mm lead length ball screw in 0.01 (1/100) mm of the movement per unit

(Encoder pulse of ERC3 = 800pulse/rev)



• Do not set the minimum movement unit out of the encoder resolution ability. If this setting is conducted, the actuator would not start moving until enough command pulse is stored in the encoder resolution error.

Encoder resolution [mm/pulse] = Ball Screw Lead Length [mm/rev] No. of Encoder Pluses [pulse/rev]

• Pay attention not to exceed the specification limit when setting the velocity, acceleration and deceleration.



## (2) Format Settings of Command Pulse Train

Set the command pulse train format in Parameter No.63 and active high/low in No.64.

#### I. Command Pulse Mode

User Parameter No.63 "Command Pulse Input Mode"

Name	Symbol	Unit	Input Range	Initial Value
Command Pulse Input Mode	CPMD	-	0 to 2	1

	Command Pulse Train Mode	Input Terminal	In Normal Rotation	In Reverse Rotation	Setting Value of Parameter No. 63
	Normal Rotation Pulse Train	PP•/PP	╶╅╎╅╎╅		2
	Reverse Rotation Pulse Train	NP•/NP		╶╴┥╶┥	2
	The normal rotation reverse rotation puls	pulse train sho se train shows	ows the motor rotation amount in the motor rotation amount in rev	normal direction, and erse direction.	
Logic	Pulse Train	PP•/PP			1
gative	Symbol	NP•/NP	Low	High	-
Neg	The command pulse rotation direction.	e shows the mo	otor rotation amount and the con	nmand symbol shows the	
	A/B Phase	PP•/PP		t t t	0
	Pulse Train	NP•/NP		t f t f	
	The A/B Phase 4-fol the rotation amount	d Pulse with th and direction.	ne phase difference of 90° shows	s the commands for	
	Normal Rotation Pulse Train	PP•/PP			2
gic	Reverse Rotation Pulse Train	NP•/NP			
ive Lc	Pulse Train	PP•/PP			1
Posit	Symbol	NP•/NP	High	Low	
	A/B Phase	PP•/PP			0
	Puise Traih	NP•/NP	• • • •	• • • •	

#### II. Command Pulse Mode Input Polarity

User Parameter No.64 "Command Pulse Input Mode Polarity"

Name	Symbol	Unit	Input Range	Initial Value
Command Pulse Input Mode CPMD Polarity		Η	0 to 1	0
Set Value				

Positive logic : 0

Negative logic : 1

Caution: Pay attention not to exceed the specification limit when setting the velocity, acceleration and deceleration.



Depending on systems and/or loads, set the following parameters if necessary.

#### (1) Position command primary filter time constant

No.	Name	Symbol	Unit	Input Range	Initial Value
55	Position command primary filter time constant	PLPF	msec	0.0 to 100.0	0.0

The acceleration/deceleration of the actuator can be set in S-shaped curve with this parameter setting. (It is not the S-shaped acceleration/deceleration function.)

If command pulse train is input at a certain frequency, the actuator is accelerated/decelerated slowly depending on the time constant.

The actuator moves by the number of command pulses.

Even if the host controller (PLC etc.) has no acceleration/deceleration function or the frequency of command pulses varies rapidly, the actuator can be accelerated/decelerated smoothly.

The delay in positioning stabilizing time requires approximately 3 times longer than the set value after the command pulse input stop. If the set value is 100ms, the stabilizing time would be approximately 300ms.



#### (2) Torque Limit

FRE

INO.	Name	Symbol	Unit	Range	Value
57	Torque Limit	TQLM	%	0 to 70	70

Set a desired torque limit used in the torque limit input signal TL, which is an external input signal.

Set the torque in % to the rated thrust (rated current).

[Refer to 1.2.1 [6] Current Limit Value and Pressing Force]

When the torque limit signal TL of the external input signal is turned ON, current limitation corresponding to the setting is applied.

When the torque current of the motor reaches the set value, the torque limiting signal TLR of the external output signal is output.

#### (3) Clearing deviation during servo OFF or alarm stop

No.	Name	Symbol	Unit	Input Range	Initial Value
58	Clearing deviation during servo OFF or alarm stop	FSTP	-	0 to 1	1

It can be selected whether to valid or invalid the deviation clear at the servo-off or an alarm stop.

0: Disable

1: Enable



#### (4) Error monitor during torque limiting

No.	Name	Symbol	Unit	Input Range	Initial Value		
59	Error monitor during torque limiting	FSTP	_	0 to 1	0		
Soloction can be made whether to enable/disable the metering of the deviation during torgue							

Selection can be made whether to enable/disable the motoring of the deviation during torque limiting (condition of TL signal being ON).

If it is set enabled, error can be issued when the deviation exceeds the specified value while in torque limiting.

0: Disable

1: Enable

#### (5) Deviation Counter Clear Input

No.	No. Name		Unit	Input Range	Initial Value
60	Deviation Counter Clear Input	FPIO	_	0 to 1	0

Selection can be made whether to enable/disable the deviation counter clear signal DCLR. 0: Enable

1: Disable

#### (6) Torque limit command input

No.	Name	Symbol	Unit	Input Range	Initial Value
61	Torque limit command input	FPIO	—	0 to 1	0

Torque control of the motor with the value set in Parameter No.57 Torque Control Value can be performed with PIO (TL Signal ON) from the host system. In this parameter, a choice can be made from using (activated) TL Signal (Torque Limiting Signal) and not using (deactivated) the signal.

If selected to be invalid, TL Signal (torque limit signal) becomes invalid.

0: Enable

1: Disable

#### (7) Pulse count direction

No.	Name	Symbol	Unit	Input Range	Initial Value
62	Pulse count direction	FPIO	-	0 to 1	Set individually

You can set the direction in which the motor turns according to command pulses.

0: Forward rotation

1: Reverse rotation

Chapter 4 Operation



# 4.4 Operation in MEC Mode 1 and 2 (Operation with PLC)

There are two types of operation modes in MEC Mode, 2-point stop and 3-point stop, and 2-point stop performs the same operation as of Single Solenoid while 3-point stop possesses a function of intermediate stop in addition to the operation same as that of Double Solenoid. ERC3 is controlled with PIO directly in MEC Mode 1 and via PIO Converter in MEC Mode 2, however, the operation method is the same for both modes. MEC Mode 2 is applicable for Simple Absolute Type.

In this mode, Quick Teach can be used. These teaching tools listed below are also able to be used. (1) MEC PC Software (2) Touch Panel Teaching

[1] Outline for Operation Patterns and Functions The settings for the operation patterns and operational conditions are to be established in a teaching tool. For the details, refer to each instruction manual.

Operat	ion Pattern	Overview		
Stopping at 2 points (2-point positioning)	[Single-solenoid mode] Movement by 1 input between 2 points	Air cylinder can perform a 2-point movement with the control same as when operating Single Solenoid. You can set the positions of the end point and start point. You can specify the moving speed and acceleration/deceleration.		
	[Double-solenoid mode] Movement by 2 input between 2 points	Air cylinder can perform a 2-point movement with the control same as when operating Double Solenoid.		
Stopping at 3 points (3-point positioning)	[3-point positioning] Movement by 2 input between 3 points	point. You can set the position of an intermediate point and perform positioning to the intermediate point. You can specify the moving speed and acceleration/deceleration.		



[2] Table for Operational Conditions (Position Table) and Positioning Complete Signal



1) to 6) = Parameter No.1 (Positioning width)

Operation Condition Table (Position Table)

			1)	2)	3)	4)	5)	6)	7)
Used PIO (input and output) Signal		Stop position	Position Spee	Speed	Acceleration	Acceleration Deceleration	on Push force	Push width	Energy- Saving
2-point stop	3-point stop		[mm]	[mm/s]	[G]	[G]	[%]	[mm]	Function
ST0 Note 1	ST0	Start point (Forward)	10.00	50.00	0.1	0.1	0	0	Enabled
_	ST0, ST1	Intermediate point (Intermediate)	50.00	50.00	0.1	0.1	70	1.00	Enabled
ST0 Note 1	ST1	End point (Backward)	100.00	50.00	0.1	0.1	0	0	Enabled

Note 1 ST0 for 2-point stop is end point move when it is ON, and start point move when OFF.

Note 2 The start point of SEP-PT is expressed as "Backward End Position", end point as "Forward End Position" and intermediate point as "Intermediate Position".

Position Detection Output and Positioning Complete Signal Content of the output signal is determined by the setting of the operation pattern (whether to use the pressing operation).

	Signal Name		Contents of Signals	Function
		LS0	Start Point Detection	The second s
Pressing Function	Not	LS1	End Point Detection	The same operation as of the sensor of the air cylinder is performed.
	used	LS2	Intermediate Point Detection	each target position set in Parameter No. 1. (Refer to the figure below.)
	Use	PE0	Start Point Positioning Complete	
		PE1	End Point Positioning Complete	It turns ON when the pressing or the positioning is complete. (It also turns ON even with a miss-operation.) It turns OEE with a movement signal to another point.
		PE2	Intermediate Point Positioning Complete	
HEND		HEND Home Return Completion		This signal is turned ON when the home return operation is completed. This signal will not exist when 3-point stop (3-point positioning) is selected as the operation pattern.

4.4 Operation in MEC Mode 1 and 2 (Operation with PLC)



- Position [mm] ········ It is the positioning stop point. The position from the origin is to be set. The positions must satisfy the following relationships: Start point < Intermediate point < End point</li>
   Speed [mm/s] ······· Set the velocity in the operation. Do not attempt to input a value more than the maximum velocity or minimum velocity <sup>(Note 1)</sup>. (Note 1) For the minimum speed, you can either check in "1.2.1 Actuator" or figure out from the formula below. Min. Speed [mm/s] = Lead Length [mm] / No. of Encoder Pluses / 0.001 [s]
- 3) Acceleration [G] ..... Set the acceleration for the startup.
- 4) Deceleration [G] ..... Set the deceleration (G) at which the actuator stops.



Caution: Setting the acceleration/deceleration (1) Do not attempt to establish the setting exceeding the rated acceleration/deceleration of the actuator. Failure to follow this may cause the life of the actuator to be shortened extremely.
<ul> <li>(2) If the actuator or work part receives impact or vibrates, lower the acceleration/deceleration. If the actuator is used continuously in such condition, the life of the actuator will drop significantly.</li> <li>(3) If the transferable weight is significantly smaller than the rated payload capacity,</li> </ul>
accelerations/decelerations greater than the rating may be set. You can shorten the cycle time this way, so contact IAI if you are interested. When contacting IAI, let us know the weight, shape and installation method of the work part as well as installation condition of the actuator (horizontal/vertical).
5) Push force [%]Set the push torque (current-limiting value) to be used in push-motion Instruction as a percent value. Increasing the current-limiting value increases the push force. If "0" is set, positioning Instruction is performed. [Refer to the 1.2.1 Actuator for the relation between the pressing force and current limiting value.]
6) Push width [mm] ······ Set the travel during push-motion Instruction. When push-motion Instruction is performed, the actuator moves at the speed and rated torque set as part of positioning information, just like normal positioning, until the remaining travel enters the range set here. Once the remaining travel enters this range, the actuator moves to the position set in 1) while pushing the load. How the actuator operates as it pushes the work part toward the end point, start point and intermediate point is illustrated below.







7) Energy-Saving Function ···· When Ecology is enabled, you can have the motor power (servo) turned off automatically upon elapse of a specified period to save power after completion of positioning. Set the applicable period beforehand using a parameter.

Parameter	Parameter name	Initial	Setting
No.		value	range
10	Auto servo OFF delay time [sec]	1	0 to 9999



[Auto motor power (Auto servo) OFF]

The motor power (servo) will turn off automatically upon elapse of a specified period after completion of positioning. When the next positioning command is issued, the motor power (servo) turns on automatically and positioning is performed. Since no holding current flows while the motor is at standstill, power consumption can be reduced.



[Statuses of position detection output signals when the push function is not used] Even when the motor power (servo) is turned off, as long as the actuator is positioned within the positioning band (parameter No.1) the start point detection signal LS0, end point detection signal LS1 or intermediate point detection signal LS2 will turn ON according to the applicable position, just like when a sensor is used. Accordingly, the position detection signal that has turned ON will remain ON after completion of positioning unless the actuator moves.

[Status of position complete signals when the push function is used] In push-motion Instruction, the motor power (servo) does not turn off automatically while the actuator is pushing the work part.

If the actuator has missed the work part, the motor power (servo) turns off automatically. Once the motor power (servo) turns off, a position complete status is lost. Accordingly, the push complete signal 0 PE0, push complete signal 1 PE1 and push complete signal 2 PE2 will all turn OFF regardless of the stop position.

Caution: No holding torque is applied in the auto servo OFF mode. Since the actuator will move in this condition if an external force is applied, pay due attention to contact and safety when setting any Instruction involving auto motor power (servo) OFF.



- [3] Power Supply and Emergency Stop Release
  - - 1) Supply the control power (CP, CP\_GND), first.
    - 2) Secondly, turn ON the motor power source (MP, MP\_GND) and the emergency stop signal EMG at the same time. Do not attempt to turn ON the emergency stop signal EMG prior to the motor power source.
      The controllers get into the serve on status by the emergency stop signal EMG being ON.

The controllers get into the servo-on status by the emergency stop signal EMG being ON. For an actuator equipped with a brake, the brake is released by the servo being turned ON.

- 3) If the emergency stop signal EMG turns OFF, the servo also turns OFF. Have the motor power (MP, MP\_GND) cut off at the same time. Do not attempt to cut off the motor power (MP, MP\_GND) prior to the emergency stop signal EMG being turned OFF. For an actuator equipped with a brake, the brake becomes in operation by turning the servo OFF.
- (2) MEC Mode 2 (CP24V, MPO, MPI, EMG(-)) ·· [Refer to 3.5.3 Circuit Diagram]
- 1) Supply the control power (CP24, GND), first.
- Secondly, turn ON the motor power source (MPO, MPI) and the emergency stop signal EMG(-) at the same time. Do not attempt to turn ON the emergency stop signal EMG(-) prior to the motor power source.

Have a jumper in advance between MPO and MPI for the built-in drive cutoff relay type. Turn ON the motor power supply (MPO and MPI) and the emergency stop signal EMG(-) at the same time for the externally mounted drive cutoff relay type.

The controllers get into the servo-on status by the emergency stop signal EMG(-) being ON. Also for an actuator equipped with a brake, the brake is released by the servo being turned ON.

 If the emergency stop signal EMG(-) turns OFF, the servo also turns OFF. Conduct a cutoff of the motor power supply (MP0 and MP1) at the same time.

Do not attempt to turn OFF the motor power supply (MPO and MPI) before the emergency stop signal EMG (-) is turned off for the externally mounted drive cutoff relay type. For an actuator equipped with a brake, the brake becomes in operation by turning the servo OFF.

Chapter 4 Operation



- T (before detecting excitation) = SON signal identification (6ms) + Excitation detection time (T1 + T2) × Number of retry (10 times Max.) + Servo ON delay time (T3) T (after detecting excitation) = SON signal identification (6ms) + Servo ON delay time (T3)
- T1 : Parameter No.36 It differs depending on the setting of excitation detection type. Set Value = 0  $\rightarrow$  160ms Set Value = 1, 2  $\rightarrow$  220ms
- T2 : Parameter No.35 Setting of excitation phase signal detection time It is set to 10ms in the initial setting.
- T3 : Fixed to 20ms
- (Note) Excitation detection operation of the motor is conducted at the first servo-on after the power is turned ON.
  - PEND would not turn ON if the pause signal \*STP is OFF.



[4] Brake release BK······ [Refer to 3.4.3 Circuit Diagram]

This is an input signal to compulsorily release the actuator brake with a function of MEC Mode 1. It is not equipped in MEC Mode 2. The brake compulsory release can be performed on the brake releasing switch mounted on the front panel of PIO Converter.

The brake in the actuator is a non-excitation operation type electromagnetic brake. In a normal operation, it automatically releases the brake with the servo on and gets to the brake operating status with the servo OFF.

There may be a case that the brake needs to be released to move the slider or rod manually by hand when installing the unit to the system or having a direct teach<sup>\*1</sup>. In such cases, turn this signal ON. The brake can be released while it is ON.

\*1 Direct teach : This operation is intended to get coordinate values to the position by moving the slider and/or the rod by hand.

Warning:	(1)	Take sufficient care to release the brake. Inappropriate brake release may cause people to be injured and/or the actuator, the work and/or the machine to be damaged.
	(2)	After the brake is released, always make the brake applied again. Any operation with the brake remaining released is extremely dangerous. The slider or rod may drop to cause people to be injured and/or the actuator, the work and/or the machine to be damaged.
	(3)	Make certain that this signal is turned OFF (brake is activated) when the power is supplied to the controller. Leaving the power on may cause a drop of the slider or rod, results in an injury or damage of the actuator unit, work piece or devices.

# [5] Time Constant for Control Signal Input

For the input signal for control of this controller, it is set to 6ms of input time constant to prevent an error operation due to chattering or noise from the next page and later.

Therefore, input each input signal for 6ms or more (Note) continuously. The signal cannot be identified if it is less than 6ms.





- [6] Operation when Operation Pattern is "2-Point Stop (2-Point Positioning)"
  - (1) Home Return (ST0, HEND, LS0, LS1, PE1) If the home-return operation is not performed with the operation panel, it will be performed with Movement Signal 1 to the first end point ST0. The actuator moves to the end point after home-return and then stops (for positioning).



- Note 1 If "Use Pressing Function" is selected in the initial setting, this signal becomes the end point positioning complete signal PE1.
- (2) Positioning Operation (ST0, LS0, LS1, PE0, PE1) Positioning is at the end point when Movement Signal 1 ST0 is ON, and goes back to start point (positioning) when it is OFF.



Note 1 If "Use Pressing Function" is selected in the initial setting and the positioning is performed, this signal becomes the positioning complete (LS0  $\rightarrow$  PE0, LS1  $\rightarrow$  PE1). If the operation pattern is "3-point stop (3-Point Positioning)"



#### (3) Pressing (ST0, PE0, PE1)

The actuator performs the pressing operation towards the end point when Movement Signal 1 ST0 is ON. The end point positioning complete signal PE1 turns ON after the pressing is completed.

When having a pressing (pulling) to the start point from the end position, turn OFF Movement Signal 1 ST0. The start point positioning complete signal PE0 will turn ON when the pressing (pulling) is complete.

In either case, even when the pressing is missed, each positioning complete signal PE0 or PE1 would turn ON.

Shown below is a time chart for when pressing to the end point.





- [7] Operation when Operation Pattern is "3-Point Stop (3-Point Positioning)"
  - (1) Home Return (ST0, LS0, LS1, PE0, PE1)

If Movement Signal 1 ST0 is ON, a stop (positioning) is made at the start point after a home-return operation. If a value other than the origin (= 0) is input, the positioning is conducted at the specified point after the home-return.

The end point movement signal 2 ST1 is invalid until the home-return complete.



Note 1 If "Use Pressing Function" is selected in the initial setting, this signal becomes the start point positioning complete signal PE0.


(2) Positioning Operation (ST0, ST1, LS0, LS1, LS2, PE0, PE1, PE2)
 Positioning is at the start point when Movement Signal 1 ST0 is ON, and at the end point when Movement Signal 2 ST1 is ON.
 When both ST0 and ST1 are ON <sup>(Note 1)</sup>, the positioning is at the intermediate point. If turning

the both S10 and S11 are ON (Note 1), the positioning is at the intermediate point. If turning the both signals OFF (Note 1) during the operation, the actuator decelerates and stops.



Note 1	ON and	OFF	can be	switched	over i	in the	initial	setting.
--------	--------	-----	--------	----------	--------	--------	---------	----------

		initial setting.
	Intermediate Point Indication Both ON	: Positioning at intermediate point
		when both ST0 and ST1 are ON, and
		decelerate and stop when both OFF
		during an operation.
	<ul> <li>Intermediate Point Indication Both OFF</li> </ul>	: Positioning at intermediate point
		when both ST0 and ST1 are OFF,
		and decelerate and stop when both
		ON during an operation.
~		

Note 2 If "Use Pressing Function" is selected in the initial setting and the positioning is performed, this signal becomes the positioning complete (LS0 to  $1 \rightarrow PE0$  to 1).



#### (3) Pressing (ST0, ST1, PE0, PE1, PE2)

Pressing movement to the end point is performed when Movement Signal 2 ST1 is ON. The end point positioning complete signal PE1 turns ON after the pressing is completed. Pressing towards the start point and intermediate point can be conducted by controlling Movement Signals 1 and 2 as the same as the ordinary positioning for the 3-point stop position (PE0 turns ON when pressing is complete at the start point and PE2 turns on when pressing is complete at the intermediate point).

Also, it is able to perform a pressing operation to the intermediate position towards the start point side. When going towards the start point side, the operation is a pulling operation, and when moving to the intermediate point, it is pulling operation if it is from the end point, and is pressing if from the start point.

Even if the pressing is missed, each positioning complete signal PE0, PE1 and PE2 will turn ON.

The diagram below is the time chart of the pressing operation in the movement towards the end point.

Caution: Even when the pressing is missed, each positioning complete signal will turn ON. If a detection of miss-pressing is required, set a large pressing band and judge with the timer.



# ERC**3**

# 4.5 Operation in MEC Mode 3 (Test Run with Quick Teach.)

# 4.5.1 Operation Panel Functions







## 4.5.2 Operations

### [1] Switches Used for Mode Selection (Auto ⇔ Manual)

When Switching to Manual Mode (Auto → Manual)	Manual mode Alarm Power 3pnt 2pnt Complete STOP POS NUM HOME MANUAL Auto	Press and hold MANUAL Button for 1 second or more and the mode changes to Manual Mode. When the mode is changed, a peep sound is made and the manual lamp turns ON.
When Switching to Auto Mode (Manual → Auto)	Manual mode Alarm Power 3pnt 2pnt Complete STOP POS NUM HOME MANUAL	Press and hold Auto Button for 1 second or more and the mode changes to Automatic Mode. When the mode is changed, a peep sound is made and the auto lamp turns ON.

## [2] Switch Used for Servo ON/OFF Operation

When Conducting Servo ON/OFF	Pos.adi			Press SERVO ON/OFF Button. Turn the servo ON and the Servo ON/OFF
Operation	-	-		amp turns ON and the lamp turns OFF
(Valid in Manual	SERVO	JOG	JOG	when the servo is turned OFF.
Mode)	ON/OFF	-	+	

## [3] Switch Used for Home-Return Operation

When Conducting Home Return Operation (Valid in Manual Mode)	Manual mode Alarm Power 3pnt 2pnt Complete STOP POS NUM HOME MANUAL Au	tart CO	Press HOME Button. (It would not operate unless the servo is ON.) The home lamp flashes while in home return operation, and is illuminated after the home return operation is complete.
	<b>_</b>		

## [4] Switches Used for Manual Operation

Moving Forward Manually (Valid in Manual Mode)	FWD	The actuator moves forward while this button is pressed. The actuator stops if the button is released. The lamp flashes while in forward operation, and illuminates when reached the end (intermediate) point.
Moving Backward Manually (Valid in Manual Mode)	BACK	The actuator moves backward while this button is pressed. The actuator stops if the button is released. The lamp flashes while in backward operation, and illuminates when reached the start point.



#### [5] Switch Used for Brake Release

It is the brake compulsory release switch for the actuator equipped with a brake.



#### [6] Switches Used to Change Positioning Point Number

Setting for the number of positioning points (2-point or 3 point stops) can be performed.

When changing the positioning point number	Manual mode Alarm Power 3pnt 2pnt Complete STOP POS NUM HOME MANUAL Auto	<ul> <li>Press STOP POS NUM Button.</li> <li>Confirm a buzzer is made for 2 seconds and release the buttons.</li> <li>If the current setting is 2-point stop</li> <li>→ The mode is changed to 3-point stop and 3pnt lamp turns ON.</li> <li>If the current setting is 3-point stop</li> <li>→ The mode is changed to 2-point stop and 2pnt lamp turns ON.</li> </ul>
--	---	---

Caution : In the case the number of positioning points is changed after the position programming is done, perform the programming again. The actuator may move to an unexpected position thus it is risky.



[7] Switches Used for Position Teaching

The position (forward, backward and intermediate) can be registered with moving the actuator without using the teaching tool.

There are 2 types in the position programming.

- 1) Direct Teaching
- 2) Jog Teaching

The following operations cannot be performed unless the home return operation is completed.

(1) When Registering Position with Direct Teaching





Registering Middle Position (If set to 3-point positioning)	FWD MIDDLE BACK POS POS	Press MIDDLE POS Button to select. If the mode is switched over, the lamp on MIDDLE POS button turns ON.
	Stop	
	SAVE	Press SAVE Button. If the registration is complete, a peep sound is made and the save lamp turns ON. Intermediate position cannot be registered when the setting is 2-point stop.
Switching to Servo ON	Dos adi	Press SERVO ON/OFF Button once again
	SERVO JOG ON/OFF - +	and operation becomes available. Servo ON/OFF lamp turns ON.

(2) When Registering Position with Jog and Inching Operations

	1 USIGOT WILL DOG and morning	
Moving Forward		Move the actuator forward to a position
Manually	Pos.adj	where it is desired to be registered
manaany		Proce IOC+ button and the actuator
	SERVO JOG JOG	riess JOG - Dullon and the actualor
	ON/OFF — +	performs the inching operation (New 1) in the
		forward direction. Keep holding the button
	=	and the operation changes to the jog
		operation (Note 1). Keep holding the button
		further and the iog operation (Note 1)
		hasomaa faster stan by stan
		becomes laster step by step.
		The JOG+ lamp flashes while the button is
		being pressed.
Moving Backward		Move the actuator backward to a position
Manually	Pos.adj	where it is desired to be registered.
······		Press IOG- button and the actuator
	SERVO JOG JOG	norforms the inching operation (Note 1) in the
	ON/OFF - +	periornis the include operation ( ) in the
		backward direction. Keep holding the
	=	button and the operation changes to the
		jog operation (Note 1). Keep holding the
		button further and the jog operation (Note 1)
		becomes faster step by step
		The IOC lown fleebes while the butten is
		being pressed.
Registering Forward	•	Press FWD POS (end point) Button to
Position (End Point)	FWD MIDDLE BACK	select. If the mode is switched over, the
, , , , , , , , , , , , , , , , , , ,	POS POS POS	lamp on FWD POS button turns ON.
	Stop pos.	
	<b>–</b>	
		Press SAVE Button. If the registration is
		complete a peep sound is made and the
	SAVE	and turne ON
		save lamp lums ON.



Registering Back Position (Start Point)	FWD MIDDLE BACK POS POS Stop pos.	Press BACK POS (start point) Button to select. If the mode is switched over, the lamp on BACK POS button turns ON.
	SAVE	Press SAVE Button. If the registration is complete, a peep sound is made and the save lamp turns ON.
Registering Middle Position (If set to 3-point positioning)	FWD MIDDLE BACK POS POS Statios.	Press MIDDLE POS Button to select. If the mode is switched over, the lamp on MIDDLE POS button turns ON.
	SAVE	Press SAVE Button. If the registration is complete, a peep sound is made and the save lamp turns ON. Intermediate position cannot be registered when the setting is 2-point stop.

(Note 1) When registering the position with using Jog/Inching Mode, press either JOG+ or JOG- button and hold it down, and the operation mode changes in the order stated below;

Movement distance : Set in Parameter No.25 (Initial Value : 0.1mm)
(after 1.6 seconds passed)
Velocity : 1mm/s
(after 1 second passed)
Velocity : 10mm/s
(after 1 second passed)
Velocity : 30mm/s
(after 1 second passed)
Velocity : 50mm/s
(after 1 second passed)
Velocity : 100mm/s

If releasing the button during jog or inching, the operation starts from 1) again.

Caution : Keep pressing Jog button and the speed increases step by step. Therefore, it is recommended to release the button once the actuator gets close to the target point and press the button again to have a more delicate operation. Otherwise, there is a risk to crash the actuator.

Position teaching function is invalid if the home return operation is incomplete. Perform the operation after performing the home-return operation.



[8] Switches and Rotary Knobs Used in Acceleration/Deceleration and Speed Settings

The speed to move and the acceleration/deceleration speed of the actuator to the forward, backward and intermediate positions can be determined.

Registering Acceleration/ Deceleration (Valid in Manual Mode)	Accel	Twist Accel Dial and adjust at the desired position. (Setting Range : 1 to 100%)
	SAVE	Press SAVE Button. If the registration is complete, a peep sound is made and the save lamp turns ON. (The setting is registered together with the speed setting.)
Registering Speed (Valid in Manual Mode)	Speed	Twist Speed Dial and adjust at the desired position. (Setting Range : * to 100%) (* It differs depending on the actuator.)
	SAVE	Press SAVE Button. If the registration is complete, a peep sound is made and the save lamp turns ON. (The setting is registered together with the acceleration setting.)

#### [9] Switches Used in Test Run

Performing Continuous Operation (Valid in Manual Mode)	RUN	Press RUN Button and a continuous operation is started. If set to 2-point positioning, the continuous operation is performed in the order of end point $\rightarrow$ start point $\rightarrow$ end point. If set to 3-point positioning, the continuous operation is performed in the order of intermediate point $\rightarrow$ end point $\rightarrow$ start point $\rightarrow$ intermediate point. The operation lamp flashes while in the continuous operation.
Stopping Continuous Operation (Valid in Manual Mode)	STOP	Press STOP Button and the operation stops. Once it is stopped, the stop lamp turns ON.

#### [10] Switches Used in Alarm Reset

Alarm Reset (Valid in Manual Mode)	STOP	Press and hold STOP button. Reset the alarm.
--	------	---



# 4.5.3 Test Run with Operation Panel

Turn ON Power	Alarm Power	Power Lamp turns ON in green.
In Case of Error Issued	Alarm Power	If an error is issued, Alarm Lamp turns ON in red. Check the alarm code either on the PC software or the touch panel teaching to have an appropriate counteraction. [Refer to Alarm]

• To Select the Mode (Auto  $\rightarrow$  Manual)



• To Perform Home Return Operation



4.5 Operation in MEC Mode 3 (Test Run with Quick Teach.)



To Perform Manual Operation

Confirm the Home-return lamp is blinking and the home-return operation is completed. Perform a home-return operation if the Home-return lamp is off and the home-return operation is not completed.





• To Confirm Current Positioning Point Number.



2pnt Lamp should be illuminated when set to 2-point positioning.



3pnt Lamp should be illuminated when set to 3-point positioning.

• To Change Positioning Point Number.



4.5 Operation in MEC Mode 3 (Test Run with Quick Teach.)



• Register the position.

Confirm the Home-return lamp is blinking and the home-return operation is completed. Perform a home-return operation if the Home-return lamp is off and the home-return operation is not completed.

(1) When Registering Position with Direct Teaching





FRTŽ



(2) When Registering Position with Jog and Inching Operations







ERCÕ



When the registration is complete, a buzzer sounds for 1 second and the lamp starts flashing.





• Register the acceleration and speed.

Confirm the Home-return lamp is blinking and the home-return operation is completed. Perform a home-return operation if the Home-return lamp is OFF and the home-return operation is not completed.









when the Quick Search (PCM-PS1-1 of PCM-PS1-2) integrated (connected) with the power unit is used to activate ERC3, the high output setting becomes invalid automatically when the Quick Search is connected. Therefore, the unit may not operate under the specifications of when the high output setting

4.5 Operation in MEC Mode 3 (Test Run with Quick Teach.)

is valid.

# Chapter 5 Power-saving Function (Automatic Servo-off and Full Servo Functions)

ERC3 actuator possesses the automatic servo OFF function and full servo function to reduce the power consumption while the actuator is stopped. When using the power saving function, read the explanation in this section narrowly to understand well so there is no trouble in safety and operation. Automatic servo OFF function is not available in Pulse Train Mode.

## 5.1 Positioner Mode 1 and 2

Automatic Servo-off function automatically turns the servo OFF in certain time after positioning process is finished. The next positioning command is issued to turn the servo ON automatically and achieve the positioning. No holding current flows in the stop state to allow the power consumption to be saved.

3 types of patterns can be set for the time since positioning complete till servo turned OFF, and either one can be selected.

In the full servo function, the power consumption can be reduced by having a servo control to save the current during a stop.

The power saving function applies the power saving method set in Parameter No.53 or "Stop Mode" in the position table depending on the stop condition of the actuator.

	Positioner Mode 1	PIO Pattern 0	PIO Pattern 1, 2
	Positionel Mode 1	FIO Fattern 0	FIO Fattern 1, 2
	Positioner Mode 2	PIO Patterns 0 to 4	PIO Pattern 5
tion	Servo-on complete after power being supplied (before positioning to target position)		Depends on setting in Parameter No.53 (Stop Mode setting in position table is invalid)
Stop Condi	Home return completion (before positioning to target position)	Power saving function executed with the setting held in Parameter No.53 (Stop Mode setting in position table is invalid)	
	Positioning complete to target position set in position tableDepends on setting of "Stop Mode" in each positi number (Setting of Parameter No.53 is invalid)		

#### Caution:

- (1) Do not use this function if the automatic servo OFF is followed by pitch feed (relative movement).
  - Servo ON/OFF may cause slight position shift to occur. If position shift occurs due to external force during servo OFF, positioning to the correct position is disabled. It is because pitch feed is operated based on the position at start used as the base point.
- (2) Automatic Servo-off Function is not effective while in pressing operation. Do not use. It becomes effective at completion of positioning. In pressing, the function becomes effective only when miss-pressing occurs (the status at the completion of operation without pressing is the same as that at the completion of positioning). No retaining torque is provided in automatic servo-off. The actuator can move with an external force. Pay attention to the interference to the peripherals and the safety in the installation.



 Setting of periods taken until automatic servo OFF Three periods from completion of positioning to automatic servo OFF can be set in the following parameters in seconds [sec].

Parameter No.	Description
36	Auto Servo Motor OFF Delay Time 1 (Unit: sec)
37	Auto Servo Motor OFF Delay Time 2 (Unit: sec)
38	Auto Servo Motor OFF Delay Time 3 (Unit: sec)

(2) Set of power-saving mode

Select a proper power-saving mode from the conditions below. Set the corresponding value in the stop mode or parameter No.53 of the position table.

Set Value	Operation after completion of positioning
0	Servo ON not changed
1	Automatic servo OFF in a certain time (set in Parameter No.36)
2	Automatic servo OFF in a certain time (set in Parameter No.37)
3	Automatic servo OFF in a certain time (set in Parameter No.38)
4	Full Servo Control
5	Full-servo control for a certain time (value set in Parameter No.36) and then automatically turning servo OFF
6	Full-servo control for a certain time (value set in Parameter No.37) and then automatically turning servo OFF
7	Full-servo control for a certain time (value set in Parameter No.38) and then automatically turning servo OFF

(3) Status of positioning complete signal in selection of automatic servo OFF

Automatic servo OFF causes the actuator to be in other than the positioning complete state due to the servo OFF. Positioning complete signal PEND is turned OFF. Changing the PEND signal to the in-position signal judging whether the actuator is stopped within the positioning width zone instead of the positioning complete signal allows PEND not to be turned OFF during servo OFF.

This setting is also reflected to the complete position numbers PM1 to PM\*\* of PIO patterns 0 to 3 in PIO converter or the current position number PE\*\* of PIO pattern 4 in positioner mode 2, which are to check the positioning complete position number. Define the setting in Parameter No.39.

Value set in	Content of PEND	Signal outputs during automatic servo OFF		
Parameter No.39	signal	PEND	PM1 to PM**	PE**
0	Positioning Completion Signal	OFF	OFF	OFF
1	In-position Signal	ON	ON	ON

(Note) SV of ERC3 Motor Unit flashes in green while the automatic servo is OFF. Status Display LED flashes in green when using PIO Converter.

# ERC**3**

#### [For Parameter No.39 = 0]

Operation of actuator	Positioning operation	Automatic servo OFF standby	Servo OFF	Positioning operation
Servo Condition	ON	ON	OFF	ON
Completed Position No. Output (Current position number output)	PM1 to ** =0 (PE** = OFF)	PM1 to ** = Output (PE** = ON)	PM1 to ** = 0 (PE** = OFF)	PM1 to ** = 0 (PE** = OFF)
Positioning Completion Signal PEND	OFF	ON	OFF	OFF
		< →		
		Servo OFF Delay Time (Parameter No.36 to 38)		

(Note) PM1 to \*\* in the areas filled in gray is the output signal of PIO Pattern 0 to 3 in Positioner Mode 2, and PE\*\* is that of PIO Pattern 4

[For Parameter No.39 = 1]

Operation of actuator	Positioning operation	Automatic servo OFF standby	Servo OFF	Positioning operation
Servo Condition	ON	ON	OFF	ON
Completed Position No. Output (Current position number output)	PM1 to ** = 0 (PE** = OFF)	PM1 to ** = Output (PE** = ON)	PM1 to ** = 0 Output (PE** = ON)	PM1 to ** = 0 (PE** = OFF)
Positioning Completion Signal PEND	OFF	ON	ON	OFF
		Servo OFF Delay Time (Parameter No.36 to 38)		

(Note) PM1 to \*\* in the areas filled in gray is the output signal of PIO Pattern 0 to 3 in Positioner Mode 2, and PE\*\* is that of PIO Pattern 4



# 5.2 Pulse Train Control Mode

Power saving cannot be performed with the automatic servo OFF. Only the full servo control setting is available.

In the full servo function, the power consumption can be reduced by having a servo control to save the current during a stop.

ondition	Servo-on complete after power being supplied (before positioning to target position)	Power saving function executed with the setting
Stop Co	Home return completion (before positioning to target position)	held in Parameter No.53
	Positioning completion	

#### Set of power-saving mode

Select a number from the conditions below and set it in Parameter No.53.

Set Value	Operation after completion of operation
0	Servo ON not changed
1	Servo ON not changed
2	Servo ON not changed
3	Servo ON not changed
4	Full servo control
5	Full servo control
6	Full servo control
7	Full servo control

5.3 MEC Mode 1, 2 and 3



#### 5.3 MEC Mode 1, 2 and 3

The setting of power saving function for MEC Mode 1 and 2 can be conducted on MEC PC Software or Teaching Pendant. The setting of power saving function for MEC Mode 3 cannot be conducted in the try run of Quick Teach.

#### 5.3.1 Automatic Servo-off Function

To have the automatic servo-off function activated, set to "Activate" in "Power Saving" in the operational condition table.

Automatic Servo-off function automatically turns the servo OFF in certain time after positioning process is finished. Servo is automatically turned ON and positioning is conducted once the next positioning command is issued. Power consumption is reduced since the retaining current does not flow during a stop.

The time setting from positioning complete till servo-off is to be established in the parameter.

- (Note) SV of ERC3 Motor Unit flashes in green while the automatic servo is OFF. Status Display LED flashes in green when using PIO Converter.
- (1) Time Setting Till Automatic Servo-off

The time from positioning complete till servo-off can be set in seconds [sec] as the unit of time in the parameter shown below.

Parameter No.	Description
10	Auto Servo-motor OFF Delay Time 1 (Unit: sec)

(2) Position Detecting Signal Condition When Auto Servo-off Selected During a positioning operation, position detecting signals LS0 to LS2 remain turned ON if the actuator is in the range of the positioning band of the target position even though the servo is turned OFF with the automatic servo-OFF function.

Operation of actuator	Positioning operation	Automatic servo OFF standby	Servo OFF	Positioning operation
Servo Condition	ON	ON	OFF	ON
Limit Switch Output	LS**=OFF	LS**=ON	LS**=ON	PE**=OFF
		<b>↓</b>		
		Servo OFF Delay		
		Time		
		(Parameter No.10)		

(3) Positioning Completion Signal Condition When Auto Servo-off Selected The servo will not turn OFF with the automatic servo-off function during pressing operation when the pressing function is used. The servo turns OFF only when the pressing operation is missed.

The positioning complete signals PE0 to PE2 turn OFF while the servo is OFF.

Operation of actuator	Pressing operation	Automatic servo OFF standby (Pressing missed)	Servo OFF (Pressing missed)	Pressing operation
-				
Servo Condition	ON	ON	OFF	ON
Current position number output	PE**=OFF	PE**=ON	PE**=OFF	PE**=OFF
		← →		
		Servo OFF Delay Time (Parameter No.10)		



Caution:

- (1) Automatic Servo-off Function is not effective while in pressing operation. Do not use. It becomes effective at completion of positioning. In pressing, the function becomes effective only when miss-pressing occurs (the status at the completion of operation without pressing is the same as that at the completion of positioning).
- (2) No retaining torque is provided in automatic servo-off. The actuator can move with an external force. Pay attention to the interference to the peripherals and the safety in the installation.
- (3) Since the operation of Quick Teach in MEC Mode 3 is a try run operation, the setting of this function cannot be conducted. However, if the setting of Parameter No.11 is conducted in advance with MEC PC Software or Teaching Pendant, the operation follows the setting. Please be careful of this.



#### 5.3.2 Full Servo Function

Set "1" in Parameter No.11 when full servo function is to be conducted. In the full servo function, the power consumption can be reduced by having a servo control to save the current during a stop.

(1) Setting of Power Saving Method

Select whether to turn the servo ON or to have the full servo control in Parameter No.11. By setting "Power Saving" valid in the position table, automatic servo-off is triggered after certain time is passed.

Value set in Parameter No.11	Operation after completion of positioning	
0	Full stop	: Servo ON not changed
1	Servo-motor stop : Full servo control	



6.1 Absolute Reset and Absolute Battery

# ERC**3**

# Chapter 6 Adjustment of Operation

# 6.1 Absolute Reset and Absolute Battery

# 6.1.1 Absolute Reset

PIO Converter is necessary for Simple Absolute Type. Simple Absolute Type retains the encoder position information in the battery backup. It is not necessary to perform the home-return operation every time the power is turned ON.

In order to hold the encoder position information, absolute reset is required.

Provide absolute reset in the following cases:

(1) Initial activation

(2) When the absolute battery was replaced with the power to the PIO converter is shut, and (3) When disconnected the power supply and  $\frac{1}{2}$  cable for the actuator from PIO converter.

(3) When disconnected the power supply and I/O cable for the actuator from PIO Converter The absolute reset is performed by using a teaching tool such as PC software or PIO. The absolute reset using PIO is available in Positioner Mode 2. Also, the absolute reset cannot be performed on Quick Teach.

Caution: If it is Pulse Train Control Mode, it would not comply with simple absolute type. Take the greatest care.

- [1] Absolute reset procedure from teaching tool
- (1) For PC software
  - 1) Connect the actuator with the PIO converter. [Refer to Chapters 3.]
  - 2) Connect the absolute battery (enclosed battery at initial startup and new battery when replaced) to the absolute battery connecting connector on the bottom of the PIO converter. [Refer to 6.1.1 [3].]
  - 3) Connect PC, turn the power ON to PIO Converter and start up RC PC software.
  - Alarm 0EE "Absolute Encoder Error Detection 2" is shown. Select position data from main window and press Alarm button to conduct alarm reset.

Edit position data[Axis No.0]				
	Location	0.00 Ala	arm code <mark>OEE</mark>	
	Jog Speed 30 [mm/s]	C 0.10mm C 0.50mm	Positioning(Test mode) Speed 100 [%]	Servo Home Alarm

5) Select position data from main window, turn the servo ON with <u>Servo</u> button, and then press <u>Home</u> button to have a home-return.

🕾 Edit position date	[Axis No.0]				
80128	x 🖻 🛍 🛙	Location	0.00	Alarm code	
+	*	Jog	Inc.	Positioning(Test mode)	Servo
Bw(-)	Fw(+)	Speed 30 [mm/s]	C 0.10mm	Speed 100 [%]	Home

6) Once the home return is complete, the point of origin is memorized at the same time the origin point is established.



- (2) For TB-02/TB-03
  - 1) Connect the actuator with the PIO converter. [Refer to Chapters 3.]
  - 2) Connect the absolute battery (enclosed battery at initial startup and new battery when replaced) to the absolute battery connecting connector on the bottom of the PIO converter. [Refer to 6.1.1 [3].]
  - 3) Connect teaching pendant and turn the power ON to PIO Converter.
  - 4) Alarm 0EE "Absolute Encoder Error Detection 2" is shown.
  - 5) Touch Reset Alm to reset the alarm in the alarm issuance window.

🔶 🗃 Troubleshooting Glossary 🖬 Axis No. Ø			
Alarm display Alarm list Check model num. Inquiry			
•Alarm descript.			
Alarm code 0EE Alarm level Cold start			
Name Absolute Encoder Error Detection 2			
Descr. It comes to the condition that the encoder mounted on the battery-less absolute type actuator cannot detect the nesition correctly.			
Detail code:**** Adrs: **** Time(yy/mm/dd hh:mm:ss) 17/05/11 17:12:25			
Troubleshooting Alarm reset			

6) Press Trial Operation on the Menu 1 screen.

7) Press Jog Inching on Trial screen.

Touch Servo to turn the servo ON and

touch Home in Jog/Inching screen.



✓ 12 Test run

 Jog inching

 Position move

 Direct move

 I/O test

🔶 🖆 Jog	inching	dn Axis No. 00
Cur.pos. Jog vel. 1mm/s 10mm/s 30mm/s 50mm/s 100mm/s	0.00 mm Inching 0.01mm 0.10mm 0.50mm 1.00mm 5.00mm	Servo Homing Brake rel.

9) Once the home return is complete, the point of origin is memorized at the same time the origin point is established.

8)



# ERC**3**

- (3) For TB-01
  - 1) Connect the actuator with the PIO converter. [Refer to Chapters 3.]
  - Connect the absolute battery (enclosed battery at initial startup and new battery when replaced) to the absolute battery connecting connector on the bottom of the PIO converter. [Refer to 6.1.1 [3].]
  - 3) Connect teaching pendant and turn the power ON to PIO Converter.
  - 4) Alarm 0EE "Absolute Encoder Error Detection 2" is shown.
  - 5) Touch Reset Alm to reset the alarm in the alarm issuance window.



6) Press Trial Operation on the Menu 1 screen.

Menul Axis No. (	
Monitor	Trial Operation
Edit Position	Alarm List
Edit Parameter	Information
Backup Data	Menu2

7) Press Jog\_Inching on Trial screen.

8) Touch Servo to turn the servo ON and touch Home in Jog/Inching screen.

Trial Operat	Axis No. 00	
	Jog_Inching	
	Position Move	
	Direct Move	
	I/O Test	
Menu 1		
Joa		Axis No. 00
Current	Pos 0.00 mm	SV OFF

Jog Vel

Inching

Urrent Pos 0.00

Menu 1

9) Once the home return is complete, the point of origin is memorized at the same time the origin point is established.



[2] Absolute reset using PIO

This feature is valid in Positioner Mode 2.

- 1) Turn the reset signal RES from OFF to ON. (Processed with ON edge.)
- 2) Check that the alarm signal \*ALM is ON (Alarm <sup>(Note 1)</sup> is cancelled).
   If the cause of the alarm is not removed, an alarm will be present again (\*ALM signal OFF). Check the condition including other alarm causes. (It is not necessary for PIO Pattern 5)
- 3) Turn ON the pause signal \*STP.
- 4) Turn the servo-on signal SON ON.
- 5) Wait until the servo-on status SV turns ON.
- 6) Turn the home return signal HOME (ST0 signal in case of PIO pattern 5) ON. Start home-return operation (with ON-edge).
- 7) When the homing completion signal HEND is turned ON (completion of home return), absolute reset is completed.

Timing chart for [Absolute Reset Process] is shown in the following page.



#### [Absolute Reset Process]



- Note 1 Have the control power supply and motor power supply in common, and have them turned ON that the same time.
- Note 2 This should be ST0 for Pattern 5



#### [3] Absolute Battery

In PIO Converter for Simple Absolute Type, there are a battery for Absolute Type and fabric hook-and-loop faster enclosed.

Separate the fastener and attach each to side surface of PIO Converter and the battery for Absolute Type. Join the fastener attached on the absolute battery and that on PIO Converter to fix them together. Connect the battery to the absolute battery connector on the bottom of the battery PIO Converter.



#### (1) Absolute Battery Type

Item	Specifications
Battery model	AB-7
Battery voltage	3.6V
Current capacity	3300mAH
Reference for battery replacing timing <sup>(Note 1)</sup>	Approx. 3 years
	(It varies significantly by the effects of the
	usage condition)

(Note 1) Replace the battery regularly.

#### (2) Absolute Battery Charge

Please have the battery charged for more than 72 hours before using for the first time or after replacing with a new one. The battery gets charged while the controller is supplied with 24V power.

It is possible to retain the encoder data for the duration shown below for each hour of battery charge.

#### Data Holding Time

Value for User Parameter No.155	0	1	2	3
Data holding time per hour of battery charge time <sup>(Note 1)</sup> (reference)	6.6H	5.0H	3.3H	1.6H
Holding time when fully charged (Note 1) (reference)	20 days	15 days	10 days	5 days

(Note 1) Followings are the reference values of time assuming the battery is new.

Leaving the controller power OFF for more than the data holding time will lead to a loss of the data. Have the battery charged as early as possible.

Caution: There is life to the battery and the duration for data holding will decrease. Replace the battery with a new one if the retaining time is remarkably dropped even with enough charging time.

# 6.1 Absolute Reset and Absolute Battery

# ERC**3**

(Example) From Monday to Friday ; charge for 8 hours per day, discharge for 16 hours, Saturday and Sunday ; use with discharge

1) Parameter Setting Value: if it is 3...

Full charge amount ; 24 [h] × 3 [day] = 72 [h]

Total charge amount ; 8 [h]  $\times$  1.6 [h]  $\times$  5 [day] = 64 [h]

Total discharge amount ; 16 [h] × 5 [day] + 48 [h] = 128 [h]

→ Assuming to have a battery charge for 72 hours before Monday, and starting on Monday with a full charge, it is necessary to have 3 days of battery charge periods in 10-day cycle.

2) Parameter Setting Value: if it is 2...

Total charge amount ; 8 [h] × 3.3 [h] × 5 [day] = 132 [h]

- Total discharge amount ; 16 [h] × 5 [day] + 48 [h] = 128 [h]
- → It is not necessary to have a continuous full charge if starting on Monday.
   4-hour charge is stored every week. The upper limit is the reference value for the retaining duration after fully charged.

#### (3) Absolute Battery Voltage Drop Detection

If the voltage of the absolute battery is dropped, the error detection responding to the voltage is held.

Voltage	PIO Signals	Alarm
$3.1V \pm 8\%$ or less	Alarm output *ALM <sup>(Note 1)</sup> OFF	0EE Absolute Encoder Error
		Detection 2
		01
		0EF Absolute Encoder Error
		Detection 3

(Note 1) \*ALM are the signals of active low.

After the power is supplied to the controller, they are usually ON and turned OFF when an error is detected.

If the alarm is generated, it will be necessary to absolute reset after the battery replacement.





(4) Replacement of absolute battery When replacing the battery, leave the power to the PIO converter ON, remove the battery connector and replace with a new battery.



6.2 High Output Setting and Gain Scheduling Function



# 6.2.1 High Output Setting

FRF

6.2

High output setting is a function to increase the speed, acceleration/deceleration and transportable weight. (It is set effective at delivery.) [Refer to 1.2.1 Actuator.] Setting of enable and disable switches over between the parameters of "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain".

# 6.2.2 Gain Scheduling Function

Stepper motor possesses the characteristics that the output decreases if speed increases. Therefore, to maintain the sufficient control performance in high speed operation range, the settings of "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain" are raised to set (to highly respond to speed change).

This may become a cause of magnetic noise or small vibration in low speed operation range in some cases.

Gain Scheduling Function is a system to change the gain in response to the speed to realize an operation with the optimized control condition.

This function cannot be used in MEC Mode.

## 6.2.3 Setting in Positioner Mode 1 & 2 and Pulse Train Control Mode

The setting of enable/disable for the high output setting and Gain Scheduling Function can be performed in parameters.

High output setting = Parameter No.152 Gain scheduling = Parameter No.144

At the delivery, the high output setting is set enable while Gain Scheduling Function disable. With the setting of enable/disable for each setting, the parameters for each function are switched over between "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain" to perform controls.

Shown in the table below is the parameter numbers of "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain" to be enable by the setting conditions.

		High output setting (Parameter No.152)	
		1 (Enable = in Delivery)	0 (Disable)
Gain scheduling (Parameter No.144)	101 to (Enable)	Parameter No.145, 146	
	to 100 (Disable = in Delivery)	Parameter No.153, 154	Parameter No.31, 32

No.31, 145, 153 = Speed Loop Proportional Gain No.32, 146, 154 = Speed Loop Integral Gain

Caution: Smart Tuning is a function that is valid when the high output setting is enable and Gain Scheduling is disable. Note that this function cannot be used in other settings. [Refer to the instruction manual of the PC software provided separately for how to handle Smart Tuning.] If the gain scheduling function is activated, an operation with the velocity and acceleration/deceleration set in Smart Tuning Function cannot be secured.
The velocity and acceleration/deceleration set in Smart Tuning Function are to be the values selected from the specifications when the gain operation is made with No.153 and 154.
When the gain scheduling function is activated, the gain operation is made with No. 145 and 146, and the actuator specifications may differ from the operation with No.153 and 154.



#### 6.2.4 Setting in MEC Mode 1 to 3

Making the high output setting enable/disable is to be conducted in Parameter No.28. The high output setting is set enable at the delivery.

With the setting of enable/disable for the high output setting, the parameters are switched over between "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain" to perform controls.

Shown in the table below is the parameter numbers of "Velocity Loop Proportional Gain" and "Velocity Loop Integrated Gain" to be enable by the setting conditions.

High output setting	0 (Disable)	Parameter No.5, 6
(Parameter No.152)	1 (Enable = in Delivery)	Parameter No.29, 30

Caution: Please note that the high output setting automatically turns disable if Quick Teach equipped with a power supply unit (PCM-PST-1 or PCM-PST-2) is connected.


6.3 I/O Parameter

### ERC**3**

#### 6.3 I/O Parameter

Parameter data should be set appropriately according to the application requirements. When a change is required to the parameters, make sure to back up the data before the change so the settings can be returned anytime.

With using PC software, it is able to store the backup to the PC.

Leave a memo if using the teaching pendant.

For a quick data recovery after such works as investigation on malfunction and replacement of ERC3 and PIO converter, it is also recommended to back up or take a note on the parameter after the setting change.

The change to the parameters will be activated after they are edited, written to the FeRAM, then either software reset or reboot of the power. It will not be active only with writing on the teaching tool.

✓ Warning: Establishment of parameter setting gives a great influence to operation. Wrongly established setting could cause not only an operation error or malfunction, but also it is very dangerous. Settings at the delivery enable the product to operate standardly. Understand very well about the control logic of ERC3 and PIO converter if making a change or performing a setting suitable to the system. Please contact us if you have anything unclear. Do not attempt to turn OFF the power to the ERC3 or PIO converter while writing the parameters.

## ERC**3**

#### 6.3.1 Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode

#### [1] I/O Parameter List

The categories in the table below indicate whether parameters should be set or not. There are five categories as follows:

- A : Check the settings before use.
- B : Use parameters of this category depending on their uses.
- C : Use parameters of this category with the settings at shipments leaving unchanged as a rule. Normally they may not be set.
- D : Parameters of the category are set at shipment in accordance with the specification of the actuator. Normally they may not be set.
- E : Parameters of the category are exclusively used by us for convenience of production. Changing their settings may not only cause the actuator to operate improperly but also to be damaged. So, never change the setting of the parameters.

Category do not appear on the teaching tool.

Also, the unused parameter numbers are not mentioned in the list.

No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Positioner Mode 1	For Positioner Mode 2	For Pulse Train Mode	Relevant sections This section
1	В	Zone 1+	ZNM1	mm	-9999.99 to 9999.99	Actual stroke on + side (Note1)	0	0		[2] (1), [2] (68)
2	В	Zone 1-	ZNL1	mm	-9999.99 to 9999.99	Actual stroke on - side (Note1)	0	0		[2] (1), [2] (68)
3	А	Soft limit+	LIMM	mm	-9999.99 to 9999.99	Actual stroke on + side (Note1)	0	0	0	[2] (2)
4	А	Soft limit-	LIML	mm	-9999.99 to 9999.99	Actual stroke on - side (Note1)	0	0	0	[2] (2)
5	D	Home return direction	ORG	-	0: Reverse 1: Normal	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (3)
6	С	Press & hold stop judgment period	PSWT	msec	0 to 9999	255	0	0		[2] (4)
7	С	Servo gain number	PLGO	-	0 to 31	In accordance with actuator (Note1)	0	0	0	[2] (5), [3]
8	В	Default velocity	VCMD	mm/s	1 to Actuator's max. speed	Rated actuator speed <sup>(Note1)</sup>	0	0		[2] (6)
9	в	Default acceleration/deceleration	ACMD	G	0.01 to actuator's max. acceleration/ deceleration	Rated actuator's acceleration/ deceleration <sup>(Note1)</sup>	0	0	0	[2] (7)
10	В	Default positioning width	INP	mm	0.01 to 999.99	0.10	0	0	0	[2] (8)
12	В	Current-limiting value at standstill during positioning	SPOW	%	1 to 70	35	0	0	0	[2] (9)
13	С	Current-limiting value during home return	ODPW	%	1 to 100	In accordance with actuator (Note1)	0	0	0	[2] (10)
15	В	Pause input disable	FPIO	Ι	0: Enabling 1: Disabling	0	0	0		[2] (11)
16	В	SIO communication speed	BRSL	bps	9600 to 230400	38400	0	0	0	[2] (12)
17	В	Minimum delay time for slave transmitter activation	RTIM	msec	0 to 255	5	0	0	0	[2] (13)
21	В	Servo ON input disable	FPIO	-	0: Enabling 1: Disabling	0		0	0	[2] (14)
22	С	Home return offset level	OFST	mm	0.00 to 9999.99	In accordance with actuator (Note1)	0	0	0	[2] (15)
23	В	Zone 2+	ZNM2	mm	-9999.99 to 9999.99	Actual stroke on + side (Note1)		0		[2] (1)
24	В	Zone 2-	ZNL2	mm	-9999.99 to 9999.99	Actual stroke on - side (Note1)		0		[2] (1)
25	A	PIO pattern selection	IOPN	-	0 to 5	0 (Standard Type)	0	0	0	[2] (17)
26	В	PIO jog velocity	IOJV	mm/s	1 to Actuator's max. speed	100		0		[2] (18)

Note 1 The setting values vary in accordance with the specification of the actuator. At shipment, the parameters are set in accordance with the specification.



I/O Parameter List (Continued)

No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Positioner Mode 1	For Positioner Mode 2	For Pulse Train Mode	Relevant sections This section
27	В	Movement command type	FPIO	Ι	0: Level 1: Edge	0	0	0		[2] (19)
28	В	Default movement direction for excitation-phase signal detection	PHSP	Ι	0: Reverse 1: Normal	In accordance with actuator (Note1)	0	0	0	[2] (20)
29	в	Excitation-phase signal detection time	PHSP	msec	1 to 999	In accordance with actuator (Note1)	0	0	0	[2] (21)
30	в	Excitation detection type	PHSP	-	0: Conventional method 1: New method 1 2: New method 2	0	0	0	0	[2] (22)
31	С	Velocity loop proportional gain	VLPG	I	1 to 27661	In accordance with actuator (Note1)	0	0	0	[2] (23), [3]
32	С	Velocity loop integral gain	VLPT	-	1 to 217270	In accordance with actuator (Note1)	0	0	0	[2] (24), [3]
33	С	Torque filter time constant	TRQF	-	0 to 2500	In accordance with actuator (Note1)	0	0	0	[2] (25), [3]
34	С	Press velocity	PSHV	mm/s	1 to actuator's max. pressing speed	In accordance with actuator (Note1)	0	0		[2] (26)
35	с	Safety velocity	SAFV	mm/s	1 to 250 (max. for actuator of 250 or less)	100	0	0	0	[2] (27)
36	В	Auto servo-motor OFF delay time 1	ASO1	sec	0 to 9999	0	0	0		[2] (28)
37	В	Auto servo-motor OFF delay time 2	ASO2	sec	0 to 9999	0	0	0		[2] (28)
38	В	Auto servo-motor OFF delay time 3	ASO3	sec	0 to 9999	0	0	0		[2] (28)
39	в	Position complete signal output method <sup>(Note2)</sup>	FPIO	-	0: PEND 1: INP	0	0	0		[2] (29)
40	С	Home-return input disable	FPIO	-	0: Enabled 1: Disabled	0	0	0	0	[2] (30)
42	С	Enable function	FPIO	-	0: Enabled 1: Disabled	1	0	0	0	[2] (31)
45	В	Silent interval magnification	SIVM	times	0 to 10	0	0	0	0	[2] (32)
46	В	Velocity override	OVRD	%	0 to 100	100	0	0		[2] (33)
47	-	PIO jog velocity 2	IOV2	mm/s	1 to Actuator's max. speed	100				[2] (18)
48	В	PIO inch distance	IOID	mm	0.01 to 1.00	0.1		0		[2] (34)
49	Ι	PIO inch distance 2	IOD2	mm	0.01 to 1.00	0.1				[2] (35)
50	В	Load output judgment time period	LDWT	msec	0 to 9999	255				[2] (36)
51	в	Torque inspected range	TRQZ	-	0: Enabled 1: Disabled	0				[2] (37)
52	в	Default acceleration/deceleration mode	CTLF	-	0 to 2	0 (Trapezoid)	0	0	0	[2] (38)
53	В	Default stop mode	CTLF	Ι	0 to 7	0 (Not Applicable)	0	0	0	[2] (39)
55	в	Position-command primary filter time constant	PLPF	msec	0.0 to 100.0	0	0	0	0	[2] (40), Chapter 4 4.3 [9] (1)
56	В	S-motion rate	SCRV	%	0 to 100	0	0	0	0	[2] (41)
57	В	Torque limit	TQLM	%	0 to 70	70			0	Chapter 4 4.3 [9] (2)
58	Е	Clearing deviation during servo OFF or alarm stop	FSTP	-	0: Enabled 1: Disabled	1			0	Chapter 4 4.3 [9] (3)
59	С	Error monitor during torque limiting	FSTP	-	0: Enabled 1: Disabled	0			0	Chapter 4 4.3 [9] (4)

Note 1 The setting values vary in accordance with the specification of the actuator. At shipment, the parameters are set in accordance with the specification. Note 2 In the pulse-train mode, INP is automatically selected. (Cannot be selected)



I/O Parameter List (Continued)

No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Positioner Mode 1	For Positioner Mode 2	For Pulse Train Mode	Relevant sections This section
60	В	Deviation counter clear input	FPIO	-	0: Enabled 1: Disabled	0			0	Chapter 4 4.3 [9] (5)
61	В	Torque limit command input	FPIO	-	0: Enabled 1: Disabled	0			0	Chapter 4 4.3 [9] (6)
62	в	Pulse count direction	FPIO	_	0: Forward motor rotation 1: Reverse motor rotation	In accordance with actuator <sup>(Note1)</sup>			0	Chapter 4 4.3 [9] (7)
63	в	Command pulse input mode (Pulse train mode)	CPMD	-	0 to 2	1 (pulse-train and moving direction angle)			0	Chapter 4 4.3 [8] (2)
64	В	Command pulse input mode polarity	CPMD	-	0: Positive Logic 1: Negative Logic	0			0	Chapter 4 4.3 [8] (2)
65	в	Electronic gear numerator	CNUM	-	1 to 4096	2048			0	Chapter 4 4.3 [8] (1)
66	в	Electronic gear denominator	CDEN	-	1 to 4096	125			0	Chapter 4 4.3 [8] (1)
67	в	Compulsory stop input	FPIO	-	0: Enabled 1: Disabled	0			0	-
71	В	Feed forward gain	PLFG	-	0 to 100	0	0	0	0	[2] (53)
77	D	Ball screw lead length	LEAD	mm	0.01 to 999.99	In accordance with actuator (Note1)	0	0	0	[2] (54)
83	в	Absolute unit	ETYP	-	0: Incremental 1: Simple Absolute Type	In accordance with specification at order accepted		0		[2] (55)
88	D	Software limit margin	SLMA	mm	0 to 9999.99	In accordance with actuator (Note1)	0	0	0	[2] (56)
91	с	Current limit value at stopping due to miss-pressing	PSFC	_	0: Current limit value during movement 1: Current limit value during pressing	0	0	0		[2] (57)
110	в	Stop method at servo OFF	FSTP	_	0: Rapid stop 1: Deceleration to stop	0	0	0	0	[2] (58)
111	в	Calendar function	FRTC	-	0: Does not use the calendar timer 1: Use the calendar timer	1		0		[2] (59)
112	в	Monitoring mode	FMNT	-	0: Does not use 1: Monitor function 1 2: Monitor function 2	0	0	0	0	[2] (60)
113	В	Monitoring period	FMNT	msec	1 to 100	1	0	0	0	[2] (61)

Note 1 The setting values vary in accordance with the specification of the actuator. At shipment, the parameters are set in accordance with the specification.



I/O Parameter List (Continued)

No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Positioner Mode 1	For Positioner Mode 2	For Pulse Train Mode	Relevant sections This section
143	-	Overload level ratio	OLWL	%	50 to 100	100				[2] (62)
144	В	Gain scheduling upper limit multiplying ratio	GSUL	%	0 to 1023	0	0	0	0	[2] (63)
145	С	GS velocity loop proportional gain	GSPC	Ι	1 to 30000	750	0	0	0	[2] (64), [3]
146	С	GS velocity loop integral gain	GSIC	-	1 to 500000	4500	0	0	0	[2] (65), [3]
147	В	Total movement count threshold	TMCT	times	0 to 999999999	0 (Disabled)	0	0	0	[2] (66)
148	В	Total operated distance threshold	ODOT	m	0 to 999999999	0 (Disabled)	0	0	0	[2] (67)
149	В	Zone output changeover	FPIO	Ι	0: To change 1: Not to change	0	0	0		[2] (68)
152	В	High output setting	BUEN	-	0: Disabled 1: Enabled	1	0	0	0	[2] (69)
153	В	BU velocity loop proportional gain	BUPC	-	1 to 10000	200	0	0	0	[2] (70), [3]
154	в	BU velocity loop integral gain	BUIC	-	1 to 100000	4000	0	0	0	[2] (71), [3]
155	A	Absolute battery retention time	AIP	days	0: 20 days 1: 15 days 2: 10 days 3: 5 days	0		0		[2] (72)
156	В	Torque inspected range/Light malfunction output select	SLAL	-	0: Torque inspected range effective 1: Light malfunction effective	0		0		[2] (73)

(Note 1) The setting values vary in accordance with the specification of the actuator. At shipment, the parameters are set in accordance with the specification.



#### [2] Detail Explanation of Parameters

Caution: To make the setting enable after a change is made to parameters, have either the software reset or power reboot.

#### (1) Zone 1+, Zone 1- (Parameter No.1, No.2) Zone 2+, Zone 2- (Parameter No.23, No.24)

No.	Name	Symbol	Unit	Input Range	Default factory setting
1	Zono 1+	<b>ZNIM1</b>	mm	-9999.99 to	Actual stroke on +
-			111111	9999.99	side
S	Zono 1	7NII 1	mm	-9999.99 to	Actual stroke on side
2	Zone 1-	ZINET		9999.99	Actual stroke off - side
22	Zono 2+	75142	22	-9999.99 to	Actual stroke on +
23	Zone 2+		111111	9999.99	side
24	Zono 2	7111.0	mm	-9999.99 to	Actual strake on side
24		ZINLZ		9999.99	Actual Stroke off - Side

Enable zone signal outputs are to be determined by Parameter No.25 "PIO Pattern Select" and Parameter No.149 "Zone Output Switchover".

[Refer to the Parameter No.149 for the details]

The minimum setting unit is 0.01mm.

If a specific value is set to both zone setting + and zone setting -, the zone signal is not output. A setting sample is shown below.

#### [Example of linear axis]



Chapter 6 Adjustment of Operation

6.3 I/O Parameter 6.3.1 Positioner M

.3.1 Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode



#### (2) Soft limit +, Soft limit - (Parameter No.3, No.4)

No.	Name	Symbol	Unit	Input Range	Default factory setting
3	Soft limit +	LIMM	mm	-9999.99 to 9999.99	Actual stroke on + side
4	Soft limit -	LIML	mm	-9999.99 to 9999.99	Actual stroke on - side

0.3mm (deg) is added to the outside of the effective actuator stroke for the setting at the delivery (since there would be an error at the end of effective stroke if set to 0). Adjustment can be made freely within the movable range considering the suitability to the system for purposes of avoidance to interference, crash, etc. Adjust the setting referring the figure below if necessary.

The operational range for jog and inching after the home return is 0.2mm less than the set value. Therefore, in case that it is necessary to have jog or inching operation up to the end of the stroke, set to the value extended by 0.3mm from the end of the stroke considering 0.1mm margin to correspond to load inertia.

An incorrect soft limit setting will cause the actuator to collide into the mechanical end, so exercise sufficient caution.

The minimum setting unit is 0.01mm.

Example) Set the effective stroke to between 0mm and 80mm Parameter No.3 (positive side) 80.3 Parameter No.4 (negative side) -0.3



Alarm Code 0D9 "Soft Limit Over Error" will be generated when the set value exceeded the value (0 when shipped out) set in Parameter No.88 "Software Limit Margin". Unless setting is established in Parameter No.88 (setting at delivery is 0), the setting in this parameter will be the threshold for Alarm Code 09D "Soft Limit Over Error".

(3) Home return direction (Parameter No.5)

No.	Name	Symbol	Unit	Input Range	Default factory setting
5	Home return direction	ORG	-	0: Reverse	In accordance with
				1: Forward	actuator

Unless there is an indication of home-reversed type (option), the direction of the home return for the straight axis is located on the motor side. [Refer to the coordinate system of the actuator.] If it becomes necessary to reverse the home direction after the actuator is installed on the machine, change the setting.



#### (4) Press & hold stop judgment period (Parameter No.6)

No.	Name	Symbol	Unit	Input Range	Default factory setting
6	Press & hold stop judgment period	PSWT	msec	0 to 9999	255

#### Judging completion of pressing operation

(1) The operation monitors the torque (current limit value) in percent in "Pressing" of the position table and turns pressing complete signal PEND ON when the load current satisfies the condition shown below during pressing. PEND is turned ON at satisfaction of the condition if the work is not stopped.

(Accumulated time in which current reaches pressing value [%])

– (accumulated time in which current is less than pressing value [%])





#### (5) Servo gain number (Parameter No.7)

No.	Name	Symbol	Unit	Input Range	Default factory setting
7	Servo gain number	PLGO	-	0 to 31	In accordance with actuator

The servo gain is also called position loop gain or position control system proportion gain. The parameter defines the response when a position control loop is used. Increasing the set value improves the tracking performance with respect to the position command. However, increasing the parameter value excessively increases the chances of overshooting.

When the set value is too low, the follow-up ability to the position command is degraded and it takes longer time to complete the positioning.

For a system of low mechanical rigidity or low natural frequency (every object has its own natural frequency), setting a large servo gain number may generate mechanical resonance, which then cause not only vibrations and/or noises but also overload error to occur.



#### (6) Default velocity (Parameter No.8)

No.	Name	Symbol	Unit	Input Range	Default factory setting
8	Default velocity	VCMD	mm/s	1 to Actuator's max. velocity	Rated actuator speed

The factory setting is the rated velocity of the actuator.

When a target position is set in an unregistered position table, the setting in this parameter is automatically written in the applicable position number. It is convenient to set the velocity often used.

(7) Default acceleration/deceleration (Parameter No.9)

No.	Name	Symbol	Unit	Input Range	Default factory setting
9	Default acceleration/deceleration	ACMD	G	0.01 to actuator's max. acceleration/ deceleration	Rated actuator's acceleration/ deceleration

The factory setting is the rated acceleration/deceleration of the actuator.

When a target position is set in an unregistered position table, the setting in this parameter is automatically written in the applicable position number.

It is convenient to set the acceleration/deceleration often used.



(8) Default positioning width (in-position width) (Parameter No.10)

No.	Name	Symbol	Unit	Input Range	Default factory setting
10	Default positioning width	INP	mm	0.01 <sup>(Note 1)</sup> to 999.99	0.10

When a target position is set in an unregistered position table, the setting in this parameter is automatically written in the applicable position number. When the remaining moving distance enters into this width, the positioning complete signal PEND/INP is output. It is convenient to set the positioning width often used. Note 1 It is down to the minimum positioning width (L = Lead length/800).

(9) Current-limiting value at standstill during positioning (Parameter No.12)

No.	Name	Symbol	Unit	Input Range	Default factory setting
12	Current-limiting value at standstill during positioning	SPOW	%	1 to 70	35

By increasing the number, the retaining torque at a stop increases.

It is not necessary to change this setting in normal use, however, it is possible to block the movement caused by external force by increasing the setting number when large external force is applied at a stop. However, there is a risk that motor or controller may burn if the setting is too high. Contact us if a change is required.

#### (10) Current-limiting value during home return (Parameter No.13)

No.	Name	Symbol	Unit	Input Range	Default factory setting
13	Current-limiting value during home return	ODPW	%	1 to 100	In accordance with actuator

The factory setting conforms to the standard specification of the actuator.

Increasing this setting will increase the home return torque.

It is not necessary to change this setting in normal use, however, home-return operation may complete in front of the proper point in some cases depending on how it is installed or load is attached when the product is vertically mounted. It is necessary to increase the setting value in such cases. Other causes can also be considered, so contact us in advance to making a change.

#### (11) Pause input disable (Parameter No.15)

No.	Name	Symbol	Unit	Input Range	Default factory setting
15	Pause input disable	FPIO	-	0 : Enabled 1 : Disabled	0

This parameter defines whether the pause input signal is disabled or enabled. Set to "1" if pause by PIO is not to be performed.

Pause by PIO Signal cannot be performed if the setting is disable.

Also, operation becomes available with no pause signal input being connected.

Set Value	Description
0	Enable (Use the input signal)
1	Disable (Does not use the input signal)



(12) SIO communication speed (Parameter No.16)

No.	Name	Symbol	Unit	Input Range	Default factory setting
16	SIO communication speed	BRSL	bps	9600 to 230400	38400

Set the SIO baud rate for the startup.

Set an appropriate value in accordance with the communication speed of the host. Communication speed can be set from 9600, 14400, 19200, 28800, 38400, 76800, 115200 or 230400bps.

Caution: After the PC software is connected, the baud rate setting is changed to that of the PC software. To make effective the value set in the parameter, turn off the power once and on it again.

(13) Minimum delay time for slave transmitter activation (Parameter No.17)

No.	Name	Symbol	Unit	Input Range	Default factory setting
17	Minimum delay time for slave transmitter activation	RTIM	msec	0 to 255	5

In this setting, set the time from receiving the command (received data) during the SIO communication till the response (sent data) is returned

(14) Servo ON input disable (Parameter No.21)

No.	Name	Symbol	Unit	Input Range	Default factory setting
21	Servo ON input disable	FPIO	-	0 : Enabled 1 : Disabled	0

This parameter defines whether the servo ON input signal is disabled or enabled.

Set this parameter to "1" if servo ON/OFF is not provided by PIO signals.

When the servo ON input signal is disabled, the servo is turned ON as soon as the controller power is turned ON.

Also, operation becomes available with no servo-on signal input being connected.

Set Value	Description
0	Enable (Use the input signal)
1	Disable (Does not use the input signal)



#### (15) Home return offset level (Parameter No.22)

No.	Name	Symbol	Unit	Input Range	Default factory setting
22	Home return offset level	OFST	mm	0.00 to 9999.99	In accordance with actuator

In this setting can set the distance from the mechanical end to the home position. An adjustment is available for the following cases.

- 1) Want to match the actuator home position and the mechanical origin of the system.
- 2) Want to set a new home after reversing the factory-set home direction.
- 3) Want to eliminate a slight deviation from the previous home position generated after replacing the actuator.

[Adjustment Process]

- 1) Homing execution
- 2) Offset check
- 3) Parameter setting change
- 4) After the setting, repeat home return several times to confirm that the actuator always returns to the same home position.

<u>^</u>	
Caution :	• Soft limit takes the home position as the datum. Therefore, when a change is made to the value of home-return offset level, also revise the value for soft limit.
	• If the home return offset has been changed, the soft limit parameters must also be adjusted accordingly.
	Do not set a smaller value than the initial setting value for Home Return Offset. Normal excitation detection cannot be performed, and there may be a risk of generating the excitation detection error or causing abnormal noise.
	In case the there is a necessity of setting a value less than the initial setting, contact IAI.

(16) Zone 2+, Zone 2- (Parameter No.23, No.24) [Refer to 6.3.1 [2] (1).]

# ERC**3**

(17) PIO pattern selection (Parameter No.25)

No.	Name	Symbol	Unit	Input Range	Default factory setting
25	PIO pattern selection	IOPN	I	0 to 5	0 (Standard Type)

Select the PIO operation pattern in Parameter No.25.

For the details of PIO patterns, refer to 4.2 Operation in Positioner Mode.

[Ear Desitionar	Mada	11
	would	- 1

Туре	Value set in parameter No 25	Mode	Overview
PIO Pattern 0	0 (at the delivery)	8-point type	<ul> <li>Number of positioning points : 8 points</li> <li>Position command : binary code</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> </ul>
PIO Pattern 1	1	3-point type (Solenoid valve type)	<ul> <li>Number of positioning points : 3 points</li> <li>Position command : Individual number signal ON</li> <li>Zone signal output : None</li> </ul>
PIO Pattern 2	n 2 2 16-point type		<ul> <li>Number of positioning points : 16 points</li> <li>Position command : binary code</li> <li>Position zone signal output*<sup>2</sup> or Zone signal output*<sup>1</sup> : 1 point (Note 1)</li> </ul>

*1	Zone signal output :	Zone range is to be set to either Parameter No.1, 2 and it is
		always available after the home-return operation is
		complete.
*2 F	Position zone signal output :	This feature is associated with the specified position number.
		The zone range is set in the position table. The zone range is
		enabled only when the position is specified but disabled if
		another position is specified.

Note 1 The position zone signal output can be switched over to the zone signal output with the setting of Parameter No.149.

6.3 I/O Parameter 6.3.1 Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode



#### [For Positioner Mode 2]

Туре	Value set in parameter No.25	Mode	Overview
PIO Pattern 0	0 (at the delivery)	Positioning mode (Standard type)	<ul> <li>Number of positioning points : 64 points</li> <li>Position command : binary code</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>
PIO Pattern 1	1	Teaching mode (Teaching type)	<ul> <li>Number of positioning points : 64 points</li> <li>Position command : binary code</li> <li>Position zone signal output*2 : 1 point (Note 1)</li> <li>Writing current position data to position table enabled by PIO signal</li> </ul>
PIO Pattern 2	2	256-point mode (Number of positioning points : 256-point type)	<ul> <li>Number of positioning points : 256 points</li> <li>Position command : binary code</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>
PIO Pattern 3	3	512-point mode (Number of positioning points : 512-point type)	<ul> <li>Number of positioning points : 512 points</li> <li>Position command : binary code</li> <li>Zone signal output : None</li> </ul>
PIO Pattern 4	4	Solenoid valve mode 1 (7-point type)	<ul> <li>Number of positioning points : 7 points</li> <li>Position command : Individual number signal ON</li> <li>Zone signal output<sup>*1</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>
PIO Pattern 5	5	Solenoid valve mode 2 (3-point type)	<ul> <li>Number of positioning points : 3 points</li> <li>Position command : Individual number signal ON</li> <li>Completion signal : Signal equivalent to LS (limit switch) enabled</li> <li>Zone signal output<sup>11</sup> : 1 point</li> <li>Position zone signal output<sup>*2</sup> : 1 point <sup>(Note 1)</sup></li> </ul>

Zone signal output \*1

: Zone range is to be set to either Parameter No.1, 2 or No.23, 24 (Note 1) and it is always available after the home-return operation is complete.

\*2

Position zone signal output : This feature is associated with the specified position number. The zone range is set in the position table. The zone range is enabled only when the position is specified but disabled if another position is specified.

The position zone signal output can be switched over to the zone signal output with Note 1 the setting of Parameter No.149.

#### (18) PIO jog velocity (Parameter No.26), PIO jog velocity 2 (Parameter No.47)

No.	Name	Symbol	Unit	Input Range	Default factory setting
26	PIO jog velocity	IOJV	mm/s	1 to Actuator's max. speed	100
47	PIO jog velocity 2	IOV2	mm/s	1 to Actuator's max. speed	100

This is the setting of JOG operation speed by PIO signal when PIO Pattern 1 is selected in Positioner Mode 2.

Set the appropriate value considering how the system is to be used.

The maximum speed is limited to 250mm/s.

Note 1 Parameter No.47 "PIO jog velocity 2" is not used.



#### (19) Movement command type (Parameter No.27)

No.	Name	Symbol	Unit	Input Range	Default factory setting
27	Movement command type	FPIO	-	0 : Level 1 : Edge	0

This is the parameter enable in the operation modes and PIO patterns shown in the table below. It is able to change the start signals ST0 to ST\* from level to edge treatment.

<u> </u>		9
Operating Mode	Parameter No.25 PIO Pattern Selection	Start Signal
Positioner Mode 1	1	ST0 to 2
Bositionar Mada 2	4	ST0 to 6
Positioner Mode 2	5	ST0 to 2

Set Value	Input method	Description
0	Level	The actuator starts moving when the input signal turns ON. When the signal turns OFF during movement, the actuator will decelerate to a stop and complete its operation.
1	Edge	The actuator starts moving when the rising edge of the input signal is detected. The actuator will not stop when the signal turns OFF during the movement, until the target position is reached.

#### [Level System]



#### [Edge System]





(20) Default movement direction for excitation-phase signal detection (Parameter No.28)

No.	Name	Symbol	Unit	Input Range	Default factory setting
28	Default movement direction for excitation-phase signal detection	PHSP	Ι	0 : Reversed direction 1 : Forward direction	In accordance with actuator

Excitation phase signal detection<sup>(Note 1)</sup> is executed at the first servo-on after the power is supplied. Detection direction at this time is determined. Define the detection direction at this time.

Even though it is generally unnecessary to change this setting, set this to the direction which the motor is easy to move when the actuator interferes with the mechanical end or peripheral object at the time the power is supplied.

If the direction not interfering is the same direction as the home return direction, set the same values as set to Parameter No.5 Home Return Direction. If the direction is opposite, set the other values from Parameter No.5. (If No.5 is 0, set 1. If No.5 is 1, set 0.)

- Note 1 In Simple Absolute Type, the 2nd excitation phase signal detection is executed at the home-return operation complete to establish the absolute home point.
- (21) Excitation-phase signal detection time (Parameter No.29)

No.	Name	Symbol	Unit	Input Range	Default factory setting
29	Excitation-phase signal detection time	PHSP	msec	1 to 999	In accordance with actuator

Excitation phase signal detection<sup>(Note 1)</sup> is executed at the first servo-on after the power is supplied. Detection direction at this time is determined. Define the detection direction at this time.

It is not necessary to change this parameter in normal use, however, there are some cases that adjustment of this parameter is enable for recovery when a problem such as the excitation phase signal detection error or operation error is generated.

Contact us if it is necessary to change this parameter.

- Note 1 In Simple Absolute Type, the 2nd excitation phase signal detection is executed at the home-return operation complete to establish the absolute home point.
- (22) Excitation detection type (Parameter No.30)

No.	Name	Symbol	Unit	Input Range	Default factory setting
30	Excitation detection type	PHSP	_	0 : Conventional method 1 : New method 1 (For vertical mount installation) 2 : New method 2 (For horizontal mount installation)	0

Excitation phase signal detection<sup>(Note 1)</sup> is executed at the first servo-on after the power is supplied, and in the new method, we succeeded to make this operation smoother and quieter than ever (when compared in IAI products).

There is a risk that the slider or rod may drop at the excitation phase signal detection if setting to "2" (New Method 1) and installing the actuator in vertical mount. Establish the setting considering the posture of the installation. When the actuator is installed vertically, and if the slide or rod drops, set to "0" (Basic Method).

Note 1 In Simple Absolute Type, the excitation detection is executed at the home-return operation complete.





(23)	Velocit	y loop	pro	portional	gain	(Parameter No.31)	)
------	---------	--------	-----	-----------	------	-------------------	---

No.	Name	Symbol	Unit	Input Range	Default factory setting
31	Velocity loop proportional gain	VLPG	-	1 to 27661	In accordance with actuator

This becomes enable when the setting of Gain Scheduling (Parameter No.144) and the high output setting (Parameter No.152) are set disable.

[Refer to 6.2 High Output Setting and Gain Scheduling Function]

This parameter determines the response of the speed control loop. When the set value is increased, the follow-up ability to the velocity command becomes better (the servo-motor rigidity is enhanced). The higher the load inertia becomes, the larger the value should be set. However, excessively increasing the setting will cause overshooting or oscillation, which facilitates producing the vibrations of the mechanical system.



(24) Velocity loop integral gain (Parameter No.32)

No.	Name	Symbol	Unit	Input Range	Default factory setting
32	Velocity loop integral gain	VLPT	-	1 to 217270	In accordance with actuator

This becomes enable when the setting of Gain Scheduling (Parameter No.144) and the high output setting (Parameter No.152) are set disable.

[Refer to 6.2 High Output Setting and Gain Scheduling Function]

Any machine produces friction. This parameter is intended to cope with deviation generated by external causes including friction. Increasing the setting value improves the reactive force against load change. That is, the servo rigidity increases. However, increasing the parameter value excessively may make the gain too high, which then cause the machine system to be vibrated due to over-shoot or shaking.

Tune it to obtain the optimum setting by watching the velocity response.





#### (25) Torque filter time constant (Parameter No.33)

No.	Name	Symbol	Unit	Input Range	Default factory setting
33	Torque filter time constant	TRQF	Ι	0 to 2500	In accordance with actuator

This parameter decides the filter time constant for the torque command. When vibrations and/or noises occur due to mechanical resonance during operation, this parameter may be able to suppress the mechanical resonance. This function is effective for torsion resonance of ball screws (several hundreds Hz).

#### (26) Press velocity (Parameter No.34)

No.	Name	Symbol	Unit	Input Range	Default factory setting
34	Press velocity	PSHV	mm/s	1 to actuator's max.	In accordance with
				pressing speed	actuator

This is the parameter to set the velocity in pressing operation.

If a change to the setting is required, make sure to have the setting below the maximum pressing velocity of the actuator. Setting it fast may disable to obtain the specified pressing force. Also when setting at a low velocity, take 5mm/s as the minimum.



Caution: If the velocity of the positioning of the position table is set below this parameter, the pressing speed will become the same as the positioning speed.

#### (27) Safety velocity (Parameter No.35)

No.	Name	Symbol	Unit	Input Range	Default factory setting
35	Safety velocity	SAFV	mm/s (deg/s)	1 to 250 (below maximum speed)	100

This is the parameter to set the maximum speed of manual operation while the safety velocity selected in the teaching tool. Do not have the setting more than necessary.



(28)	Auto servo motor OFF	delav time 1, 2, 3	(Parameter No.36)	. No.37. No.38)
------	----------------------	--------------------	-------------------	-----------------

No.	Name	Symbol	Unit	Input Range	Default factory setting
36	Auto servo motor OFF delay time 1	ASO1	sec	0 to 9999	0
37	Auto servo motor OFF delay time 2	ASO2	sec	0 to 9999	0
38	Auto servo motor OFF delay time 3	ASO3	sec	0 to 9999	0

Set the duration before the servo turns OFF after positioning process is complete when the power saving function is used.

[Refer to Chapter 5 Power-saving Function.]

(29) Position complete signal output method (Parameter No.39)

No.	Name	Symbol	Unit	Input Range	Default factory setting
39	Position complete signal output method	FPIO	-	0: PEND 1: INP	0

It is valid when a mode other than PIO Pattern 1 = 3-point type [Solenoid Valve Type] in Positioner Mode 1 and PIO Pattern = 5 (Solenoid Valve Type 2 [3-point type]) in Positioner Mode 2 is being selected.

Select the type of positioning complete signal. There are two types of positioning complete signals, PEND and INP, and the condition of being OFF differs for each type. Select the suitable one considering the control method.

|--|

Setting	Signal Name	Description
0	PEND	<ul> <li>Turns ON if in positioning complete condition</li> <li>Remains ON even if current position is out of positioning width after positioning is complete</li> <li>Turns OFF during a pause no matter of moving/stopping</li> <li>Turns OFF during servo-off with no exception</li> </ul>
1	INP	Turns ON when current position is in the positioning width of indicated position number, and OFF when out of positioning width

Complete position No. outputs PM1 to PM\*\* and current position No. outputs PE0 to PE6 are issued in the similar way.

(30) Home-return input disable (Parameter No.40)

No.	Name	Symbol	Unit	Input Range	Default factory setting
40	Home-return input disable	FPIO	-	0 : Enabled 1 : Disabled	0

This parameter defines whether the home return input signal is disabled or enabled. Normally this parameter need not be changed.

Set Value	Description
0	Enable (Use the input signal)
1	Disable (Does not use the input signal)



#### (31) Enable function (Parameter No.42)

No.	Name	Symbol	Unit	Input Range	Default factory setting
42	Enable function	FPIO	_	0 : Enabled 1 · Disabled	1

Set valid/invalid the deadman switch function if the teaching pendant is equipped with a deadman switch.

Set Value	Description
0	Enable (Use the input signal)
1	Disable (Does not use the input signal)

#### (32) Silent interval magnification (Parameter No.45)

No.	Name	Symbol	Unit	Input Range	Default factory setting
45	Silent interval magnification	SIVM	times	0 to 10	0

It is not necessary to change the parameter if a teaching tool such as PC software is to be used.

#### (33) Velocity override (Parameter No.46)

No.	Name	Symbol	Unit	Input Range	Default factory setting
46	Velocity override	OVRD	%	0 to 100	100

When move commands are issued from the PLC, the moving speed set in the "Velocity" field of the position table can be overridden by the value set by this parameter.

Actual movement velocity = [Velocity set in the position table] × [setting value in Parameter No.46] Example) Value in the "Velocity" field of the position table: 500mm/s

Setting in Parameter No.46 20%

In this case, the actual movement speed becomes 100mm/s.

The minimum setting unit is 1% and the input range is 1 to 100%.

(Note) This parameter is ignored for move commands from a teaching tool such as PC software.

(34) PIO jog velocity 2 (Parameter No.47) [Refer to Parameter No.26 PIO jog velocity]

6.3 I/O Parameter 6.3.1 Positioner Mode 2 and Pulse Train Control Mode



(35) PIO inch distance, PIO inch distance 2 (Parameter No.48, No.49)

No.	Name	Symbol	Unit	Input Range	Default factory setting
48	PIO inch distance	IOID	mm	0.01 to 1.00	0.1
49 <sup>(Note1)</sup>	PIO inch distance 2	IOD2	mm	0.01 to 1.00	0.1

Set the inching distance for the inching input command from PLC when PIO Pattern = 1 (Teaching Mode) is selected in Positioner Mode 2. The maximum allowable value is 1 mm.

Note 1 Parameter No.49 "PIO inch distance 2" is not used.

(36) Load output judgment time period (Parameter No.50)

No.	Name	Symbol	Unit	Input Range	Default factory setting
50	Load output judgment time period	LDWT	msec	0 to 9999	255

If the PIO Pattern = 0, 2, 3, 4 is selected in Positioner Mode, set up the time to judge if Torque Level Status Signal (TRQS) is ON.

Torque Level Status Signal (TRQS) turns on when the commanded torque exceeds the value set as the "threshold" of the position data for more than the time set in this parameter at pressing operation.

(37) Torque inspected range (Parameter No.51)

No.	Name	Symbol	Unit	Input Range	Default factory setting
51	Torque inspected range	TRQZ	-	0 : Enabled 1 : Disabled	0

Load output (LOAD) turns ON when the current exceeds the value [%] set as the threshold in the position table within the range (inspection range) set in Zone + / Zone – in the position table while performing the pressing operation with PIO Pattern = 0, 2, 3, 4 being selected in Positioner Mode 2.

#### (38) Default acceleration/deceleration mode (Parameter No.52)

No.	Name	Symbol	Unit	Input Range	Default factory setting
52	Default acceleration/deceleration mode	CTLF	Ι	0 to 2	0 (Trapezoid)

These values are automatically set to "Acceleration/Deceleration Mode" of the applicable position number when the target position is written to the unregistered position table.

<u> </u>	0
Set Value	Description
0	Trapezoid
1	S-motion
2	Primary delay filter



#### (39) Default stop mode (Parameter No.53)

No.	Name	Symbol	Unit	Input Range	Default factory setting
53	Default stop mode	CTLF	Ι	0 to 7	0 (Does not use)

This parameter defines the power-saving function. [Refer to Chapter 5 Power-saving Function.]

#### (40) Position-command primary filter time constant (Parameter No.55)

No.	Name	Symbol	Unit	Input Range	Default factory setting
55	Position-command primary filter time constant	PLPF	msec	0.0 to 100.0	0

Use this in the case to set the value in "Acceleration/Deceleration" box in the position table to 2 "1-step delay filter", or in the case that there is no acceleration/deceleration function the host controller in Pulse Train Control Mode.

The primary delay filter is disabled if "0" is set.

The greater the setting value is, the longer the delay is and the slower the acceleration/deceleration is. Even though the impact at acceleration and deceleration are reduced, longer time is required especially for the operation end, thus the cycle time will be extended.

Refer to 4.3 [9] (1) Position command primary filter time constant for the details of Pulse Train Control Mode.





(41) S-motion rate (Parameter No.56)

No.	Name	Symbol	Unit	Input Range	Default factory setting
56	S-motion rate	SCRV	%	0 to 100	0

This parameter is used when the value in the "Acceleration/deceleration mode" field of the position table is set to "1 [S-motion]".

This enables to ease the impact at acceleration and deceleration without making the takt time longer.



The S-motion is a sine curve that has the acceleration time as 1	cycle.
The level of its swing width can be set by this parameter.	-

Setting of Parameter No.56 [%]	Level of swing width
0 [Set in delivery]	No S-motion (Dotted line shown in the image below)
100	Sine curve swing width × 1 (Double-dashed line shown in the image below)
50	Sine curve swing width × 0.5 (Dashed line shown in the image below)
10	Sine curve swing width × 0.1 (Solid line shown in the image below)



Caution: 1) If the S-motion is specified in acceleration/deceleration mode, executing position command or direct value command while the actuator is moving causes an actuator to move along the trapezoid pattern. To change a speed during operation, be sure to specify such a position command while the actuator is in pause state.

- 2) If acceleration time or deceleration time exceeds 2 seconds, do not specify S-motion control. The actuator will fail to operate normally.
- 3) Do not perform temporary stop during acceleration or deceleration. The speed change (acceleration) may cause the dangerous situation.



- (42) Torque limit (Parameter No.57)
   This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (43) Deviation clear at servo OFF & alarm stop (Parameter No.58) This parameter is exclusively used for the pulse-train control mode. [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (44) Deviation error monitor during torque limiting (Parameter No.59) This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (45) Deviation counter clear input (Parameter No.60)
   This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (46) Torque limit command input (Parameter No.61) This parameter is exclusively used for the pulse-train control mode. [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (47) Pulse count direction (Parameter No.62) This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (48) Command pulse input mode (Parameter No.63)
   This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (49) Command pulse input mode polarity (Parameter No.64)
   This parameter is exclusively used for the pulse-train control mode.
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (50) Electronic gear numerator (Parameter No.65) This parameter is exclusively used for the pulse-train control mode. [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]





- (51) Electronic gear denominator (Parameter No.66) This parameter is exclusively used for the pulse-train control mode. [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (52) Compulsory stop input (Parameter No.67)
   This parameter is exclusively used for the pulse-train control mode...
   [Refer to Chapter 4, 4.3 Operation in Pulse Train Control Mode, [9] Parameter Settings Required for Advanced Operations]
- (53) Position feed forward gain (Parameter No.71)

No.	Name	Symbol	Unit	Input Range	Default factory setting
71	Feed forward gain	PLFG	I	0 to 100	0

This parameter defines the level of feed forward gain to be applied to position control. Setting this parameter allows the servo gain to be increased and the response of the position control loop to be improved. This is the parameter to improve the takt time and traceability even more after fine-tuning the settings for "Servo Gain Number (Parameter No.7)", "Velocity Loop Proportional Gain (Parameter No.31)", "BU velocity loop proportional gain (Parameter No.153)", "GS velocity loop proportional gain (Parameter No.145)" etc. This can result in shorter positioning time.

The gain adjustment of position, speed and current loop in feedback control can directly change the response of the servo control system. Thus, improper adjustment may cause the control system to be unstable and further vibrations and/or noises to occur. On the other hand, since this parameter only changes the speed command value and does not relate with the servo loop, it neither makes the control system unstable nor generate continuous vibrations and/or noises. However, excessive setting may generate vibrations and/or noises until the machine can follow command values in every operation.

In the trapezoidal pattern, adding the value resulting from multiplying the speed command by the feed forward gain to the speed command can reduce the delay of speed follow-up and the position deviation.

The feedback control providing control in accordance with the result causes control delay to occur. In contrast, compensative control is available that is not dependent on control delay.





#### (54) Ball screw lead length (Parameter No.77)

No.	Name	Symbol	Unit	Input Range	Default factory setting
77	Ball screw lead length	LEAD	mm	0.01 to 999.99	In accordance with actuator

This parameter set the ball screw lead length.

The factory setting is the value in accordance with the actuator characteristics.

Caution: If it is not suited to the actuator specifications, not only that operation cannot be performed with the indicated speed, acceleration/deceleration or movement amount, but also it may generate an alarm or cause malfunction.

#### (55) Absolute unit (Parameter No.83)

No.	Name	Symbol	Unit	Input Range	Default factory setting
83	Absolute unit	ETYP	-	0: Incremental 1: Simple Absolute Type	0

Set to 1 if simple absolute type and 0 if others.

#### (56) Software limit margin (Parameter No.88)

No.	Name	Symbol	Unit	Input Range	Default factory setting
88	Software limit margin	SLMA	mm	0 to 9999.99	0

This is the parameter to set the amount of over error detection against the soft limit errors set in Parameters No.3 and No.4.

It is not necessary to change the setting in normal use.







FRE

No.	Name	Symbol	Unit	Input Range	Default factory setting
91	Current limit value at stopping due to miss-pressing	PSFC	_	0: Current limiting value at stop 1: Current limit value during pressing	0

This parameter defines the restricted current value at stopping due to miss-pressing. Servo-lock is executed following this setting until the next movement command.

(57) Current limit value at stopping due to miss-pressing (Parameter No.91)

Parameter No.91	Description
0	Current limitation value while in operation stop (setting value in the current limiting value at positioning stop (Parameter No.12))
1	Press-motion current-limiting value

#### (58) Stop method at servo OFF (Parameter No.110)

No.	Name	Symbol	Unit	Input Range	Default factory setting
110	Stop method at servo OFF	PSOF	_	0: Rapid stop 1: Deceleration to stop	0

Select the stop method of when the servo is turned OFF during an operation. If 1 is selected, the actuator decelerates with position data in execution and stops.

#### (59) Calendar function (Parameter No.111)

No.	Name	Symbol	Unit	Input Range	Default factory setting
111	Calendar function	FRTC	-	0: Unused 1: Use	1

Select use/not use of the calendar function (RTC) in PIO converter.

Set the current time with using a teaching tool when the calendar function is used.

[Refer to the instruction manual of the teaching tool for the details.]

In use of RTC, the alarm occurrence time in the alarm list is the time at which an alarm has occurred.

If RTC is not in use, the alarm generated time in the alarm list shows the time passed since 0sec that is the time the power is supplied to the controller.

Set Value	Description
0	Unused
1	Use



#### (60) Monitoring mode (Parameter No.112)

No.	Name	Symbol	Unit	Input Range	Default factory setting
112	Monitoring mode	FMNT	-	0: Does not use 1: Monitor function 1	0
				2: Monitor function 2	

The controller can be connected with PC software to monitor the servo. This parameter allows you to select a monitoring mode function (servo monitor). Check the Instruction Manual of the RC PC software for details.

Set Value	Description
0	Unused
1	Sets the 4CH record mode.
2	Sets the 8CH record mode.

#### (61) Monitoring period (Parameter No.113)

No.	Name	Symbol	Unit	Input Range	Default factory setting
113	Monitoring period	FMNT	msec	1 to 100	1

Establish the setting for the sampling cycle (for time frequency to gather data) when the monitoring mode is selected.

By making this parameter bigger, the sampling cycle becomes longer.

It is set to 1ms in the initial setting. Setting can be established in 1ms unit up to 100ms.

1ms frequency setting	100ms frequency setting
At 4CH Record Mode:	At 4CH Record Mode:
Max. Obtainable Time 1.5sec	Max. Obtainable Time 150sec
At 8CH Record Mode:	At 8CH Record Mode:
Max. Obtainable Time 0.75sec	Max. Obtainable Time 75sec

#### (62) Overload level ratio (Parameter No.143)

No.	Name	Symbol	Unit	Input Range	Default factory setting
143	Overload level ratio	OLWL	%	50 to 100	100

This parameter is not used.

6.3 I/O Parameter 6.3.1 Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode

# ERC**3**

(63) Gain scheduling upper limit multiplying ratio (Parameter No.144)

No.	Name	Symbol	Unit	Input Range	Default factory setting
144	Gain scheduling upper limit multiplying ratio	GSUL	%	0 to 1023	0 (Disabled)

Gain scheduling is the function to change the gain in accordance with the operation speed. This parameter shows the multiplying rate of the upper limit of the changeable gain. With the set multiplying rate, the values for GS Velocity Loop Proportional Gain (Parameter No.145) and GS Velocity Loop Integrated Gain (Parameter No.146) are changed.

Set Value	Description
100 or less	Gain scheduling disabled
101 to 1023	Gain scheduling enabled Set to 300 if enable

(64) GS velocity loop proportional gain (Parameter No.145)

No.	Name	Symbol	Unit	Input Range	Default factory setting
145	GS velocity loop proportional gain	GSPC	Ι	1 to 30000	750

If the gain scheduling upper limit multiplying ratio (Parameter No.144) is set enabled, this parameter setting becomes enable for the velocity loop proportional gain. It is not necessary to change the setting in normal use.

(65) GS velocity loop integral gain (Parameter No.146)

No.	Name	Symbol	Unit	Input Range	Default factory setting
146	GS velocity loop integral gain	GSIC	Ι	1 to 500000	4500

If the gain scheduling upper limit multiplying ratio (Parameter No.144) is set enabled, this parameter setting becomes enable for the velocity loop integral gain. It is not necessary to change the setting in normal use.

(66) Total movement count threshold (Parameter No.147)

No.	Name	Symbol	Unit	Input Range	Default factory setting
147	Total movement count threshold	тмст	Times	0 to 999999999	0 (Disabled)

Notice will be made with Movement Counter Threshold Exceeding Alarm (04E) if the total number of movement exceeds the value set in this parameter. The judgment would not be made if the value is set to 0.



#### (67) Total operated distance threshold (Parameter No.148)

No.	Name	Symbol	Unit	Input Range	Default factory setting
148	Total operated distance threshold	ODOT	m	0 to 999999999	0 (Disabled)

Notice will be made with Movement Distance Threshold Exceeding Alarm (04F) if the total distance of movement exceeds the value set in this parameter. The judgment would not be made if the value is set to 0.

#### (68) Zone output changeover (Parameter No.149)

No.	Name	Symbol	Unit	Input Range	Default factory setting
149	Zone output changeover	FPIO	-	0: Not to change 1: To change	0

The enable zone signals are determined by the setting of this parameter and the setting of Parameter No.25 "PIO Pattern Select".

The relationship between the parameter settings and enable zone signal outputs are as shown in the table below.

Operating Mode	Parameter No.25	Parameter No.149 Zo	one Output Changeover	
Operating wode	PIO Pattern Selection	0	1	
	0	ZONE1 no m	atter settings	
Positioner Mode 1	1	There are no	zone outputs	
	2	PZONE	ZONE1	
	0	ZONE1	ZONE1	
	0	PZONE	ZONE2	
	1			
Positioner Mode 2	2	FZONE	ZONET	
	3	There is no zone signal output		
	4	ZONE1	ZONE1	
	5	PZONE	ZONE2	
Pulse Train Mode	There is no zone signal output			

#### (69) High output setting (Parameter No.152)

No.	Name	Symbol	Unit	Input Range	Default factory setting
152	High output setting	BUEN	-	0: Disable 1: Enable	1 (Enabled)

Establish the setting of enable/disable for the high output function.

# 6.3 I/O Parameter 6.3.1 Positioner Mode 1, Positioner Mode 2 and Pulse Train Control Mode

## ERC**3**

(70) BU velocity loop proportional gain (Parameter No.153)

No.	Name	Symbol	Unit	Input Range	Default factory setting
153	BU velocity loop proportional gain	BUPC	-	1 to 10000	200

If the high output setting is set enabled, this parameter setting becomes enable for the velocity loop proportional gain.

This is the parameter to determine the responsiveness of the velocity loop. Setting bigger values provides more capacity to track the speed command (it is described as the servo stiffness gets higher). The higher the load inertia becomes, the larger the value should be set. Setting the value too large causes such problems as overshooting and vibration, which would make the mechanical components vibrate.



(71) BU velocity loop integral gain (Parameter No.154)

No.	Name	Symbol	Unit	Input Range	Default factory setting
154	BU velocity loop integral gain	BUIC	-	1 to 100000	4000

If the high output setting is set enabled, this parameter setting becomes enable for the velocity loop integrated gain.

Any machine produces friction. This parameter is intended to cope with deviation generated by external causes including friction. Setting bigger values provides more reinforced reaction force against the load fluctuation, thus higher servo stiffness. However, increasing the parameter value excessively may make the gain too high, which then causes the machine system to be vibrated due to overshoot or shaking.

Tune it to obtain the optimum setting by watching the velocity response.





#### (72) Absolute battery retention time (Parameter No.155)

No.	Name	Symbol	Unit	Input Range	Default factory setting
155	Absolute battery retention time	AIP	days	0:20 days 1:15 days 2:10 days 3: 5 days	0

For Simple Absolute Type, establish the setting to define how long the position information of the encoder is to be remained for after the power to the controller is turned OFF. Setting can be done from four grades. Maximum number of the motor revolution due to external force during the power is OFF is controlled by the set days. Establish the setting assuming the speed when the work transporting parts, slider or rod, on the actuator is moved by external force during the power being OFF. The position information will lose if the number of motor revolution exceeds the set value. Consider safety margin when establishing the setting.

Motor	r rotation	[rpm]	= Move	d sp	beed	[mm/s]	/ Lead	length	[mm]	$\times 60$	
											_

		<u> </u>			
Sotting	Position information	Motor max. rotation speed			
Setting	retaining day (reference)	(rpm)			
0 (Initial setting)	20 days	100			
1	15 days	200			
2	10 days	400			
3	5 days	800			
2 3	10 days 5 days	400 800			

(73) Torque inspected range/Light malfunction output select (Parameter No.156)

No.	Name	Symbol	Unit	Input Range	Default factory setting
156	Torque inspected range/Light malfunction output select	SLAL	-	0: Load judgment output or torque level status signal output 1: Message level alarm	0

The output of Load judgment output (LOAD) or Torque level status signal (TRQS) can be changed to an output of Message Level Alarm (ALML) when PIO Pattern = 0, 2, 3, 4 is selected in Positioner Mode 2.



[3] Servo Adjustment

The parameters are preset at the factory before shipment so that the actuator operates stably within the rated (maximum) transportable weight.

However, the preset setting cannot always be the optimum load condition in the actual use. In such cases, servo adjustment may be required.

This section describes the basic servo adjustment method.

Caution: Rapid and excessive settings are dangerous. They may devices including the actuator to be damaged and/or people to be injured. Take sufficient note on the setting. Record settings during servo adjustment so that prior settings can always be recovered.

When a problem arises and the solution cannot be found, please contact IAI.

No.	Situation that requires adjustment		How to Adjust						
1	Takes time to finish positioning	•	<ul> <li>Set Parameter No.55 "Position command primary filter time constant" to "0" if it is set.</li> </ul>						
	Positioning accuracy is not appropriate Shorter takt time is desired	•	<ul> <li>Increase the value of Parameter No.7 "Servo gain number". By setting a larger value, the follow-up ability to the position command becomes better. Set the value to any of 3 to 10 roughly or up to 15 at the maximum. If the value is too large, an overshoot is caused easily and may cause noise or vibration. For the velocity loop proportional gain parameter, the parameter number differs depending on the setting of enable/disable of Gain Scheduling and the high output setting.</li> <li>Shown below is the table of velocity loop proportional gain parameter numbers that are enable.</li> </ul>						
			Gain Scheduling	101 to (Enable)	Parameter No.145	Parameter No.145			
			(Parameter No.144)	to 101 (Disable)	Parameter No.153	Parameter No.31			
2	Vibration is generated at acceleration/deceleration	•	<ul> <li>The cause of the problem is excessive "acceleration/deceleration setting" or vulnerable structure of the unit on which the actuator is installed. If possible, reinforce the unit itself, first.</li> <li>Decrease the values of "acceleration/deceleration setting".</li> <li>Decrease the number of Parameter No.7 "Servo gain number". If the Parameter No.7 "Servo gain number" is too low, it takes long time to finish the positioning.</li> </ul>						



No.	Situation that requires adjustment		How	to Adjust					
3	Speed is uneven during the movement Speed accuracy is not appropriate	<ul> <li>Increase the value setting a larger val command become Setting too large va to vibrate. As a refe by little by 20% fro For the velocity loc number differs dep Gain Scheduling a Shown below is parar</li> <li>Gain Scheduling (Parameter No.144)</li> </ul>	of "Velocit ue, the foll s better. alue makes erence for m the initia op proportio bending on nd the high the table of meter num	y loop proportiona ow-up ability to th s the mechanical of the setting, increa al setting. onal gain paramet the setting of ena n output setting. of velocity loop pro- bers that are enal <u>High Output Setting</u> 1 (Enable) Parameter No.145	al gain". By e speed components easy ase the value little er, the parameter able/disable of oportional gain ole. (Parameter No.152) 0 (Disable) Parameter No.145				
4	Abnormal noise is generated. Especially, when stopped state and operation in low speed (less than 50mm/sec), comparatively high noise is generated.	<ul> <li>Input the Parameter increase by 50 as large, it may cause generation of vibra</li> <li>[Important] Prior to A This phenomenon is mechanical componer also resonate if its st Before having an adj</li> <li>Isn't the setting in "Velocity Loop Program" described b For the velocity loop integ differs depending Scheduling and the Otion of the set in the set ing</li> </ul>	Constant". Try to the setting is too bility and lead the uator itself may belt-driven type. n Number", Loop Integrated eter and the arameter number able of Gain						
		Shown below is parar	the table on the table of	of velocity loop pro bers that are enat	portional gain ble.				
				High Output Setting	(Parameter No.152)				
			101 to	1 (Enable)	0 (Disable)				
		Gain Scheduling (Parameter No.144)	(Enable) to 101 (Disable)	Parameter No.145 Parameter No.153	Parameter No.145 Parameter No.31				
		Shown below is the table of velocity loop integrated parameter numbers that are enable. High Output Setting (Paramete							
			101 to	T (Enable)	0 (Disable)				
		Gain Scheduling (Parameter No.144)	(Enable) to 101	Parameter No.146 Parameter No.154	Parameter No.146 Parameter No.32				
		<ul> <li>2) The stiffness of the load is sufficient as much as portion the attachments are not loosened.</li> <li>3) The actuator unit is mounted securely with a propertion of the secure of the secu</li></ul>							



No.	Situation that requires adjustment	How to Adjust
5	Large static friction of	<ul> <li>Set Parameter No.71 "Feed forward gain".</li> </ul>
	load makes actuator start slowly.	Select a value in the range from 10 to 50 roughly. The larger the setting value is, the smaller the deviation is. Then the response
	Large load inertia makes	is improved.
	response of actuator low	Setting a large value may cause vibrations and/or noises to
	at start and stop.	occur.
	Takt time is desired to be	Set the feed forward gain in order to improve the response of
	shortened.	the actuator further after adjusting Parameter No.7 "Servo gain
		number" and Parameter No.31 "Velocity loop proportional gain".



#### 6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3

#### [1] I/O Parameter List

The categories in the table below indicate whether parameters should be set or not. There are five categories as follows:

- A : Check the settings before use.
- B : Use parameters of this category depending on their uses.
- C : Use parameters of this category with the settings at shipments leaving unchanged as a rule. Normally they may not be set.
- D : Parameters of the category are set at shipment in accordance with the specification of the actuator. Normally they may not be set.
- E : Parameters of the category are exclusively used by us for convenience of production. Changing their settings may not only cause the actuator to operate improperly but also to be damaged. So, never change the setting of the parameters.

Category do not appear on the teaching tool.

Also, the unused parameter numbers are not mentioned in the list.

#### [MEC Mode 1, MEC Mode 2 and MEC Mode 3]

		,								
No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Mec Mode 1	For Mec Mode 2	For Mec Mode 2	Relevant sections This section
1	В	Positioning width	INP	mm	0.01 to Actuator eigenvalue	In accordance with actuator (Note1)	0			[2] (1)
3	С	Servo gain No.	PLG0	-	0 to 31	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (2) [3]
4	С	Torque filter time constant	TRQF	-	0 to 2500	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (3) [3]
5	С	Velocity loop proportional gain	VLPG	-	1 to 27661	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (4) [3]
6	С	Velocity loop integral gain	VLPT	-	1 to 217270	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (5) [3]
7	С	Press velocity	PSHV	mm/s	1 to actuator's max. pressing speed	In accordance with actuator <sup>(Note1)</sup>	0	0		[2] (6)
8	С	Press & hold stop judgment period	PSWT	msec	0 to 9999	255	0	0		[2] (7)
9	в	Current limitation in pressing and bridging	PSFC	_	0: Current limitation value while moving 1: Push-motion current-limiting value	0	0	0		[2] (8)
10	В	Auto servo motor OFF delay time	ASO1	sec	1 to 9999	1	0	0	0	[2] (9)
11	В	Stop mode selection	SMOD	-	0: Full stop 1: Servo-motor stop	0	0	0	0	[2] (10)
12	В	Current-limiting value at standstill during positioning	SPOW	%	1 to 70	35	0	0	0	[2] (11)
13	С	Current-limiting value during home return	ODPW	%	1 to 100	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (12)
15	С	Soft limit	LIMM	mm	0.01 to 9999.99	Actual stroke (Note1)	0	0	0	[2] (13)
16	С	Home return offset level	OFST	mm	0.00 to 9999.99	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (14)
17	D	Home return direction	ORG	-	0: Reverse 1: Forward	In accordance with actuator <sup>(Note1)</sup>	0	0	0	[2] (15)
18	В	Simple absolute unit	ETYP	-	0: Incremental 1: Simple absolute type 1	In accordance with specification at order accepted		0		[2] (16)
19	A	Absolute battery retention time	AIP	days	0: 20 days 1: 15 days 2: 10 days 3: 5 days	0		0		[2] (17)
20	В	Position data change password	PASS		0000 to 9999	0000	0	0		[2] (18)
25	В	PIO inch distance	IOID	mm	0.01 to 1.00	0.1	0	0	0	[2] (19)

Note 1 The setting values vary in accordance with the specification of the actuator. At shipment, the parameters are set in accordance with the specification.

Note 2 This setting cannot be made for Quick Teach. This shows the effective parameters during an operation.

6.3 I/O Parameter

6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3


No.	Category	Name	Symbol	Unit	Input Range	Default factory setting	For Mec Mode 1	For Mec Mode 2	For Mec Mode 2	Relevant sections This section
26	В	Total movement count threshold	TMCT	time	0 to 99999999	0 (Disabled)	0	0		[2] (20)
27	В	Total operated distance threshold	ODOT	m	0 to 99999999	0 (Disabled)	0	0		[2] (21)
28	в	High output setting	BUEN	-	0: Disabled 1: Enabled	1	0	0		[2] (22)
29	в	BU velocity loop proportional gain	BUPC	1	1 to 10000	200	0	0		[2] (23) [3]
30	В	BU velocity loop integral gain	BUIC	-	1 to 10000	4000	0	0		[2] (24) [3]

Caution :	<ul> <li>Parameter setting cannot be conducted in Quick Teach.</li> </ul>
	Use either MEC PC Software or a teaching pendant.
	• Please note that the high output setting automatically turns disable if Quick Teach equipped with a power supply unit (PCM-PST-1 or PCM-PST-2) is connected.

Chapter 6 Adjustment of Operation



#### [2] Detail Explanation of Parameters

#### (1) Default positioning width (in-position) (Parameter No.1)

No.	Name	Symbol	Unit	Input Range	Default factory setting
1	Default positioning width	INP	mm	0.01 <sup>(Note 1)</sup> to 999.99	0.10

The positioning complete signal PEND/INP is output once the remaining movement amount comes into this width.

Note 1 It is down to the minimum positioning width (L = Lead length/800).

#### (2) Servo gain number (Parameter No.3)

No.	Name	Symbol	Unit	Input Range	Default factory setting
3	Servo gain number	PLGO	Ι	0 to 31	In accordance with actuator

The servo gain is also called position loop gain or position control system proportion gain. The parameter defines the response when a position control loop is used. Increasing the set value improves the tracking performance with respect to the position command. However, increasing the parameter value excessively increases the chances of overshooting.

When the set value is too low, the follow-up ability to the position command is degraded and it takes longer time to complete the positioning.

For a system of low mechanical rigidity or low natural frequency (every object has its own natural frequency), setting a large servo gain number may generate mechanical resonance, which then cause not only vibrations and/or noises but also overload error to occur.



#### (3) Torque filter time constant (Parameter No.4)

No.	Name	Symbol	Unit	Input Range	Default factory setting
4	Torque filter time constant	TRQF	_	0 to 2500	In accordance with actuator

This parameter decides the filter time constant for the torque command. When vibrations and/or noises occur due to mechanical resonance during operation, this parameter may be able to suppress the mechanical resonance. This function is effective for torsion resonance of ball screws (several hundreds Hz).

6.3 I/O Parameter 6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3



#### (4) Velocity loop proportional gain (Parameter No.5)

No.	Name	Symbol	Unit	Input Range	Default factory setting
5	Velocity loop proportional	VLPG	-	1 to 27661	In accordance with
	gain				actuator

It is enable when the high output setting (Parameter No.28) is set disable.

This parameter determines the response of the speed control loop. When the set value is increased, the follow-up ability to the velocity command becomes better (the servo-motor rigidity is enhanced). The higher the load inertia becomes, the larger the value should be set. However, excessively increasing the setting will cause overshooting or oscillation, which facilitates producing the vibrations of the mechanical system.

[Reference Item] Refer to 6.2 High Output Setting and Gain Scheduling Function



#### (5) Velocity loop integral gain (Parameter No.6)

No.	Name	Symbol	Unit	Input Range	Default factory setting
6	Velocity loop integral gain	VLPT	_	1 to 217270	In accordance with actuator

It is enable when the high output setting (Parameter No.28) is set disable.

Any machine produces friction. This parameter is intended to cope with deviation generated by external causes including friction. Increasing the setting value improves the reactive force against load change. That is, the servo rigidity increases. However, increasing the parameter value excessively may make the gain too high, which then cause the machine system to be vibrated due to over-shoot or shaking.

Tune it to obtain the optimum setting by watching the velocity response. [Reference Item] Refer to 6.2 High Output Setting and Gain Scheduling Function





#### (6) Press velocity (Parameter No.7)

No.	Name	Symbol	Unit	Input Range	Default factory setting
7	Press velocity	PSHV	mm/s	0.01 to actuator's max. pressing speed	In accordance with actuator

This is the parameter to set the velocity in pressing operation.

If a change to the setting is required, make sure to have the setting below the maximum pressing velocity of the actuator. Setting it fast may disable to obtain the specified pressing force. Also when setting at a low velocity, take 5mm/s as the minimum.





(7) Press & hold stop judgment period (Parameter No.8)

No.	Name	Symbol	Unit	Input Range	Default factory setting
8	Press & hold stop judgment period	PSWT	msec	0 to 9999	255

#### Judging completion of pressing operation

Monitoring the torque (current limit) set in "Pressing Force" in the operation condition table in %, it turns ON the pressing complete signal PE\* when the load current during pressing operation comes to the following condition. PE\* turns ON once the condition is satisfied even if the work is not stopped.

(Accumulated time in which current reaches pressing value [%])

- (accumulated time in which current is less than pressing value [%]) ≥ 255 ms (Parameter No.8) Decrease in current due to movement of work Current Pressing [%] Time 200ms 20ms 75ms Operation Approach end 295ms Pressing start start Contacting work 200ms + 75ms – 20ms ≥ 255ms Pressing complete (PENDoutput)

6.3 I/O Parameter 6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3



(8) Current limit value at stopping due to miss-pressing (Parameter No.9)

No.	Name	Symbol	Unit	Input Range	Default factory setting
9	Current limit value at stopping due to miss-pressing	PSFC	-	0: Current limiting value at stop 1: Current limit value during pressing	0

This parameter defines the restricted current value at stopping due to miss-pressing. This restricted current value locks the servo till the next moving command.

(9) Auto servo motor OFF delay time (Parameter No.10)

No.	Name	Symbol	Unit	Input Range	Default factory setting
10	Auto servo motor OFF delay time	ASO1	sec	0 to 9999	1

Set the duration before the servo turns OFF after positioning process is complete when the power saving function is used.

[Refer to Chapter 5 Power-saving Function.]

(10) Stop mode selection (Parameter No.11)

No.	Name	Symbol	Unit	Input Range	Default factory setting
11	Stop mode selection	CTLF	Ι	0: Full stop 1: Servo-motor stop	0 (Does not use)

This parameter defines the power-saving function. For complete stop, the actuator stops with the servo being on. For servo stop, it stops with the full servo control. [Refer to Chapter 5 Power-saving Function.]

(11) Current-limiting value at standstill during positioning (Parameter No.12)

No.	Name	Symbol	Unit	Input Range	Default factory setting
12	Current-limiting value at standstill during positioning	SPOW	%	1 to 70	35

When the value is increased, the stop holding torque is increased. It is not necessary to change this setting in normal use. Movement due to external force can be prevented by setting the value bigger in case a large force is applied during a stop. However, there is a risk that motor or controller may burn if the setting is too high. Please contact IAI.

(12) Current-limiting value during home return (Parameter No.13)

No.	Name	Symbol	Unit	Input Range	Default factory setting
13	Current-limiting value during home return	ODPW	%	1 to 100	In accordance with actuator

The factory setting conforms to the standard specification of the actuator.

Increasing this setting will increase the home return torque.

It is not necessary to change this setting in normal use. Home-return operation may complete in front of the proper point in some cases depending on how it is installed or load is attached when the product is vertically mounted. It is necessary to increase the setting value in such cases. Other causes can also be considered, so contact us in advance to making a change.



#### (13) Soft limit (Parameter No.15)

No.	Name	Symbol	Unit	Input Range	Default factory setting
15	Soft limit	LIMM	mm	0.01 to 9999.99	Actual stroke

Actuator enable stroke is set at the delivery.

Adjustment can be made freely within the movable range considering the suitability to the system for purposes of avoidance to interference, crash, etc.

The minimum setting unit is 0.01mm.

Example) Assuming the effective stroke length is set to 80mm;



Note that the operational range with jog or inching after home-return complete should be 0.1mm outside the setting value. Also, Alarm Code 0D9 "Soft Limit Exceeding Error" is issued when exceeded the setting value by 0.3mm.

#### (14) Home return offset level (Parameter No.16)

No.	Name	Symbol	Unit	Input Range	Default factory setting
16	Home return offset level	OFST	mm	0.00 to 9999.99	In accordance with actuator

In this setting can set the distance from the mechanical end to the home position. An adjustment is available for the following cases.

- 1) Want to match the actuator home position and the mechanical origin of the system.
- 2) Want to set a new home after reversing the factory-set home direction.
- 3) Want to eliminate a slight deviation from the previous home position generated after replacing the actuator.

#### [Adjustment Process]

- 1) Homing execution
- 2) Offset check
- 3) Parameter setting change
- 4) After the setting, repeat home return several times to confirm that the actuator always returns to the same home position.

#### Caution:

- Soft limit takes the home position as the datum. Therefore, when a change is made to the value of home-return offset level, also revise the value for soft limit.
- If the home return offset has been changed, the soft limit parameters must also be adjusted accordingly.

Do not set a smaller value than the initial setting value for Home Return Offset. Normal excitation detection cannot be performed, and there may be a risk of generating the excitation detection error or causing abnormal noise.

In case the there is a necessity of setting a value less than the initial setting, contact IAI.

6.3 I/O Parameter 6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3



#### (15) Home return direction (Parameter No.17)

No.	Name	Symbol	Unit	Input Range	Default factory setting
17	Home return direction	ORG	-	0: Reverse 1: Forward	In accordance with actuator

Unless there is an indication of home-reversed type (option), the direction of the home return for the straight axis is located on the motor side. [Refer to the coordinate system of the actuator.]

If it becomes necessary to reverse the home direction after the actuator is installed on the machine, change the setting.

#### (16) Simple absolute unit (Parameter No.18)

No.	Name	Symbol	Unit	Input Range	Default factory setting
18	Simple absolute unit	ETYP	Ι	0 : Enabled 1 : Disabled	0

Set to 1 for Simple Absolute Type of PIO Converter, and 0 for others.

#### (17) Absolute battery retention time (Parameter No.19)

No.	Name	Symbol	Unit	Input Range	Default factory setting
19	Absolute battery retention time	AIP	days	0:20 days 1:15 days 2:10 days 3: 5 days	0

For Simple Absolute Type, establish the setting to define how long the position information of the encoder is to be remained for after the power to the controller is turned OFF. Setting can be done from four grades. Maximum number of the motor revolution due to external force during the power is OFF is controlled by the set days. Establish the setting assuming the speed when the work transporting parts, slider or rod, on the actuator is moved by external force during the power being OFF. The position information will lose if the number of motor revolution exceeds the set value. Consider safety margin when establishing the setting.

Motor rotation [rpm] = Moved speed [mm/s] / Lead length [mm]  $\times$  60

Setting	Position information retaining day (reference)	Motor max. rotation speed (rpm)
0 (Initial setting)	20 days	100
1	15 days	200
2	10 days	400
3	5 days	800



#### (18) Position Data Change Password (Parameter No.20)

No.	Name	Symbol	Unit	Input Range	Default factory setting
20	Position Data Change Password	PASS	-	0000 to 9999	0

Set the password for when making a change to the position data. [Refer to MEC PC Software and teaching pendant instruction manuals provided separately for how to set up.]

#### (19) PIO inch distance (Parameter No.25)

No.	Name	Symbol	Unit	Input Range	Default factory setting
25	PIO inch distance	IOID	mm	0.01 to 1.00	0.1

Set the distance for inching operation (pitch feeding) of Quick Teach. Setting can be conducted in 0.01mm unit.

#### (20) Total movement count threshold (Parameter No.26)

No.	Name	Symbol	Unit	Input Range	Default factory setting
26	Total movement count threshold	тмст	Times	0 to 99999999	0 (Disabled)

Notice will be made with Movement Counter Threshold Exceeding Alarm (04E) if the total number of movement exceeds the value set in this parameter. The judgment would not be made if the value is set to 0.

#### (21) Total operated distance threshold (Parameter No.27)

No.	Name	Symbol	Unit	Input Range	Default factory setting
27	Total operated distance threshold	ODOT	m	0 to 99999999	0 (Disabled)

Notice will be made with Movement Distance Threshold Exceeding Alarm (04F) if the total distance of movement exceeds the value set in this parameter. The judgment would not be made if the value is set to 0.

#### (22) High output setting (Parameter No.28)

No.	Name	Symbol	Unit	Input Range	Default factory setting
28	High output setting	BUEN	Ι	0: Disable 1: Enable	1 (Enabled)

Establish the setting of enable/disable for the high output function.

Caution : Please note that the high output setting automatically turns disable if Quick Teach equipped with a power supply unit (PCM-PST-1 or PCM-PST-2) is connected.

# 6.3 I/O Parameter 6.3.2 MEC Mode 1, MEC Mode 2 and MEC Mode 3



(23) BU velocity loop proportional gain (Parameter No.29)

No.	Name	Symbol	Unit	Input Range	Default factory setting
29	BU velocity loop proportional gain	BUPC	-	1 to 10000	200

If the high output setting is set enabled, this parameter setting becomes enable for the velocity loop proportional gain.

This is the parameter to determine the responsiveness of the velocity loop. Setting bigger values provides more capacity to track the speed command (it is described as the servo stiffness gets higher). The higher the load inertia becomes, the larger the value should be set. Setting the value too large causes such problems as overshooting and vibration, which would make the mechanical components vibrate.



(24) BU velocity loop integral gain (Parameter No.30)

No.	Name	Symbol	Unit	Input Range	Default factory setting
30	BU velocity loop integral gain	BUIC	-	1 to 100000	4000

If the high output setting is set enabled, this parameter setting becomes enable for the velocity loop integrated gain.

Any machine produces friction. This parameter is intended to cope with deviation generated by external causes including friction. Setting bigger values provides more reinforced reaction force against the load fluctuation, thus higher servo stiffness. However, increasing the parameter value excessively may make the gain too high, which then causes the machine system to be vibrated due to overshoot or shaking.

Tune it to obtain the optimum setting by watching the velocity response.





#### [3] Servo Adjustment

The parameters are preset at the factory before shipment so that the actuator operates stably within the rated (maximum) transportable weight.

However, the preset setting cannot always be the optimum load condition in the actual use. In such cases, servo adjustment may be required.

This section describes the basic servo adjustment method.

Caution:	Rapid and excessive settings are dangerous. They may devices including the actuator to be damaged and/or people to be injured. Take sufficient note on the setting
	Record settings during servo adjustment so that prior settings can always be recovered.
	When a problem arises and the solution cannot be found, please contact IAI.

No.	Situation that requires adjustment	How to Adjust	
1	Takes time to finish positioning Positioning accuracy is not appropriate Shorter cycle time is desired	<ul> <li>Increase the value of Parameter No.3 "Servo gain number". By setting a larger value, the follow-up ability to the position command becomes better. Set the value to any of 3 to 10 roughly or up to 15 at the maximum. If the value is too large, an overshoot is caused easily and may cause noise or vibration.</li> <li>For the velocity loop proportional gain parameter, the parameter number differs depending on the setting of enable/disable of Gain Scheduling and the high output setting.</li> <li>Shown below is the table of velocity loop proportional gain parameter numbers that are enable.</li> <li>High Output Setting (Parameter No.28)</li> <li>1 (Enable)</li> <li>0 (Disable)</li> <li>Parameter No.29</li> </ul>	
2	Vibration is generated at acceleration/deceleration	<ul> <li>The cause of the problem is excessive "acceleration/deceleration setting" or vulnerable structure of the unit on which the actuator is installed. If possible, reinforce the unit itself, first.</li> <li>Decrease the values of "acceleration/deceleration setting".</li> <li>Decrease the number of Parameter No.3 "Servo gain number". If the Parameter No.3 "Servo gain number" is too low, it takes long time to finish the positioning.</li> </ul>	



	No.	Situation that requires	How to Adjust				
	No. 3	Situation that requires adjustment Speed is uneven during the movement Speed accuracy is not appropriate	<ul> <li>How to Adjust</li> <li>Increase the value of Parameter No.3 "Velocity loop proportional gain". By setting a larger value, the follow-up ability to the speed command becomes better. Setting too large value makes the mechanical components easy to vibrate. As a reference for the setting, increase the value little by little by 20% from the initial setting. For the velocity loop proportional gain parameter, the parameter number differs depending on the setting of enable/disable of Gain Scheduling and the high output setting.</li> <li>Shown below is the table of velocity loop proportional gain parameter numbers that are enable.</li> <li>High Output Setting (Parameter No.28)</li> <li>1 (Enable)</li> <li>Parameter No.29</li> </ul>				
	4	Abnormal noise is generated. Especially, when stopped	<ul> <li>Input the Parameter No.4 "Torque Filter Time Constant". Try to increase by 50 as a reference for the setting. If the setting is too large, it may cause a loss of control system stability and lead</li> </ul>				
		state and operation in low speed (less than 50mm/sec), comparatively high noise is generated.	<ul> <li>large, it may cause a loss of control system stability and lead the generation of vibration.</li> <li>[Important] Prior to Adjustment: This phenomenon is likely to occur when the stiffness of the mechanical components is not sufficient. The actuator itself may also resonate if its stroke is over 600mm or it is belt-driven type. Before having an adjustment, check if:</li> <li>1) Isn't the setting in Parameter No.3 "Servo Gain Number", "Velocity Loop Proportional Gain" or "Velocity Loop Integrated Gain" described below to extreme? For the velocity loop proportional gain parameter and the speed loop integrated gain parameter, the parameter number differs depending on the setting of enable/disable of Gain Scheduling and the high output setting.</li> <li>Shown below is the table of velocity loop integrated gain parameter numbers that are enable.</li> </ul>				
			Velocity Loop Proportional Gain Velocity Loop				
			Velocity Loop Integral Gain Parameter No.30 Parameter No.6				
			2) The stiffness of the load is sufficient as much as possible, or the attachments are not loosened.				
			3) The actuator unit is mounted securely with a proper torque.				
1		1	(4) There is no waviness on the actuator mounting surface				



# ERC**3**

### Chapter 7 Troubleshooting

#### 7.1 Action to Be Taken upon Occurrence of Problem

Upon occurrence of a problem, take an appropriate action according to the procedure below in order to ensure quick recovery and prevent recurrence of the problem.

#### 1) Status LEDs and PIO Check on ERC3 and PIO Converter [ERC3 main body]

				IY A. OFF X. FIASHINY
LE	ED		Status of PIO C	Dutput Signal
		Operation status	CON Mode Type	MEC Mode Type
(GN) (RD	(RD)		*ALM Outp	out <sup>(Note 1)</sup>
		Control Power Supply ON	ON	1
×	×	Control Power Supply OFF	OF	F
		Servo OFF	OF	F
× O		Motor driving power supply OFF	OF	F
	0	Emergency Stop	OF	F
		Alarm (Operation cancellation level or more)	OF	F
0	×	Servo ON	ON	J
☆	×	During automatic servo-off	ON	l
0 (0R)		In initializing process at power being ON	OFF	

Note 1 The output signals with \* mark are the active low signals that turn ON in normal condition and turn OFF while in abnormal condition.

Note 2 Servo-motor Auto OFF [Refer to Chapter 5 Power-saving Function]

#### [PIO converter]

#### O : Illuminating × : OFF ☆ : Flashing

⊸

. Elechine

		, i j					
LE	ED		Status of PIO Output Signal				
				CON Mode Type	è	MEC Mode Type	
SV (GN)	ALM (RD)	Operation status	SV Output (Servo ON)	*ALM Output (Note 1)	*EMGS Output (Note 1)(Note 2)	*ALM Output (Note 1)	
			,	(Alarm)	(Emergency Stop Status)		
		Control Power Supply ON	OFF	ON	ON	ON	
×	×	Control Power Supply OFF	OFF	OFF	OFF	OFF	
		Servo OFF	OFF	OFF	_	OFF	
		Motor driving power supply OFF	OFF	OFF	-	OFF	
~	0	Emergency Stop	OFF	OFF	OFF	OFF	
^		Alarm (Operation cancellation level or more)	OFF	OFF	-	OFF	
0	×	Servo ON	ON	ON	ON	ON	
☆	×	During automatic servo-off (Note 3)	OFF	ON	-	ON	
0 (OR)		In initializing process at power being ON	OFF	OFF	_	OFF	

Note 1 The output signals with \* mark are the active low signals that turn ON in normal condition and turn OFF while in abnormal condition.

Note 2 \*EMGS output is not prepared for Pulse Train Control Type.

Note 3 Servo-motor Auto OFF [Refer to Chapter 5 Power-saving Function]



- 2) Check whether an alarm occurs on the host controller (PLC, etc.).
- 3) Check the voltage of the main power supply (24V DC).
- 4) Check the voltage of power supply for the PIO (24V DC).
- 5) Alarm Check (Note1)
- Check the alarm code on the teaching tool such as PC software.
- 6) Check the connectors for disconnection or connection error.
- 7) Check the cables for connection error, disconnection or pinching. Cut off the main power of the system which ERC3 or PIO converter is installed in and remove the cables around the measurement point (to avoid conductivity through the surrounding circuit) before checking the conductivity.
- Check the I/O signals.
   Using the host controller (PLC, etc.) or a teaching tool such as PC software, check the presence of inconsistency in I/O signal conditions.
- 9) Check the noise elimination measures (grounding, installation of surge killer, etc.).
- 10) Check the events leading to the occurrence of problem (Note 1), as well as the operating condition at the time of occurrence.
- 11) Analyze the cause.
- 12) Treatment
  - Note 1 If parameter No.111 (Selection of using calendar function) is set to "1" (use), it is possible to know the date and time at which the alarm occurred. Set the date and time from the teaching tool such as PC software at the first power-on of the ERC3 and PIO converter.

The date and time data set once is retained for about 10 days if the power supply of the PIO converter is OFF. If the setting is not conducted or the time data is lost, it will be the time passed since 0sec when the power is turned ON. Even if the date and time data is lost, the generated error code is retained. Alarms subject to this function only include those in 7.4 Alarm but do not include

Alarms subject to this function only include those in 7.4 Alarm but do not include errors in the teaching tool such as PC software.

#### (I) Notice:

In troubleshooting, exclude normal portions from suspicious targets to narrow down the causes. Check 1) to 10) described above before contacting us.



# ERCÓ

#### 7.2 Fault Diagnosis

This section describes faults largely divided into three types as follows:

- Impossible operation of controller
   Positioning and speed of poor precision (incorrect operation)
   Generation of noise and/or vibration

#### Impossible operation of controller 7.2.1

Situation	Possible cause	Check/Treatment
1) Positioner Mode 1.	(1) Proper power is not supplied.	(1) Ensure that appropriate voltage is
Pulse Train Control	(2) Servo-on command PIO is not input	supplied and the wiring is in the right
Mode	to ERC3 and PIO converter.	condition.
Status Display LED	<ol> <li>Poor contact of flat cable</li> </ol>	[Refer to Chapter 3, 3.1.3 [1], 3.2.3
does not turn ON in	(3) Occurrence of alarm.	[1], 3.3.3 [1], 3.4.3 [1] and 3.5.3 [1]
green even though	(4) During emergency-stop.	wiring of Power Line and
the power to ERC3 is	<ol> <li>Was the emergency-stop switch</li> </ol>	Emergency Stop Circuit.]
supplied in MEC	released?	(2) 1) Are the PIO cable connectors
Mode 1 or MEC Mode	2) Positioner Mode 1, MEC Mode 1,	inserted to the mating connectors
2.	Pulse Train Control Mode	securely? Check the input signals
2) Positioner Mode 2.	EMG on the ERC3 is not	on the I/O monitor of the teaching
SV in Status Display	connected.	tool such as PC software.
LEDs does not turn	3) Positioner Mode 2, MEC Mode 2	Caution
ON even though the	EMG- on the power supply	In I/O cable conduction check, do not
power to PIO	connector of PIO Converter is	widen female pins of the connectors.
Converter is supplied	disconnected.	Failure to follow this may cause poor
in MEC Mode 2.	4) MEC Mode 3	contact.
	The wiring of the emergency stop	
	connector on Quick Teach is	(3) Check the error code with the
	disconnected.	teaching tool being connected and
		remove the cause by referring the
		alarm list.
		[Refer to 7.4 Alarm List.]
		(4) 1) Release the emergency stop
		switch.
		2) Positioner Mode 1, MEC Mode 1,
		Pulse Train Control Mode
		Check the connection of wires on
		EMG of ERC3.
		3) Positioner Mode 2, MEC Mode 2
		Check the connection of wires on
		PIO Converter power supply
		connector EMG
		[Refer to Chapter 3, 3.1.3 [1],
		3.2.3 [1], 3.3.3 [1], 3.4.3 [1] and
		3.5.3 [1] wiring of Power Line and
		Emergency Stop Circuit.]
		<ol> <li>Check the wiring of the</li> </ol>
		emergency stop connector on
		Quick Teach. If it is not to be
		used, have the enclosed plug
		connector to make short-circuit.



Situation	Possible cause	Check/Treatment
1) Positioner Mode 1.	(1) Occurrence of alarm.	(1) Check the error code with the
Pulse Train Control	(2) During emergency-stop.	teaching tool being connected and
Mode	1) Was the emergency-stop switch	remove the cause by referring the
Status Display LED	released?	alarm list.
on ERC3 turns ON In	2) Positioner Mode 1, MEC Mode 1, Bulao Train Control Mode	[Refer to 7.4 Alarm List.]
in MEC Mode 1 or	EMG on the ERC3 is not	switch
MEC Mode 3	connected	2) Positioner Mode 1 MEC Mode 1
2) Positioner Mode 2.	3) Positioner Mode 2, MEC Mode 2	Pulse Train Control Mode
MEC Mode 2	EMG- on the power supply	Check the connection of wires on
ALM in Status LEDs	connector of PIO Converter is	EMG of ERC3.
on PIO Converter	disconnected.	3) Positioner Mode 2, MEC Mode 2
turns ON at the	4) MEC Mode 3	Check the connection of wires on
power boot.	The wiring of the emergency stop	PIO Converter power supply
	disconnected	IRefer to Chapter 3, 3,1,3 [1]
		3 2 3 [1] 3 3 3 [1] 3 4 3 [1] and
		3.5.3 [1] wiring of Power Line and
		Emergency Stop Circuit.]
		4) Check the wiring of the
		emergency stop connector on
		Quick Teach. If it is not to be
		used, have the enclosed plug
The host controller (PLC)	PIO signal communication is disabled	1) Are the PIO cable connectors
cannot control PIO (24V	1) Positioner Mode 1 MEC Mode 1	inserted to the mating connectors
DC I/O).	Connection failure of PIO Type I/O	securely? Check the input signals
	cable to be connected to ERC3	on the I/O monitor of the teaching
	2) Positioner Mode 1, MEC Mode 1	tool such as PC software.
	Connection failure of the ribbon	▲ Caution
	cable to be connected to PIO	In I/O cable conduction check, do not
	Converter	widen female pins of the connectors.
		Failure to follow this may cause poor



Situation	Possible cause	Check/Treatment					
Both position No. and	There is a problem either in PIO signal	1) Is Status LED on ERC3 turned ON					
start signal are input to	treatment, position table setting or	in green?					
the controller, but the	operation mode selection.	If PIO Converter is used, is Status					
actuator does not move.	1) Servo OFF condition	LED turned ON in green?					
	2) The pause signal is OFF.	[Refer to Name for Each Parts and					
	3) Positioning command is issued to a	Their Functions]					
	stop position.	Turn ON the servo-on signal SON of					
	4) There is no positioning data set to the	PIO.					
	commanded position number.	2) Operation is available when PIO					
		pause signal *STP is ON and pause					
		when it is OFF. Turn it ON. [Refer to					
		Chapter 3, 3.1.2 and 3.3.2]					
		3) Check the sequence or the settings					
		of the position table.					
		4) It will generate Alarm Code 0A2					
		"Position Data Error". Conduct the					
		position table setting					

[In the case of Positioner Mode]

(Note) Refer to Chapter 3 Wiring for PIO signal.



Situation	Possible cause	
In spite of inputting	PIO signal processing or parameter	1) IS Status LED on ERC3 turned ON
pulse-train to the	setting is incorrect.	in green?
controller, the actuator	1) Servo OFF state	If PIO Converter is used, is Status
does not move.	2) The pause signal is OFF.	LED turned ON in green?
	3) The pulse-train type, a parameter, is	[Refer to Name for Each Parts and
	selected incorrectly.	Their Functions]
	4) The positive/negative logic of	Turn ON the servo-on signal SON of
	pulse-train, a parameter, is selected	
		2) Operation is available when PIO
	5) The unit moving distance per pulse,	pause signal *STP is ON and pause
	which is a setting condition of	when it is OFF. Turn it ON. [Refer to
	electronic gear ratio, a parameter, is	Chapter 3, 3.2.2.]
	too small.	3) Check the pulse train type.
		Format Settings of Command Pulse
		I rain.]
		4) Check the positive/negative logic of
		pulse-train. (Host units supplied by
		some manufacturers have
		positive/negative logic opposite to
		our logic. Reverse the logic setting
		IDefer to Charter 4, 4,2 (0) (2)
		Earmot Sottings of Command Dulas
		Train 1
		5) Do not make the unit moving
		distance less than the resolution of
		the encoder. The actuator does not
		move unless pulses by the
		resolution of the encoder are input
		IRefer to Caution in Chapter 4.4.3
		[Relef to Caution in Chapter 4, 4.5
		(Note) In case of 3) or 4) the actuator
		may not sometimes operate
		smoothly
		You may not find case 5) when
		the actuator is moved for a long
		distance at a high frequency
		distance at a high frequency.

In the case of Pulse	e Train Control Model
	i nam oona or moaoj

(Note) Refer to Chapter 3 Wiring for PIO signal.

# 7.2 Fault Diagnosis

ERC <b>3</b>
--------------

	Situation	Possible cause	Check/Treatment			
1	) Positioner Mode 1.	Cable treatment or mode selection.	1) Positioner Mode 1, MEC Mode 1,			
	Pulse Train Control	<ol> <li>Emergency stop condition</li> </ol>	Pulse Train Control Mode			
	Mode	2) Servo OFF condition	Check the connection of wires on			
	An operation cannot	3) In pause	EMG of ERC3.			
	be performed even		[Refer to Chapter 3, 3.1.3 [1], 3.2.3			
	though a teaching		[1] and 3.4.3 [1] wiring of Power Line			
	tool is connected and		and Emergency Stop Circuit.]			
	the motor and control		2) Positioner Mode 2, MEC Mode 2			
	power are supplied to		Check the connection of wires on			
	ERC3 in MEC Mode1		PIO Converter power supply			
	or MEC Mode3.		connector EMG			
4	2) Positioner Mode 2.		[Refer to Chapter 3, 3.3.3 [1] and			
	An operation cannot		3.5.3 [1] Wiring of Power Line and			
	though a togohing		Emergency Stop Circuit.j			
	tool is connected and		1) Supply 24V/DC to EMC- terminal of			
	the motor and control		the power connector			
	power are supplied to					
	PIO Converter in					
	MEC Mode2		If the process of 1) is conducted, put			
			back the setting as soon as the			
1	The emergency stop		adjustment work is finished.			
5	witch is released on the		Starting the operation without			
t	eaching tool)		putting it back may cause a serious			
T	,		accident since the emergency stop			
			is set invalid.			
			2) 3) Select the teach mode on the			
			teaching tool.			

[Startup Adjustment with Teaching Tool when Control Circuit Incomplete]



#### 7.2.2 Positioning and speed of poor precision (incorrect operation)

Situation	Possible cause	Check/Treatment
Completion of operation	In the home return of our standard	1) Reduce the load.
on the way to home return	<ul> <li>specification, the actuator is first pressed to the mechanical end, moved oppositely, and subject to positioning stop at the home position. Therefore, the product may judge as the mechanical end even though it is still on the way when the load is large and interfere with surrounding object.</li> <li>A load exceeding its rating weight is installed on the actuator.</li> <li>It is touched to interference in the way of the run.</li> <li>Torsion stress is applied to guide due to improper fixing method of the actuator or uneven fastening of bolts.</li> <li>The sliding resistance of the actuator itself is large.</li> </ul>	<ol> <li>Remove the interference.</li> <li>Loosen the fixing bolts once and check whether the slider can move smoothly. If the slider can move smoothly, check if there is a deformation on the attached surface, and install the actuator again following the instructions stated in Instruction Manual.</li> <li>Please contact IAI.</li> </ol>
Shocks at start and/or stop.	Acceleration/deceleration is set too high.	Decrease the settings of acceleration/deceleration.
Overshoot during deceleration to stop.	The load inertia is large.	Decrease the setting of deceleration.
Positioning of poor precision Uneven speed during movement Acceleration/deceleratio n not smooth (bad speed response) Trace of poor precision	[Refer to 6.3.1 [3] and 6.3.2 [3] Servo Adju (Note) When the pulse-train operation mod commands.	stment.] le is selected, first adjust pulse-train

#### [In the case of Positioner Mode]

Situation	Possible cause	Check/Treatment		
Positioning at a position different from that of commanded position No.	<ul> <li>PIO signal processing is incorrect.</li> <li>1) Start signal CSTR is input too early after position No. command. Or position No. command and start signal are input concurrently.</li> <li>2) The correct position No. is not specified due to PIO signal disconnection or poor connector contact.</li> </ul>	<ol> <li>The stop position may be set for another purpose. Make sure to complete the reading of the position numbers to ERC3 before inputting the start signal. [Refer to Chapter 4, 4.2 Operation in Positioner Mode and 10.6 Example of Basic Positioning Sequence.]</li> <li>Check the input signal on I/O monitor on the teaching tool.</li> </ol>		
Complete signal PEND is not output even though positioning process is completed.	PIO signal processing is incorrect. 1) Start signal CSTR is not turned OFF.	<ol> <li>Make the start signal CSTR turned OFF before completing the positioning process by the turn-off of positioning complete signal PEND after starting operation, and so on.</li> </ol>		



Situation	Possible cause	Check/Treatment
The actuator does not	PIO signal processing or parameter	1) Check the setting of electronic gear
stop at the command	setting is incorrect.	ratio. The nost controller also has
position.	1) Incorrect electronic gear failo	Cet the electronic gear ratio parameter.
	2) Acceleration/deceleration is set	Set the electronic gear ratio not to
	Incorrectly in the nost controller.	be inconsistent with that of the host
	(1) The nulse train type a nerometer is	controller. In addition, reduce the
	4) The pulse-train type, a parameter, is	electronic gear ratio as much as
	5) The unit moving distance per pulse	possible. If hot, data overnow may
	which is a softing condition of	disable correct positioning
	electronic dear ratio a parameter is	Refer to Chanter 4, 4,3 [3] (1)
	too small	Electrical Gear Setting 1
		2) The actuator operates at the speed
		and acceleration/deceleration
		based on the frequency of input
		pulses Check if the
		acceleration/deceleration set in the
		host controller exceed the rating
		acceleration/deceleration of the
		actuator
		3) Noise can be misread as the pulse
		if it jumps into the pulse train.
		Take proper measures against
		noise. [Refer to Chapter 2, 2.3.4
		Noise Prevention and How to
		Attach Electrical Devices.]
		Check the cable connection
		between the controller and AK-04 if
		AK-04 is used.
		Cable length :
		50mm or shorter recommended
		(as short as possible)
		Shield treatment :
		Use the shield treatment wire.
		4) Check the pulse-train type.
		[Refer to Chapter 4, 4.3 [3] (2)
		Format Settings of Command
		Pulse Irain.j
		5) Do not make the unit moving
		distance less than the resolution of
		move unless pulses by the
		resolution of the encoder are input
		Refer to Caution in Chanter 4.4.3
		[3] (1) Electronic Gear Setting]
		(Note) In case of 2) or 3) the
		actuator may not sometimes
		operate.
		You may not find case 4)
		when the actuator is moved
		for a long distance at a high
		frequency.
The actuator does not	To avoid unnatural move, the actuator	Set to the full-servo mode.
reach the command	would not move unless the differential	(Set Parameter No.53 Stop Mode initial
position when operated	pulse becomes 3 pulses or more.	setting to 4.)
with extremely low		
speed.		

[In the case of Pulse Train Control Mode]



#### 7.2.3 Generation of noise and/or vibration

Situation	Possible cause	Check/Treatment		
Generation of noise and/or vibration from actuator itself	Noise and vibration are generated by many causes including the status of load, the installation of the actuator, and the rigidity of the unit on which the actuator is installed.	Servo adjustment may improve the situation. [Refer to 6.3.1 [3], 6.3.2 [3] Servo Adjustment.] It may be improved with setting to Full Servo Mode if the case occurs during deceleration and stop. [Refer to Chapter 5 Power-saving Function]		

[	In t	he	case	of	Positioner	Mode]	

Situation	Possible cause	Check/Treatment
Vibrations of load	<ol> <li>Acceleration/deceleration is set too high.</li> <li>The installation structure and/or the installed load are easily affected by acceleration/deceleration.</li> </ol>	<ol> <li>Decrease the settings of acceleration/deceleration.</li> </ol>

#### [In the case of Pulse Train Control Mode]

Situation	Possible cause	Check/Treatment
Vibrations of actuator or load	Acceleration/deceleration is set too high.	Decrease the setting of acceleration/deceleration in the host controller.
Generation of noise during acceleration	The host controller has no acceleration/deceleration function or does not have acceleration/deceleration function from speed 0. (Some positioning units have acceleration/deceleration function but cannot use the function from speed 0. Note this when you select a positioning unit.)	[Refer to 6.3.1 [3], 6.3.2 [3] Servo Adjustment]



# ERC**3**

#### 7.3 Alarm Level

The alarms are classified to 3 types of levels by the content of the error.

Alarm level	ALM lamp	*ALM signal	Status when an error occurred	Cancellation method
Message <sup>(Note 1)</sup>	OFF	No output	No stop	Alarm of maintenance output such as battery voltage drop or the teaching tool such as PC software [Refer to Instruction Manual of each tool for details.]
Operation release	ON	Output	Servo OFF after deceleration to stop	Reset the alarm by the PIO or teaching tool.
Cold start	ON	Output	Servo OFF after deceleration to stop	Software reset or power reconnection by teaching tool. Home return is required for any actuators of other than simple absolute specification.

Caution: Reset each alarm after identifying and removing the cause. If the cause of the alarm cannot be removed or when the alarm cannot be reset after removing the cause, please contact IAI. If the same error occurs again after resetting the alarm, it means that the cause of the alarm has not been removed.

(Note 1) In PIO Patterns 0, 2, 3 and 4, if Parameter No. 156 Torque Check / Light Malfunction Output is set to 1, an output is made to PIO (OUT 15) when it meets the message level alarm condition described in the next section (7.4).



#### 7.4 Alarm List

Alarm Code	Alarm Level	Alarm Name	Cause/Treatment		Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
02C		Monitoring data type change command during monitoring	Cause Treatment	Changing data type was directed during monitoring by the monitoring function of PC software. Stop the monitoring before changing data type.	0	0	×	×
02D	2D Monitoring related command in monitoring function invalid status 2E RTC related command in RTC invalid status		Cause Treatment	An attempt was made to perform monitoring in the state where the monitoring function is set to be ineffective. Set parameter No.112 (Selection of monitoring mode) to "1" or "2" ("0": no use).	0	0	×	×
02E			Cause Treatment	An attempt was made to use the calendar in the state where the RTC (calendar) function was made ineffective. Set parameter No.111 (Selection of use of calendar function) to "1" ("0": no use).	×	0	×	×
048	Message	Driver overload alarm	Cause Treatment	: There is a risk of overload with the current operation condition. : Lower the setting of acceleration/deceleration. Also, increase the frequency of pause.	0	0	0	0
04E	Exceeded movement coun threshold		Cause	In the case of Positioner Mode 2, the total number of movement exceeded the number set in Parameter No.147 "Threshold for Total Number of Movement". In the case of MEC Mode 2, the total number of movement exceeded the number set in Parameter No.26 "Threshold for Total Number of Movement".	x	0	x	0
04F		Exceeded operated distance threshold	Cause	In the case of Positioner Mode 2, the total distance of actuator drive exceeded the number set in Parameter No.148 "Threshold for Total Distance of Drive". In the case of MEC Mode 2, the total distance of actuator drive exceeded the number set in Parameter No.27 "Threshold for Total Number of Drive".	x	0	x	0
080	Operation release	Move command in servo OFF	Cause	<ul> <li>A move command was issued when the servo is OFF.</li> <li>Positioner Mode 1, Positioner Mode 2, Pulse Train Control Mode Issue a movement command after confirming the servo is ON (servo ON signal SV or position complete signal PEND is ON).</li> <li>MEC Mode 1, MEC Mode 2 Cancel the emergency stop if it is not yet cancelled, and turn the servo ON to make a movement command.</li> </ul>	0	0	0	0



Alarm Code	Alarm Level	Alarm Name		Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
082		Position command in incomplete home return	Cause : Treatment :	<ul> <li>A position move command was issued before home return was completed.</li> <li>1) Positioner Mode 1, Positioner Mode 2, Pulse Train Control Mode Issue a command after confirming that home return has been completed HEND is ON.</li> <li>2) MEC Mode 1, MEC Mode 2 In the case of 2-point stop, make sure the home-return complete HEND signal is ON before making a movement command. In the case of 3-point stop, input ST0 Signal to perform a home-return operation before making a movement command.</li> </ul>	0	0	0	0
084	ion release	Absolute position move command when home return is not yet completed	Cause : Treatment :	<ul> <li>A move command was issued when home return was still in progress.</li> <li>1) Positioner Mode 1, Positioner Mode 2, Pulse Train Control Mode Issue a movement command after performing home return operation and confirming the complete signal HEND.</li> <li>2) MEC Mode 1, MEC Mode 2 In the case of 2-point stop, perform a home-return operation and confirm the home-return complete HEND signal before making a movement command. In the case of 3-point stop, turn OFF the movement command, reset the alarm and redo the home-return operation.</li> </ul>	0	Ο	Ο	Ο
085	Operat	Position No. error during movement	Cause : Treatment :	A non-existing (invalid) position number was specified in the positioner mode. Check the position table again and indicate an effective position number.	0	0	×	×
090		Software reset during servo ON	Cause : Treatment :	A software reset command was issued when the servo was ON. Issue a software reset command after confirming that the servo is OFF (SV signal is 0).	0	0	0	0
091		Position No. error in teaching	Cause : Treatment :	The position number out of the available range was selected in the teaching. Select the position number from 63 or smaller.	0	0	×	×
092		PWRT signal detection during movement	Cause :	Input was made while the current position writing signal PWRT is in the JOG operation in Teaching Mode of PIO Pattern 1. Input the PWRT signal after confirming that the job button is not pressed and the actuator is stopped (MOVE output signal is OFF).	×	0	×	×
093		PWRT signal detection in incomplete home return	Cause : Treatment :	Input was made while the current position writing signal PWRT is in home-return incomplete in Teaching Mode of PIO Pattern 1. Input the HOME signal first to perform home return, and then input the PWRT signal after confirming that the home return has completed (HEND output signal is ON).	×	0	×	×



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0A1	Cold start	Parameter data error	Cause : The data input range in the parameter area is not appropriate. Example 1) This occurs when the relation of the positive and negative sides of the soft limit is clearly inappropriate, for example, when the value for the soft limit positive side is set to 200.3mm while the soft limit negative side is 300mm, in Positioner Mode 1 or Positioner Mode 2. [Refer to 3.2 [2] Soft limit +, Soft limit -] Treatment : Change the value to the appropriate one.	0	0	0	0
0A2	Operation release	Position data error	<ul> <li>Cause :1) A move command was input when no target position was set in the "Position" field of a position No. in the position table.</li> <li>2) The value of the target value in the "Position" field exceeded the Parameter No.3 and 4 "Soft limit set value".</li> <li>3) The target position in "Position" box is indicated in a number for relative coordinates in Electromagnetic Valve Type in PIO Pattern 1 of Positioner Mode 1 or Electromagnetic Valve Mode 2 in PIO Pattern 5 of Positioner Mode 2.</li> <li>Treatment : 1) Set the target position.</li> <li>2) Change the target position value to the one within the soft limit set value.</li> <li>3) The target position cannot be set by relative coordinate (incremental feed).</li> </ul>	O	0	O	O
0A3		Position command data error	Cause : 1) The value for the velocity or acceleration/deceleration exceeds the maximum setting.	0	0	0	0
0A4		Command counter overflow	Cause : The number of input command pulses exceeded the range of -134217728 to +134217728 (H'F8000000 to '07FFFFF). Treatment : Attempt to make the value of the electrical gear ratio smaller (make the movement against the unit bigger).	0	×	×	×



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0A7	Operation release	Command deceleration error	Cause : Because there is not enough deceleration distance when the deceleration is changed to a lower setting during the operation, the actuator exceeded the soft limit when deceleration was made from the current position with the deceleration after the change. Deceleration starting position not resulting in soft limit overshoot soft limit overshoot will occur. Soft limit The cause is that the timing to make the next movement command when the speed was changed during the operation was late. Treatment : Make the timing earlier for the movement command for the deceleration speed change.	0	0	Ο	0
0A8	Cold start	Unsupported motor/encoder types	Cause : Motor or encoder cannot be identified. Treatment : Please contact us if the alarm is issued even with the applicable actuator and the same problem happens again even after rebooting the power.	0	0	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
088	Cold start	Excitement detection error	<ul> <li>Cause : The excitation detection starts when the servo is turned on for the first time after the power is supplied. Detection process does not complete in the specific time (set in Parameter No.29 if Positioner Mode 1, Positioner Mode 2 or Pulse Train Control Mode).</li> <li>1) Connection error or wire breakage of motor/encoder cables.</li> <li>2) Brake is not released (when equipped with a brake).</li> <li>3) Load to the motor is high due to external force.</li> <li>4) Power was turned on while touching to the mechanical end.</li> <li>5) The resistance in the actuator sliding operation is large.</li> <li>6) In the case of Positioner Mode 1, Positioner Mode 2 or Pulse Train Control Mode, a smaller number than the initial value was set in Parameter No.22 Home-Return Offset.</li> <li>In the case of MEC Mode 1 or MEC Mode 2, a smaller number than the initial value was set in Parameter No.16 Home-Return Offset.</li> <li>Treatment : 1) Check for the motor/encoder cable wiring condition.</li> <li>2) For Positioner Mode 1 and MEC Mode 1, if the problem is solved with 24V DC 150mA being supplied to BK, it may be concerned a malfunction of the controller inside the ERC3 motor unit.</li> <li>3) Confirm that there is no error in the mechanical part assembly condition.</li> <li>4) Move the slider or the rod to a point where it would not hit the mechanical end and reboot the system.</li> <li>5) If the loaded weight is within the allowable range, turn the power OFF and check the resistance in sliding operation by moving the slider with hand.</li> <li>6) In the case of Simple Absolute Type, the excitation detection is executed again at the home-return complete. If the Parameter No.22 Home Return Offset is set smaller than the initial setting, the actuator interferes with the mechanical end and excitation detection cannot be performed properly.</li> </ul>	0	Ο	0	Ο



Alarm Code	Alarm Level	Alarm Name		Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0BE		Home return timeout	Cause : Treatment :	Home return does not complete after elapse of a certain period after the start of home return. This error does not occur in normal operation. Please contact IAI.	0	0	0	0
0C0	asse	Actual speed excessive	Cause : Treatment :	<ul> <li>This indicates the number of motor rotation exceeded the number of allowable rotation.</li> <li>1) The slide resistance of the actuator is locally high.</li> <li>2) The load is increased too much due to a external force. With the reasons above, it can be considered a sudden speed increase has occurred before detecting the servo error.</li> <li>Even though this would not occur in normal operation, check if there is any abnormality in the parts assembly condition. Also check if there is a possibility that an external force may be applied in the direction of the actuator movement.</li> </ul>	0	0	0	0
0C1	Operation rele	Servo error	Cause :	<ul> <li>It indicates 2 seconds has passed without making a move since a move command was received.</li> <li>1) Connection error or wire breakage of motor/encoder cables.</li> <li>2) Brake is not released (when equipped with a brake).</li> <li>3) Load to the motor is high due to external force.</li> <li>4) The resistance in the actuator sliding operation is large.</li> <li>1) Check for the motor/encoder cable wiring condition.</li> <li>2) For Positioner Mode 1 and MEC Mode 1, if the problem is solved with 24V DC 150mA being supplied to BK, it may be concerned a malfunction of the controller inside the ERC3 motor unit.</li> <li>3) Confirm that there is no error in the mechanical part assembly condition.</li> <li>4) If the loaded weight is within the allowable range, turn the power off and check the resistance in sliding operation by moving the slider with hand.</li> </ul>	0	0	Ο	0
0C8	id start	Overcurrent	Cause : Treatment :	The output current in the power circuit section is increased abnormally. This alarm will not be generated in normal operation. There may be concerned a degradation of motor winding insulation, malfunction of the controller inside the ERC3 motor unit, etc. Please contact IAI.	0	0	0	0
0C9	ŏ	Overvoltage	Cause : Treatment :	The power voltage reached the overvoltage. There may be concerned a malfunction of a component of the controller inside the ERC3 motor unit. Please contact IAI.	0	0	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0CA	old start	Overheat	Cause : This shows the heat on the components inside the controller inside the ERC3 motor unit is too high. 1) Operation is performed with the load condition exceeding the specified range. 2) High temperature around the controller. 3) Load to the motor is high due to external force. 4) Components' failure of the controller inside the ERC3 motor unit. Treatment : 1) Revise the operation condition such as decreasing the acceleration/deceleration speed. 2) Lower the surrounding temperature of the controller. 3) Confirm that there is no error in the mechanical part assembly condition. (Note) This error would not normally occur. If it occurs, confirm there is not (1) to (3) above. If the same problem occurs again even after taking these actions, it may be concerned the malfunction of the controller inside the ERC3 motor unit. Please contact IAI.	Ο	0	Ο	0
0000	ŏ	Control power source voltage error	<ul> <li>Cause : The control power voltage dropped less than the voltage drop threshold (120% of 24V DC = 28.8V).</li> <li>1) The voltage of 24V DC power supply is high.</li> <li>2) Components' malfunction of the controller inside the ERC3 motor unit</li> <li>3) During acceleration/deceleration and servo-on that use the remote sensing function of 24V DC power supply, the current consumption rises transiently.</li> <li>Using the remote sensing function with a power supply with no enough current capacity may cause overvoltage responding to the current thange.</li> <li>Treatment : 1) 2) Check the voltage of the power supply.</li> <li>3) Think to use a power supply with enough current capacity or not to use the remote sensing function. In the case that the voltage is normal, please contact IAI</li> </ul>	0	Ο	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
OCE	Operation release	Drop in control supply voltage	Cause : The control power voltage dropped less than the voltage drop threshold (80% of 24V DC = 19.2V). 1) The voltage of 24V DC power supply is low. 2) Components' malfunction of the controller inside the ERC3 motor unit Treatment : Check the voltage of the power supply. In the case that the voltage is normal, please contact IAI.	0	0	0	0
0D4	Cold start	Drive Source Error	<ul> <li>Cause : 1) Motor power input voltage (input to MP+ of ERC3) is too high for Position Mode 1, MEC Mode 1 and Pulse Train Control Mode Motor power input voltage (input to MPI of PIO Converter) is too high for Positioner Mode 2 and MEC Mode 2 During acceleration/deceleration and servo-on, the current consumption rises transiently. Using the remote sensing function with a power supply with no enough current capacity may cause overvoltage responding to the current change.</li> <li>2) Overcurrent is generated on the motor power supply line</li> <li>Treatment : 1) Check the power supply voltage input to MP+ of ERC3 for Position Mode 1, MEC Mode 2. Check the power supply voltage input to MP+ of PIO Converter for Position Mode 2 and MEC Mode 2. Think to use a power supply with enough current capacity or not to use the remote sensing function.</li> </ul>	0	0	0	0
0D5		Differential Counter Overflow with Home Return Incomplete	Cause : This alarm indicates that the position deviation counter has overflowed. 1) The speed dropped or stopped during JOG move due to an impact of external force, hit to the mechanical end or overload. 2) The excited-phase detection operation following the power-on is unstable. Treatment : 1) This error occurs when the actuator cannot be operated as it is commanded. Check the load conditions such as if the work is touching to the surrounding object, or brake is properly released, and remove the cause. 2) Overload is concerned. Revise the transportable weight.	0	0	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0D8	on release	Deviation overflow	<ul> <li>Cause : This alarm indicates that the position deviation counter has overflowed.</li> <li>1) The speed dropped or the actuator stopped due to the effect of external force or overload.</li> <li>2) The excited-phase detection operation following the power-on is unstable.</li> <li>Treatment : 1) This error occurs when the actuator cannot be operated as it is commanded. Check the load conditions such as if the work is touching to the surrounding object, or brake is properly released, and remove the cause.</li> <li>2) Overload can be concerned. Revise the transportable weight and redo the home-return operation.</li> </ul>	0	0	Ο	0
0D9	Operati	Software stroke limit exceeded	Cause : The current position of the actuator exceeds the software stroke limit. Treatment : Return the actuator to be within the range of the software stroke limit.	0	0	0	0
ODC		Pressing motion range over error	<ul> <li>Cause : 1) After the pressing operation has complete, the force to push back is too large and the pushed back to the pressing start position ("Position" in the position table).</li> <li>2) The actuator touched the work during the approach movement before the pressing movement.</li> <li>Treatment : 1) Revise the setting and adjust it so the force to push back gets smaller.</li> <li>2) Set the "Position" setting in front in the position table to shorten the approach distance.</li> </ul>	0	0	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
OEO	Cold start	Overload	<ul> <li>Cause :1) The work weight exceeds the rated weight, or an external force is applied and the load increased.</li> <li>2) If the actuator is equipped with a brake, the brake is not released.</li> <li>3) The slide resistance of the actuator is locally high.</li> <li>Treatment :1) Check the work and its surrounding area to remove the cause.</li> <li>2) For Positioner Mode 1 and MEC Mode 1, if the problem is solved with 24V DC 150mA being supplied to BK, it may be concerned a malfunction of the controller inside the ERC3 motor unit. Please contact IAI. If the problem cannot be solved, it may be concerned a malfunction of the brake, breakage of a cable or malfunction of the controller inside the ERC3 motor unit. Please contact IAI.</li> <li>3) In the case that the work can be moved by hand, move it. Then, check that there is no location where a sliding resistant is too large. Check if the installation face is distorted. When the error occurs in operation of the actuator only, Please contact IAI.</li> </ul> <b>Mathematical Caution</b> Restart the operation after making sure to remove the cause. If you cannot determine that the cause is removed completely, wait for at least 30 minutes before turning on the power to prevent the motor coil from burning.	0	Ο	Ο	Ο
0E5		Encoder receipt error	<ul> <li>Cause : It shows that a proper data from the simple absolute PCB in PIO Converter was not received by the controller inside the ERC3 motor unit for Positioner Mode 2 and MEC Mode 2 in Simple Absolute Type.</li> <li>1) Connector connection failure (If the detail code in the error list of the teaching tool is 0002H.)</li> <li>2) Effect of noise (If the detail code in the error list of the teaching tool is 0001H.)</li> <li>3) Malfunction of components (communication area) of the controller inside the ERC3 motor unit.</li> <li>Treatment : 1) Check if any wire breakage on a connector and the condition of wire connections.</li> <li>2) Interrupt the power to the peripheral equipment and activate only the ERC3 actuator. If any error does not occur, it might be caused by noise. Take proper measures against noise.</li> <li>If the cause is due to 3) or 4), it is necessary to replace the ERC3. If the cause cannot be specified, please contact IAI</li> </ul>	Ο	0	Ο	Ο



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0ED		Absolute encoder error detection 1	Cause : The current position was changed while the controller inside the ERC3 motor unit is loading or saving the absolute data Treatment : Avoid a condition that gives vibration to the actuator.	0	0	0	0
OEE	Operation release	Absolute encoder error detection 2	Cause : The position data was not detected properly by the encoder for Positioner Mode 2 and MEC Mode 2 in Simple Absolute Type. 1) When the power is supplied for the first time to Simple Absolute applicable type (before executing absolute reset) 2) Voltage drop of absolute battery. (If the detail code in the error list of the teaching tool is 0001H.) 3) Connector connection failure (If the detail code in the error list of the teaching tool is 0002H.) 4) Changed the parameters Treatment : 2) Supply the power for 72 hours or more and after charging the battery enough, perform the absolute reset operation. If the same failure occurs often even with enough battery charge, it is considered the end of the battery life. Replace the battery. Conduct an absolute reset for 1), 2) and 4). [Refer to Chapter 6, 6.1 Absolute Reset and Absolute Battery]	0	0	0	0
0EF		Absolute encoder error detection 3	The position data was not detected properly by the encoder for Positioner Mode 2 and MEC Mode 2 in Simple Absolute Type. (Encoder overspeed error) Cause : The current position changed with a speed more than the rotation velocity setting by an external cause during the power shutoff. Treatment : Set the rotation velocity to a higher speed than what currently is. If the same failure occurs again, it is necessary to have an absolute reset. [Refer to Chapter 6, 6.1 Absolute Reset and Absolute Battery]	0	0	0	0
0F4	Cold start	Mismatched PCB	This error would not occur in ERC3. If occurs, please contact IAI.	0	0	0	0
0F5	Operation release	Nonvolatile memory write verify error	It is verified at the data writing process to the non-volatile memory that the data inside the memory and the data to be written are matched. There was a mismatch detected in this process. Cause : Malfunction of non-volatile memory in the controller inside the ERC3 motor unit. Treatment : When the error is caused even when the power is re-input, please contact IAI.	0	0	0	0



Alarm Code	Alarm Level	Alarm Name	Cause/Treatment	Positioner Mode 1 Pulse Train Control Mode	Positioner Mode 2	MEC Mode 1	MEC Mode 2
0F6		Nonvolatile memory write timeout	There is no response in the specified time duration during the data writing to the non-volatile memory. Cause : Malfunction of non-volatile memory in the controller inside the ERC3 motor unit. Faulty nonvolatile memory. Treatment : When the error is caused even when the power is re-input, please contact IAI.	0	0	0	0
0F8		Nonvolatile memory data destroyed	Abnormal data was detected during the nonvolatile memory check after starting. Cause : Malfunction of non-volatile memory in the controller inside the ERC3 motor unit. Treatment : When the error is caused even when the power is re-input, please contact IAI.	0	0	0	0
0FA	Cold start	CPU error	CPU in the controller inside the ERC3 motor unit is not working properly. Cause : 1) Faulty CPU. 2) Malfunction due to noise. Treatment : When the error is caused even when the power is re-input, please contact IAI.	0	0	0	0
0FC		Logic error (Components' failure of the controller inside the ERC3 motor unit.)	Controller inside the ERC3 motor unit is not working properly. Cause : 1) Malfunction due to the effect of noise, etc. 2) Malfunction of peripheral circuit components. Treatment : Turn the power OFF and reboot. If the error occurs again, check for presence of noise. Also, if you have another ERC3 or PIO converter, replace it and try. A recurring error with the spare controller suggests presence of noise. If the cause cannot be identified, please contact IAI.	0	Ο	0	0
100 to 1FF	Message	Alarm on teaching tool	[Refer to the Instruction Manual of teaching tool.]	0	0	0	0
200 to 2FF	Operation release	Alarm on teaching tool	[Refer to the Instruction Manual of teaching tool.]	0	0	0	0
300 to 3FF	Cold start	Alarm on teaching tool	[Refer to the Instruction Manual of teaching tool.]	0	0	0	0


# ERC**3**

# Chapter 8 Actuator Maintenance Check

## 8.1 Inspection Items and Schedule

Follow the maintenance inspection schedule below.

It is assumed that the equipment is operating 8 hours per day.

If the equipment is running continuously night and day or otherwise running at a high operating rate, inspect more often as needed.

	T
ISlider	ivoei
Louran	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,

	External visual inspection	Internal inspection	Greasing (Note 1)
Start of work inspection	0		
1 month inspection	0		
3 month inspection			0
3 months after starting operation			Depends on grease
6 months inspection	0	O (Note 2)	supply timing (reference)
Every 6 month inspection	0	O (Note 2)	

#### [Rod Type]

	External visual inspection	Internal inspection	Greasing (Note 1)
Start of work inspection	0		
1 month inspection	0		
3 month inspection			O (Rod sliding surface) (Ball screw/Guide)
3 months after starting operation			⊖ (Rod sliding surface)
6 months inspection			Depends on grease
Every 6 month inspection	0	O (Note 2)	supply timing (reference)
Start of work inspection	0	O (Note 2)	(Ball screw/Guide)

Note 1 Grease film may run out if the actuator is moved back and forth continuously over a distance of 30 mm or less. As a guide, perform a back-and-forth operation five times or so over a distance of 50 mm or more after a back-and-forth operation over such short distance has been repeated 5,000 to 10,000 times. This will restore oil film.

Note 2 Check the condition of grease, and wipe off the grease before supplying new in case it is extremely dirty.

\*1 Supply grease to the rod sliding surface when grease is used up in the inspection at work start or every three months. First, wipe off the old grease and then supply new grease. Sometimes grease is separated from the base oil due to the installing posture or operating conditions and the base oil leaks from the inside of actuator to the outside. Check visually whether the oil drips or not when

[Grease Supply Timing (Reference)]

supplying grease.

Perform grease supply when it has reached to either the operation distance or spent months described in the table below.

Maximum Spaced of Llos [mm/s]	Grease Supply Timing (Reference)	
Maximum Speed of Ose [mm/s]	Operated distance	Months
0 to 750 or less	1,250 km	12 month
750 to 1,200	2,500 km	12-1101101



 Caution: 
 An actuator after 6 months of storage may have caused a degradation of the grease. Supply grease before start using. [Refer to 8.6 "Grease Supply"]

> Degradation speed of grease may differ depending on the environment of use (temperature, humidity and ambient conditions). It is recommended to shorten the grease supply period if the actuator is used under a bad condition such as in high temperature, high humidity or in dusty ambience.

Also, it is recommended to improve the environment conditions in case the grease changes its color due to the bad condition of use.

## 8.2 External Visual Inspection

An external visual inspection should check the following things.

Main unit	Loose actuator mounting bolts, other loose items
Stainless steel sheet (Slider type of stainless steel sheet specification )	Scratches, deviation • slack
Rod sliding surface (Rod type)	Grease lubrication Dripping of grease base oil, etc. Dust or foreign objects on sliding surface
Cables	Scratches, proper connections
Overall	Irregular noise, vibration

 The life of the stainless steel sheet should be 5000km of driving distance as a reference. However, replace the stainless steel sheet when it is necessary depending on the condition of use.

The sheet can be replaced by the user, but make sure there is no deviation or slack on the stainless steel sheet. Deviation or slack on the stainless steel sheet may damage the sheet. It is recommended that you bring the unit to us or have our service engineer visit your site for replacement work if you have any concern in the work.

• If the actuator is installed in the vertical orientation, the grease applied on the guide may drop in some environmental conditions. Clean and supply the grease when it is necessary.



# 8.3 Cleaning

- Clean exterior surfaces as necessary.
- If the grease base oil or others drip on the rod sliding surface and its periphery, wipe it off with a soft cloth, etc.
- Use a soft cloth to wipe away dirt and buildup.
- Do not blow too hard with compressed air as it may cause dust to get in through the gaps.
- Do not use oil-based solvents as they can harm lacquered and painted surfaces.
- To remove severe buildup, wipe gently with a soft cloth soaked in a neutral detergent or alcohol.

8.4 Internal Inspections for Slider Type 8.5 Internal Cleaning for Slider Type



# 8.4 Internal Inspections for Slider Type

Turn off the power, remove the screw cover or side cover and inspect inside visually. When inspecting the interior, check the following items.

Main unit	Loose mounting bolts, other loose items
Guide section	Lubrication, buildup

Visually inspect the interior of the equipment. Check whether dust or other foreign matter has gotten inside and check the lubrication state.

The lubrication may have turned brown. This is not a problem as long as the travel surfaces shine as though they are wet.

If the grease is mixed with dust and does not have a shiny appearance, or if the grease has lost its efficacy due to prolonged use, then clean each section and reapply grease. The procedure for internal inspections is outlined below.

(1) Standard Type (Screw Cover Type)

- 1) Loosen the screws on the screw cover and detach the screw cover.
- 2) Check inside.
- 3) After finishing the inspection, assemble back in the reverse order. Make sure there is no interference to the slider when putting on the screw cover.

(2) Standard Type (Stainless Steel Sheet Type), Cleanroom Type

- 1) Loosen the attachment screws on the side cover and detach the side cover.
- 2) Check inside.
- After finishing the inspection, assemble back in the reverse order. When attaching the side cover, push up the stainless steel sheet firmly so excess force would not be applied to the stainless steel sheet.

Caution: Pay attention not to bend the stainless steel sheet forcefully or apply damage in the inspection inside for the standard type (stainless steel sheet type) and cleanroom type.
 Do not attempt to pull the sheet to avoid a change of the attachment condition from the initial.
 Change in the attached condition may cause the sheet to be mounted unevenly or impact the product life. In such cases, please contact IAI Sales Engineer Department.
 Also you may get hurt on the edge of the stainless steel sheet. Wear gloves when you work on it.

# 8.5 Internal Cleaning for Slider Type

• Use a soft cloth to wipe away dirt and buildup.

- Do not blow too hard with compressed air as it may cause dust to get in through the gaps.
- Do not use oil-based solvents, neutral detergent or alcohol.



8.6 Grease Supply

### 8.6.1 Grease Supply for Slider Type

- [1] Other Types than Cleanroom Type
- (1) Grease Applied to Guide

IAI uses the following grease in our plant.

Guide	Idemitsu Kosan	Daphne Grease MP No.2

Other companies also sell similar types of grease. For details, give the above grease name to the manufacturer you want to purchase from and ask what corresponding product they have available. Here are some examples of similar products.

Showa Shell Oil	Albania Grease S2
Mobil Oil	Unirex N2

Warning: Never use anything other than synthetic poly- olefin grease. Mixing poly- grease with other grease not only reduces the performance of the grease, it may even cause damage to the actuator.

#### (2) Grease applied on Ball Screw

IAI uses the following grease in our plant.

Ball Screw	Kyodo Yushi	Multitemp LRL 3	
Warning: N v c	Vever use anything othe vith other grease not on ause damage to the act	r than synthetic poly- olefin grease. Mix ly reduces the performance of the greas tuator.	king poly- grease se, it may even

#### [2] Cleanroom Type

On the guide and ball screws, the urea based grease that has great low particle-emission, stable torque characteristics, brilliant lubrication and anti-dust effect equivalent to the lithium based grease is applied.

Guide, Ball Screw	Kuroda Precision Industries	C grease	
Warning: N	Never use anything othe with other grease not on	r than synthetic poly- olefin grease. Mix ly reduces the performance of the grea	xing poly- grease

cause damage to the actuator.



### 8.6.2 How to Supply Grease on Slider Type

[1] Standard Type (Screw Cover Type)

1) Remove the thin-head screws with a 1.5mm hex wrench for SA5 and 2.0mm wrench for SA7.



Thin-Head Screw

2) Detach the screw cover.



3) After cleaning up the guide on both sides, apply the grease. Slide the slider back and forth to evenly apply the grease. Wipe off the excess grease at last.





4) After cleaning up the ball screw, apply the grease by hand. Move the slider back and forth to evenly apply the grease.

For some of the low lead actuators, the slider would not move manually with hand. Move it with JOG operation of the controller.

**Ball Screw** 

Wipe off the excess grease at last.



5) Attach the slider cover and tighten the thin-head screws with 1.5mm hex wrench for SA5 and 2.0mm wrench for SA7.



Thin-Head Screw

Caution: In case the grease got into your eye, immediately go see the doctor to get appropriate care. After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease off.



- [2] Standard Type (Stainless Steel Sheet Type), Cleanroom Type
- 1) Remove the screws and detach the side covers on both sides.





 On the guide part, insert a spatula between the slider and the base or apply grease with a grease injector while moving the slider back and forth.
 Supply the grease to the guides on both sides.

Lastly, wipe off the excess grease.







3) Apply the grease on the ball screw with hand after cleaning it, and move the slider back and forth to spread the grease.

In this process, pay attention to the stainless steel sheet so that you would not touch and make it deformed.

Lastly, wipe off the excess grease.



4) Attach the side covers after grease supply is finished.

If you touch the edge of the stainless sheet in the attaching process, the sheet may get damaged or wavy which result in shortening life or earlier wear-out.

To avoid touching the edge of the sheet, insert a shim (approximately 0.1 to 0.2mm) between the sheet and cover to push up the sheet, and then push in the cover.



Shim

Caution: I Do not damage the stainless steel sheet by bending it forcefully during the check inside. Also you may get hurt on the edge of the stainless steel sheet. Wear gloves when you work on it. The front cover is supporting the ball screw. Do not detach it. If the adjustment of the front cover is improper, it may cause the increase of

driving resistance, shortened life of each area, or abnormal noise due to a misalignment of the axis center.

• In case the grease got into your eye, immediately go see the doctor to get appropriate care. After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease off.



#### 8.6.3 Grease Supply for Rod Type

(1) Grease Applied to Ball Screw and Rod Sliding Part

IAI uses the following grease in our plant.

Ball Screw	Kvodo Yushi	Multitemp LRL 3
Dan Oorow	Ttyouo Tuom	

Use lithium grease spray for the maintenance work of ball screws. Make it 1 sec or less to apply the spray in one time.

Wako Chemical	Spray Grease No. A161 or equivalent
---------------	-------------------------------------

Warning: Never use anything other than synthetic poly- olefin grease. Mixing poly- grease with other grease not only reduces the performance of the grease, it may even cause damage to the actuator.



## 8.6.4 How to Supply Grease on Rod Type

1) Remove the thin-head screw with a 1.5mm hex wrench.



2) Slide the rod for more than the half of the stroke distance.

For some of the low lead actuators, the rod would not move manually with hand. Move it with JOG operation of the controller.

To supply grease to the ball screw, put the spray grease into the screw hole. (1 second or less for spraying)





3) On the rod sliding part, apply grease by hand. Wipe off the old grease, and then supply new grease.



4) After applying the grease, move the rod back and forth so the grease spreads out evenly. For some of the low lead actuators, the rod would not move manually with hand. Move it with JOG operation of the controller.



5) Reinstall the thin-head screw with a 1.5mm hex wrench.



Warning: When supplying grease, do not attempt to use spray oil. Make sure to use spray grease. Also make sure to make the spraying time 1 second or less, and do not make it longer than 1 second in continuous or supply twice in quick cycle. If applying excess grease, the oil may flow to the electrical components and may cause an error operation.

Caution: In case the grease got into your eye, immediately go see the doctor to get appropriate care. After finishing the grease supply work, wash your hands carefully with water and soap to rinse the grease off.



#### 8.6.5 How to Replace and Adjust Stainless Steel Sheet

The screws and other components detached for the replacement will be necessary when rebuild the product. Prepare a storage box beforehand to keep the components in it.

#### [1] Preparation

- (1) Items Required for Replacement Work
- Stainless Steel Sheet for Replacement
- Hex Wrench
- Measure

#### (2) Caution for the stainless steel sheet tension

Degradation and wear-out of the stainless steel sheet relies on its tension of attachment. If the stainless steel sheet is pulled with a huge force and the gap between the sheet and the slider cover is large, there is a risk of metal fatigue.

On the other hand, if the tension is too loose, the stainless steel sheet may interfere with the back face of the slider cover, which may cause dust generation. Adjust the tension of the stainless steel sheet to obtain the specific dimension for the clearance to the back side of the slider cover.

#### (3) Names of the Parts



Stainless Steel Sheet Holder Plate



- [2] Procedure for Replacement and Tuning
- (1) Move the slider to the middle of the actuator
- (2) Remove the screws affixing the slider cover. For SA5C, there is a plate spring. Remove the spring.

Standard Type (Stainless Steel Sheet Type) Condition with Slider Covers Detached (plate spring also removed)



Clean Room Type Condition with Slider Covers Detached



- (3) With a screw driver, remove the 2 screws on each side and detach the holder plate and old stainless steel sheet.
- (4) Hold the new stainless steel sheet with the holder plate and the screws. At this time, tighten the screws on the motor side properly and leave the other side loose.



side loose.



- (5) Adjust the stainless steel sheet tension.
  - Adjust the tension of stainless steel sheet by moving back and forth..
     For Clean Type, make the roller pressed down to touch the side covers. It is not necessary for Standard Type since there is no roller.
  - 2) Tune the tension of the sheet so the distance between the peak of the sheet and the top surface of the slider become as shown in the figure below and temporarily tighten the screws on the opposite side of the motor to hold the stainless steel sheet.





Distance between Peak of Stainless Steel Sheet and Slider Top Surface

	H (mm)	
Standard Type	SA5C	0.5 to 1.0
Type )	SA7C	1.0 to 2.0
Cleanroom Tyme	SA5C	0.5 to 1.0
Cleanroom Type	SA7C	2.0 to 3.0

(6) Slide the slider several times in the entire range of the stroke to ensure that there is no touch of the slider to the stainless steel sheet, and check the tension at the same time. For those such as low lead type or brake-equipped type that cannot be moved with hand, turn on

For those such as low lead type or brake-equipped type that cannot be moved with hand, turn on the power supply to the controller and move the slider in approximately 20mm/s using either the teaching pendant or PC software.

(7) After making sure that there is no touch of the slider body to the stainless steel sheet, fasten alternatively the two screws that have been temporarily fixed. Finally, apply even torque to fasten them for fixing the stainless sheet.

If uneven torque is applied to fasten the screws, the sheet might meander or rise.

Tightening Torque	0.41N•m
-------------------	---------



#### Motor Replacement Process 8.7

[Items required for replacing the motor] • Motor Unit for Replacement

- Hex wrench set



[Procedure]

1) Remove the screw affixing the actuator and motor unit with 2.5mm hex wrench for SA5 and SA4 and 3.0mm wrench for RA7 and RA6.



2) Detach the motor unit.





3) Make the profiles on the actuator side and motor unit side aligned so the projection matches to the slit.



Apply grease to the coupling part. TL101Y grease made by NOK

4) Attach the motor unit for replacement with the projection being matched with the slit.

matched with each other.



5) Tighten the screw to affix the motor unit to the actuator with 2.5mm hex wrench.



# Chapter 9 External Dimensions

# 9.1 ERC3-SA5C Standard Type (Screw Cover Type)



Stroke	l w/o	With	А	В	С	D	F	G	Н	J	Weight*
	Brake	Brake									[ĸg]
50	284.5	327	73	0	0	0	142	4	4	0	1.4
100	334.5	377	100	85	0	0	192	4	4	1	1.5
150	384.5	427	100	85	1	0	242	4	6	1	1.6
200	434.5	477	200	185	1	1	292	6	6	1	1.7
250	484.5	527	200	185	2	1	342	6	8	1	1.9
300	534.5	577	300	285	2	2	392	8	8	1	2.0
350	584.5	627	300	285	3	2	442	8	10	1	2.1
400	634.5	677	400	385	3	3	492	10	10	1	2.2
450	684.5	727	400	385	4	3	542	10	12	1	2.3
500	734.5	777	500	485	4	4	592	12	12	1	2.4
550	784.5	827	500	485	5	4	642	12	14	1	2.5
600	834.5	877	600	585	5	5	692	14	14	1	2.7
650	884.5	927	600	585	6	5	742	14	16	1	2.8
700	934.5	977	700	685	6	6	792	16	16	1	2.9
750	984.4	1027	700	685	7	6	842	16	18	1	3.0
800	1034.5	1077	800	785	7	7	892	18	18	1	3.1

\* A model with brake increases the weight by 0.4kg.



# 9.2 ERC3-SA7C Standard Type (Screw Cover Type)



	l	_										Woight*
Stroke	w/o	With	Α	В	С	D	F	G	Н	J	K	[ka]
	Brake	Brake										[149]
50	347.5	398.5	0	0	1	0	174.5	4	4	0	2	3.2
100	397.5	448.5	100	85	1	0	224.5	6	4	1	3	3.4
150	447.5	498.5	100	85	2	0	274.5	6	6	1	3	3.6
200	497.5	548.5	200	185	2	1	324.5	8	6	1	3	3.8
250	547.5	598.5	200	185	3	1	374.5	8	8	1	3	4.0
300	597.5	648.5	300	285	3	2	424.5	10	8	1	3	4.3
350	647.5	698.5	300	285	4	2	474.5	10	10	1	3	4.5
400	697.5	748.5	400	385	4	3	524.5	12	10	1	3	4.7
450	747.5	798.5	400	385	5	3	574.5	12	12	1	3	4.9
500	797.5	848.5	500	485	5	4	624.5	14	12	1	3	5.1
550	847.5	898.5	500	485	6	4	674.5	14	12	1	3	5.4
600	897.5	948.5	600	585	6	5	724.5	16	14	1	3	5.6
650	947.5	998.5	600	585	7	5	774.5	16	16	1	3	5.8
700	997.5	1048.5	700	685	7	6	824.5	18	16	1	3	6.0
750	1047.5	1098.5	700	685	8	6	874.5	18	18	1	3	6.2
800	1097.5	1148.5	800	785	8	7	924.5	20	18	1	3	6.5

\* A model with brake increases the weight by 0.5kg.



# 9.3 ERC3D, ERC3CR-SA5C Standard Type (Stainless Steel Sheet Type), Cleanroom Type

Note: Stainless steel sheet type is not equipped with vacuum or joint.



Stroke	w/o Brake	With Brake	A	В	С	D	F	G	Н	J	к	Weight* [kg]
50	299.9	342.4	73	0	0	4	4	166	0	0	192.4	1.6
100	349.9	392.4	100	0	0	4	4	216	1	85	244.2	1.8
150	399.9	442.4	100	0	1	4	6	266	1	85	294.2	2.0
200	449.9	492.4	200	1	1	6	6	316	1	185	344.2	2.1
250	499.9	542.4	200	1	2	6	8	366	1	185	394.2	2.3
300	549.9	592.4	300	2	2	8	8	416	1	285	444.2	2.5
350	599.9	642.4	300	2	3	8	10	456	1	285	494.2	2.6
400	649.9	692.4	400	3	3	10	10	516	1	385	544.2	2.8
450	699.9	742.4	400	3	4	10	12	566	1	385	594.2	3.0
500	749.9	792.4	500	4	4	12	12	616	1	485	644.2	3.1
550	799.9	842.4	500	4	5	12	14	666	1	485	694.2	3.3
600	849.9	892.4	600	5	5	14	14	716	1	585	744.2	3.5
650	899.9	942.4	600	5	6	14	16	766	1	585	794.2	3.6
700	949.9	992.4	700	6	6	16	16	816	1	685	844.2	3.8
750	999.9	1042.4	700	6	7	16	18	866	1	685	894.2	4.0
800	1049.9	1092.4	800	7	7	18	18	916	1	785	944.2	4.1

\* A model with brake increases the weight by 0.4kg.



# 9.4 ERC3D, ERC3CR-SA7C Standard Type (Stainless Steel Sheet Type), Cleanroom Type

Note: Stainless steel sheet type is not equipped with vacuum or joint.



Stroke	w/o Brake	With Brake	А	В	С	D	E	F	G	н	J	к	Weight* [kg]
50	372.2	423.2	0	0	1	4	2	4	199	0	0	237.7	3.6
100	422.2	473.2	100	0	1	6	3	4	249	1	85	287.7	3.9
150	472.2	523.2	100	0	2	6	3	6	299	1	85	337.7	4.1
200	522.2	573.2	200	1	2	8	3	6	349	1	185	387.7	4.4
250	572.2	623.2	200	1	3	8	3	8	399	1	185	437.7	4.7
300	622.2	673.2	300	2	3	10	3	8	449	1	285	487.7	4.9
350	672.2	723.2	300	2	4	10	3	10	499	1	285	537.7	5.2
400	722.2	773.2	400	3	4	12	3	10	549	1	385	587.7	5.5
450	772.2	823.2	400	3	5	12	3	12	599	1	385	637.7	5.7
500	822.2	873.2	500	4	5	14	3	12	649	1	485	687.7	6.0
550	872.2	923.2	500	4	6	14	3	14	699	1	485	737.7	6.3
600	922.2	973.2	600	5	6	16	3	14	749	1	585	787.7	6.5
650	972.2	1023.2	600	5	7	16	3	16	799	1	585	837.7	6.8
700	1022.2	1073.2	700	6	7	18	3	16	849	1	685	887.7	7.1
750	1072.2	1123.2	700	6	8	18	3	18	899	1	685	937.7	7.3
800	1122.2	1173.2	800	7	8	20	3	18	949	1	785	987.7	7.6

\* A model with brake increases the weight by 0.5kg.



# 9.5 ERC3-RA4C



Stroke	w/o Brake	With Brake	F	Weight* [kg]
50	286	328.5	142	1.4
100	336	378.5	192	1.7
150	386	428.5	242	2.0
200	436	478.5	292	2.3
250	486	528.5	342	2.6
300	536	578.5	392	2.9

\* A model with brake increases the weight by 0.4kg.



# 9.6 ERC3-RA6C



	l	-		Weight*	
Stroke	w/o	With	F	[ka]	
	Brake	Brake		[49]	
50	334.5	385.5	158	3.9	
100	384.5	435.5	208	4.4	
150	434.5	485.5	258	4.9	
200	484.5	535.5	308	5.4	
250	534.5	585.5	358	5.9	
300	584.5	635.5	408	6.4	

\* A model with brake increases the weight by 0.5kg.

10.1 Input and Output Response Performance When PIO

Converter is Used

# ERCJ =

# Chapter 10 Appendix

10.1 Input and Output Response Performance When PIO Converter is Used

When controlling ERC3 with using PIO converter, there is a delay in the response time as described below;

- Input Delay Time of PIO Converter The digital input time constant with the hardware is 2ms at maximum. The digital input filter time with the firmware is 5ms at maximum. Therefore, there is 7ms of input response time in total for PIO converter.
- 2) Communication Cycle Time (I/O Update Time) of PIO Converter 5ms at maximum is required for the communication cycle time of PIO converter under the condition that there is no failure in the communication. The cycle time should be 10ms at maximum with a communication error occurred.
- Delay Time in Output Operation There should be no delay time in the digital output operation of the firmware. It outputs the output data received from ERC3 in communication cycle every time.

Considering the time described above, the timing for the input and output signals should be as shown below;





# 10.2 Way to Set Multiple Controllers with 1 Teaching Tool

Settings of several controller units can be performed with 1 unit of teaching tool with the method stated below if using PIO converter. ERC3 should be in CON Mode. The following method cannot be applied if ERC3 is in the serial communication type.

It is usually necessary to connect the teaching tool to the controllers one by one when making a setup to multiple controllers with one unit of teaching tool. In this section, explains how to perform the settings without connecting and disconnecting the plug.

- Requisite devices :
  - (1) SIO Converter (RCB-TU-SIO-A or RCB-TU-SIO-B) : 1 unit : Required by the number of controllers

(2) Controller Link Cable (CB-RCB-CTL002)

- Accessories (1) 4-way junction (Manufactured by AMP 5-1473574-4) : 1 unit
  - 2) e-CON Connector (Manufactured by AMP 4-1473574-4) : 1 unit
    - 3) Terminal Resistance (220 $\Omega$ , with a e-CON connector) : 1 unit

Instead of the e-CON cable attached to the controller link cable, a terminal block may be used. In this configuration, disconnect the e-CON connector from the controller link cable.



#### 10.2.1 Connecting Example







## 10.2.2 Detailed Connection Diagram of Communication Lines

(Note 1) Apply a 2-pair shielded cable.

When connecting a cable other than recommended to (A) and (B), make sure to use a hard-cored cable equivalent to the vinyl cable (KIV) dedicated for control devices with the sheath outer diameter from <u>1.35 to 1.60mm</u>. Using cables with outer diameter out of the specification may cause poor contact to occur.

Caution: When cables with outer diameter out of the specification are used, use a terminal block instead of 4-direction junction. In this configuration, disconnect the e-CON connector of the link cable. If an error possibly caused by poor contact occurs frequently, replace the junction with the terminal block.

#### 10.2.3 Axis No. Setting

Connect the PC software or teaching pendant and select the axis number. Supply power to the controller only for the set axis number.

Laution: The axis number must be unique.

# ERCÕ

# 10.2.4 Handling of e-CON connector (how to connect)



#### Caution :

- 1) e-CON connector cannot be reused once the press-welding is failed. Use a new connector to retry the press-welding.
- 2) When connecting to the socket, hold the connector with care not to touch the clamp lever, insert the connector in parallel to the socket until the clamp lever makes a "click" sound.
- 3) After joining to the socket, do not pull the cables or pull the connector without releasing the lock of the clamp lever.

# ERC**3**

#### 10.2.5 SIO Converter

The SIO converter converts the communication mode from RS232C to RS485 or vice versa.



#### 1) Power/Emergency Stop Terminal Board (TB2)

.,	······································
Symbol	Description
EMG1, EMG2	Turn the PORT switch ON to output the emergency stop switch signal, OFF to short-circuit EMG1 and EMG2.
	When applying the emergency stop switch of the teaching pendant to the emergency stop of the system, obtain the signal from here.
24V	Positive side of the 24V DC power supply (Power supply for the teaching pendant and conversion circuit.)
0V	Negative side of the 24V DC power supply
FG	Frame ground

(Note) 0V is connected to the pin No. 7 (GND) on the communication connector for the controller.

#### Connection method

Use a connection cable satisfying the following specifications :

Item	Specification
Applicable wire	Solid Wire : $\phi$ 0.8 to 1.2mm/Stranded : AWG Size 20 to 18 (0.5 to 0.75mm <sup>2</sup> )
Stripped wire length	10mm

Use for Continuity Check

Insert a flathead scewdriver with a bit size of approx. 2.6mm.



Connection Cable



- 2) Link-connection Terminal Board (TB1)
  This is the connection port to obtain communication connection with the controller.
  Connect terminal "A" on the left side to communication line SGA of the controller. (Terminal A is connected to pin 1 of (7) internally.)
  Connect terminal "B" on the right side to communication line SGB of the controller. (Terminal B is connected to pin 2 of (7) internally.)
  Use a twisted pair shielded cable for the connection of SGA and SGB to TB1.
- 3) D-sub, 9-pin connector
   A connection port with the PC. (RS232C)
   It is used when the operation is conducted with using SIO communication.
- 4) Mini DIN, 8-pin connector This connector is connected to PC software, teaching pendant.
- 5) PORT Switch

The port switch is used to enable/disable connector (4). Set the switch to ON if connector (4) is used or OFF if not used. The switchover of valid/invalid on the teaching pendant is held at the same time as the emergency stop button switch signal output (between EMG1 and 2).

6) LED Indicators for Monitoring

LED1 : Lights/blinks while the controller sends signals. LED2 : Lights/blinks while signals are sent from the RS232C connector.

7) e-CON Connector

It is used when connecting to the controller with e-CON connector without using 2).



#### 10.2.6 Communications Cable

1) Controller Link Cable (CB-RCB-CTL002)





# 10.3 Conformity to Safety Category

In this section shows an example of a circuit using the dedicated teaching pendant. However, it is not possible for us to check the conformity of our product to the condition of your system. Therefore, it is necessary that the user construct the circuit considering the condition of use and the categories to be applied.

#### [1] System Configuration

When it is required to construct a system applicable for the Safety Category

(ISO12100-1/ISO13849-1), use TP Adapter (Model Code: RCB-LB-TGS) that is applicable for the Safety Category.

The system can conform to up to safety category B to 4 (ISO12100-1/ISO13849-1) by changing connections of system I/O connectors.

In this case, it is recommended to use a teaching pendant equipped with a dead man's switch (Model Code: TB-02D or TB-01D/DR).





#### [2] Wiring and setting of safety circuit

1) Power supply

To use safety relays and/or contactors of 24V DC specification in the safety circuit, the control power supply should be used only for the circuit as much as possible. (Do not use the same power source as the driving power supply for this controller.)

It is the risk prevention treatment preparing for the cases such as the operation error of the safety circuit caused by not enough power capacity.

2) Specification of system I/O connector for TP adapter

Connector Name		System I/O Co	nnector	Applicable Wire
Upper side	Cable side	FMC1.5/6-ST-3.5 <sup>(Note 1)</sup>		
(EMG side)	TP adapter side	MCDN1.5/6-G1-3.5P26THR		AWG24 to 16
Lower side	Cable side	FMC1.5/6-ST-3.5 <sup>(Note 1)</sup>		(0.2 to 1.25m <sup>2</sup> )
(ENB side)	TP adapter side	MCDN1.5/6-G1-3.5P26THR		

	Pin No.	Signal name	Description			
	1	EMG1-	Emergency stop contact 1			
	2	EMG1+	(30V DC or less, 100mA or less)			
Unnereide	3	EMG2-	Emergency stop contact 2			
(EMC side)	4	EMG2+	(30V DC or less, 100mA or less)			
(EINIG SIGE)	5	EMGIN	Emergency stop detection input			
	6	EMGOUT	24V power supply output for emergency stop detection input			
	7	ENB1-	Enable contact 1			
	8	ENB1+	(30V DC or less, 100mA or less)			
Loweroide	9	ENB2-	Enable contact 2			
	10	ENB2+	(30V DC or less, 100mA or less)			
	11	ENBIN	Enable detection input			
	12 ENBOUT		24V power supply output for enable detection input			

Note 1 Connectors on the cable side are attached under conditions where initial wiring has been conducted.

In order to support each category, remove the initial wiring and wire your safety circuit.



- Connection of dummy plug of TP adapter When operating the controller with AUTO Mode, make sure to connect the enclosed dummy plug (DP-4S) to TP Connector.
- 4) Enable function\*

If you are using the enable function, set it to Enable using the controller parameter. Parameter No.42 Enable function

0 ··· Enable

- 1 ··· Disable [Default setting at shipment]
- \* Enable function : It is the function to monitor the status of the signal (safety switch, dead man's switch on teaching pendant, etc.) to permit the devices to operate.





• Detailed category 1 circuit example





2) In case of category 2




• Detailed category 2 circuit example





3) In case of category 3 or 4







• Detailed category 3 or 4 circuit example





# [4] TP adapter and Related Parts1) TP adapter external dimensions









- 2) Connection Cable
  - Controller/TP Adaptor Connection Cable
    Use this cable to connect the controller and TP adapter (RCB-LB-TGS).
    Model : CB-CON-LB005 (standard cable length : 0.5m)
    Maximum cable length : 2.0m

CN	1							CN2
- 🗢								- □
		CN1				CN2		
	Color	Signal	No.		No.	Signal	Color	
	BR	SGA	1		1	SGA	BR	
	YW	SGB	2		2	SGB	YW	
	RD	5V	3		3	5V	RD	
	OR	ENBL	4		4	ENBL	OR	
	BL	EMGA	5		5	EMGA	BL	
	GN	24V	6		6	24V	GN	
	PL	GND	7		7	GND	PL	
	GY	EMGB	8		8	EMGB	GY	
	Shield	FG	i	[		FG	Shield	

8PIN MIN DIN Connector (overmolded)

8PIN MIN DIN Connector (overmolded)



#### 3) Dummy plug

Connect a dummy plug to the teaching pendant connecting connector. Make sure to connect a dummy plug if the AUTO mode is specified. Without the connection, it will be the emergency stop condition. Model: DP-4S (when TP adapter is RCB-LB-TGS)





Plug: HDR-E26MSG1





processing.

## 10.4 When Connecting Power Supply with + Grounding

When using ERC3 with + grounding, there is a risk of short-circuit of 24V DC power supply if connected to the PC. This is because many PCs have the communication ground (GND) and the frame ground (FG) connected inside and short-circuit occurs through the frame ground. Also, if controllers with different 24V DC power supplies are connected with serial communication, the communication line may become the route of controller power supply in some cases depending on the timing to turn on the power, resulting in the malfunction of the communication line.

Troubleshooting is summarized separately in [ME0271 Caution for + Grounding 24V Power Controller]. Please refer to it.



## 10.5 Example of Basic Positioning Sequence (PIO Patterns 0 to 3 in PIO Converter)

This section shows an example in which a simple operation box directs ERC3 to move the actuator successively to three positions on an axis.

### 10.5.1 I/O Assignment

о <i>и</i> р				PLC			_
Operation Box			-	Input	Output	Operation	Box
Emergency stop (Relay Circuit)	canc	el EMGRS <sup>-</sup>	T 📥	IN0		EMRSTL (	Emergency stop cancel display
RC Start -		START	$\Rightarrow$	IN1 ──	OUT1 —O—	STARTL (	RC Start Display
RC Stop -	<u>}-</u> -	STOP	$\Rightarrow$	IN2 ──	OUT2 ————	STOPL (	RC Stop Display
Pause -	 E	HOLD	$ \rightarrow $	IN3   —   —		HOLDL (	Pause Display
Home Return	- <u>/</u> ]	HOME		IN4 ──┤	OUT4 ————————————————————————————————————	HOMEL (	Home Return Display
Completed Position No.1	- La	PM1		IN5   ──	OUT5 ————————————————————————————————————	ZONE1L (	Zone 1 Display
Completed Position No.2	nvert	PM2	$\square$	IN6 ──┤	OUT6 ————————————————————————————————————	PZONEL (	Position Zone Display
Completed Position No.4	DC3 CG3	PM4		IN7 ──┤	OUT7 ————————————————————————————————————	RMDL (	Manual Mode Display
Moving	ша	MOVE		IN8	OUT8 ————————————————————————————————————	PC1	Command Position No.1
Zone1		ZONE1	$\square$	IN9 ──┤	OUT9 ————————————————————————————————————	PC2	Command Position
Position Zone		PZONE	$\square$	IN10	OUT10 ————————————————————————————————————	PC4	Command Position
Operating Mode		RMDS		IN11 ──	OUT11 ———————————————————————————————————	HOME	Home Return
Home Return		HEND	$\square$	IN12 ──	OUT12 ————	*STP	*Pause
Point Positioning		PEND		IN13 ──	OUT13 —O—	CSTR	Start
Operation Preparation End		SV		IN14 →	OUT14	SON	Servo ON
* Alarm		*ALM		IN15   ──	OUT15 ————	RES	Reset

"\*" in codes above shows the signal of the active low. Input signal is processed with it is turned OFF and output signal is usually ON when the power is supplied and is OFF when signal output.



#### 10.5.2 Ladder Sequence

- [1] Servo ON (Emergency Stop) Circuit
- It is presumed that the emergency stop release circuit installed in the operation box possesses the self-retaining circuit as shown in "3.1.3 [1] Emergency Stop Circuit". When it comes to the emergency stop release condition, "Servo-on" signal from PLC to PCON turns ON.
- 2) Then if the emergency stop release state continues, the operation ready complete signal (sent from PCON to PLC) is turned on to go on the "Emergency stop release" lamp, which indicates that the actuator can be operated.



#### [2] Operation and Stop Circuit





#### [3] Pause Circuit

Pause is provided by a single pushbutton. In a similar way as use of an alternate switch, push the button to make the actuator pause and push it again to release the pause of the actuator. Pushing the pushbutton leads the "pause command and pause lamp ON" state and pushing the pushbutton again brings "pause release command and pause lamp OFF".





#### [4] Reset Circuit

If the "Stop" button on the operation box is pushed during pause, the "Reset" signal sent from PLC to ERC3 and PIO converter are turned ON and the remaining moving distance is cancelled. In addition, this operation releases the pause. (It is because the pause is not required with no remaining moving distance.)





#### [5] Home Return Circuit





[6] Decode Circuit of Positioning Complete Position No.

The decode circuit converts the binary data of positioning complete position No. sent from ERC3 and PIO converter to PLC into the corresponding bit data.



#### [7] Actuator Start Circuit

If the "Operation" switch on the operation box is pushed, the lamp of the "Operation" pushbutton switch described in (3) Operation and Stop Circuit goes on and, at the same time, the actuator starts successive positioning of position No.  $1 \rightarrow 2 \rightarrow 3 \rightarrow 1 \rightarrow 2^{\bullet \bullet \bullet}$ . The circuit below is intended for the activation.





#### [8] Position 1 Operation Circuit

The main circuit is designed to process and manage signals "start"  $\rightarrow$  "moving"  $\rightarrow$  "positioning complete" to move the actuator to position No.1.



• Circuit 10 is designed to start positioning to position No.1 again after positioning to position No.3 is completed.

If the "Operation" lamp goes off, the operation circuit is reset entirely. When the "Stop" button is
pushed, the actuator will stop at completion of the operation being executed. At emergency
stop, the actuator is stopped immediately (which is the function of ERC3 and PIO Converter ).



#### [9] Position 2 Operation Circuit

The main circuit is designed to process and manage signals "start"  $\rightarrow$  "moving"  $\rightarrow$  "positioning complete" to move the actuator to position No.2. This circuit indicates the same sequence as that of position No.1.





ERCÕ

The main circuit is designed to process and manage signals "start"  $\rightarrow$  "moving"  $\rightarrow$  "positioning complete" to move the actuator to position No.3. This circuit indicates the same sequence as that of position No.1.





[11] Commanded Position No. Output Ready Circuit

The ready circuit is designed to hold start command and output commanded position No. in the binary code.

Interlock is taken so that position No. command may not be specified incorrectly.



- Once a moving command to a position is issued, any of circuits A, B and C is turned ON to
  remember it unless a moving command to another position is issued. The operation circuit is
  cancelled by a stop command such as an emergency stop command. However, the circuit
  remembers the positions to which the actuator moved and the positions at which the actuator
  stopped until the cancellation. Such sequence design is also intended to cope with errors
  occurred and helpful to find the causes of the errors from circuit status, stop position
  inconsistency and other conditions.
- Taking interlock in both commands and results is usual means in circuit design to prevent results from being ON simultaneously. For example, if both SOLs in a solenoid valve of double SOL type are turned ON simultaneously, the coils are burned instantly. In another case, PLC executes a program in descending order but operations are not always done in the order. If you create a sequence program taking operation order into account, circuit change and/or addition due to debugging and specification change may cause the operation order to be modified without intention. Take interlock securely.



[12] Commanded Position No. Output Circuit

Depending on the result of the ready circuit, this circuit converts position No. to the binary code and outputs the data from PLC to ERC3 and PIO converter.



[13] Start Signal Output Circuit

After 20msec from the output of position No., this circuit outputs the start signal from PLC to ERC3 and PIO converter.





#### [14] Other Display Circuits (Zone 1, Position Zone, and Manual Mode)



#### [Reference]

Programs and functions of PLC are expressed differently depending on manufacturers. However, the contents of sequence designs do not vary fundamentally. Though arithmetic and data processing commands seem differently, any manufacturer defines command words executing the same functions as those of other manufacturers.

Chapter 10 Appendix

10.6 Life

# ERC**3**

### 10.6 Life

The mechanical life of the actuator is represented by that of the guide receiving the greatest moment load. Operation life of the linear guide is to be determined by the total driving distance which can reach without having 90% flaking (peeling on rail surface). Operation life can be figured out with the calculation method shown below.

#### 10.6.1 How to Calculate Operation Life

For the operation life of the linear guide, use the dynamic allowable moment stated in 1.2 Specifications, and figure out with the formula below.

$$L = \left(\frac{C_{M}}{M}\right)^{3} \cdot 5000 \text{km}$$

In addition, have a calculation for the drop of life with the formula below if there is a concern that the life could drop due to the condition of vibration or way to be attached.

 $L = \left(\frac{C_{M}}{M} \cdot \frac{f_{ws}}{f_{w}} \cdot \frac{1}{f_{\alpha}}\right)^{3} \cdot 5000 \text{ km}$ 

L : Operation life (km)  $C_M$  : Dynamic allowable moment (N·m) M : Moment to work (N·m)  $f_{ws}$  : Standard operational coefficient  $f_w$  : Load coefficient  $f_\alpha$  : Attachment coefficient 5000km : Standard rated life of ROBO Cylinder

Explained below is regarding the standard operational coefficient  $f_{ws}$ , load coefficient  $f_w$  and attachment coefficient  $f_{\alpha}$ . Refer to the contents below to set them up.

Relef to the contents below to set them u

[Standard operatinal coefficient fws]

For ROBO Cylinders described in this manual,  $f_{ws}$  = 1.2. It is a coefficient defined for each model, some models such as RCS3 high-speed type is 1.35.



#### [Load coefficient fw]

It is a coefficient to consider the life drop due to operational conditions.

Load coefficient	w Operation Condition	Reference for acceleration/deceleration
1.0 to 1.5	Small vibration or impact in slow operation	1.0G or less

#### [Attachment coefficient $f\alpha$ ]

Attachment coefficient  $f_{\alpha}$  is a coefficient to consider the life drop due to the condition of actuator attachment.

Attachment coefficient f $\alpha$	1.0	1.2	1.5
	Attachment in whole area	Attachment on both ends	Attachment on spots
Attached condition			

\* As the figures are those in common for each manual, they are not for ERC3. Replace to figures for ERC3 and select the attachment coefficient.

\* Even when in attachment in whole area, and the actuator is seated in the whole length of the product, select 1.2 or 1.5 for the attachment coefficient depending on the position of screw fixing.

\* For attachment in whole area, use all of the tapped holes (counterbored holes) on the seat surface to fix.

#### 10.6.2 Operation Life

The operation life depends on the moment to work. With light load, it will be longer than 5,000km, the standard rated life. With no consideration of vibration and attachment condition, the operation life is 40,000km according to the calculation with formula in the previous page underassumption that 0.5  $C_M$  (half of dynamic allowable moment) of moment is applied on. It shows that it can be 8 times longer than the standard rated life, which is 5,000km.

# ERC**3**

## Chapter 11 Warranty

## 11.1 Warranty Period

One of the following periods, whichever is shorter:

- 18 months after shipment from our company
- 12 months after delivery to the specified location
- 2,500 operational hours

### 11.2 Scope of Warranty

Our products are covered by warranty when all of the following conditions are met. Faulty products covered by warranty will be replaced or repaired free of charge:

- (1) The breakdown or problem in question pertains to our product as delivered by us or our authorized dealer.
- (2) The breakdown or problem in question occurred during the warranty period.
- (3) The breakdown or problem in question occurred while the product was in use for an appropriate purpose under the conditions and environment of use specified in the Instruction Manual and catalog.
- (4) The breakdown or problem in question was caused by a specification defect or problem, or by a quality issue with our product.

Note that breakdowns due to any of the following reasons are excluded from the scope of warranty:

- Anything other than our product
- Modification or repair performed by a party other than us (unless we have approved such modification or repair)
- Anything that could not be easily predicted with the level of science and technology available at the time of shipment from our company
- A natural disaster, man-made disaster, incident or accident for which we are not liable
- Natural fading of paint or other symptoms of aging
- Wear, depletion or other expected result of use
- Operation noise, vibration or other subjective sensation not affecting function or maintenance

Note that the warranty only covers our product as delivered and that any secondary loss arising from a breakdown of our product is excluded from the scope of warranty.

### 11.3 Honoring the Warranty

As a rule, the product must be brought to us for repair under warranty.



## 11.4 Limited Liability

- (1) We shall assume no liability for any special damage, consequential loss or passive loss such as a loss of expected profit arising from or in connection with our product.
- (2) We shall not be liable for any program or control method created by the customer to operate our product or for the result of such program or control method.

## 11.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications

- (1) If our product is combined with another product or any system, device, etc., used by the customer, the customer must first check the applicable standards, regulations and/or rules. The customer is also responsible for confirming that such combination with our product conforms to the applicable standards, etc. In such a case we will not be liable for the conformance of our product with the applicable standards, etc.
- (2) Our product is for general industrial use. It is not intended or designed for the applications specified below, which require a high level of safety. Accordingly, as a rule our product cannot be used in these applications. Contact us if you must use our product for any of these applications:
  - Medical equipment pertaining to maintenance or management of human life or health
  - A mechanism or mechanical equipment intended to move or transport people (such as a vehicle, railway facility or aviation facility)
  - Important safety parts of mechanical equipment (such as safety devices)
  - Equipment used to handle cultural assets, art or other irreplaceable items
- (3) Contact us at the earliest opportunity if our product is to be used in any condition or environment that differs from what is specified in the catalog or Instruction Manual.

## 11.6 Other Items Excluded from Warranty

The price of the product delivered to you does not include expenses associated with programming, the dispatch of engineers, etc. Accordingly, a separate fee will be charged in the following cases even during the warranty period:

- Guidance for installation/adjustment and witnessing of test operation
- Maintenance and inspection
- Technical guidance and education on operating/wiring methods, etc.
- Technical guidance and education on programming and other items related to programs



## Change History

Revision Date	Revision Description					
2011.09	First Edition					
2011.10	Second Edition Pg. 278, 303 and 304 Parameter for MEC Mode added					
2011.11	Third edition Pg. 21, 109 and 141 Maximum load current 4.2A when high output setting added Pg. 37 Change the lost motion of Rod type lead 20 and 24. 0.1mm or less $\rightarrow 0.2$ mm or less Pg. 46 Horizontally oriented wall mount for the slider types SA5C and SA7C $\times \rightarrow O$ However, a note added to warn that it is easy for a foreign object to get inside from the opening. Pg. 192 Correction the chart of the electromagnetic valve type. Pressing (tension) $\times \rightarrow O$ Pitch Feeding (relative moving feed) $\times \rightarrow O$					
2012.02	Fourth edition Pg. 117, 118, 162, 163, 164, 176, 177, 179, 181, 183 and 188 Wire color of No.84 corrected from BL to YW					
2012.03	Fifth edition Pg. 47 Note added to tell platform should have a structure with enough stiffness Pg. 47, 48, 49, 52, 53 and 54 Note changed to 1.8 times more of the nominal diameter for the length of thread engagement on aluminum Pg. 159 Note "Connect the contact of a conductor to cable between MP+ and MP- terminals" deleted Pg. 172, 287 Setting table of PIO pattern for pulse train control mode added Pg. 255 Explanation of DCLR added					
2012.04	Sixth edition Pg. 62, 63, 117, 118, 162, to 164, 177, 178, 180, 182, 184 and 188 Pin numbers in cable diagram changed to 1, 2, 3 to 13 from top Pg. 74 to 77 Weight added to appearance drawing Pg. 160 and 161 Contact CR load current changed Pg. 203 Instruction added for home return operation in PIO Pattern 2 of ERC3 main unit Pg. 353 IN13 b contact					



Revision Date	Revision Description
2012.06	Seventh edition Revised overall
2012.06	Edition 7B Note corrected
2012.10	Eighth edition Pg. 423 "2,500 operational hours" added to Warranty Period.
2013.01	Ninth edition Slider Standard Type (Stainless Steel Sheet Type) and Cleanroom Type added.
2013.02	Tenth edition Pg. 48 Change made to payload capacity by acceleration/deceleration for RA4C Lead 20. Pg. 50 Change made to payload capacity by acceleration/deceleration for RA6C Lead 24.
2013.07	Eleventh edition Pg. 118, 119 PIO Pattern 0, 2, 3, 4 *ALML $\rightarrow$ LOAD/TRQS, *ALML Pg. 315, 316 Relevant section/This section of the note corrected Pg. 333 (36), (37) Explanation added Pg. 344 (73) Explanation added
2014.01	Twelfth edition RCM-PST-EU deleted
2014.12	Edition 12C Pg. 61 Connection of Pin No. A4 for NPN type corrected to 24V Pg. 73 Note added for space required for maintenance inspection
2015.04	Thirteenth edition Pg. 80, 85 Dynamic allowable moment value changed Pg. 385 Change made to inspection schedule Pg. 439 Change made about life
2015.06	Edition 13B Pg. 388 Grease change due to production stop Albania Grease No.2 $\rightarrow$ Albania Grease S2 Mobilux 2 $\rightarrow$ Unirex N2

Revision Date	Revision Description
2016.04	Edition 13C Pg. 385, 386, 395 The contents about grease supply on rod sliding surface and cleaning are added
2016.08	Edition 13D Pg. 317, 348 Default factory setting for absolute battery retention time are corrected to 0 from 2
2016.12	Edition 13E Pg. 393 Specifies the grease of rod sliding surface
2017.02	Edition 13F Pg. 386 Change made in the caution note for stainless steel sheet external visual inspection
2018.12	Edition 13H Pg. 56 SA7C Pressing Force changed
2019.05	Fourteenth Edition General Applicable teaching pendant changed to TB-01/TB-02/TB-03 2.3.4, 9.5 Correction made to dimensions of square nut for T-shaped slot 10.3 Descriptions revised regarding Safety Categories
2020.07	Edition 14B Pg. 159 Correction made to model code for power supply cable side MC1.5/7-ST-3.5 → FMC1.5/7-ST-3.5 Pg. 390 Grease changed from Daphne Eponex Grease No. 2 to Daphne Grease MP No. 2
2021.10	Edition 14C Pg. 13 Complied with RoHS3 Directive Pg. 31, 32 Enclosure of DVD instruction manual deleted Pg. 321, 357 "Caution: The home direction cannot be changed for the rod type actuators." Deleted
2022.12	Edition 14D Correction made in Table of Contents and Bookmark Pg. 16 *ALM Output in emergency stop corrected to on Chapter 9 Description revised regarding weight



Revision Date	Revision Description
2023.12	Edition 14E Pg. 61 B11 in input and output connection diagram corrected from output to input Pg. 73 Descriptions revised Pg. 176 Correction made to 2) Pattern Numbers in Power Supply and Emergency Stop Release



# **IAI** Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan TEL +81-54-364-5105 FAX +81-54-364-2589 website: www.iai-robot.co.jp/

# IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505 TEL +1-310-891-6015 FAX +1-310-891-0815 Chicago Office: 110 East State Parkway, Schaumburg, IL 60173 TEL +1-847-908-1400 FAX +1-847-908-1399 Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066 TEL +1-678-354-9470 FAX +1-678-354-9471 website: www.intelligentactuator.com

Technical Support available in Europe

## IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany TEL +49(0)6196-88950 FAX +49(0)6196-889524 website:www.iai-automation.com

Technical Support available in Great Britain



Duttons Way, Shadsworth Business Park, Blackburn, Lancashire, BB1 2QR, United Kingdom TEL +44(0)1254-685900 website: www.lcautomation.com

## IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China TEL +86-21-6448-4753 FAX +86-21-6448-3992 website: www.iai-robot.com

## IAI Robot (Thailand) Co., Ltd.

825 PhairojKijja Tower 7th Floor, Debaratana RD., Bangna-Nuea, Bangna, Bangkok 10260, Thailand TEL +66-2-361-4458 FAX +66-2-361-4456 website:www.iai-robot.co.th

The information contained in this document is subject to change without notice for purposes of product improvement. Copyright © 2023. Dec. IAI Corporation. All rights reserved.