

X-SEL Teaching Pendant

Operating Manual Ver. 9.0





Please Read Before Use

Thank you for purchasing our product.

This Instruction Manual describes all necessary information to operate this product safely such as the operation procedure, structure and maintenance procedure.


Before operation, read this manual carefully and fully understand it to operate this product safely. The enclosed CD or DVD in this product package includes the Instruction Manual for this product.

For the operation of this product, print out the necessary sections in the Instruction Manual or display them using the personal computer.

After reading through this manual, keep this Instruction Manual at hand so that the operator of this product can read it whenever necessary.

[Important]

- This Instruction Manual is original.
- The product cannot be operated in any way unless expressly specified in this Instruction Manual. IAI shall assume no responsibility for the outcome of any operation not specified herein.
- Information contained in this Instruction Manual is subject to change without notice for the purpose of product improvement.
- If you have any question or comment regarding the content of this manual, please contact the IAI sales office near you.
- Using or copying all or part of this Instruction Manual without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.



INTELLIGENT ACTUATOR




List of Support Models

Model Name	Support Started Version
XSEL-J/K	V0.01
SEL-E/G ^(Note 1)	V1.02
DS-S-C1 ^(Note 1)	V1.02
XSEL-P/Q	V1.13
TT	V1.14
SSEL	V1.30
ASEL	V1.40
PSEL	V1.40

Note 1 When the year of manufacture is too old, the emergency stop switch is not effective.

Be careful.



INTELLIGENT ACTUATOR

Table of Contents

Safety Guide.....	1
1. Forward.....	8
2. Before Use.....	8
3. Safety Precautions.....	9
4. Warranty.....	10
4-1. Warranty.....	10
4-2. Scope of the Warranty.....	10
4-3. Honoring the Warranty.....	10
4-4. Limited Liability.....	10
4-5. Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications.....	11
4-6. Other Items Excluded from Warranty.....	11
5. Connection to Controller.....	12
6. Teaching Pendant Function and Specifications.....	16
6-1. Main Operation Keys and Functions.....	16
7. Mode Transition Diagram.....	19
8. How to Save Data.....	24
8-1. Set-up at Shipment with System Memory Backup Battery.....	24
8-2. Set-up at Shipment without System Memory Backup Battery.....	25
8-3. Caution.....	26
9. Simple Operation Procedure.....	27
9-1. Creation of Position Data.....	28
9-2. Programming.....	37
9-3. Changing Application Program.....	45
10. Program Execution.....	50
10-1. Operation Confirmation.....	50
10-2. Setting of Brake Point.....	52
10-3. Monitor under Operation.....	52
11. Position Edit.....	55
11-1. Mdi (Manual direct input).....	55
11-2. Teach (Teaching).....	56
11-3. Example of Teaching Input.....	67
11-4. Position Data: Copy or Move.....	72
11-5. Position Data: Clear.....	73
12. Program Edit.....	74
12-1. How to Input Program.....	74
12-2. Symbol Input during Program Edit.....	79
12-3. Single Line Comment Input.....	81

12-4.	Program: Copy or Move	83
12-5.	Program: Clear	84
12-6.	Flash ROM Writing	86
13.	Symbol Edit	87
13-1.	Symbol Edit Items	87
13-2.	Input Example: Symbolize Local Integer Variable	88
13-3.	Symbol Edit Screen of Each Items	92
13-4.	Flash ROM Writing	96
14.	Parameter Edit	97
14-1.	Parameter Edit Items.....	97
14-2.	Input Example: Edit Each-Axis Parameter.....	98
15.	Monitor	101
15-1.	Monitor Items.....	101
15-2.	Input Port.....	102
15-3.	Output Port	102
15-4.	Global Flag	102
15-5.	Global Variable	103
15-6.	Axis Status	104
15-7.	System Status	108
15-8.	Error Detail Information	111
15-9.	Version Information	112
16.	Controller	114
16-1.	Controller Items	114
16-2.	Flash ROM Writing	115
16-3.	Software Reset.....	116
16-4.	Error Reset.....	116
16-5.	Memory Clear.....	117
16-6.	Re-Connection	117
16-7.	Baud Rate Change.....	118
16-8.	Safety Velocity.....	118
16-9.	Driver Power Recovery Request	119
16-10.	Action Pause Release Request.....	119
16-11.	Driver Power Recovery Request (RPwr) and Action Pause Release Request (Ract) ..	120
16-12.	Absolute Reset	121
16-13.	Procedures for Resetting Absolute-Battery Voltage-Down Warning Error.....	124
*Supplement	126
	Synchro Specification Absolute Reset.....	126
	About Error Level Management	135
	X-SEL Teaching Pendant Error List (Application Part).....	136
	X-SEL Teaching Pendant Error List (Core Part)	139
Change History	140

Safety Guide

“Safety Guide” has been written to use the machine safely and so prevent personal injury or property damage beforehand. Make sure to read it before the operation of this product.

Safety Precautions for Our Products

The common safety precautions for the use of any of our robots in each operation.

No.	Operation Description	Description
1	Model Selection	<ul style="list-style-type: none"> ● This product has not been planned and designed for the application where high level of safety is required, so the guarantee of the protection of human life is impossible. Accordingly, do not use it in any of the following applications. <ol style="list-style-type: none"> 1) Medical equipment used to maintain, control or otherwise affect human life or physical health. 2) Mechanisms and machinery designed for the purpose of moving or transporting people (For vehicle, railway facility or air navigation facility) 3) Important safety parts of machinery (Safety device, etc.) ● Do not use the product outside the specifications. Failure to do so may considerably shorten the life of the product. ● Do not use it in any of the following environments. <ol style="list-style-type: none"> 1) Location where there is any inflammable gas, inflammable object or explosive 2) Place with potential exposure to radiation 3) Location with the ambient temperature or relative humidity exceeding the specification range 4) Location where radiant heat is added from direct sunlight or other large heat source 5) Location where condensation occurs due to abrupt temperature changes 6) Location where there is any corrosive gas (sulfuric acid or hydrochloric acid) 7) Location exposed to significant amount of dust, salt or iron powder 8) Location subject to direct vibration or impact ● For an actuator used in vertical orientation, select a model which is equipped with a brake. If selecting a model with no brake, the moving part may drop when the power is turned OFF and may cause an accident such as an injury or damage on the work piece.

No.	Operation Description	Description
2	Transportation	<ul style="list-style-type: none"> ● When carrying a heavy object, do the work with two or more persons or utilize equipment such as crane. ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● When in transportation, consider well about the positions to hold, weight and weight balance and pay special attention to the carried object so it would not get hit or dropped. ● Transport it using an appropriate transportation measure. The actuators available for transportation with a crane have eyebolts attached or there are tapped holes to attach bolts. Follow the instructions in the operation manual for each model. ● Do not step or sit on the package. ● Do not put any heavy thing that can deform the package, on it. ● When using a crane capable of 1t or more of weight, have an operator who has qualifications for crane operation and sling work. ● When using a crane or equivalent equipments, make sure not to hang a load that weighs more than the equipment's capability limit. ● Use a hook that is suitable for the load. Consider the safety factor of the hook in such factors as shear strength. ● Do not get on the load that is hung on a crane. ● Do not leave a load hung up with a crane. ● Do not stand under the load that is hung up with a crane.
3	Storage and Preservation	<ul style="list-style-type: none"> ● The storage and preservation environment conforms to the installation environment. However, especially give consideration to the prevention of condensation. ● Store the products with a consideration not to fall them over or drop due to an act of God such as earthquake.
4	Installation and Start	<p>(1) Installation of Robot Main Body and Controller, etc.</p> <ul style="list-style-type: none"> ● Make sure to securely hold and fix the product (including the work part). A fall, drop or abnormal motion of the product may cause a damage or injury. Also, be equipped for a fall-over or drop due to an act of God such as earthquake. ● Do not get on or put anything on the product. Failure to do so may cause an accidental fall, injury or damage to the product due to a drop of anything, malfunction of the product, performance degradation, or shortening of its life. ● When using the product in any of the places specified below, provide a sufficient shield. <ol style="list-style-type: none"> 1) Location where electric noise is generated 2) Location where high electrical or magnetic field is present 3) Location with the mains or power lines passing nearby 4) Location where the product may come in contact with water, oil or chemical droplets

No.	Operation Description	Description
4	Installation and Start	<p>(2) Cable Wiring</p> <ul style="list-style-type: none"> ● Use our company's genuine cables for connecting between the actuator and controller, and for the teaching tool. ● Do not scratch on the cable. Do not bend it forcibly. Do not pull it. Do not coil it around. Do not insert it. Do not put any heavy thing on it. Failure to do so may cause a fire, electric shock or malfunction due to leakage or continuity error. ● Perform the wiring for the product, after turning OFF the power to the unit, so that there is no wiring error. ● When the direct current power (+24V) is connected, take the great care of the directions of positive and negative poles. If the connection direction is not correct, it might cause a fire, product breakdown or malfunction. ● Connect the cable connector securely so that there is no disconnection or looseness. Failure to do so may cause a fire, electric shock or malfunction of the product. ● Never cut and/or reconnect the cables supplied with the product for the purpose of extending or shortening the cable length. Failure to do so may cause the product to malfunction or cause fire. <p>(3) Grounding</p> <ul style="list-style-type: none"> ● The grounding operation should be performed to prevent an electric shock or electrostatic charge, enhance the noise-resistance ability and control the unnecessary electromagnetic radiation. ● For the ground terminal on the AC power cable of the controller and the grounding plate in the control panel, make sure to use a twisted pair cable with wire thickness 0.5mm² (AWG20 or equivalent) or more for grounding work. For security grounding, it is necessary to select an appropriate wire thickness suitable for the load. Perform wiring that satisfies the specifications (electrical equipment technical standards). ● Perform Class D Grounding (former Class 3 Grounding with ground resistance 100Ω or below).

No.	Operation Description	Description
4	Installation and Start	<p>(4) Safety Measures</p> <ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● When the product is under operation or in the ready mode, take the safety measures (such as the installation of safety and protection fence) so that nobody can enter the area within the robot's movable range. When the robot under operation is touched, it may result in death or serious injury. ● Make sure to install the emergency stop circuit so that the unit can be stopped immediately in an emergency during the unit operation. ● Take the safety measure not to start up the unit only with the power turning ON. Failure to do so may start up the machine suddenly and cause an injury or damage to the product. ● Take the safety measure not to start up the machine only with the emergency stop cancellation or recovery after the power failure. Failure to do so may result in an electric shock or injury due to unexpected power input. ● When the installation or adjustment operation is to be performed, give clear warnings such as "Under Operation; Do not turn ON the power!" etc. Sudden power input may cause an electric shock or injury. ● Take the measure so that the work part is not dropped in power failure or emergency stop. ● Wear protection gloves, goggle or safety shoes, as necessary, to secure safety. ● Do not insert a finger or object in the openings in the product. Failure to do so may cause an injury, electric shock, damage to the product or fire. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.
5	Teaching	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● Perform the teaching operation from outside the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. ● When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. ● When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. ● Place a sign "Under Operation" at the position easy to see. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>

No.	Operation Description	Description
6	Trial Operation	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● After the teaching or programming operation, perform the check operation one step by one step and then shift to the automatic operation. ● When the check operation is to be performed inside the safety protection fence, perform the check operation using the previously specified work procedure like the teaching operation. ● Make sure to perform the programmed operation check at the safety speed. Failure to do so may result in an accident due to unexpected motion caused by a program error, etc. ● Do not touch the terminal block or any of the various setting switches in the power ON mode. Failure to do so may result in an electric shock or malfunction.
7	Automatic Operation	<ul style="list-style-type: none"> ● Check before starting the automatic operation or rebooting after operation stop that there is nobody in the safety protection fence. ● Before starting automatic operation, make sure that all peripheral equipment is in an automatic-operation-ready state and there is no alarm indication. ● Make sure to operate automatic operation start from outside of the safety protection fence. ● In the case that there is any abnormal heating, smoke, offensive smell, or abnormal noise in the product, immediately stop the machine and turn OFF the power switch. Failure to do so may result in a fire or damage to the product. ● When a power failure occurs, turn OFF the power switch. Failure to do so may cause an injury or damage to the product, due to a sudden motion of the product in the recovery operation from the power failure.

No.	Operation Description	Description
8	Maintenance and Inspection	<ul style="list-style-type: none"> ● When the work is carried out with 2 or more persons, make it clear who is to be the leader and who to be the follower(s) and communicate well with each other to ensure the safety of the workers. ● Perform the work out of the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the “Stipulations for the Operation” and make sure that all the workers acknowledge and understand them well. ● When the work is to be performed inside the safety protection fence, basically turn OFF the power switch. ● When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. ● When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. ● Place a sign “Under Operation” at the position easy to see. ● For the grease for the guide or ball screw, use appropriate grease according to the Operation Manual for each model. ● Do not perform the dielectric strength test. Failure to do so may result in a damage to the product. ● When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. ● The slider or rod may get misaligned OFF the stop position if the servo is turned OFF. Be careful not to get injured or damaged due to an unnecessary operation. ● Pay attention not to lose the cover or untightened screws, and make sure to put the product back to the original condition after maintenance and inspection works. Use in incomplete condition may cause damage to the product or an injury. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>
9	Modification and Dismantle	<ul style="list-style-type: none"> ● Do not modify, disassemble, assemble or use of maintenance parts not specified based at your own discretion.
10	Disposal	<ul style="list-style-type: none"> ● When the product becomes no longer usable or necessary, dispose of it properly as an industrial waste. ● When removing the actuator for disposal, pay attention to drop of components when detaching screws. ● Do not put the product in a fire when disposing of it. The product may burst or generate toxic gases.
11	Other	<ul style="list-style-type: none"> ● Do not come close to the product or the harnesses if you are a person who requires a support of medical devices such as a pacemaker. Doing so may affect the performance of your medical device. ● See Overseas Specifications Compliance Manual to check whether complies if necessary. ● For the handling of actuators and controllers, follow the dedicated operation manual of each : unit to ensure the safety.

Alert Indication

The safety precautions are divided into “Danger”, “Warning”, “Caution” and “Notice” according to the warning level, as follows, and described in the Operation Manual for each model.

Level	Degree of Danger and Damage	Symbol
Danger	This indicates an imminently hazardous situation which, if the product is not handled correctly, will result in death or serious injury.	 Danger
Warning	This indicates a potentially hazardous situation which, if the product is not handled correctly, could result in death or serious injury.	 Warning
Caution	This indicates a potentially hazardous situation which, if the product is not handled correctly, may result in minor injury or property damage.	 Caution
Notice	This indicates lower possibility for the injury, but should be kept to use this product properly.	 Notice

1. Forward

Thank you very much for purchasing our X-SEL Controller Teaching Pendant. Improper usage or mishandling may result in a product not only being unable to deliver full functions but also produce unexpected troubles or shorten the product's life. Please read this Manual carefully, and operate the product properly by paying attention to its handling. When operating the Teaching Pendant, always keep this Manual at hand and read the relevant items as required.

For the actuator and controller to be used, be sure to refer to the Instruction Manuals attached to the products.

- While the teaching pendant is left connected, "Effect" is valid for the safety velocity (SVel). Therefore, the fastest velocity is under 250 mm/sec when the program is started from the teaching pendant. To operate the controller according to the program velocity command, it is required to change the condition to "No Effect."
For selection of the safety velocity between Effect and No Effect, refer to "16-8. Safety Velocity."
- When connecting this teaching pendant to the X-SEL-Q type (global specification), emergency stop cannot be reset.
- The display screens must show version 1.13 or newer of the teaching pendant application software. To confirm the version, refer to the section "15-9. Version Information."

2. Before Use

- (1) Be sure to read this Instruction Manual for proper use of this product.
- (2) Part or all of this Instruction Manual may not be used or reproduced without permission.
- (3) For any handling and operating methods other than those described in this Instruction Manual, interpret them as "don't" or "can't."
- (4) Please take note that we shall not be liable for any effects resulting from using this Instruction Manual.
- (5) Descriptions in this Instruction Manual are subject to change due to product improvements etc., without prior notice in the future.

3. Safety Precautions

- (1) Use a genuine product specified by us for wiring between the actuator and X-SEL Controller.
- (2) Keep out of the operating range of a machine such as an actuator while it is operating or in a ready state (condition in which the controller's power is ON). When using it in places where persons may approach, fence it off.
- (3) Before carrying out assembly and adjustment work or maintenance and inspection work of the machine, be sure to disconnect the power cord. While working, display the plate specified as such at an easy-to-read location. In addition, give special consideration to prevent third parties from turning on the power carelessly by hauling in the power cord to the operator. Alternatively, lock the power plug or receptacle and direct the operator to keep the key or prepare a safety plug.
- (4) When more than one operator works, advance work by determining the signal method and checking each other's safety. Especially, for work associated with axial movement regardless of power ON/OFF or motor-driven/manual operation, be sure to confirm safety by calling out to other(s) in advance.
- (5) When the user (customer) extends wiring, malfunction may occur due to faulty wiring. In this case, inspect wiring thoroughly and check it for properness before turning on the power.

4. Warranty

4.1 Warranty Period

One of the following periods, whichever is shorter:

- 18 months after shipment from our company
- 12 months after delivery to the specified location

4.2 Scope of the Warranty

Our products are covered by warranty when all of the following conditions are met. Faulty products covered by warranty will be replaced or repaired free of charge:

- (1) The breakdown or problem in question pertains to our product as delivered by us or our authorized dealer.
- (2) The breakdown or problem in question occurred during the warranty period.
- (3) The breakdown or problem in question occurred while the product was in use for an appropriate purpose under the conditions and environment of use specified in the operation manual and catalog.
- (4) The breakdown of problem in question was caused by a specification defect or problem, or by a quality issue with our product.

Note that breakdowns due to any of the following reasons are excluded from the scope of warranty:

- [1] Anything other than our product
- [2] Modification or repair performed by a party other than us (unless we have approved such modification or repair)
- [3] Anything that could not be easily predicted with the level of science and technology available at the time of shipment from our company
- [4] A natural disaster, man-made disaster, incident or accident for which we are not liable
- [5] Natural fading of paint or other symptoms of aging
- [6] Wear, depletion or other expected result of use
- [7] Operation noise, vibration or other subjective sensation not affecting function or maintenance

Note that the warranty only covers our product as delivered and that any secondary loss arising from a breakdown of our product is excluded from the scope of warranty.

4.3 Honoring the Warranty

As a rule, the product must be brought to us for repair under warranty.

4.4 Limited Liability

- (1) We shall assume no liability for any special damage, consequential loss or passive loss such as a loss of expected profit arising from or in connection with our product.
- (2) We shall not be liable for any program or control method created by the customer to operate our product or for the result of such program or control method.

4.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications


- (1) If our product is combined with another product or any system, device, etc., used by the customer, the customer must first check the applicable standards, regulations and/or rules. The customer is also responsible for confirming that such combination with our product conforms to the applicable standards, etc. In such a case we will not be liable for the conformance of our product with the applicable standards, etc.
- (2) Our product is for general industrial use. It is not intended or designed for the applications specified below, which require a high level of safety. Accordingly, as a rule our product cannot be used in these applications. Contact us if you must use our product for any of these applications:
 - [1] Medical equipment pertaining to maintenance or management of human life or health
 - [2] A mechanism or mechanical equipment intended to move or transport people (such as a vehicle, railway facility or aviation facility)
 - [3] Important safety parts of mechanical equipment (such as safety devices)
 - [4] Equipment used to handle cultural assets, art or other irreplaceable items
- (3) Contact us at the earliest opportunity if our product is to be used in any condition or environment that differs from what is specified in the catalog or operation manual.

4.6 Other Items Excluded from Warranty


The price of the product delivered to you does not include expenses associated with programming, the dispatch of engineers, etc. Accordingly, a separate fee will be charged in the following cases even during the warranty period:

- [1] Guidance for installation/adjustment and witnessing of test operation
- [2] Maintenance and inspection
- [3] Technical guidance and education on operating/wiring methods, etc.
- [4] Technical guidance and education on programming and other items related to programs

5. Connection to Controller



K (J) Type Controller



P Type Controller

Caution

- Set the teaching pendant type selection switch to the right.

1. Connect actuators, I/O 24VDC power source, and system I/O to the controller first. Then connect the cable connector of the teaching pendant to the controller's teaching connector when the main power supply of the controller is OFF.
2. After you flip the mode switch to MANU side, supply power to the controller.

Teaching Pendant

LCD Display

```

SEL Teaching
TP   V1.13 05/01/15
TPC  V0.02 01/05/15
Please wait...
  
```

F1	F2	F3	F4
----	----	----	----

Displays the version of the teaching pendant and moves to the following page, the mode selection screen.

```

Err [DEE]
CTL Not Connented

Back Next
  
```

F1	F2	F3	F4
----	----	----	----

If the mode is switched to AUTO side, the teaching pendant does not connect to the controller and the screen on the left will be displayed. Press ESC key and make it reconnected.

Re-connection Screen

```

Re - Connent
Do you want to
re - Connent?
Yes No
  
```

F1	F2	F3	F4
----	----	----	----

Turn on the mode switch to MANU side and press the F1 (Yes) key to execute re-connection.

Mode Selection Screen

```

Mode Selection

Edit Play Moni Ctl
  
```

F1	F2	F3	F4
----	----	----	----

This is the basic screen for all operations.

! Extra Caution

When the X-SEL controller J/K type executes “OPEN 1” (channel 1 shared for the teaching pendant) within the SEL program in the MANU (manual) mode, the right of use of the serial port channel 1 is forcefully moved to the SEL program and communication with the teaching pendant is disconnected. The program in the controller is running. (*Error No. A5D “SCIF open error non-auto mode”)

Afterwards, if you wish to stop movement, press ON the Emergency Stop Button (Be especially careful during Jog operation).

*In a case prior to Ver 0.16 of controller main application.

For the controller P/Q type as well as the J/K type with the controller main application ver. 0.16 or later, the following are applied regarding OPEN of the TP port (teaching connector) according to the servo not in use or in use:

<MANU mode, servo not in use>		
	Before execution of OPEN	After execution of OPEN
Connection of TP port	Connection to Teaching Pendant	Forced movement to SEL program connection (Message error) Program is executing

Error occurring after OPEN command execution: Error No. A50 “SCIF open error during non-AUTO mode”

<MANU mode, servo in use>		
	Before execution of OPEN	After execution of OPEN
Connection of TP port	Connection to Teaching Pendant	Connection to Teaching Pendant (Cold start error) Program is ending

Error occurring after OPEN command execution: Error No. E.89 “SCIF open error during non-AUTO mode (servo ON)”

The channel No. of the TP port varies according to the controller’s type.


J/K type: 1 ch “OPEN 1”

P/Q type: 0 ch “OPEN 0”

The above “Extra Caution” notes pertain to all other than “MANU mode with I/O parameter No. 90 = 2 (IAI Protocol).

6. Teaching Pendant Function and Specifications

6.1 Main Operation Keys and Functions



1. LCD Display

4 lines with 20 characters per line capacity display. Shows programs and motion status.

2. Emergency Stop Button

Executes emergency stop.

3. Deadman Switch (Option)


Before operating keys for Servo OFF → Servo ON, keep pressing both sides (ON) and operating keys.

If you press only one side or not press both sides, key operation for Servo OFF → Servo ON doesn't work.

When servo is ON, this switch is under the state of both-side pressed, but when you release the switch, the operation will be finished and the panel window 7 seg LED displays "dsf."

4. **F1 F2 F3 F4 (Function keys)**

Correspond to each item in the LCD display (function key section).



5. **SF key (Shift key)**

If there are more than 5 selectable functions (“→” will be displayed at right side of the function key area), it will change the display items in the function key area.)

6. **WRT key (Write key)**

Transmits edit data to the controller. (Data will be saved in the memory of the controller.)
Only the data shows on the LCD display will be transmitted. (Plural position No., program step No, etc., can't be transmitted all together at the same time.)

7. **ESC key (Escape key)**

Returns to the previous status from the current status.
If you press this key during data input, the data will be cancelled.

8. **BS key (Backspace key)**

If you press this key during data input, clear one letter before.
At other time, clear the data where the cursor is placed.

9. **← key (Cursor backward key)**

Backward the cursor. It's reverse of Return key function.

10. **10 keys**

You can input number, alphabet, and sign.

When the cursor is at any item requiring the input of characters other than “0” to “9” (such as hexadecimal and character strings), the input mode selection is displayed in the function key area. (Alph: alphabet symbol input, Num: numeric value input)

11.  key (Return key)
Confirms the input data and moves the cursor position forward .
12.  ·  key
Increment or decrement edit and display item No. (Position No., Program No., Step No., etc.)
13.  key
Switches servo ON or OFF of axes. (It is valid within Teac (teach) mode area)
14.  key
Executes homing. (It is valid in the Teac (teach) mode area with the servo ON)


 Note : For the Linear Servo actuator, LSAS-N10/N15 quasi absolute type, the actuator moves in a range of approximately 16mm from the stop position when a home return operation is conducted after the power is turned on to confirm the current position. Watch the actuator movement during operation.


15.  key
Starts actuator movement or continuous movement. (It is valid in the Teac (teach) mode area with the servo ON.)
16.  key
Stops actuator movement or continuous movement. (It is valid in the Teac (teach) mode area with the servo ON.)
17.  (Jog keys)

	Minus direction jog movement for the 1st axis and 5th axis	}	(It's valid in the Teac (teach) mode area with the servo ON
	Plus direction jog movement for the 1st axis and 5th axis		
	Minus direction jog movement for the 2nd axis and 6th axis		
	Plus direction jog movement for the 2nd axis and 6th axis		
	Minus direction jog movement for the 3rd axis		
	Plus direction jog movement for the 3rd axis		
	Minus direction jog movement for the 4th axis		
	Plus direction jog movement for the 4th axis		


Caution



- Such jog actions with the JOG button are also valid for any not-homed axes. However, coordinate values in this case have no meaning. Therefore, be extremely careful about interference with the stroke end.
- If jog operation is performed to the axis in action under the operation-button-acceptable condition, the operation of the applicable axis is aborted when the JOG operation button is turned OFF. (The next operation starts, if any.)





7. Mode Transition Diagram





8. How to Save Data


Since the X-SEL Controller adopts flash memory, there is a storage area by battery backup and a storage area by flash memory according to the data to be stored.

In addition, even if data is transferred from the PC software or Teaching Pendant, the data is only to be written in memory as shown in the chart below and the data is erased by power-off or controller reset.

To ensure data storage, write the data you want to store in flash memory.

8-1. Set-up at Shipment with System Memory Backup Battery

(Other parameter No. 20=2 (System memory backup battery equipped))



* Encoder parameters are not stored within the controller but in the EEPROM of the actuator's encoder itself. They are read into the controller at power-on or software-reset time.

Since the program, parameter, and symbol will be read from flash memory at restart time, the data in memory becomes the original data before editing unless the data is written in flash memory.

The controller always operates according to the data in memory (within the dotted box) excluding parameters.


Content 1: Parameters excluding content 2 below and encoder parameter

Content 2: Driver card, IO slot card (electric power type card) parameter

Content 3: Flag, Variable, and String

8-2. Set-up at Shipment without System Memory Backup Battery

Other parameter No.20=0 (System memory backup battery unequipped)



Since the program, parameter, symbol, and position will be read from flash memory at restart time, the data in memory becomes the original data before editing unless the data is written in flash memory.

The controller always operates according to the data in memory (within the dotted box) excluding parameters.

Note: SEL global data can't be saved without the backup battery.

8-3. Caution

Cautions in data transfer and flash writing

Never shut OFF the main power while the data is transmitting and writing into flash.
Data may be lost and controller may be rendered inoperable.

Cautions in storing parameters in a file

Encoder parameters are stored in EEPROM of the actuator's encoder itself (not in EEPROM within the controller, which is different from the other parameter types). When the power is turned on or software is reset, encoder parameters are read from EEPROM into the controller.

Therefore, if you store the parameters of the controller, which has been powered on or of which software has been reset when the actuator (encoder) is not connected, in a file, the encoder parameters stored in this file become invalid values.

Cautions in transferring a parameter file to controller


When the parameter file is transferred to the controller, the encoder parameters are transferred to EEPROM of the encoder (excluding manufacturing information and function information).

Therefore, if you transfer the parameter file read from the controller, which has started up when the actuator is not connected, to the controller (which is connected to the actuator), the encoder parameters of invalid values are written in EEPROM of the encoder.

When storing the parameters in a file, do so when the actuator is connected.

9. Simple Operation Procedure

Here, the program and position data to draw a simple “pentagon” passing through the following 6 points (① and ⑥ are same position) by the actuator of 2 axes (X, Y) are created.




Position Data (① to ⑥)

9-1. Creation of Position Data


Input 6 points position data which can draw pentagon as the following position data list.

No.	Axis1	Axis2	Vel	Acc	Dcl
1	0.000	50.000	xxxx	x.xx	x.xx
2	50.000	100.000	xxxx	x.xx	x.xx
3	100.000	50.000	xxxx	x.xx	x.xx
4	100.000	0.000	xxxx	x.xx	x.xx
5	0.000	0.000	xxxx	x.xx	x.xx
6	0.000	50.000	xxxx	x.xx	x.xx


Connect the teaching pendant to the controller and turn on MODE switch to MANU side. Supply the power to the controller.




Display the version of the teaching pendant and move to the mode selection screen. (to the following page)



If the MODE switch is AUTO side, the teaching pendant does not connect to the controller and display as the screen on the left. Press ESC key to make it re-connection display.




Turn on MODE switch to MANU side and press F1 (Yes) key to re-connect.



Mode Selection Screen


This is the basic screen for all operations.
Press the F1 key (Edit).

* If you make a wrong selection or input, press the ESC key and return to the previous screen. Then, you can continue operation. You can return to the basic screen by pressing the ESC key several times from any screen.




Edit Mode Screen

Press the F1 key (Posi).



Position (Position Data) Edit Screen

Press the F1 key (Mdi).



The above is the display of a 2 axis controller. Nothing displays in the 3rd and 4th axes data location.

Position No. Input Mode

The cursor is placed at position No.

If there is no data, x.xxx will be displayed. Press the return key and place the cursor at first axis position data.

* If the data is already input, write over (original data is gone) or use the PAGE UP · PAGE DOWN keys to be placed at x.xxx and then input the data.

Clear all axis input data by pressing the F1 (Clr) key twice. You can clear the controller data with (Clr) key even if the WRT key is not pressed.

When input the 5th and 6th axes data, press the F4 (Axis) key to switch the display to the 5th and 6th axes data display screen.

(The F4 (Axis) key is used to switch the 1st to 4th axes display screen to the 5th and 6th axes display screen.)

Axis No. on the cursor location

Mdi - 1	Axis	①/2	
x. xxx		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

① Data input for the first point

Input 0 (number) and press the return key, 0.000 will be displayed and then the axis No. changes to 2 and the cursor position moves to the second axis position data.

* Position data can be input as 7 digit real having 3 decimal places. This is the maximum amount and range is different by actuator type, so, please check the catalogs.

Mdi - 1	Axis	2/2	
0.000		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

Input 50 at the second axis position data and press return key. (*Every press of return key, the cursor position moves. When you miss input, place the cursor to the miss input position and write over.) Also you can return the input data to x.xxx with the F3 (Canc) key.

Mdi - 1	Axis	1/2	
0.000		50.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key, position No. forwards 1 and becomes 2.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Position No. 2

Mdi - ②	Axis	1/2	
x. xxx		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

② Data input for the second point

Input 50 on the first axis position data and press return key.

Mdi - 2 Axis 2/2			
50.000		x. xx <u>x</u>	
Vel Canc Axis			
F1	F2	F3	F4

The cursor moves to the second axis position data. Input 100 and press return key.

Mdi - 2 Axis 1/2			
50.00 <u>0</u>		100.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key and move to position No. 3.

Mdi - 3 Axis 1/2			
x. xx <u>x</u>		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

③ Data input for the third point

Input 100 for the first axis position data and press the return key.

Mdi - 3 Axis 2/2			
100.000		x. xx <u>x</u>	
Vel Canc Axis			
F1	F2	F3	F4

Input 50 for the second axis position data and press return key.

Mdi - 3 Axis 1/2			
100.00 <u>0</u>		50.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key and move to position No. 4.

Mdi - 4 Axis 1/2			
x. xx <u>x</u>		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

④ Data input for the fourth point

Input 100 for the first axis position data and press the return key.

Mdi - 4 Axis 2/2			
100.000		x. xx <u>x</u>	
Vel Canc Axis			
F1	F2	F3	F4

Input 0 for the second position data and press the return key.

Mdi - 4 Axis 1/2			
100.00 <u>0</u>		0.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key and move to position No. 5.

Mdi - 5 Axis 1/2			
x. xx <u>x</u>		x. xxx	
Vel Canc Axis			
F1	F2	F3	F4

⑤ Data input for the fifth point

Input 0 for the first axis position data and press the return key.

Mdi - 5 Axis 2/2			
0.000		x. xx <u>x</u>	
Vel Canc Axis			
F1	F2	F3	F4

Input 0 for the second axis position data and press the return key.

Mdi - 5 Axis 1/2			
0.00 <u>0</u>		0.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key and move to position No. 6.

Mdi - 6 Axis 1/2			
x.xx <u>x</u>		x.xxx	
Vel Canc Axis			
F1	F2	F3	F4

⑥ Data input for the sixth point

Input 0 for the first axis position data and press the return key.

Mdi - 6 Axis 2/2			
0.000		x.xx <u>x</u>	
Vel Canc Axis			
F1	F2	F3	F4

Input 50 for the second axis position data and press the return key.

Mdi - 6 Axis 1/2			
0.00 <u>0</u>		50.000	
Vel Canc Axis			
F1	F2	F3	F4

Transmit the data with the WRT key and move to position No.7.

Mdi - 7 Axis 1/2			
x.xx <u>x</u>		x.xxx	
Vel Canc Axis			
F1	F2	F3	F4

Finish editing, then write the data to Flash ROM. The cursor moves to the position No. by pressing ESC key.

Mdi - 7		Axis1 - 2/2	
x. xxx		x. xxx	
Axis			
F1	F2	F3	F4

Return to the position edit screen by pressing the ESC key.

Edit-Posi			
Mdi	Teac	Copy	Clr
F1	F2	F3	F4

The edit mode screen will be appear by pressing the ESC key once more.

Edit			
Posi	Prog	Sym	Para
F1	F2	F3	F4

The Flash ROM writing screen will be appear by pressing the ESC key again.


Flsh			
Flash Write?			
<input checked="" type="radio"/> Yes	<input type="radio"/> No		
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.


Flsh			
Writing Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**



Go back to the edit screen by pressing the ESC key.



That's all for inputting basic position data.

9-2. Programming

Here, make a program by changing the data of the position data created in section 9-1.

Application Program List

No.	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				HOME	11			
2				VEL	100			
3				MOVL	1			
4				MOVL	2			
5				MOVL	3			
6				MOVL	4			
7				MOVL	5			
8				MOVL	6			
9				EXIT				

This is the X-SEL program that was created in this chapter.

For the details of each command, please refer to the operating manual that comes with the controller.

Here, only input Cmnd (command) and Operand1 (operation 1) columns are used.

Caution for the HOME command:

For restart after homing temporary stop, execute it from the beginning of the homing sequence.

The homing operation of the ABS encoder axis becomes the movement to the multi-rotation data reset position.

When operation is reset during its execution in a mode other than the absolute reset mode of the PC compatible software/Teaching Pendant, the “real position soft limit error” may occur depending on the position. It is not recommended to execute homing at times other than during adjustment time of the absolute encoder axis.

Use the HOME command only for the increment specification.

Mode Selection			
Edit	Play	Moni	Ctl
F1	F2	F3	F4

Select the F1 key (Edit) at the mode selection screen.

Prog			
Posi	Prog	Sym	Para
F1	F2	F3	F4

Select the F2 key (Prog) at the Edit Mode screen.

Edit-Prog			
Mdfy	Copy	Clr	
F1	F2	F3	F4

Select the F1 key (Mdfy) on the program edit and new creation screen.

Program No.			
Step No.			
Mdf	①	-	① :
F1	F2	F3	F4

/ ①

The number of step saved at the controller

Change to the program No. input screen. The cursor is located at the program No. Move the cursor to the step No. with return key.

* If the program data is already input, write over (the data will be gone) or select the program No. which has no program data. The cursor location on program No. or step No. can be changed with PAGE UP · PAGE DOWN keys.

Also, you can change the program No. and step No., by pressing the return key after the 10 key input.

```
Mdf 1- 1 :
Ins Del Cmnt / 0
F1 | F2 | F3 | F4
```

The Cursor moves to the appropriate step No. Press the return key.

```
Mdf 1 - 1 :
-
ABPG ACC ACHZ ADD→
F1 | F2 | F3 | F4
```

Input commands.

Commands are displayed in the function key area.

How to search the command

- ① When the cursor is located at commands input locations, commands are displayed in alphabetical order by pressing SF key.
- ② Alphabets are allocated on 10 keys. (ex. GHI are allocated to 9.) When the cursor is located at command input location, display the first command word which starts with each alphabet in the function key area each time by pressing the 10 key.

Display the command you'd like to input in the function key area with the steps of ① and ② above and press the corresponding function key.

```
Mdf 1 - 1 :
-
GACC GDCL GOTO GRP→
F1 | F2 | F3 | F4
```

The command which starts from G

```
Mdf 1 - 1 :
-
GTTM GVEL HOLD HOME→
F1 | F2 | F3 | F4
```

The command which starts from H

```
Mdf 1 - 1 :
-
IFEG IFGE IFGT IFLE→
F1 | F2 | F3 | F4
```

The command which starts from I

```
Mdf 1 - 1 :
HOME
GTTM GVEL HOLD HOME→
F1 | F2 | F3 | F4
```

How to search the command, HOME

The commands which start with G, H, or I will be displayed by pressing the 9 key of the 10 keys. (Some commands can't be displayed by pressing one of the 10 keys. In this case, press the SF (shift) key and one of the 10 keys for more option.)

Display HOME in the function key area and press the F4 key (HOME). (If you want to backspace previous operation, press BS key.) Press the return key.

```

Mdf 1 - 1 :
HOME -

Num  Sym  *   ,
-----
F1   F2   F3   F4
  
```

The cursor moves to operation 1.
Input 11 and press the return key.

When you redo an input

Move the cursor where you want to redo an input by pressing the ← key and return key. Write over or delete with BS (backspace) key. Or redo from step No. by using ESC key.

```

Mdf 1 - 1 :
HOME 11
-

F1   F2   F3   F4
  
```

Transmit data to the controller by pressing the WRT key.
Step No. moves to 2.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Step No. 2

```

Mdf 1 - ② :
-

ABPG ACC ACHZ ADD→
-----
F1   F2   F3   F4
  
```

Press the 10 key, 2 or SF(shift) key to search VEL.

```

Mdf 1 - 2 :
-

VAL  VALH  VEL  VLMX→
-----
F1   F2   F3   F4
  
```

Select the F3 key (VEL).

```

Mdf 1 - 2 :
VEL
-

VAL  VALH  VEL  VLMX→
-----
F1   F2   F3   F4
  
```

Press the return key.

Mdf 1 - 2 :			
VEL -			
Num	Sym	*	,
F1	F2	F3	F4

Here, input the velocity* as 100, and press the return key.

* Check the maximum velocity listed in the catalogs. When velocity is input into position data, priority is given there.

Mdf 1 - 2 :			
VEL 100			
-			
F1	F2	F3	F4

Transmit the data to the controller by pressing the WRT key. The cursor moves to step No. 3.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 1 - 3 :			
-			
ABPG	ACC	ACHZ	ADD→
F1	F2	F3	F4

By using the 5 and SF(shift) keys, this will display the MOVL.

Mdf 1 - 3 :			
-			
LET	MOD	MOVL	MOVP→
F1	F2	F3	F4

Select the F3 key (MOVL).

Mdf 1 - 3 :			
MOVL			
LET	MOD	MOVL	MOVP→
F1	F2	F3	F4

Press the return key. The cursor moves to operation 1.

Mdf 1 - 3 :			
MOVL -			
Num	Sym	*	,
F1	F2	F3	F4

Input 1 on position No. and press the return key.

Mdf 1 - 3 :			
MOVL 1			
-			
F1	F2	F3	F4

Transmit the data to the controller by pressing the WRT key.
The cursor moves to step No.4.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 1 - 4 :			
-			
ABPG	ACC	ACHZ	ADD→
F1	F2	F3	F4

Input MOVL 2 ~ MOVL 6 program data into steps No. 4~8 by the same procedure and transmit the data to the controller.

Mdf 1 - 9 :			
-			
ABPG	ACC	ACHZ	ADD→
F1	F2	F3	F4

Display EXIT in the function key area by using the 8 and SF keys.

Mdf 1 - 9 :			
-			
EOR	EXIT	EXPG	EXSP→
F1	F2	F3	F4

Select the F2 key (EXIT) and press the return key.

Mdf 1 - 9 :			
EXIT -			
F1	F2	F3	F4

Transmit the data to the controller by pressing the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 1 - 10 :			
-			
ABPG ACC ACHZ ADD→			
F1	F2	F3	F4

Finish editing the program and write the data to Flash ROM.
Press the ESC key.
(The cursor moves to the step No.)

Mdf 1 - 10:			
Ins Del Cmnt / 9			
F1	F2	F3	F4

Press the ESC key.
(The cursor moves to the program No.)

Mdf 1 - 10:			
/ 9			
F1	F2	F3	F4

Press the ESC key.
Return to the program edit screen.

Edit - Prog			
Mdfy Copy Clr			
F1	F2	F3	F4

Press the ESC key.
Return to the edit screen.

Edit			
Posi Prog Sym Para			
F1	F2	F3	F4

Press the ESC key.

Flsh			
Flash Write?			
Yes		No	
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.

Flsh			
Writing Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait...." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**

Flsh			
Complete!			
F1	F2	F3	F4

Flash ROM writing is complete.
Return to the edit screen with the ESC key.

9-3. Changing Application Program

Change the program you made in the previous section (9-2).

Insert and delete the program step to allow the same action to be repeated.

1	HOME	11		1	HOME	11
2	VEL	100		2	VEL	100
3	MOVL	1		3	TAG	1
4	MOVL	2		4	MOVL	1
5	MOVL	3		5	MOVL	2
6	MOVL	4		6	MOVL	3
7	MOVL	5		7	MOVL	4
8	MOVL	6	Change	8	MOVL	5
9	EXIT			9	GOTO	1

Insert "TAG 1" into step No.3, delete the line which displays "MOVL 6," and write over "GOTO 1" replacing it with "EXIT."

Mode Selection			
Edit	Play	Moni	Ctl
F1	F2	F3	F4

Select the F1 key (Edit) on the mode selection screen.

Edit			
Posi	Prog	Sym	Para
F1	F2	F3	F4

Press the F2 key (Prog) on the program mode screen.

```

Edit - Prog

Mdfy Copy Clr

F1 | F2 | F3 | F4
  
```

Select the F1 key (Mdfy) on the program edit and new creation screen.

```

Mdf 1 - 1 :
HOME 11

/ 9

F1 | F2 | F3 | F4
  
```

Change to the program edit mode screen. Press the return key once and position the cursor at the step No.

```

Mdf 1 - 1 :
HOME 11

Ins Del Cmnt / 9

F1 | F2 | F3 | F4
  
```

Insert a 1 line step between step No. 2 and 3. Input 3 by pressing "3" or display 3 by pressing the PAGE UP key twice.

```

Mdf 1 - 3 :
MOVL 1

Ins Del Cmnt / 9

F1 | F2 | F3 | F4
  
```

Select the F1 key (Ins).
I, Insert of I will be displayed after step No. 3.

```

Mdf 1 - 3Ⓛ :
-
ABPG ACC ACHZ ADD→

F1 | F2 | F3 | F4
  
```

Display "TAG" by using the 1 key or the SF (shift) key.

Mdf 1 - 31:			
-			
SVOF SVON SYST TAG→			
F1	F2	F3	F4

Select the F4 key (TAG) and press the return key.

Mdf 1 - 31:			
TAG -			
Num	Sym	*	,
F1	F2	F3	F4

Input 1 into operation 1 and press the return key.

Mdf 1 - 31:			
TAG 1			
-			
F1	F2	F3	F4

Transmit the data to the controller by pressing the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 1 - 41			
-			
ABPG ACC ACHZ ADD→			
F1	F2	F3	F4

Display the step No. 4 screen by pressing the ESC key twice.

Mdf 1 - 4:			
MOVL 1			
Ins	Del	Cmnt	/ 10
F1	F2	F3	F4

Delete the "MOVL 6." Input 9 for the step No. by pressing the 9 key directly to the same cursor location or display the "MOVL 6" by pressing PAGE UP key 5 times.
(The cursor is located at step No.9.)

```
Mdf 1 - 9:
MOVL 6

Ins Del Cmnt / 11
```

F1	F2	F3	F4
----	----	----	----

Press the F2 key (Del).

```
Del 1 - 9:
MOVL 6

Del
```

F1	F2	F3	F4
----	----	----	----

Press the F2 key (Del) one more time.
(If you wish to cancel deleting, press the ESC key.)

```
Mdf 1 - 9:
EXIT

Ins Del Cmnt / 10
```

F1	F2	F3	F4
----	----	----	----

Press the return key.

```
Mdf 1 - 9:
EXIT

ABPG ACC ACHZ ADD→
```

F1	F2	F3	F4
----	----	----	----

Display "GOTO" by using the 9 key or SF (shift) key.

```
Mdf 1 - 9:
EXIT

GACC GDCL GOTO GRP→
```

F1	F2	F3	F4
----	----	----	----

Select the F3 key (GOTO) and press the return key.

Mdf 1 - 9:			
GOTO -			
Num	Sym	*	,
F1	F2	F3	F4

Input the same value you input at "TAG" operation 1 on operation 1. Here, input 1 and press the return key.

Mdf 1 - 9:			
GOTO 1			
-			
F1	F2	F3	F4

Transmit the data to the controller by pressing the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 1 - <u>10</u> :			
-			
ABPG	ACC	ACHZ	ADD→
F1	F2	F3	F4

Press the ESC key several times and move to the Flash ROM writing screen.

Flsh			
Flash Write?			
Yes	No		
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key. If not, press the F2 (No) key.

Flsh			
Write Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**


Flsh			
Complete!			
F1	F2	F3	F4

Flash ROM writing is complete. Return to the edit screen with the ESC key.


10. Program Execution

Execute the program made at the previous chapter.

10-1. Operation Confirmation



Press the F2 (Play) key from the mode selection screen and move to the play mode screen.




There are 3 kinds of items at the play mode screen:

F1 (Run): Move to the program No. input screen to execute.


F2 (TSts): Move to the task status screen which is already executing.

F3 (AStop): Finish all programs which are executing. (F2 and F3 keys are function keys which are used after executing programs.)

Task Status




The cursor is located at the program No. Input the program No. you'd like to execute with the PAGE UP · PAGE DOWN keys and press the return key.



Move to the operation mode selection screen.
 Select step by step execution or the continuance operation.

Operation Mode Selection




Start the continuance operation by pressing the F1 (Strt) key.


Start the operation by pressing the F2 (Step) key.



Continuance Operation Mode



Step Operation Mode




Display the current executing program step. (except continuance movement commands)

Switch to the step operation by pressing the F2 (Sus) key.
 Select the finish operation by pressing the F3 (Stop) key.


After displaying the current executing program step, display the next step.

Execute programs step by step, each time you press the F2 (Step) key.
 Switch to continuance operation by pressing the F1 (Cont) key.
 Select the finish operation by pressing the F3 (Stop) key.



The monitor under operation

- F1 (Posi): Display Current Position
- F2 (LFlg): Local Flag
- F3 (LVar): Local Variable




The monitor under operation

- F1 (Posi): Display Current Position
- F2 (LFlg): Local Flag
- F3 (LVar): Local Variable

Note: When the teaching pendant is connected, it is in the "Safety Velocity Specified" state. Therefore, the setting of program and parameter doesn't effect to maximum velocity and it is always under 250mm/sec.
 For the switching safety velocity mode, please refer to "16-8. Safety Velocity."



③ Local String



LStr	[1]	0123456789
	0	- >	-
	10	- >	
Num			

F1	F2	F3	F4
----	----	----	----

The cursor is located in the data area (column). Input the ASCII code by pressing one of 10 keys and press return key to substitute letters. (Convert hexadecimal A~F to alphabet with the F1 (Alph/Num) key and then input substitution.)

Move the cursor location with the return key and ← key.

The PAGE UP · PAGE DOWN keys scrolls the cursor every 20 columns each time they are pressed .

11. Position Edit

11-1. Mdi (Manual Direct Input)

The input value of the position data can be entered with the 10 numeric keys.

For inputting input data for a coordinate by using the 10 numeric keys, please refer to "9. Simple Operation Procedures."

How to input Vel (Velocity), Acc (Acceleration), and Dcl (Deceleration) on each position No.

Mdi (Manual Direct Input)

Transit to the Manual Direct Input screen: **Edit** - **Posi** - **Mdi** - **Position No.** Return

Mdi - 1 Axis 1/2			
0.000		50.000	
(Vel) Canc Axis			
F1	F2	F3	F4

Vel is displayed at the function key area of the data input screen for each axis. Press the F2 (Vel) key.

Position No.

Vel - ①			
Vel [0]		Acc [0.00] Dcl [0.00]	
F1	F2	F3	F4

Vel · ACC · Dcl Input Screen

Move the cursor with the return key and input the value to the required place by using the 10 keys. Then press the return key.

Vel - 1			
Vel [200]		Acc [0.50] Dcl [0.50]	
F1	F2	F3	F4

After input, transmit the data to the controller with the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Vel - 2			
Vel [0]		Acc [0.00] Dcl [0.00]	
F1	F2	F3	F4


The position No. will be incremented and the next input screen, Vel · Acc · Dcl, will be displayed.

11-2. Teach (Teaching)

Teaching is one way to input position data moving the actuator to an arbitrary position and getting that actuator's current position as data.

Methods for moving the actuators to a designated position are the jog, inching, and manual operation with a servo OFF status.


The fundamental flow of teaching is as follows:



Input the position data by teaching and repeating ①~③.

Teaching is transacted mainly at the teaching screen.

Transition to the teaching screen: Edit - Posi - Teac



(1) Teaching Screen

There is the position No. selection screen and each-axis data input screen for the teaching screen. Execute teaching of all axes simultaneously (take in current position · clear) on the position No. selection screen. Execute teaching of each axis at each-axis data input screen.)

① Position No. Selection Screen

Teac- 100	Axis1-2/2		
X. XXX	X. XXX		
Disp	Scan	Clr	Axis→
F1	F2	F3	F4



Teac- 100	Axis1-2/2		
X. XXX	X. XXX		
Cont	JVel	In	out →
F1	F2	F3	F4



Teac- 100	Axis1-2/2		
X. XXX	X. XXX		
Usr0			→
F1	F2	F3	F4



Description of the function key

F1(Disp): Switch the input data screen to the current position display.

F2(Scan): Take the current positions of all axes into the input screen.
(TP Ver 1.02 or later)

F3(Clr): Clear the all-axis data of the selected position No. by pressing this key twice.
Clear the controller's data without pressing the WRT key.
(TP Ver. 1.02 or later)

F4(Axis): Switch the 1st to 4th axes display screen to the 5th and 6th axes display screen.
(Effective for 5 axes or more)

F1(Cont): Execute continuance operation.

F2(JVel): Set the jog velocity.


F3(In): Monitor the input port.

F4(Out): Monitor the output port.

F2(UsrO): Turn ON/OFF the output ports (sequential 8 points at the maximum set to parameters).
(It is required to preset the I/O parameters No. 74 and No. 75.)

Input the position No. with the 10 keys, and press the return key to move to the each-axis data input screen.

② Each-axis Data Input Screen




Description of the function key

F1(Disp): Switch the input data screen to the current position display.
 F2(Scan): Take the current position of the axis at which the cursor is located into the input screen.
 F3(Canc): Clear the input data.
 F4(Axis): Switch the 1st to 4th axes display screen to the 5th and 6th axes display screen.
 (Effective for 5 axes or more)



F1(Vel): Input the data of velocity to each position No.
 F2(JVel): Set the jog velocity.
 F3(In): Monitor the input port.
 F4(Out): Monitor the output port.

F1(Cont): Move to the continuance transition mode.
 F2(UsrO): Turn ON/OFF the output ports (sequential 8 points at the maximum set to parameters).
 (It is required to preset the I/O parameters No. 74 and No. 75.)

For incremental specification, it is required to execute homing after supplying power before you start teaching. For Spurious Absolute Type, it is necessary to conduct a home-return operation before the teaching after the power is turned ON.




Turn the servo On by pressing the ON/OFF key in the teaching screen condition.
To confirm servo ON/OFF status, press the F1 (Disp) key.
All axes start homing by pressing the HOME key.



After homing is complete, execute teaching.

The data of the current position screen before homing doesn't have meaning.




Note : For the Linear Servo actuator, LSAS-N10/N15 quasi absolute type, the actuator moves in a range of approximately 16mm from the stop position when a home return operation is conducted after the power is turned on to confirm the current position. Watch the actuator movement during operation.

(2) Movement of an actuator

① Jog Operation

Teac-	100	Axis1-2/2	
X.	XXX	X. XXX	
(Disp)	Scan	Clr Axis→	
F1	F2	F3	F4



Current Position Display

Teac-	100	Axis1-2/2	
	64.683N	85.317N	
(Disp)	Scan	Clr Axis→	
F1	F2	F3	F4

N: Servo ON
F: Servo OFF

(The above diagram is 2 axes specification; valid jog keys are 1→, 2→, ←1, and ←2.)

Teac-	100	Axis1-2/2	
	64.683N	85.317N	
Cont	(JVel)	In Out →	
F1	F2	F3	F4

Jog velocity 50mm/sec

JVel			
Vel[50]	Dis[0.000]	
Acc[0.30]	Dcl[0.30]		
F1	F2	F3	F4

Turn the servo ON status by pressing the ON/OFF key in the teaching screen condition.

To confirm the servo ON/OFF status, press the F1 (Disp) key to display the current position.

Press the 1→, 2→, 3→, 4→, ←1, ←2, ←3, and ←4 keys to move the actuator to a designated position. (1~4 indicate axis No. and the right direction arrows represent plus direction (forward) and the left direction arrows represent minus direction (backward)).

To execute jog operation for the 5th and 6th axes, press the F4 (Axis) key to switch the display to the 5th and 6th axes data display screen.

(1→: Plus direction for the 5th axis, ←1: Minus direction for the 5th axis, 2→: Plus direction for the 6th axis, ←2: Minus direction for the 6th axis.)

Changing the Jog Velocity

Change the actuator's moving velocity at the time of the jog operation.

Display "JVel" (jog velocity) on the Teaching screen and press the function key that it corresponds to. (Depending on the screen condition, you need to press SF (shift) key to display "JVel.")

Input Vel (velocity), Acc (acceleration), and Dcl (deceleration) at the time of the jog operation with the 10 keys and press the return key. Set Dis (inching distance) 0.000.

You can also set the inching distance from this screen.

Return to the teaching screen with the ESC key and execute the jog operation.

② Inching Operation

Inching distance 0.1mm

JVel			
Vel [0]	Dis [0.100]		
Acc [0.30]	DcI [0.30]		
F1	F2	F3	F4

Teac- 100		Axis1-2/2	
64.683N	85.317N		
Cont	JVel	In	Out →
F1	F2	F3	F4

(The above diagram is 2 axes specification; valid jog keys are 1→, 2→, ←1, and ←2.)

Set the inching distance. (the moving distance each time pressing jog key.) Input the value on Dis (inching distance) at the jog velocity change screen and press the return key.

Value input range is 0.001~1.000 (unit: mm).

Return to the teaching screen with the ESC key and execute the inching operation.

Clicking jog key once moves one inching distance.

Clicking any of 1→ through 4→ makes inching movement in the coordinate plus direction, while clicking any of ←1 through ←4 makes inching movement in the coordinate minus direction.

Pressing and holding the jog key changes to jog operation. In approximately 1.6 seconds after the jog key is pressed, inching operation changes to jog operation and further continuing to press the key changes the jog velocity per second as follows:

1→10→50→100 mm/sec.

③ Manual Movement with Servo OFF Status

Servo OFF

Teac- 100		Axis1-2/2	
64.683	85.317		
Disp	Scan	Clr	Axis→
F1	F2	F3	F4

Press the ON/OFF key to turn the servo OFF.

To confirm the servo ON/OFF status, press the F1 (Disp) key.

Move the actuators to the designated position via manual mode.

(3) Take in the current position as a data

Take the selected actuator's location as position data into the teaching screen.

Teac- 100		Axis 1/2	
X. XXX	X. XXX		
Disp	Scan	Canc	Axis→
F1	F2	F3	F4

Input the position No. into which data is taken on the position No. selection screen with the 10 keys.

Or select position No. into which data is taken with the PAGE UP · PAGE DOWN keys on the data input screen.

Teac- 100		Axis 1/2	
64.683	X. XXX		
Disp	Scan	Canc	Axis→
F1	F2	F3	F4

Take in the current position data of all axes by pressing the F2 (Scan) key on the position No. selection screen.

Take in the current position data of the axis where the cursor is located by pressing the F2 (Scan) key on the each-axis data input screen. (The data is executed per axis. The diagram on the left is for taking in data on the each-axis data input screen.)

(4) Transmit to the Controller

Transmit the taken-in data to the controller.

Teac- 100	Axis 2/2
64.683	85.317
Disp	Scan Canc Axis→

F1	F2	F3	F4
----	----	----	----

Teac- (10)	Axis 2/2
X.XXX	X.XXX
Disp	Scan Canc Axis→

F1	F2	F3	F4
----	----	----	----

Press the WRT key in the teaching screen condition. Save the taken-in data to the controller memory. Position No. will be increased 1 by pressing the WRT key.

You can only transmit 1 screen of data to the controller. You can't transmit plural position No. data at one time.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

(5) I/O Monitor · Location Confirmation

During teaching operation, you can monitor the input and output ports. You can also confirm the location by moving an actuator to a to the location of the position data with teaching.

① Input / Output Monitor

Select In or Out from the function keys in the teaching screen condition.

In: Input port Out: Output port

Input Port

Moni - In	0123456789
0 - >	0000000000
10 - >	0000000000

F1	F2	F3	F4
----	----	----	----

Output Port

Moni - Out	0123456789
300 - >	1110000000
310 - >	0000000000
0 / 1	

F1	F2	F3	F4
----	----	----	----

You can switch the status of the output port OFF/ON (0/1) where the cursor is located by pressing the F1 (0/1) key.

(OFF/ON (0/1) status is switched each time you press F1 key.)

② Moving

Move the actuator to the location of the position data transmitted to the controller.

Position No. to move

Teac-	①	Axis1-2/2	
	0.000	50.000	
(Disp)	Scan	Clr Axis→	
F1	F2	F3	F4

Select position No. to move in the teaching screen condition.

Press the ON/OFF key to turn the servo ON.

To confirm the servo ON/OFF status, press the F1 (Disp) key.

It starts moving by pressing the MOVE key. To the Stop, press STOP key.

Teac-	1	Axis1-2/2	
	0.000	50.000	
Cont	(JVel)	In Out→	
F1	F2	F3	F4

When you confirm or change the moving velocity, press F2 (JVel) key to move to the velocity changing screen.


Moving velocity 50mm/sec

JVel			
Vel[50	Dis[0.000]	
Acc[0.30]	Dcl[0.30]		
F1	F2	F3	F4

Input alteration data with 10 keys and press return key. After changing, return to the previous screen with ESC key.

③ Continuous movement


Move the actuator continuously to the location of the position data transmitted to the controller.



Select the position No. to move first in the teaching screen condition and press return key.


Press the ON/OFF key to turn the servo ON.

To confirm the servo ON/OFF status, press the F1 (Disp) key.




Press the F1 (Cont) key.

When you change the moving velocity, press the F2 (Jvel) key to move to the velocity change screen.



Input changed data with the 10 keys and press the return key. After changing, return to the previous screen with the ESC key.

(The moving velocity is set 50mm/sec at the diagram on the left.)




Continuous movement starts by pressing MOVE key. During continuous movement, the display changes to the current position display. To stop, press the STOP key.

To re-start continuous movement, press the MOVE key.

Note: Please take note that it may take a few seconds before movement start after the MOVE key is pressed. (The time elapsed until movement start varies according to the number of registered position data.)

(6) User-specified output port operation

The output ports set for the parameter can be easily turned ON/OFF.
Select UsrO among the function keys in a teaching screen condition.



(A) User-specified output port status

The conditions of user-specified output ports are displayed as “1” (=ON) and “0” (=OFF).
(The conditions are displayed from the first specified port for the number of specified ports.)

(B) Current position and servo ON/OFF

The current position and servo ON/OFF condition (“N”=ON, “F”=OFF) are displayed for each axis.

(C) Function for operation of user-specified output ports

This is the function for ON/OFF operation of user-specified output ports.

This function is allocated to “Usr1,” “Usr2,” “Usr3”... in this order from the first user-specified port for the number of specified ports.

(“Usr1” to “Usr4” and “Usr5” to “Usr8” are changed with the SF key.)

ON/OFF operation can be performed for each output port by pressing the function keys (F1 to F4) corresponding to “Usr1” to “Usr4” and “Usr5” to “Usr8.”

(When the port status display is “0” [OFF], the port ON command is given. When the port status display is “1” [ON], the port OFF command is given.)

① Setting of user-specified output port parameters

For the operation method for parameter setting, refer to “14. Parameter Edit.”

The first port No. and the number of ports are set with the following parameters:

- Number of ports
I/O parameter No. 74 “Qnt Prt Usr Out” (Number of output ports used by TP user [hand, etc.])
- First port No.
I/O parameter No. 75 “Top No. Use Out” (First output port No. by TP user [hand, etc.])

(Setting example) When the first port No. is set to 308 and the number of ports is set to 8:

“Usr1” (F1 key) ····· Output port 308
“Usr2” (F2 key) ····· Output port 309
“Usr3” (F3 key) ····· Output port 310
“Usr4” (F4 key) ····· Output port 311
“Usr5” (F1 key) ····· Output port 312
“Usr6” (F2 key) ····· Output port 313
“Usr7” (F3 key) ····· Output port 314
“Usr8” (F4 key) ····· Output port 315

11-3. Example of Teaching Input

Entering the data into position No.10 using the jog and into position No.11 by manual operation with Servo OFF status.

Mode Selection			
Edit Play Moni Ctl			
F1	F2	F3	F4

Select the F1 (Edit) key on the mode selection screen.

Edit			
Posi Prog Sym Para			
F1	F2	F3	F4

Select the F1 (Posi) key.

Edit - Posi			
Mdi Teac Copy Clr			
F1	F2	F3	F4

Select the F2 (Teac) key.

Teac - 1 Axis1 - 2/2			
0.000		50.000	
Disp	Scan	Clr	Axis→
F1	F2	F3	F4

Input 10 to Position No. by using the PAGE UP · PAGE DOWN keys or the 10 keys and then the return key.

Teac - 10 Axis 1/2			
x. xx <u>x</u>		x. xxx	
Disp	Scan	Canc	Axis→
F1	F2	F3	F4

Turn the servo ON by pressing the ON/OFF key.

```

Teac - 10 Axis  1/2
 253.977N  119.495N

(Disp) Scan Canc Axis→
F1 | F2 | F3 | F4
  
```

Move the actuator to the designated position by pressing the jog keys, ←1, 1→, ←2, and 2→.

```

Teac - 10 Axis  1/2
 272.727N  144.905N

(Disp) (Scan) Canc Axis→
F1 | F2 | F3 | F4
  
```

Take in the current position data of the axis No. where the cursor is located by pressing the F2 (Scan) key.
Switch the display to the data input screen with the F1 (Disp) key. Confirm that the data has been taken in.

```

Teac - 10 Axis  1/2
 272.727  x.xxx

Disp (Scan) Canc Axis→
F1 | F2 | F3 | F4
  
```

Press the return key to move the cursor to the next axis. Then press the F2 (Scan) key.

```

Teac - 10 Axis  2/2
 272.727  144.905

Disp Scan Canc Axis→
F1 | F2 | F3 | F4
  
```


Transmit position data to the controller by pressing the WRT key.
The Position No. moves to 11.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

```

Teac - 11 Axis  1/2
  x.xxx  x.xxx

Disp Scan Canc Axis→
F1 | F2 | F3 | F4
  
```




Turn the servo OFF by pressing the ON/OFF key. Press the F1 (Disp) key to confirm the servo OFF status.


Move each axes to the designate position via manual mode.

Note: Be sure to confirm the status is servo OFF and then execute operation.


You have to release the brake for the Z axis to be moved by manual mode. When the brake is released for that reason, there is a possibility that the Z axis may fall by weight, such as a hand attached at the tip. Therefore, do not execute teaching to the Z axis via manual mode.



Take in the current position data of the axis No. where the cursor is located by pressing the F2 (Scan) key.



Press the return key and make the cursor move to the next axis. Then press the F2 (Scan) key.



Transmit position data to the controller by pressing the WRT key.

The Position No. moves to 12.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Teac - 12 Axis 1/2			
x. xx <u>x</u>		x. xxx	
Disp	Scan	Canc	Axis→
F1	F2	F3	F4

Finish the position data input by teaching.
Press the ESC key.

Teac - 1 <u>2</u> Axis1 - 2/2			
x. xxx		x. xxx	
Disp	Scan	Canc	Axis→
F1	F2	F3	F4

Press the ESC key.

Edit - Posi			
Mdi	Teac	Copy	Clr
F1	F2	F3	F4

Press the ESC key.

Edit			
Posi	Prog	Sym	Para
F1	F2	F3	F4

Press the ESC key.

Flsh			
Flash Write?			
Yes	No		
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.

Flsh
Writing Flash ROM
Please wait...

F1	F2	F3	F4
----	----	----	----

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**


Flsh
Complete!

F1	F2	F3	F4
----	----	----	----


Return to the edit screen with the ESC key.

11-4. Position Data: Copy or Move


The following operating instructions are to copy or move the position data to another position No.



Select F1 (Edit) key on the mode selection screen.




Select the F1 (Posi) key.



Select the F3 (Copy) key.

Positions from which data is copied or moved




Input the first No. and the last No. of the positions from which data is copied or moved by using the 10 keys and press the return key.

Input the first No. of the positions to which data is copied or moved by using the 10 keys and press the return key.

To copy the data, press the F3 (Copy) key. To move the data, press the F4 (Move) key.


Positions to which data is copied or moved
First No.




Return to the previous screen with the ESC key.
To write Flash ROM, press the ESC key several times to return to the Flash ROM writing screen.

11-5. Position Data: Clear


The following operating instructions are to clear the position data.




Select the F1 (Edit) key on the mode selection screen.



Select the F1 (Posi) key.




Select the F4 (Clr) key.



Input the first No. and the last No. of the position data to clear by using the 10 keys and press the return key.

To clear the selected position data, press the F3 (Clr) key.

To clear the data for all positions (No. 1 through No. 3000), press the F4 (AClr) key.



Return to the previous screen.

To write to Flash ROM, press the ESC key several times to return to the Flash ROM writing screen.

12. Program Edit

12-1. How to Input Program


How to input Expansion Condition (E), Input Condition (N·Cnd), and Output (Pst)

The sequence of program inputs for the teaching pendant is different from the program edit screen of the PC software.


The sequence is as ① Command (Cmnd), ② Operation 1 (Operand 1), ③ Operation 2 (Operand 2), ④ Output (Pst), ⑤ Expansion Condition (E) and ⑥ Input Condition (N·Cnd).

PC Software Program Edit Screen

No.	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
10	A	N	600	CPGE	200	*201	900	



Teaching Pendant LCD Display



Input the program below as an example.

Program No. 2

No.	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1			601					
2	A	N	600	CPGE	200	*201	900	

Input only the Input Condition at step No.1 and input data all except Comment at step No.2.

Mode Selection			
Edit	Play	Moni	Ctl
F1	F2	F3	F4

Select the F1 (Edit) key on the mode selection screen.

Edit			
Posi	Prog	Sym	Para
F1	F2	F3	F4

Select the F2 (Prog) key on the edit mode screen.

Edit-Prog			
Mdfy	Copy	Clr	
F1	F2	F3	F4

Select the F1 key (Mdfy) on the program edit and new creation screen.

Mdf 1- 1 :			
F1	F2	F3	F4

Input the program No. by using the 10 keys and press the return key.

Mdf 2- 1 :			
Ins	Del	Cmnt	/ 0
F1	F2	F3	F4

The cursor moves to step No. Press the return key.

Mdf 2- 1 :			
-			
ABPG	ACC	ACHZ	ADD →
F1	F2	F3	F4

Input section of Cmnd

Press the return key.

Mdf 2- 1 :			
-			
F1	F2	F3	F4

Input section of Operand 1

Press the return key.

Mdf 2- 1 :			
-			
F1	F2	F3	F4

Input section of Operand 2

Press the return key.

Mdf 2- 1 :			
-			
F1	F2	F3	F4

Input section of Pst

Press the return key.

Mdf 2- 1 : _			
LD	A	0	AB →
F1	F2	F3	F4

Input section of E

Press the return key.

Mdf 2-	1 :	-	
Sym N			
F1	F2	F3	F4

Input section of N-Cnd

Input "601" by using the 10 keys and press the return key.

Mdf 2-	1 :	601	
-			
ABPG	ACC	ACHZ	ADD →
F1	F2	F3	F4

Transmit the data of step No.1 to the controller by pressing the WRT key.
Step No. moves to 2.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf 2-	2 :		
-			
ABPG	ACC	ACHZ	ADD →
F1	F2	F3	F4

Input section of Cmnd

Display CPGE in the function key area by using the 7 key and SF key.

For searching commands, please refer to section "9-2. Programming."

Mdf 2-	2 :		
-			
CLR	COS	CPEQ	CPGE →
F1	F2	F3	F4

Select the F4 (CPGE) key and press return.

Mdf 2-	2 :		
CPGE	_		
Num	Sym	*	'
F1	F2	F3	F4

Input section of Operand 1

Input 200 by using the 10 keys and press return.

(When designating an indirect variable at Operand 1, select the F3(*) key first.
When inputting a string at Operand 1, press the F1 (Num) key to change to F1(Alph). Input the string with the F4 (') key and the 10 keys which become alphabet inputs.

Mdf 2- 2 :			
CPGE 200			
-			
Num	Sym	*	,
F1	F2	F3	F4

Input section of Operand 2 (Indirect variable designation)

Select the F3 (*) key first. Then input 201 by using the 10 keys and press the return key.
(When you input a string at Operand 2, use the same format as Operand1.)

Mdf 2- 2 :			
CPGE 200			
*201			
	Sym	*	-
F1	F2	F3	F4

Input section of Pst

Input 900 by using the 10 keys and press the return key.
(When designating an indirect variable at Operand 1, select the 3 (*) key first.)

Mdf 2- 2 : _			
CPGE 200			
*201 900			
LD	(A)	0	AB →
F1	F2	F3	F4

Input section of E

Select the F2 (A) key and press the return key.
(Input expansion condition of virtual ladder task on this screen with the function keys as well.)

Mdf 2- 2 : _			
CPGE 200			
*201 900			
	Sym	(N)	
F1	F2	F3	F4

Input section of N · Cnd

Select the F3 (N) key first. Input "600" by using the 10 keys and press the return key.

Mdf 2- 2 : A N600			
CPGE 200			
*201			
ABPG	ACC	ACHZ	ADD →
F1	F2	F3	F4

Transmit the data of step No. 2 to the controller by pressing the WRT key.
Step No. moves to 3.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Finish the program input. Return to the Flash ROM writing screen by using the ESC key.

12-2. Symbol Input during Program Edit

Symbol can be input when the cursor is located at Operand 1 · 2 (operation 1 · 2), Pst (output) and Cnd (input condition) in the “Sym” state displayed in the function key area.

Example:

Input symbol of the program step below.

No.	E	N	Cnd	Cmnd	Operand 1	Operand 2	Pst	Comment
1				MOVL	TAIKIITI			

Symbolize position No. 10 as “TAIKIITI.”

Mdf 3-	1 :		
MOVP	_		
-			
Num	Sym	*	,
F1	F2	F3	F4

Select the F2 (Sym) key in the function key area within the state of the cursor that has been located in the Operand 1 section.

Move to the symbol edit screen.

Edit-Sym			
Cnst	Var	Prog	Posi
F1	F2	F3	F4

Select items to edit the symbols with function keys. In this case, since we're going to edit the Position No., press the F4 (Posi) key.

Sym -Posi			
1:			
		/	11
F1	F2	F3	F4

Input 10 for position No. by using the 10 keys and press the return key.

Sym -Posi			
10: _			
Alph / 11			
F1	F2	F3	F4

The 10 keys become alphabet inputs. Input "TAIKIITI."
For the input procedure, please refer to the section "13. Symbol Edit."

Sym -Posi			
10: TAIKIITI			
Alph / 11			
F1	F2	F3	F4

Transmit the symbol data to the controller by pressing the WRT key. Return to the edit screen.

The letter, S indicates symbol is used.

Mdf 3- 1 :			
MOVP (S)10			
- Num Sym * ,			
F1	F2	F3	F4

Definition value of Symbol

The teaching pendant can't display symbols as inputs. In this case, display "S10" instead of "TAIKIITI."

(In the state where the cursor is located in the symbolized section, if F2 (Sym) key is chosen, it will move to the symbol edit screen. The symbol can then be changed.)

Mdf 3- 2 :			
-			
ABPG ACC ACHZ ADD→			
F1	F2	F3	F4


Transmit the data of this program step to the controller by pressing the WRT key.

To finish the program input, return to the Flash ROM writing screen by using the ESC key.


12-3. Single Line Comment Input

Turns a step from a program into a comment (invalid step) and you can input numbers, alphabets and signs (* · _).


Mode Transition: **Edit**—**Prog**—**Mdfy**—Program No. return
 Move the cursor to the step No. for comment input.




Press the F3 (Cmnt) key.



“C” will be displayed after the step No.
 Press the return key.




Each time you press the F1 key, the display of the F1 key area switches from “Alph” to ‘Num’.



Alphabet input

Display “Alph” in the F1 key area.
 Alphabets are allocated to each of the 10 keys.
 Ex) Each time you press 6, display changes P→ Q→ R→p→q→r→P→ Display the alphabet you’d like to input and press the return key. The example of the left displays “P.”



On the left is an example for inputting the word “Palette.”

Mdf64-	1C:	Pale	
tte	■		
Num			
F1	F2	F3	F4

Input numerical value

Display "Num" in the F1 key area.
Input the numerical value by using the 10 keys.

Mdf64-	1C:	Pale	
tte1	■		
Num			
F1	F2	F3	F4

The diagram on the left is an example for inputting "1."

Mdf64-	1C:	Pale	
tte1			
-			
Num			
F1	F2	F3	F4

After finishing the comment input, press the return key again.
Transmit the input data to the controller by pressing the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Mdf64-	2	:	
-			
ABPG	ACC	ACHZ ADD →	
F1	F2	F3	F4

The screen moves to the next step No.

To finish the program input, return to the Flash Rom writing screen by using the ESC key.

Note: Full size character data input by the PC software can't be displayed on the teaching pendant.

12-4. Program: Copy or Move

The following operating instructions are to copy or move a program to another program No.

Mode Selection			
ⓔdit	Play	Moni	Ctl
F1	F2	F3	F4

Select the F1 (Edit) key on the mode selection screen.

Edit			
Posi	ⓔrog	Sym	Para
F1	F2	F3	F4

Select the F2 (Prog) key.

Edit-Prog			
Mdfy	ⓔopy	Clr	
F1	F2	F3	F4

Select the F2 (Copy) key.

Prog-Copy			
From	①	[10]	
To	①	[0]	
Copy Move / 10			
F1	F2	F3	F4

Program No. from which a program is copied or moved

Program No. to which a program is copied or moved

Input the program No. from which a program is copied or moved by using the 10 keys and press the return key.

Input the program No. to which a program is copied or moved by using the 10 keys and press the return key.

To copy the program, press the F2 (Copy) key. To move the program, press the F3 (Move) key.

Prog-Copy			
Complete!			
F1	F2	F3	F4

Return to the previous screen with the ESC key. Furthermore, press the ESC key several times and return to the Flash ROM writing screen.

12-5. Program: Clear

The following operating instructions are to clear a program.

Mode Selection			
ⓔdit	Play	Moni	Ctl
F1	F2	F3	F4

Select the F1 (Edit) key on the mode selection screen.

Edit			
Posi	ⓔrog	Sym	Para
F1	F2	F3	F4

Select the F2 (Prog) key.

Edit-Prog			
Mdfy	Copy	ⓔlr	
F1	F2	F3	F4

Select the F3 (Clr) key.

Prog-Clr			
No.	③	-	①
Clr	Aclr	/	94
F1	F2	F3	F4

Program No. to clear

Input "0."

Input the program No. to clear by using the 10 keys and press the return key.

- ① To clear a single program, press the F2 (Clr) key. The program No. 3 will be cleared in the example diagram on the left.

Prog-Clr			
No.	④	-	⑥
Clr	Aclr	/	94
F1	F2	F3	F4

A series of programs

First No.

Last No.

- ② To clear a series of multiple programs, press the F2 (Clr) key. The programs No. 4, No. 5 and No. 6 will be cleared in the example diagram on the left.
- ③ To clear all the programs (No. 1 through No. 64), press the F3 (Aclr) key.

Prog-Clr
Complete!

F1	F2	F3	F4
----	----	----	----

Return to the previous screen with the ESC key.
Furthermore, press the ESC key several times and
return to the Flash ROM screen.



12-6. Flash ROM Writing

The edit data will be cleared by restoring the power and executing software reset, only if the program edit data was transmitted to the controller.

To save the data after restoring the power and executing software reset, write the data to Flash ROM.

From the final editing screen, return to the Flash ROM writing screen with the ESC key.

Flsh			
Flash Write?			
Yes		No	
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.

Flsh			
Writing Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.


*** Never shut off the power to the controller during Flash ROM writing.**

Flsh			
Complete!			
F1	F2	F3	F4


Flash ROM writing is complete.
Return to the edit screen with the ESC key.

13. Symbol Edit

Symbol (Names) can be applied to variables, input ports, flags, points, etc., in X-SEL controller.




Select the F1 (Edit) key.



Select the F3 (Sym) key.


13-1. Symbol Edit Items




Symbolized items will be displayed in the function key area. Each time by pressing SF key, items are shifted and displayed.

Symbol Edit Items

Cnst: Constant number
 Var: Variable
 Prog: Program No.
 Posi: Position No.



In: Input port No.
 Out: Output port No.
 Flag: Flag No.
 Axis: Axis No.



Tag: Tag No.
 SubR: Subroutine No.

Aclr: All clear
 Clear all the symbol data.

Display the list of items to symbolize by using the SF(shift) key and select with the function keys.



13-2. Input Example: Symbolize Local Integer Variable

Symbolize Variable No. 5 of program No. 3 to "Cnt5." Press the F2 (Var) key.

Mode Transition: Edit Sym Var

Sym - Var			
Itg Real			
F1	F2	F3	F4

Select an integer or real number.
Press the F1 (Itg) key.
(Int: Integer, Real: Real number)

Sym - Var [Prog 0]			
200 :			
/ 0			
F1	F2	F3	F4

The cursor is located at program No.
Input the local area program No.
(To symbolize global area, leave 0.)
Input 3 and press the return key.

Sym - Var [Prog 3]			
① :			
F1	F2	F3	F4

Variable No. Local area program No.

The cursor is located at variable No.
Input 5 and press the return key.

Sym - Var [Prog 3]			
5 : _			
Alph			
F1	F2	F3	F4

Input the symbol name "Cnt5."

How to input

Alphabets are allocated to each of the 10 keys. Each time by pressing 7 of the 10 key, It changes A→B→C→a→b→c→A
Display "C" and press the return key.

Sym - Var1 [Prog 3]			
5 : C■			
Alph			
F1	F2	F3	F4

Press 5 several times to display "n."
Press the return key.

Sym - Var1 [Prog 3]			
5 : Cn■			
Alph			
F1	F2	F3	F4

Press the 1 (10 keys) several times to display "t."
Then press the return key.

Sym - Var1 [Prog 3]			
5 : Cnt■			
Alph			
F1	F2	F3	F4

The F1 key area display changes to Num by pressing the F1 (Alph) key. It becomes a numerical input.

Sym - Var1 [Prog 3]			
5 : Cnt■			
Num			
F1	F2	F3	F4

Numerical input

Input 5 by using the 10 keys.

Sym - Var1 [Prog 3]			
5 : Cnt5■			
Num			
F1	F2	F3	F4

Press the return key to determine the symbol name.

Sym - Var1 [Prog 3]			
5 : <u>Q</u> nt5			
Alph / 0			
F1	F2	F3	F4

After determining symbol name, the cursor moves to the top letter.

If it's before determination, you can fix the letters one by one with the BS key.

After determination, the name is corrected by overwriting all the characters.

Transmit the symbol data to the controller by pressing the WRT key.

* If you change the screen with the PAGE UP · PAGE DOWN or ESC keys before transmitting the data, the input data will be invalid.

Sym - Var1 [Prog 3]			
6 : _			
Alph / 1			
F1	F2	F3	F4

To finish edit, return to the edit screen with the ESC key.

Edit			
Posi Prog Sym Para			
F1	F2	F3	F4

Press the ESC key.

Flsh			
Flash Write?			
Yes No			
F1	F2	F3	F4

Press the F1 (Yes) to write the data to Flash ROM. If not, press F2 (No) key.

Flsh			
Writing Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**

Flsh Complete!			
F1	F2	F3	F4

Return to the edit screen with the ESC key.

13-3. Symbol Edit Screen of Each Items

(1) Constant Number

Select the F1 (Cnst) key on the constant number symbol edit screen.

Mode Transition: Edit - Sym - Cnst

Selection of Integer Type · Real Number Type Constant Number

Sym - Cnst			
ltg Real			
F1	F2	F3	F4

Select an integer or real number.

F1 (ltg): Integer
F2 (Real): Real Number

① Integer Type Constant Number

Mode Transition: Edit - Sym - Cnst - ltg

Integer Type Constant Number Symbol Edit Screen

Sym - Cnst - ltg			
1 : <input type="text"/>			
[<input type="text"/>]			
Alph		/ 0	
F1	F2	F3	F4

Input alphabet and number.

Input constant value.

② Real Number Type Constant Number

Mode Transition: Edit - Sym - Cnst - Real

Real Type Constant Number Symbol Edit Screen

Sym - Cnst - Real			
1 : <input type="text"/>			
[<input type="text"/>]			
Alph		/ 0	
F1	F2	F3	F4

(2) Variable

Select the F2 (Var) key on the variable symbol edit screen.

Mode Transition: Edit - Sym - Var

Selection of Integer Type · Real Number Type Variable

Sym - Var			
ltg Real			
F1	F2	F3	F4

Select an integer or real number.

F1 (ltg): Integer
F2 (Real): Real Number

① Integer Type Variable No.

Mode Transition: Edit - Sym - Var - ltg

Integer Type Variable No. Symbol Edit Screen

Sym - Varl - [Prog 0]			
200 : <input type="text"/>			
Alph / 0			
F1	F2	F3	F4

Input program No. at local area.
Input 0 at global area.

Input alphabet and number.

Input variable No. by PAGE UP ·
PAGE DOWN key or 10 keys

② Real Number Type Variable No.

Mode Transition: Edit - Sym - Var - Real

Real Number Type Variable No. Symbol Edit Screen

Sym - VarR - [Prog 0]			
300 : <input type="text"/>			
Alph / 0			
F1	F2	F3	F4

(3) Program

Select F3 (Prog) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Prog

Program No. Symbol Edit Screen

Input program No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(4) Position

Select F4 (Posi) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Posi

Position No. Symbol Edit Screen

Input position No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(5) Input Port

Select F1 (In) key on the symbol edit item screen.

Mode Transition: Edit - Sym - In

Input Port No. Symbol Edit Screen


Input input port No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(6) Output Port

Select F2 (Out) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Out

Output Port No. Symbol Edit Screen



Input alphabet and number.


Input output port No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(7) Flag

Select F3 (Flag) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Flag

Flag No. Symbol Edit Screen



Input program No. at local area. Input 0 at global area.

Input alphabet and number.


Input flag No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(8) Axis

Select F4 (Axis) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Axis

Axis No. Symbol Edit Screen



Input alphabet and number.


Input axis No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(9) Tag

Select F1 (Tag) key on the symbol edit item screen.

Mode Transition: Edit - Sym - Tag

Tag No. Symbol Edit Screen



Input program No. since tag No. is in the local area.

Input alphabet and number.


Input tag No. by the PAGE UP · PAGE DOWN keys or 10 keys.

(10) Subroutine

Select F2 (SubR) key on the symbol edit item screen.

Mode flow: Edit - Sym - SubR

Subroutine No. Symbol Edit Screen



Input program No. since subroutine No. is in the local area.

Input alphabet and number.

Input subroutine No. by the PAGE UP·PAGE DOWN keys or 10 keys.

13-4 Flash ROM Writing

The edit data will be the by restoring power and executing software reset, only if the symbol edit data was transmitted to the controller.

To save the data after restoring the power and executing software reset, write the data to Flash ROM.

From the final editing screen, return to the Flash ROM writing screen with the ESC key.

Flsh Flash Write?			
<input checked="" type="radio"/> Yes No			
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.

Flsh Writing Flash ROM Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**

Flsh Complete!			
F1	F2	F3	F4


Flash ROM writing is complete.
Return to the edit screen with the ESC key.

14. Parameter Edit


You can change the parameters corresponding to your system.

When you change the parameters by yourself, please note the parameter contents.

Parameters will be valid by restoring the power or executing software reset after Flash ROM writing.



Select the F1 (Edit) key on the mode selection screen.




Select the F4 (Para) key on the edit screen.

14-1. Parameter Edit Items


Parameter items will be displayed in the function key area.

Each time by pressing the SF key, items will be shifted and displayed.



Parameter Edit Items

I/O: I/O parameter
 Comn: All-axis common parameter
 Axis: Each-axis parameter
 Drv: Driver card parameter



Ecdr: Encoder parameter
 losl: I/O slot card parameter
 Othe: Other parameter

Select the parameter item to edit with function key.

14-2. Input Example: Edit Each-Axis Parameter

Set the soft limit + for the first and second axis of each-axis parameter No.7, 300mm and 200mm. Select the F3 (Axis) key on the screen of previous page, A.

Mode Transition: Edit → Para → Axis

Para - Axis Axis 1/ 2			
1 : Axis Action Typ			
[0]			
F1	F2	F3	F4

The cursor is located at the parameter No. Input 7 by using the 10 keys and press the return key.

Connecting Axis number
Editing Axis No.

Para - Axis Axis 1/ 2			
7 : Soft Limit +			
[160000]			
Dev-		Dev+	
F1	F2	F3	F4

It becomes the soft limit + of each-axis parameter No.7 edit screen.

Input data of axis No. 1

Depending on the parameter items, set the parameter by axis or I/O board. (Each-axis parameter, driver card parameter, encoder parameter, and I/O slot card parameter.) Confirm that the screen is the first axis edit screen.

Use F3 (Dev-) key and F4 (Dev+) key to change axis No.

Input 300000 and press the return key. (Unit: 0.001mm)

Para - Axis Axis 1/ 2			
7 : Soft Limit +			
[300000]			
Dev-		Dev+	
F1	F2	F3	F4

Transmit the parameter data to the controller by pressing the WRT key.

Note:

One transfer (WRT key) with the Teaching Pendant saves the data only on the current screen in memory. Therefore, it is required to input the parameter data and transfer it by axis (device).

Un-transmitted data will be invalid when switching the screen.

Para - Axis Axis 1/ 2			
8 : Soft Limit -			
[0]			
Dev- Dev+			
F1	F2	F3	F4

Input data of axis No. 2

The display screen moves to parameter No. 8. Axis No. 2 of parameter No. 7 is not edited yet, so, return to the parameter No. 7 edit screen with the PAGE DOWN key.

Para - Axis Axis 1/ 2			
7 : Soft Limit +			
[300000]			
Dev- Dev+			
F1	F2	F3	F4

Change the axis No. to 2 by using the F4 (Dev+) key.

Axis No. 2

Para - Axis Axis 2/ 2			
7 : Soft Limit +			
[160000]			
Dev- Dev+			
F1	F2	F3	F4

Input 200000 by using the 10 keys and press the return key.

Para - Axis Axis 2/ 2			
7 : Soft Limit +			
[200000]			
Dev- Dev+			
F1	F2	F3	F4

Transmit the parameter data to the controller by pressing the WRT key.

Para - Axis Axis 2/ 2			
8 : Soft Limit -			
[0]			
Dev- Dev+			
F1	F2	F3	F4

To continue editing each-axis parameter, move the cursor to the parameter No. and input the parameter No. to edit.
To finish each-axis parameter edit, return to the Flash ROM writing screen with the ESC key.

```

Flsh
Flash Write?

Yes  No

F1 | F2 | F3 | F4
  
```

To write the data to Flash ROM, press the F1 (Yes) key.
If not, press the F2 (No) key.

```

Flsh
Writing Flash ROM
Please wait...

F1 | F2 | F3 | F4
  
```

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**

```

Flsh
Do you want to
re - start controller?
Yes  No

F1 | F2 | F3 | F4
  
```

After writing the data to Flash ROM, the screen changes to the software reset screen.
To have a valid changed parameter, execute a software reset. Press the F1 (Yes) key.

```

Flsh
Do you want to
re - start controller?
Please wait...

F1 | F2 | F3 | F4
  
```

During software reset, "Please wait..." blinks.

```

Mode Selection


Edit Play Moni Ctl

F1 | F2 | F3 | F4
  
```

When the software reset is complete, it returns to the mode selection screen.

15. Monitor

Monitor each status, global variable, port status, etc.





Select the F3 (Moni) key from The mode selection screen.

15-1. Monitor Items

Monitor items will be displayed in the function key area.

Each time by pressing the SF key, items will be shifted and displayed.

Monitor Items Screen



In: Input port
 Out: Output port
 GFlg: Global flag
 GVar: Global variable

Asts: Axis status
 SSts: System status
 ErrL: Error detail information
 Ver: Version information

Select the item to monitor with the function key.

15-2. Input Port

Display the ON/OFF status of input port.
 Select the F1 (In) key on the monitor items screen.

Mode Transition: Moni In

Moni - In	0123456789
0 - >	0000000000
10 - >	0000000000

1: ON, 0: OFF
 Each time the PAGE UP · PAGE DOWN keys are pressed, the 20 port numbers are scrolled.

F1	F2	F3	F4
----	----	----	----

15-3. Output Port

Displays the ON/OFF status of the output port. Also, it can switch the ON/OFF status of the output port.

Select F2 (Out) key on the monitor items screen.

Mode Transition: Moni Out

Moni - Out	0123456789
300 - >	<u>1</u> 1100000000
310 - >	0000000000
0 / 1	

The output port where the cursor is located can be switched ON/OFF status each time by pressing the F1 (0/1) key.
 1: ON, 0: OFF
 The cursor location can be moved with return key or ← key.
 Each time the PAGE UP · PAGE DOWN keys are pressed, 20 port numbers are scrolled.

F1	F2	F3	F4
----	----	----	----

(The diagram above is the screen showing output port Nos. 300-302 ON.)

15-4. Global Flag

Displays the ON/OFF status of global flag. Also, it can switch the ON/OFF status of the global flags.

Select the F3 (GFlg) key on the monitor items screen.

Mode Transition: Moni GFlg

Moni - Gflg	0123456789
600 - >	<u>0</u> 0000000000
610 - >	0000000000
0 / 1	

Global flags where the cursor is located can be switched ON/OFF each time by pressing the F1 (0/1) key.
 1: ON, 0: OFF
 The cursor location can be moved by return key or ← key.
 Each time the PAGE UP · PAGE DOWN keys are pressed, 20 flags numbers are scrolled.

F1	F2	F3	F4
----	----	----	----

15-5. Global Variable

Displays the contents of global variable and global string. Also, a numeric value can be substituted for a global variable and letter string can be substituted for a global string.

Select the F4 (GVar) key on the monitor items screen.

Mode Transition:

Moni - GVar			
ltg	Real	str	
F1	F2	F3	F4

3 kinds of global variables are displayed:
 Itg: Integer Type (No. 200~299, No.1200~1299)
 Real: Real Number Type (No. 300~399, No. 1300~1399)
 Str: String (No. 300~999)

(1) Global Integer Type Variable

Mode Transition:

GVar - Itg			
200	- >	0	
201	- >	0	
F1	F2	F3	F4

(2) Global Real Number Type Variable

Mode Transition:

GVar - Real			
300	>	0.000000	
301	>	0.000000	
F1	F2	F3	F4

The cursor is located in the data column (variable content). To substitute a value, input numeric value by using the 10 keys and press the return key. The cursor location can be moved with the return key and ← key.

The variable No. can be changed with the PAGE UP · PAGE DOWN keys.

(3) Global String

Mode Transition:

Moni - Gstr 0123456789			
300	- >	-	
310	- >		
Num			
F1	F2	F3	F4


The cursor is located in the data column.
 To substitute letters, input the ASCII code by using the 10 keys and press the return key. (Input hexadecimal, A~F after switching to Alph with the F1 (Alph/Num) key.)

The cursor location can be moved with the return key and ← key. Each time by pressing the PAGE UP · PAGE DOWN keys, the column scrolls 20 rows.



15-6. Axis Status

Displays the current position of each axis, servo status, sensor status, etc.
Select the F1 (ASts) key from the monitor items screen.

Mode Transition: Moni ASts




Posi: Current Position
Srvo: Servo Status
Snsr: Sensor Input Status
Ecdr: Encoder Status



ErrA: Axis Related Error

(1) Current position


Mode Transition: Moni ASts Posi



N: Servo ON
F: Servo OFF

(2) Servo status


Mode Transition: Moni ASts Srvo



Axis No. can be switched with the PAGE UP · PAGE DOWN keys.

Servo ON axis in use

Homing



Servo

Moving Command Normal End



ASts - Srvo Axis 1 / 2			
Over Push - limit : OFF			
(Reserved6) : OFF		(System Reservation)	
Back Next			
F1	F2	F3	F4

Over Push Limit Error

(System Reservation)

Back Next

ASts - Srvo Axis 1 / 2			
(Reserved7) : OFF			
(System Reservation)			
Back Next			
F1	F2	F3	F4

(System Reservation)

Back Next

(3) Sensor Input Status

Mode Transition: Moni — ASts — Snsr

ASts - Snsr Axis ① / 2			
Creep Sensor : OFF			
Overrun Sensor : OFF			
Back Next			
F1	F2	F3	F4

Axis No. Axis No. can be switched with the PAGE UP · PAGE DOWN keys.

Creep Sensor

Overrun Sensor

Back Next

Home Sensor : OFF			
(Reserved3) : OFF		(System Reservation)	
Back Next			
F1	F2	F3	F4

Home Sensor

(System Reservation)

Back Next

(4) Encoder Status

Mode Transition: Moni — ASts — Ecdr

Axis No. can be switched with the PAGE UP · PAGE DOWN keys.


ASts - Ecdr Axis ① / 2

OS : OFF — Over Speed

FS : OFF — Full Absolute Status

Back Next

F1	F2	F3	F4
----	----	----	----




ASts - Ecdr Axis 1 / 2

CE : OFF — Count Error

OF : OFF — Counter Over Flow

Back Next

F1	F2	F3	F4
----	----	----	----




ASts - Ecdr Axis 1 / 2

(Reserved4) : OFF — System Reservation

ME : OFF — Multi-rotation Error

Back Next

F1	F2	F3	F4
----	----	----	----



ASts - Ecdr Axis 1 / 2

BE : OFF — Battery Error

BA : OFF — Battery Alarm

Back Next

F1	F2	F3	F4
----	----	----	----

(5) Axis Related Error

Mode Transition: Moni — ASts — ErrA

Axis No. can be switched with the PAGE UP · PAGE DOWN keys.


Error Code

Axis No.

Err [000] Axis ① / 2

Back Next

F1 | F2 | F3 | F4



Err [000] Axis 1 / 2

Prg. No [0]


Step No [0]

Back Next

Program No.

Step No.

F1 | F2 | F3 | F4



Err [000] Axis 1 / 2

Axis No [0]


Pos. No [0]

Back Next

Axis No.

Position No.

F1 | F2 | F3 | F4



Err [000] Axis 1 / 2

Info. 1 [0]


Info. 2 [0]

Back Next

Information 1

Information 2

F1 | F2 | F3 | F4



Err [000] Axis 1 / 2

Info. 3 [0]

Info. 4 [0]

Back Next

Information 3

Information 4

F1 | F2 | F3 | F4

15-7. System Status

Display system status.

Select the F2 (SSts) key on the monitor items screen.

Mode Transition:

Moni - SSts			
Mode	Err	Sts1	Sts2 →
F1	F2	F3	F4

Mode: System Mode
 Err: System Error
 Sts1: System Status 1
 Sts2: System Status 2



Moni - SSts			
Sts3	Sts4		→
F1	F2	F3	F4

Sts3: System Status 3
 Sts4: System Status 4

(1) System Mode

Mode Transition:

SSts - Mode			
System Mode	[MANUAL]		
F1	F2	F3	F4

System Mode

(2) System Error

Mode Transition:

SSts - Err			
Serious Err	[000]		
Latest Sys Err	[000]		
F1	F2	F3	F4

Serious Level System Error No.


Latest System Error No.

(3) System Status 1

Mode Transition: Moni — SSts — Sts1


SSts - Sts1			
MANU_AUTO SW : MANU			
TP Enable SW : ON			
Back Next			
F1	F2	F3	F4

Operation Mode SW Status
TP Enable SW Status




SSts - Sts1			
Safety Gate : CLOS			
Emergency SW : NON			
Back Next			
F1	F2	F3	F4

Safety Gate Status
Emergency Stop SW Status



SSts - Sts1			
Pwr Abnormality : NON			
Batt Volt Down : NON			
Back Next			
F1	F2	F3	F4

Power Abnormality Status
Battery Voltage Down Warning Status



SSts - Sts1			
Battery Error : NON			
(Reserved7) : OFF			
Back Next			
F1	F2	F3	F4


Battery Voltage Error Status
System Reservation

(4) System Status 2

Mode Transition: Moni — SSts — Sts2


SSts - Sts2			
Wrt FROM AP Dat : NON			
Wrt Slave Para : NON			
Back Next			
F1	F2	F3	F4

Application Data Flash ROM Write Status
Slave Parameter Write Status




SSts - Sts2			
Servo Interlock : NON			
I/O Interlock : NON			
Back Next			
F1	F2	F3	F4

Servo Interlock Status
I/O Interlock Status



SSts - Sts2			
Wait for Reset : NON			
Prg Execution : NON			
Back Next			
F1	F2	F3	F4

Wait for Reset Status
Program Execution Status



SSts - Sts2			
Vel / Pos Monitor : NON			
Driver Monitor : NON			
Back Next			
F1	F2	F3	F4

Velocity Command/ Position Pulse Monitor (Main) Status
Driver Monitor Status

(5) System Status 3

Mode Transition: Moni — SSSts — Sts3


```

SSSts - Sts3
Power Down      : NON
System Drive    : NON
Back Next
    
```

Power Down Status

System Drive Status

F1	F2	F3	F4
----	----	----	----




```

SSSts - Sts3
System Ready    : RDY
Req Fnc Slct   : OFF
Back Next
    
```

System Ready Status

Function select flag request status

F1	F2	F3	F4
----	----	----	----




```

SSSts - Sts3
(Reserved4)     : OFF
(Reserved5)     : OFF
Back Next
    
```

(System Reservation)

(System Reservation)

F1	F2	F3	F4
----	----	----	----



```

SSSts - Sts3
(Reserved6)     : OFF
(Reserved7)     : OFF
Back Next
    
```

(System Reservation)

(System Reservation)

F1	F2	F3	F4
----	----	----	----

(6) System Status 4

Mode Transition: Moni — SSSts — Sts4

System status 4 is all reserved.
(System Reservation)

15-8. Error Detail Information

Displays the error detail information.

Select the F3 (ErrL) key on the monitor items screen.

Mode Transition:

Err [C74] List ① / 50
 Actual Position }
 Out of Range }
 Back Next Aclr

F1 | F2 | F3 | F4

List No.
 Error Code
 Error Message

Err [C74] List 1 / 50
 Prg. No [0]
 Step No [0]
 Back Next

F1 | F2 | F3 | F4

Program No.
 Step No.

Err [C74] List 1 / 50
 Axis No [2]
 Pos. No [0]
 Back Next

F1 | F2 | F3 | F4

Axis No.
 Position No.

Err [C74] List 1 / 50
 Info. 1 [0]
 Info. 2 [0]
 Back Next

F1 | F2 | F3 | F4

Information 1
 Information 2

Err [C74] List 1 / 50
 Info. 3 [40]
 Info. 4 [128]
 Back Next

F1 | F2 | F3 | F4

Information 3
 Information 4

15-9. Version Information

Displays version information.

Select the F4 (Ver) key on the monitor items screen.

Mode Transition:

Moni - Ver			
Main	Drv	TP	
F1	F2	F3	F4

Main: Main
 Drv: Driver
 TP: Teaching Pendant

(1) Main

Mode Transition:

Ver - Main			
Main	V0.21	01/06/12	
Maic	V0.09	01/03/08	
F1	F2	F3	F4

Controller Main Application Version

Controller Main Core Version

(2) Driver

Mode Transition:

Ver - Drv Axis 1 / 2			
Drv	V0.23	00/00/00	
F1	F2	F3	F4

Driver CPU Version

(3) Teaching Pendant

Mode Transition:

Ver - TP			
TP	V1.02	01/06/11	
TPc	V0.02	01/05/15	
F1	F2	F3	F4

Teaching Pendant Application Version

Teaching Pendant Core Version

(4) Mount SIO (Controller P/Q type only)

Mode Transition:

Ver -SIO			
Std1	V0.00	00/00/00	
Std2	V0.00	00/00/00	
F1	F2	F3	F4

Channel 1 Version

Channel 2 Version

* "Nonuse" is displayed for the channel with the I/O parameters No. 201 and No. 213 set to "Nonuse."

(5) FPGA

Mode Transition:

Ver -FPGA			
FPGA	0000h		
Board ID	0000h		
F1	F2	F3	F4

FPGA Version (HEX)

Board ID (HEX)

(6) Control Constant Table Management Information

Mode Transition:

Ver	CTbl	ID	0/31	
Data	V0.00			
Frmt	V0.00			
F1	F2	F3	F4	

Currently Displayed Table ID/Largest Table ID


Data Version

Format Version

* Change the table ID to display with the PAGE UP · PAGE DOWN keys.

16. Controller

How to execute operation related to the controller such as a software reset and an error reset.




Select the F4 (Ctl) key on the mode selection screen.

Controller operation items are displayed in the function key area.

16-1. Controller Items

Each time by pressing the SF key, operation items will be shifted and displayed.



16-2. Flash ROM Writing

After clearing the data from Flash ROM, write data which is saved in controller memory to Flash ROM.

Select the F1(Flash) key on the controller item screen.

Mode Transition: Ctl Flash

Flash			
Flash Write?			
Yes		No	
F1	F2	F3	F4

To write the data to Flash ROM, press the F1 (Yes) key.

If not, press the F2 (No) key. The screen returns to the controller item screen.

Flash			
Writing Flash ROM			
Please wait...			
F1	F2	F3	F4

During Flash ROM writing, "Please Wait..." blinks.

*** Never shut off the power to the controller during Flash ROM writing.**

Flash			
Complete!			
F1	F2	F3	F4

Return to the controller item screen with the ESC key.

16-3. Software Reset

Executes software reset of the controller. The data which is not written to Flash ROM will be cleared.

Select the F2 (SRst) key on the controller item screen.

Mode Transition: Ctl SRst

SRst			
Do you want to			
re - start controller?			
Yes		No	
F1	F2	F3	F4

To execute a software reset, press the F1 (Yes) key. If not, press the F2 (No) key. The screen returns to the mode selection screen.

16-4. Error Reset

Executes error reset of the controller. Reset the message-level and action-release-level errors. If the cause of the error is not solved, the error will reoccur again.

Select the F3 (ERst) key on the controller item screen.

Mode Transition: Ctl ERst

ERst			
Do you want to			
Continue?			
Yes		No	
F1	F2	F3	F4

To execute an error reset, press the F1 (Yes) key. If not, press the F2 (No) key. The screen returns to the controller item screen.

16-5. Memory Clear

Zero clears the global variable.

Select the F4(MClr) key on the controller item screen.

Mode Transition: Ctl MClr

MClr			
GVar			
F1	F2	F3	F4

Press the F1 (Gvar) key.

MClr			
Global variables			
Will be cleared. OK?			
Yes	No		
F1	F2	F3	F4

To clear memory, press the F1 (Yes) key.
If not, press the F2 (No) key. The screen returns to the previous screen.

MClr - GVar			
Complete!			
F1	F2	F3	F4

Returns to the previous screen with the ESC key.

16-6. Re-Connection

Re-connect to the controller. In a communicable state, the off-line mode can be moved to the on-line mode.

Select the F1(Cnct) key on the controller item screen.

Mode Transition: Ctl Cnct

Re - Connect			
Do you want to			
re - connect?			
Yes	No		
F1	F2	F3	F4

To re-connect, press the F1 (Yes) key.
If not, press the F2 (No) key. It will return to the previous screen.

SEL Teaching			
TP	V1.00	01106111	
TPC	V0.02	01105115	
Please wait...			
F1	F2	F3	F4

During re-connection, "Please wait..." blinks.

After a re-connection completes, it returns to the mode selection screen.

16-7. Baud Rate Change

Changes the communication baud rate between the controller and the teaching pendant.
Select the F2 (Baud) key on the controller item screen.

Mode Transition: Ctl Baud

Ctl - Baud			
Please Select - > [2]			
0:9.6 1:19.2 2:38.4			
OK Canc			
F1	F2	F3	F4

Input values corresponding to the baud rate by using the 10 keys and press the return key.
0: 9.6 1: 19.2 2: 38.4 [bps]
To change the baud rate, press the F1 (OK) key.
To cancel, press F2 (Canc) key. It returns to the previous screen.

Please wait...			
F1	F2	F3	F4

During baud rate change, "Please wait.... " blinks.

Return to the baud rate change screen.

16-8. Safety Velocity

Switches the safety velocity limit status at manual mode.
Select the F2 (SVel) key on the controller item screen.

Mode Transition: Ctl SVel

Ctl - SVel			
Efct Safety Vel - > 1			
(0:Not Efct 1: Efct)			
OK Canc			
F1	F2	F3	F4

Input 1 or 0 by using the 10 keys and press the return key.
1: Safety Velocity Limit Effect
The fastest velocity is under 250mm/sec. The setting of the programs and parameters do not affect it.
0: Safety Velocity Limit does not Effect
There in no safety velocity limit.

To switch the safety velocity limit status, press the F1 (OK) key.
To cancel, press the F2 (Canc) key.

16-9. Driver Power Recovery Request

Requests to recover driver power to the controller.

Select the F3 (RPwr) key on the controller item screen.

Mode Transition: Ctl RPwr

Recover Power			
Do you want to			
Continue?			
Yes	No		
F1	F2	F3	F4

To execute driver power recovery request, press the F1 (Yes) key. Return to the previous screen.
If not, press the F2 (No) key. Return to the previous screen.

16-10. Action Pause Release Request

Request to release action pause to the controller.

Select the F4 (RAct) key on the controller item screen.

Mode Transition: Ctl RAct

Restart Act			
Do you want to			
Continue?			
Yes	No		
F1	F2	F3	F4

To execute a action pause release request, press the F1 (Yes) key. Return to the previous screen.
If not, press the F2 (No) key. Return to the previous screen.

16-11. Driver Power Recovery Request (RPwr) and Action Pause Release Request (Ract)

(1) Driver Power Recovery Request

① How to execute Driver Power Recovery Request

Execute Driver Power Recovery Request by any of the following:

- Set 1 in I/O parameter No.44 (Input Select Function 014 = Driver Power Cut-off Release Input) and ON edge input on Input port No.14.
- From the software menu, execute Controller → Driver Power Recovery Request.
- From the mode selection screen of the teaching pendant, select Ctl (Controller operation) → RPwr (Driver Power Recovery Request) and execute.

② Case which requires executing Driver Power Recovery Request

Only the following case requires executing Driver Power Recovery Request:

- When you set 1 in I/O parameter No.44, Driver Power Cut-off cause occurs → Recover after the main cause of cut-off is solved.

(2) Action Pause Release Request:

① How to execute Action Pause Release Request

Execute Action Pause Release Request by any of the following:

- Set 1 in I/O parameter No. 35 (input selection function 005 = Action Pause Release Signal) and ON edge input on input port No.5.
- From the software menu, execute Controller (C) → Action Pause Release Request (L).
- From the mode selection screen of the teaching pendant, select Ctl (Controller operation) → Ract (Action Pause Release Request) and execute.

② Case which requires Action Pause Release Request

Each of the following cases requires executing Action Pause Release Request.

- When you set 2 on other parameter No.9 (Deadman SW recovery type = action continuation recovery [during automatic operation only]), stop according to dead man SW during automatic operation → recover after releasing stop (action pause release).
- When you set 2 on other parameter No.10 (emergency stop recovery type = action continuation recovery [during automatic operation only]), emergency stop during automatic operation → recover after emergency stop release (action pause release).
- When you set 2 on other parameter No.11 (safety gate OPEN time recovery type = action continuation recovery [during automatic operation only]), safety gate OPEN during automatic operation → recovery after safety gate CLOSE (action pause release).
- When you set 1 on I/O parameter No.36 (input selection function 006 = pausing action signal), OFF level input on input port No.6 during automatic operation (pausing action) → recover after ON level input on Input port No.6 (action pause release).

* If case (1) ② and (2) ② occur at the same time, you need to first execute Driver Power Recovery Request. After completing it, execute the Action Pause Release Request.

16-12. Absolute Reset

Executes absolute data reset.

Select the F1 (RAbs) key on the controller item screen.

Mode Transition: -

ABS Reset			
Do you want to			
Continue?			
<input checked="" type="radio"/> Yes	<input type="radio"/> No		
F1	F2	F3	F4

To execute absolute reset, press the F1 (Yes) key. If not, press the F2 (No) key. Return to the previous screen.

ABS Reset			
Select Axis - > <input type="text" value="0"/>			
OK Canc			
F1	F2	F3	F4

Axis No. Input

Input the axis No. for executing absolute reset by using the 10 keys and press the return key.

ABS Reset			
Select Axis - > <input type="text" value="1"/>			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

To continue absolute reset, press the F1 (OK) key. To cancel, press the F2 (Canc) key. To cancel on screens ①~⑥ (see below), press the F2 (Canc) key.

ABS Reset			
1. Ecdr M - Dat Rst [1]			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

① Encoder multi-rotation data reset 1

Press the F1 (OK) key.

ABS Reset			
2. Ctl Error Reset			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

② Controller error reset

Press the F1 (OK) key.

ABS Reset			
3. Servo - ON			
<input type="radio"/> OK Canc			
F1	F2	F3	F4

③ **Servo ON**
F1 (OK) key.

ABS Reset			
4. Homing			
<input type="radio"/> OK Canc			
F1	F2	F3	F4

④ **Homing**
F1 (OK) key.

ABS Reset			
5. Servo - OFF			
OK Canc			
F1	F2	F3	F4

⑤ **Servo OFF**
You can execute absolute reset with the teaching pendant application version 1.02 or later and driver CPU ver 0.23 or later with servo ON status. Do not press the F1 (OK) key but press the PAGE UP key. Then move to “⑥ Encoder multi-rotation data reset 2.”

ABS Reset			
6. Ecdr M - Dat Rst [2]			
<input type="radio"/> OK Canc			
F1	F2	F3	F4

⑥ **Encoder multi-rotation data reset 2**
Press the F1 (OK) key.

ABS Reset			
Select Axis - > 1			
OK Canc			
F1	F2	F3	F4

Return to the axis No. input screen.
 To execute absolute reset on other axes, input axis No. here and press the F1 (OK) key. Repeat ①~⑥.
 To finish absolute reset, press the ESC key.

ABS Reset			
Do you want to re - start controller?			
Yes No			
F1	F2	F3	F4

Move to the software reset screen.
 Press F1 (Yes) key to execute software reset.
 After the software reset, return to the mode selection screen.


That's all for the absolute reset operation.

16-13. Procedures for Resetting Absolute-Battery Voltage-Down Warning Error

When the absolute-encoder-battery voltage-down warning error (error code A03) occurs or a battery with no error occurring is replaced, the encoder error and software are reset. Homing in the absolute reset procedures does not have to be attempted again.

Keep the controller's main power ON until the following procedures have been completed:


- ① Turn the servo OFF for all the axes for error resetting. (Use the ON/OFF key on the teaching screen.)
- ② Replace the batteries of the axes for error resetting.
When the voltage of absolute data holding batteries decreases, replace them together with the battery unit.




Remove the bolt fixing the battery unit on the front panel with an hexagonal wrench, as shown at the left.

Pull it out as it is toward you.


Replace the battery unit with a new one.



- ③ Select the F1 (RAbs) key from the controller items screen.



- ④ To reset the encoder error, press the F1 (Yes) key.
If not, press the F2 (No) key. Return to the previous screen.



- ⑤ Axis No. Input
Input the axis No. for an encoder error reset with the 10 keys and press the return key.

ABS Reset			
Select Axis - > 1			
Ⓚ Canc			
F1	F2	F3	F4

- ⑥ To continue the encoder error reset, press the F1 (OK) key.
To cancel the encoder error reset, press the F2 (Canc) key.

ABS Reset			
7. Encoder Err Reset			
OK Canc			
F1	F2	F3	F4

- ⑦ Press the PAGE UP/PAGE DOWN key several times to display "7. Encoder Err Reset" screen.

ABS Reset			
7. Encoder Err Reset			
OK Canc			
F1	F2	F3	F4

- ⑧ To reset the encoder error, press the F1 (OK) key.
(To cancel the encoder error reset, press the F2 (Canc) key.)

ABS Reset			
7. Encoder Err Reset			
OK Canc			
F1	F2	F3	F4

- ⑨ When also resetting the encoder error reset for another axis, press the F2 (Canc) key. Return to the screen of ⑥ above and press the return key. Repeat the steps of ⑥~⑨ above in the same manner.
To complete the encoder error reset, press the ESC key.

Ctl			
Flsh ⓀRst ERst MClr→			
F1	F2	F3	F4

- ⑩ Reset software.
Display "SRst" in the function key area with the SF key.
Press the F2 (SRst) key.
For the following operations, refer to "16-3. Software Reset."

Supplement: Synchro Specification Absolute Reset

The following are descriptions about the absolute reset methods for synchro specification axes. The products ordered as the synchro specification are shipped after setting parameters to the synchro specification. However, change the parameters when executing an absolute reset.

1. Synchro Axes

Synchro axes are comprised of the master axis (main axis) and the slave axis (sub-axis). The axis of which the number is smaller becomes the master axis.

Program commands are valid only for the master axis. (Commands to the slave axis are prohibited.)


As the absolute reset methods, there is the standard procedure and the special procedure. Which procedure to be used is determined by the “each-axis parameter No. 38 encoder ABS/INC type” values for the master and slave axes.

“Each-Axis Parameter No. 38 Encoder ABS/INC Type” Values		Absolute Reset Methods
Master Axis	Slave Axis	
1	1	Special procedure
1	0	Standard procedure
0	0	

(When the value is 0 for both the master axis and the slave axis, both the axes are of the increment specification.)


Example 1) When special procedure is executed for 2-axis controller:

Mode Transition: Edit—Para—Axis



Note: To change the axis No., use the F3 (Dev-) key or F4 (Dev+) key.

Example 2) When standard procedure is executed for 2-axis controller:



2. Location Adjustment of Synchro Axes Sliders

Align the synchro axes sliders. (Physical parallel adjustment)


- (1) Adjust the relative locations between the sliders of the master and slave axes and connect them while the axes are not connected to the controller via cables (controller main power OFF).
- (2) If location adjustment cannot be made while the axes are not connected to the controller via cables (such as with the brake), follow the steps below.
 - ① Disconnect the sliders temporarily and connect the axes to the controller via cables.
 - ② Record the current values of the “each-axis parameter No. 65 synchro other axis No.” for the master and slave axes. (Record them to return to their original values in a later process.)
 - ③ To cancel the synchro function temporarily, input 0 to the “each-axis parameter No. 65 synchro other axis No.” for both the master and slave axes, and execute the data transfer to the controller, Flash ROM writing and controller restart (software reset) in this order.
 - ④ Execute an absolute reset (standard procedure) for each of the master and slave axes as a single axis.
 - ⑤ Adjust the relative locations of the sliders by jog operation, etc., and connect them.
 - ⑥ Input the values recorded in ② above to the “each-axis parameter No. 65 synchro other axis No.” for the master and slave axes, and execute the data transfer to the controller, Flash ROM writing and controller restart (software reset) in this order.

3. Special Procedure Absolute Reset

In the case of “each-axis parameter No. 38 encoder ABS/INC type”: master axis = 1 and slave axis = 1:

- (1) Record the current value of the “each-axis parameter No. 83 ABS synchro slave axis coordinate initialization cancel” for the slave axis. (Record it to return to the original value in a later process.)

Mode Transition: Edit → Para → Axis



- (2) Input 0 for the “each-axis parameter No. 83 ABS synchro slave axis coordinate initialization cancel” for the slave axis.

Para-Axis	Axis 2/2		
83:Canc	Init Coord		
[0]		
Dev-	Dev+		
F1	F2	F3	F4

Input 0 with the 10 keys and press the return key.

Press the ESC key several times to move to the Flash ROM writing screen.

Flash			
Flash Write ?			
<input checked="" type="radio"/> Yes	No		
F1	F2	F3	F4

Write the data to Flash ROM.
Press the F1 (Yes) key.

Flash			
Do you want to re-start controller?			
<input checked="" type="radio"/> Yes	No		
F1	F2	F3	F4

Execute restart (software reset).
Press the F1 (Yes) key.

(3) Execute an absolute reset according to the following special procedure (forced operation by ignoring the screen steps):

Mode Transition: Ctl RAbs

① Execute the "encoder multi-rotation data reset 1" for the slave axis.

ABS Reset			
Select Axis -> 2			
<input checked="" type="radio"/> OK	Canc		
F1	F2	F3	F4

Input the axis No. of the slave axis and press the return key.
Press the F1 (OK) key.

ABS Reset			
1. Ecdr M-Dat Rst (1)			
<input checked="" type="radio"/> OK	Canc		
F1	F2	F3	F4

Press the F1 (OK) key.

ABS Reset
2. Ctl Error Reset

OK Canc

F1	F2	F3	F4
----	----	----	----

Exit from the absolute reset mode temporarily with the ESC key, without pressing the F1 (OK) key.

Ctl			
<input type="radio"/> RAbs <input type="radio"/> SVel			
F1	F2	F3	F4

Press the F1 (RAbs) key to return to the absolute reset mode.

② Execute an absolute reset for the master axis according to the screen steps.

ABS Reset			
Select Axis -> ①			
<input type="radio"/> OK <input type="radio"/> Canc			
F1	F2	F3	F4

Input the axis No. of the mater axis and press the return key.
Press the F1 (OK) key.

ABS Reset			
1. Ecdr M-Dat Rst (1)			
<input type="radio"/> OK <input type="radio"/> Canc			
F1	F2	F3	F4

Press the F1 (OK) key.

ABS Reset			
2. Ctl Error Reset			
<input type="radio"/> OK <input type="radio"/> Canc			
F1	F2	F3	F4

Press the F1 (OK) key.

ABS Reset			
3. Servo-ON			
<input type="radio"/> OK <input type="radio"/> Canc			
F1	F2	F3	F4

Press the F1 (OK) key.

ABS Reset			
4. Homing			
<input type="radio"/> OK <input type="radio"/> Canc			
F1	F2	F3	F4

Execute homing.
Press the F1 (OK) key.

ABS Reset			
5. Servo-OFF			
OK Canc			
F1	F2	F3	F4

Press the PAGE UP key to advance the screen, without pressing the F1 (OK) key.

ABS Reset			
6. Ecdr M-Dat Rst (2)			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

Press the F1 (OK) key.

③ Execute the “encoder multi-rotation data reset 1” for the slave axis again.

ABS Reset			
Select Axis -> ②			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

Input the axis No. of the slave axis again and press the return key.
Press the F1 (OK) key.

ABS Reset			
1. Ecdr M-Dat Rst (1)			
<input checked="" type="radio"/> OK Canc			
F1	F2	F3	F4

Press the F1 (OK) key.

ABS Reset			
2. Ctl Error Reset			
OK Canc			
F1	F2	F3	F4

Exit from the absolute reset mode with the ESC key, without pressing the F1 (OK) key.

ABS Reset			
Do you want to re-start controller?			
<input checked="" type="radio"/> Yes No			
F1	F2	F3	F4

Restart the controller.
Press the F1 (Yes) key.

Return the slave-axis value for the “each-axis parameter No. 83 synchro slave axis coordinate initialization cancel” to the original value.

Mode Transition:

Slave axis

Para-Axis Axis 2/2			
83:Canc Init Coord			
[①]	
Dev-		Dev+	
F1	F2	F3	F4

Press the WRT key to transfer the data.

Para-Axis Axis 2/2			
84:Synch Vel Max			
[0]	
Dev-		Dev+	
F1	F2	F3	F4

Advance to the next parameter screen. Move to the Flash ROM writing screen with the ESC key.

Flash			
Flash Write?			
<input checked="" type="radio"/> Yes		No	
F1	F2	F3	F4

Write the data to Flash ROM.
Press the F1 (Yes) key.

Flsh			
Do you want to re-start controller?			
<input checked="" type="radio"/> Yes		No	
F1	F2	F3	F4

Restart the controller.
Press the F1 (Yes) key.

(5) Set the preset home value to uniform the coordinate values of the master and slave axes.

① If the controller 7 segment display is “rdy” while the servo is OFF, read the displayed current positions of the master and slave axes.

(If the error No. C74 real position soft limit over error occurs, reset the error. When “rdy” is displayed, the current positions can be read.)

Mode Transition: Moni ASts Posi

Position	Axis1-2/2
-0.006F	1.731F
Axis	
F1	F2
F3	F4

* If the servo is turned ON at this stage, error No. D0A driver overload error, error No. C6B deviation overflow error, error No. CA5 stop deviation overflow error, etc., occurs.

② Calculate the following:

Each-axis parameter No. 12 preset home value for slave axis [0.001 mm]

+ ((displayed current position value for master axis [mm] - displayed current position value for slave axis [mm]) × 1000)

Slave axis
↓

Para-Axis	Axis 2/2
12:Preset Home	[-977]
Dev-	Dev+
F1	F2
F3	F4

In this example:

$$-977 + ((-0.006 - 1.731) \times 1000) = -2714$$

③ Input the calculation result in ② above to the “each-axis parameter No. 12 preset home value” for the slave axis.

Para-Axis	Axis 2/2
12:Preset Home	[-2714]
Dev-	Dev+
F1	F2
F3	F4

After pressing the return key, press the WRT key to transfer the data.

Move to the Flash ROM writing screen with the ESC key.

Flash			
Flash Write ?			
<input checked="" type="radio"/> Yes		No	
F1	F2	F3	F4

Write the data to Flash ROM.
Press the F1 (Yes) key.

Flsh			
Do you want to re-start controller?			
<input checked="" type="radio"/> Yes		No	
F1	F2	F3	F4

Restart the controller.
Press the F1 (Yes) key.

(7) Display the current positions on the teaching screen.

After turning the servo ON, execute action check by jogging. (Master axis operation)

Mode Transition:

Teac-	<u>1</u>	Axis-2/2	
61. 622N		61. 622N	
Clr	Scan	Disp Axis→	
F1	F2	F3	F4

To switch the current position screen to the input data screen, press the F3 (Disp) key.
To turn the servo ON/OFF, use the ON/OFF key.

If the error No. D0A driver overload error, error No. C6B deviation overflow error, error No. CA5 stop deviation overflow error, etc., occurs, check the following items:

- If the current position of the master axis is greatly different from that of the slave axis, setting in (5) may be wrong.
- Confirm that there are no input errors or change omissions as for the parameters below.
 - “Each-axis parameter No. 65 synchro other axis No.”
 - “Each-axis parameter No. 83 ABS synchro slave axis coordinate initialization cancel”
- Confirm that slider actions are not restrained.

4. Standard Procedure Absolute Reset

In the case of “each-axis parameter No. 38 encoder ABS/INC type:” master axis = 1 and slave axis = 0:

After “2. Location Adjustment of Synchro Axes Sliders,” execute a normal absolute reset only for the master axis.

For the operating method, refer to the Teaching Pendant Instruction Manual.

Note: The synchro axis for which the standard procedure absolute reset has been executed does not have the function of correcting the slider displacement during power OFF after the servo is turned ON.

© About Error Level Management

Error level	Origin of System Error Assignment	Error No. (HEX)	Indication (7SEG, DISPLAY, etc.)	Error list	Error LED output	Program operation		Error reset	Note
						Other parameter No. 4 = 0	Other parameter No. 4 = 1		
Secret level	MAIN Application	800 - 88F							Special maintenance error level
	MAIN Core	890 - 8AF		○					
	PC	8B0 - 8DF							
	TP	8E0 - 8FF							
Message level	MAIN Application	900 - 93F							Indicates Status, Input Error, etc.
	MAIN Core	940 - 97F							
	PC	980 - 9AF		△ (Battery-related and field-bus-related errors are registered in the error list.)					
	PC (Update tool)	9B0 - 9BF							
	TP	9C0 - 9FF							
	Flash ACK Time Out	A00 - A6F		○					
	MAIN Core	A70 - A9F							
	PC	AA0 - ACF							
	TP	AD0 - AFF							
	MAIN Application	B00 - B9F							
Action Release level	MAIN Core	BA0 - BBF							Errors interfering with action. For any minor errors with a level lower than this, error release is attempted with the auto-reset function at the external active command (SIO/PIO) receipt.
	PC	BC0 - BDF							
	TP	BE0 - BFF		○					
	MAIN Application	C00 - CCF							
	MAIN Core	CD0 - CDF		○					
	PC	CE0 - CEF							
	TP	CF0 - CFF							
	MAIN Application	D00 - D8F							
	MAIN Core	D90 - DAF							
	PC	DB0 - DCF							
Cold start level	PC (Update tool)	DD0 - DDF							Need to turn ON power again. (CPU and OS will operate normally.)
	TP	DE0 - DFF		○					
	MAIN Application	E00 - E8F							
	MAIN Core	E90 - EBF							
	PC	EC0 - EDF							
	TP	EE0 - EFF							
System failure level	MAIN Application	FF0 - FBF							Need to turn ON power. (CPU and OS will not operate.)
	MAIN Core	FC0 - FCF							
	PC	FD0 - FDF							
	TP	FE0 - FEF							

TP: Teaching Pendant, PC: PC software



X-SEL Teaching Pendant Error List (Application Part)

(It is an error peculiar to a Teaching Pendant. Refer to the instruction manual of X-SEL controller for the error of a controller.)

Error No.	Error message	The explanation, solution, etc.
9C0	Input data error	Input data error. Check the input data.
9C1	Input data too small	Too-small input data. Check the allowable input range.
9C2	Input data too large	Too-large input data. Check the allowable input range.
9C3	SEL Cmnd Input Error	SEL command input error. Invalid data is input for the SEL command.
9C4	Inputting Conditions are not allowed	Input-condition input prohibition error. The input condition is used in the step where use of such condition is not allowed.
9C5	Input Condition Data Error	Input condition data error. An invalid value is input for the input condition.
9C6	Input Condition is out of range	Input condition out-of-range error. A value out of the input range is input for the input condition.
9C7	No Input Condition yet	Input-condition no input error. No input condition is input in the step where such condition is essential.
9C8	Undefined Symbol (Input Condition)	Undefined symbol (input condition) use error. An undefined symbol is used for the input condition.
9C9	Operand not inputted (Oprnd1)	Operand 1 no input error. The operand 1 is not input in the step where the operand 1 is essential.
9CA	Operand not inputted (Oprnd2)	Operand 2 no input error. The operand 2 is not input in the step where the operand 2 is essential.
9CB	Operand not inputted (Oprnd3)	Operand 3 no input error. The operand 3 is not input in the step where the operand 3 is essential.
9CC	Inputting Oprnd is not allowed (Oprnd1)	Operand 1 input prohibition error. The operand 1 is used in the step where use of the operand 1 is prohibited.
9CD	Inputting Oprnd is not allowed (Oprnd2)	Operand 2 input prohibition error. The operand 2 is used in the step where use of the operand 2 is prohibited.
9CE	Inputting Oprnd is not allowed (Oprnd3)	Operand 3 input prohibition error. The operand 3 is used in the step where use of the operand 3 is prohibited.
9CF	Operand1 is invalid	Operand 1 data error. An invalid data is input for the operand 1. Check the data.
9D0	Operand2 is invalid	Operand 2 data error. An invalid data is input for the operand 2. Check the data.
9D1	Operand3 is invalid	Operand 3 data error. An invalid data is input for the operand 3. Check the data.
9D2	Inputted Operand is out of range (Oprnd1)	Operand 1 input out-of-range error. A value out of the allowable input range is input for the operand 1.
9D3	Inputted Operand is out of range (Oprnd2)	Operand 2 input out-of-range error. A value out of the allowable input range is input for the operand 2.
9D4	Inputted Operand is out of range (Oprnd3)	Operand 3 input out-of-range error. A value out of the allowable input range is input for the operand 3.
9D5	Undefined symbol (Oprnd1)	Operand 1 undefined symbol use error. An undefined symbol is used for the operand 1.

9D6	Undefined symbol (Oprnd2)	Operand 2 undefined symbol use error. An undefined symbol is used for the operand 2.
9D7	Undefined symbol (Oprnd3)	Operand 3 undefined symbol use error. An undefined symbol is used for the operand 3.
9D8	Symbol type error (Oprnd1)	Operand 1 symbol type error. A symbol of the type not allowable for the operand 1 or outside of the scope is used.
9D9	Symbol type error (Oprnd2)	Operand 2 symbol type error. A symbol of the type not allowable for the operand 2 or outside of the scope is used.
9DA	Symbol type error (Oprnd3)	Operand 3 symbol type error. A symbol of the type not allowable for the operand 3 or outside of the scope is used.
9DB	Symbol type error (Input Condition)	Input-condition symbol type error. A symbol of the type not allowable for the input condition or outside of the scope is used.
9DC	Invalid Symbol String	Symbol string error. An invalid character is used at the head of the symbol or in the character string.
9DD	Multiple declaration of a Symbol	Symbol multiple declaration error. The same symbol has multiple definitions.
9DE	Symbol value not inputted	Symbol value no input error. No symbol-defined value is input.
9E0	Servo OFF while in Action	Servo OFF while in action. An action command is given to the axis with the servo OFF. Turn on the servo first.
9E1	Not yet Homed MOVE	Movement/continuous movement prohibition error at not-yet-homed time. Complete homing first.
9E2	Not yet Homed TEACH	Teaching prohibition error at not-yet-homed time. Complete homing first.
9E3	Function not Supported	Unsupported function error. An unsupported function is attempted to execute.
9E4	Encoder type error	Encoder type error. Check the ABS/INC type (each-axis parameter No. 38) of the operation target axis.
9E5	Axis number error	Axis No. error. The specification of the axis No. is invalid.
9E6	No effective axis	No effective axis error. There is no effective axis that can be edited and operated. Check the effective axis pattern (all-axis common parameter No. 1).
9E7	EEPROM write error (1)	EEPROM write error.
9E8	EEPROM write error (3)	EEPROM write error.
9E9	EEPROM read error (4)	EEPROM read error.
9EA	EEPROM read error (5)	EEPROM read error.
9EB	Password error	Password error. The password is invalid.
9EC	Position Data has been changed.	Movement/continuous movement prohibition error at position data change time. After writing the changed data in the controller, make a reattempt.

9ED	Can not edit while running program (TP)	Program edit prohibition error while running. Editing operation cannot be performed for the running program. Exit from the program first.
9EE	Too many Symbol Definitions	Excessive number of symbol definitions.
9EF	Can not reset M-Dat when servo is ON.	Absolute encoder multi-rotation data reset prohibition error at servo ON time.
DE0	Receive Data Invalid	Received data string error (TP). The received data has an error. When it is not eliminated even through re-connection, contact the manufacturer.
DE1	Header Logic Error (IAI Protocol Send)	IAI protocol send data header logic error
DE2	Command ID Logic Err (IAI Protocol Send)	IAI protocol send data command ID logic error
DE3	Receive Data Error (IAI Protocol Recv)	IAI protocol receive data error
DE4	Response Time-out (IAI Protocol Recv)	IAI protocol response time-out error
DE5	Overrun Error (Master Mode)	Overrun error (in Master mode)
DE6	Framing Error (Master Mode)	Framing error (in Master mode)
DE7	Parity Error (Master Mode)	Parity error (in Master mode)
DE8	Send Que Overflow (Master Mode)	SCI send queue overflow (in Master mode)
DE9	Receive Que Overflow (Master Mode)	SCI receive queue overflow (in Master mode)
DEA	Send Buffer Overflow (IAI Protocol Send)	IAI protocol send buffer overflow
DEB	Receive Buffer Overflow (Master Mode)	IAI protocol receive buffer overflow (in Master mode)
DEC	Send Que Overflow (IAI Protocol Send)	IAI protocol send queue overflow
DED	Receive Que Overflow (IAI Protocol Recv)	IAI protocol receive queue overflow
DEE	CTL Not Connected	Controller no connection error. Communications cannot be established or an unsupported controller is connected.

X-SEL Teaching Pendant Error List (Core Part)

(It is an error peculiar to a Teaching Pendant. Refer to the instruction manual of X-SEL controller for the error of a controller.)

Error No.	Error message	The explanation, solution, etc.
AE0	Overrun error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AE1	Framing error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AE2	SCI break detection error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AE3	Parity error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AE4	Motorola S checksum error	The update program file has an error. Check the file.
AE5	Motorola S record format error	The update program file has an error. Check the file.
AE6	Motorola S load address error	The update program file has an error. Check the file.
AE7	Motorola S write address over error	The update program file has an error. Check the file.
AE8	Flash ROM timing limit excess error (write)	Flash ROM write has timed out (during update).
AE9	Flash ROM timing limit excess error (erase)	Flash ROM erase has timed out (during update).
AEA	Flash ROM verify error	Flash ROM erase/write is invalid (during update).
AEB	Flash ROM ACK time-out	Flash ROM erase/write is invalid (during update).
AEC	IAI protocol header error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AED	IAI protocol checksum error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AEE	IAI protocol terminal ID error	There is a communication error. Check noise, connecting equipment, communication setting, etc.
AEF	IAI protocol command ID error	There is a communication error. Check noise, connecting equipment, communication setting, etc.



Change History

Revision Date	Revision Description
2012.11	<p data-bbox="427 459 582 488">Ninth Edition</p> <ul data-bbox="459 510 957 616" style="list-style-type: none"><li data-bbox="459 510 890 539">• Contents changed in Safety Guide<li data-bbox="459 546 831 575">• List of Support Models added<li data-bbox="459 582 957 611">• “Change History” added to the last page



IAI Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan
TEL +81-54-364-5105 FAX +81-54-364-2589
website: www.iai-robot.co.jp/

Technical Support available in USA, Europe and China

IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505
TEL (310) 891-6015 FAX (310) 891-0815
Chicago Office: 110 East State Parkway, Schaumburg, IL 60173
TEL (847) 908-1400 FAX (847) 908-1399
Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066
TEL (678) 354-9470 FAX (678) 354-9471
website: www.intelligentactuator.com

IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany
TEL 06196-88950 FAX 06196-889524

IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China
TEL 021-6448-4753 FAX 021-6448-3992
website: www.iai-robot.com