




Touch Panel Display RCM-PM-01

Operating Manual Third Edition



Please Read Before Use

Thank you for purchasing our product.

This Operating Manual describes all necessary information items to operate this product safely such as the operation procedure, structure and maintenance procedure.

Before the operation, read this manual carefully and fully understand it to operate this product safely.

The enclosed CD/DVD in this product package includes the Operating Manual for this product. For the operation of this product, print out the necessary sections in the Operating Manual or display them using the personal computer.

After reading through this manual, keep this Operating Manual at hand so that the operator of this product can read it whenever necessary.

[Important]

- This Operating Manual is original.
- The product cannot be operated in any way unless expressly specified in this Operating Manual. IAI shall assume no responsibility for the outcome of any operation not specified herein.
- Information contained in this Operating Manual is subject to change without notice for the purpose of product improvement.
- If you have any question or comment regarding the content of this manual, please contact the IAI sales office near you.
- Using or copying all or part of this Operating Manual without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.

Table of Contents

Safety Guide.....	1
Caution in Handling	6
Support Models	7
1. General Information about Touch Panel Display	9
1.1 Before Installation	9
1.2 Dimensional Drawing	10
1.3 Wiring	10
1.3.1 COM Port (Power: RS422/RS485)	10
1.3.2 Connection	11
1.4 Body Installation Example	14
1.5 Check before Trial Run	14
1.6 Option/Repair Part	14
2. Functions and Specifications of Touch Panel Display	15
2.1 Specifications	15
2.2 Description of Each Part	16
3. Connection with/Disconnection from Controller	17
3.1 Connection of Touch Panel Display	17
3.2 Disconnection of Touch Panel Display	17
4. Operation: Mode Flow Chart	18
4.1 Initial Screen upon Power-on, Japanese/English Select Screen and TP "MANU" Mode Screen	24
4.2 Axis (Controller) Select (upon Power-on)	26
4.3 Menu Select	27
4.4 Axis (Controller) select	29
4.5 Monitor	30
4.6 TP Operation Mode	33
4.7 Alarm Display	34
4.8 Edit	35
4.8.1 Basic Operation	36
4.8.2 Position Data Table Contents	40
4.8.3 Data New Input	46
4.8.4 Data Modification	72
4.9 Move	73
4.9.1 Basic Operation	73
4.10 Parameters	85
4.11 Display	90

4.12 Restart	94
4.13 Version	95
5. GATEWAY MENU	96
6. Message Area	99
6.1 Touch Panel Display Message Level Error	99
6.2 Controller Error	99
7. Warranty	100
7.1 Warranty Period	100
7.2 Scope of Warranty	100
7.3 Honoring Warranty	100
7.4 Limited Liability	100
7.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications	101
7.6 Other Items Excluded from Warranty	101
* Appendix Touch Panel Display Error Message	102
Change History	103

Safety Guide

“Safety Guide” has been written to use the machine safely and so prevent personal injury or property damage beforehand. Make sure to read it before the operation of this product.

Safety Precautions for Our Products

The common safety precautions for the use of any of our robots in each operation.

No.	Operation Description	Precautions
1	Model Selection	<ul style="list-style-type: none">• This product has not been planned and designed for the application where high level of safety is required, so the guarantee of the protection of human life is impossible. Accordingly, do not use it in any of the following applications.<ol style="list-style-type: none">1) Medical equipment used to maintain, control or otherwise affect human life or physical health.2) Mechanisms and machinery designed for the purpose of moving or transporting people (For vehicle, railway facility or air navigation facility)3) Important safety parts of machinery (Safety device, etc.)• Do not use it in any of the following environments.<ol style="list-style-type: none">1) Location where there is any inflammable gas, inflammable object or explosive2) Place with potential exposure to radiation3) Location with the ambient temperature or relative humidity exceeding the specification range4) Location where radiant heat is added from direct sunlight or other large heat source5) Location where condensation occurs due to abrupt temperature changes6) Location where there is any corrosive gas (sulfuric acid or hydrochloric acid)7) Location exposed to significant amount of dust, salt or iron powder8) Location subject to direct vibration or impact• Do not use the product outside the specifications. Failure to do so may considerably shorten its life and cause a product breakdown or facility operation stop.
2	Transportation	<ul style="list-style-type: none">• Consider well so that it is not bumped against anything or dropped during the transportation.• Transport it using an appropriate transportation measure.• Do not step or sit on the package.• Do not put any heavy thing that can deform the package, on it.• When using a crane capable of 1t or more of weight, have an operator who has qualifications for crane operation and sling work.• When using a crane or equivalent equipments, make sure not to hang a load that weighs more than the equipment's capability limit.• Use a hook that is suitable for the load. Consider the safety factor of the hook in such factors as shear strength.• Do not get on the load that is hung on a crane.• Do not leave a load hung up with a crane.• Do not stand under the load that is hung up with a crane.
3	Storage and Preservation	<ul style="list-style-type: none">• The storage and preservation environment conforms to the installation environment. However, especially give consideration to the prevention of condensation.





No.	Operation Description	Precautions
4	Installation and Start	<p>(1) Installation of Robot Main Body and Controller, etc.</p> <ul style="list-style-type: none"> ● Make sure to securely hold and fix the product (including the work part). A fall, drop or abnormal motion of the product may cause a damage or injury. ● Do not get on or put anything on the product. Failure to do so may cause an accidental fall, injury or damage to the product due to a drop of anything, malfunction of the product, performance degradation, or shortening of its life. ● When using the product in any of the places specified below, provide a sufficient shield. <ol style="list-style-type: none"> 1) Location where electric noise is generated 2) Location where high electrical or magnetic field is present 3) Location with the mains or power lines passing nearby 4) Location where the product may come in contact with water, oil or chemical droplets <p>(2) Cable Wiring</p> <ul style="list-style-type: none"> ● Use our company's genuine cables for connecting between the actuator and controller, and for the teaching tool. ● Do not scratch on the cable. Do not bend it forcibly. Do not pull it. Do not coil it around. Do not insert it. Do not put any heavy thing on it. Failure to do so may cause a fire, electric shock or malfunction due to leakage or continuity error. ● Perform the wiring for the product, after turning OFF the power to the unit, so that there is no wiring error. ● When the direct current power (+24V) is connected, take the great care of the directions of positive and negative poles. If the connection direction is not correct, it might cause a fire, product breakdown or malfunction. ● Connect the cable connector securely so that there is no disconnection or looseness. Failure to do so may cause a fire, electric shock or malfunction of the product. ● Never cut and/or reconnect the cables supplied with the product for the purpose of extending or shortening the cable length. Failure to do so may cause the product to malfunction or cause fire. <p>(3) Grounding</p> <ul style="list-style-type: none"> ● Make sure to perform the grounding of type D (Former Type 3) for the controller. The grounding operation should be performed to prevent an electric shock or electrostatic charge, enhance the noise-resistance ability and control the unnecessary electromagnetic radiation.

No.	Operation Description	Precautions
4	Installation and Start	<p>(4) Safety Measures</p> <ul style="list-style-type: none"> • When the product is under operation or in the ready mode, take the safety measures (such as the installation of safety and protection fence) so that nobody can enter the area within the robot's movable range. When the robot under operation is touched, it may result in death or serious injury. • Make sure to install the emergency stop circuit so that the unit can be stopped immediately in an emergency during the unit operation. • Take the safety measure not to start up the unit only with the power turning ON. Failure to do so may start up the machine suddenly and cause an injury or damage to the product. • Take the safety measure not to start up the machine only with the emergency stop cancellation or recovery after the power failure. Failure to do so may result in an electric shock or injury due to unexpected power input. • When the installation or adjustment operation is to be performed, give clear warnings such as "Under Operation; Do not turn ON the power!" etc. Sudden power input may cause an electric shock or injury. • Take the measure so that the work part is not dropped in power failure or emergency stop. • Wear protection gloves, goggle or safety shoes, as necessary, to secure safety. • Do not insert a finger or object in the openings in the product. Failure to do so may cause an injury, electric shock, damage to the product or fire. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity.
5	Teaching	<ul style="list-style-type: none"> • Perform the teaching operation from outside the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. • When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. • When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. • Place a sign "Under Operation" at the position easy to see. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. <p>* Safety protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.</p>
6	Trial Operation	<ul style="list-style-type: none"> • After the teaching or programming operation, perform the check operation one step by one step and then shift to the automatic operation. • When the check operation is to be performed inside the safety protection fence, perform the check operation using the previously specified work procedure like the teaching operation. • Make sure to perform the programmed operation check at the safety speed. Failure to do so may result in an accident due to unexpected motion caused by a program error, etc. • Do not touch the terminal block or any of the various setting switches in the power ON mode. Failure to do so may result in an electric shock or malfunction.

No.	Operation Description	Precautions
7	Automatic Operation	<ul style="list-style-type: none"> • Before the automatic operation is started up, make sure that there is nobody inside the safety protection fence. • Before the automatic operation is started up, make sure that all the related peripheral machines are ready for the automatic operation and there is no error indication. • Make sure to perform the startup operation for the automatic operation, out of the safety protection fence. • In the case that there is any abnormal heating, smoke, offensive smell, or abnormal noise in the product, immediately stop the machine and turn OFF the power switch. Failure to do so may result in a fire or damage to the product. • When a power failure occurs, turn OFF the power switch. Failure to do so may cause an injury or damage to the product, due to a sudden motion of the product in the recovery operation from the power failure.
8	Maintenance and Inspection	<ul style="list-style-type: none"> • Perform the work out of the safety protection fence, if possible. In the case that the operation is to be performed unavoidably inside the safety protection fence, prepare the "Stipulations for the Operation" and make sure that all the workers acknowledge and understand them well. • When the work is to be performed inside the safety protection fence, basically turn OFF the power switch. • When the operation is to be performed inside the safety protection fence, the worker should have an emergency stop switch at hand with him so that the unit can be stopped any time in an emergency. • When the operation is to be performed inside the safety protection fence, in addition to the workers, arrange a watchman so that the machine can be stopped any time in an emergency. Also, keep watch on the operation so that any third person can not operate the switches carelessly. • Place a sign "Under Operation" at the position easy to see. • For the grease for the guide or ball screw, use appropriate grease according to the Instruction Manual for each model. • Do not perform the dielectric strength test. Failure to do so may result in a damage to the product. • When releasing the brake on a vertically oriented actuator, exercise precaution not to pinch your hand or damage the work parts with the actuator dropped by gravity. * Safety Protection Fence : In the case that there is no safety protection fence, the movable range should be indicated.
9	Modification	<ul style="list-style-type: none"> • Do not modify, disassemble, assemble or use of maintenance parts not specified based at your own discretion. • In such case, the warranty is not applied.
10	Disposal	<ul style="list-style-type: none"> • When the product becomes no longer usable or necessary, dispose of it properly as an industrial waste. • Do not put the product in a fire when disposing of it. The product may burst or generate toxic gases.

Alert Indication

The safety precautions are divided into “Danger”, “Warning”, “Caution” and “Notice” according to the warning level, as follows, and described in the Instruction Manual for each model.

Level	Degree of Danger and Damage	Symbol
Danger	This indicates an imminently hazardous situation which, if the product is not handled correctly, will result in death or serious injury.	 Danger
Warning	This indicates a potentially hazardous situation which, if the product is not handled correctly, could result in death or serious injury.	 Warning
Caution	This indicates a potentially hazardous situation which, if the product is not handled correctly, may result in minor injury or property damage.	 Caution
Notice	This indicates lower possibility for the injury, but should be kept to use this product properly	 Notice


Caution in Handling

1. Be sure the operation power of the touch 0.5N or less.
Occasionally damages if operating by the power of 0.5N or more.
2. In the case of pushing the screen of the touch panel at the same time by two points or more, the switch might work when there is a switch in the center of the pushed point.
3. Disconnect the Touch Panel Display from the PCON/ACON/SCON/ERC2 following the below.
 - * After disconnecting the Touch Panel Display from the PCON/ACON/SCON/ERC2 controller with the AUTO/MANU switch, always turn the AUTO/MANU switch to AUTO.
 - * For the PCON/ACON/ERC2 controller without the AUTO/MANU switch, always set the TP Operation Mode to "Monitor 2" before disconnecting the Touch Panel Display from the controller. (Refer to "4.6 TP Operation Mode.")
 - (Note) In the case of ERC2 or when controller setting is made by connecting the Touch Panel Display to the gateway unit or SIO converter:
 - If the Touch Panel Display is disconnected while the setting of "Teach 1" or "Teach 2" remains, I/O will become invalid and control from PLC will become impossible.
 - If the Touch Panel Display is disconnected while the setting of "Monitor 1" remains, the maximum speed will become the safety speed set for the parameters regardless of a command from PLC.
4. Insertion/Removal of Connector for Connecting Touch Panel Display and Controller

The Touch Panel Display was developed with the intention of being used while always connected to the controller by integrating the Display into an electromagnetic box or operation box.

Turn off the power to the controller before inserting or removing the connector for connecting the Touch Panel Display and controller.

Inserting or removing the connector while the power is turned ON causes a controller failure.



Support Models

The following are the versions to which we have started support:

Table 1 List of Support Models

Model Name	Support Started Version
ERC2	V1.00
ERC3*1	V2.00
PCON	V1.00
PCON-CA	V2.00
ACON	V1.00
SCON	V1.00
ROBONET	V1.00

*1 ERC3 is available to be connected only to CON mode. It is not connected to MEC mode.

(Note) Check the model to connect and the version of the Touch Panel Display. If any unsupported model is connected, unexpected movement may occur.

Corresponding Versions of Controllers

The following are the corresponding versions of connectable controllers. For any earlier versions, it is required to update them.




Model Name	Support Started Version
PCON/ERC2	v0008 or later
ACON	v0009 or later
SCON	v0015 or later

RC ROBO CYLINDER

1. General Information about Touch Panel Display

1.1 Before Installation

■ Check of Accessories

Mounting Fixture × 4	Mounting Screw × 4	Connector × 1
		


- When installing the Touch Panel Display, observe the following installation conditions and precautions:
 - Install it in a place at an ambient temperature of 0 to 50°C and relative humidity of 20 to 85% where water droplets do not splash on it.
 - When installing it onto a stuffy place such as a control panel, avoid an increase in the temperature of the display body and ensure that an ambient temperature will not exceed 50°C by performing forced cooling.
 - Avoid places which receive direct sunlight and places where condensation is likely to occur.
 - Avoid places where flammable or corrosive gas is generated and places where dust, iron powder or oily smoke is excessive.
 - Avoid places where organic solvent (thinner, benzene, etc.) or strong alkali (ammonia, caustic soda, etc.) may attach to it.
 - Avoid places near high-pressure equipment, power equipment, transmitters such as radio equipment and equipment which generates high switching surge. With regard to high voltage lines, power lines, electric power lines and COM port connection cables, install wiring using separate ducts.

■ Names of Each Part


Front View



Side View



Back View




Operation Mode
Setting Switches

COM Port


TOOL Port

- Operation Mode Setting Switches




SW No.	OFF	ON
1	<u>Always set it to OFF</u> before use.	
2	<u>Always set it to ON</u> before use.	
3	<u>Always set it to OFF</u> before use.	
4		

1.2 Dimensional Drawing



1.3 Wiring

1.3.1 COM Port (Power: RS422/RS485)



Caution: Be careful about wiring and routing to avoid exogenous noise from being applied or introduced to wiring cables. It is recommended to use shielded lines as wiring cables.

E is used to set the end station.


For the detailed wire connection by connected equipment, refer to "1.3.2 Connection".

Always use the insulated DC power supply as the power source.


For the detailed wiring, refer to "1.3.2 Connection".

1.3.2 Connection

- (1) Connection with Controller or ROBONET Gateway R Unit: Bus-Powered Connection
It is recommended to use the “controller connection cable with the emergency stop box (CB-RCM-PM-SIO030-EB)” (option) as a connection cable.




- (2) Connection with Controller or ROBONET Gateway R Unit: Self-Powered Connection




* The above is the connection diagram on the serial communication lines only. For the connection of the power supply and emergency stop line, refer to the operating manual of each controller.

(3) Connection with Multiple Controllers




* The above is the connection diagram on the serial communication lines only. For the connection of the power supply and emergency stop line, refer to the operating manual of each controller.

- * One controller can be connected to another with the controller link cable (option) and junction box shown below.



Wiring between the Touch Panel and junction must be installed by the customer.


- Controller link cable (Each one unit of the e-CON connector, junction and terminal resistor are supplied)
Model: CB-RCB-CTL002



1.4 Body Installation Example

■ Panel Cutout/Drilling Method

Appropriate Panel Thickness: 1.0 to 5.0 mm



* When mounting other parts or laying out cables for the Panel during installation, it is recommend to leave a clearance of approx. 30 to 50 mm around RCM-PM-01 in consideration of cable damage prevention and workability during installation.



Caution: Never block the body slit.

■ Installation (Including mounting fixtures used: 4 locations)

- (1) Insert the RCM-PM-01 body into the mounting plate.
- (2) Fit the mounting fixtures into the grooves of the RCM-PM-01 body, tighten screws and fix the RCM-PM-01 body onto the mounting plate.

Note 1) Screw torque: 0.1 to 0.25 Nm

Note 2) If you tighten screws excessively, the touch switches may not operate normally due to front side deformation. Tighten them to an appropriate torque.




1.5 Check before Trial Run

- Make sure that the power supply voltage and each connection are correct before turning on the power.

1.6 Option/Repair Part

- Controller connection cable with the emergency stop box (CB-PM-SIO030-EB)



2. Functions and Specifications of Touch Panel Display

This Touch Panel Display is designed to function as the Display Operation Unit to edit or display the data (position data, some parameter data, etc.) through the communication between the controllers. User adjustment such as assignment of axis numbers cannot be performed. This is intended to be used for the status monitoring and position data change during operation in the field.

(Note) It is recommended to use our Teaching Pendant or PC-compatible software for equipment installation and adjustment.


This Touch Panel Display was created exclusively for PCON, ACON, SCON, ERC2 and ROBONET.

* This is not compatible with the single version of GateWay Unit (RCM-GW-**).


2.1 Specifications

Item	Specification
Operating Ambient Temperature & Humidity	Temperature: 0° to 50°C Humidity: 10 to 85% RH (No condensation) * RH relative humidity
Environment Resistance	IP65 (In initial condition) Dust-proof and drip-proof only from the panel front
Mass	Approx. 160g

2.2 Description of Each Part



(1) Touch Panel Operation Display Screen



(2) Controller Connector

(1) Touch Panel Operation Display Screen

This is comprised of the STN monochrome LCD and touch panel.
This displays the edit and teaching contents of various set values.
Operation can be performed by the touch panel system.

(2) Controller Connector (COM Port)

This is the connector to connect with the controller.

3. Connection with/Disconnection from Controller

3.1 Connection of Touch Panel Display

- (1) Turn OFF the power to the controller.
- (2) Connect the main communication port connectors on the front panel of the controller to the Touch Panel Display controller connecting connector (COM port) by the connection cable.
- (3) Turn ON the power to the controller.

3.2 Disconnection of Touch Panel Display

- (1) Turn OFF the power to the controller.
- (2) Take OFF the connection cables from the main communication port connectors on the front panel of the controller.
- (3) Turn ON the power to the controller.

Caution: In the case of PCON, ACON, SCON, ERC2 or ROBONET, if the Touch Panel Display connected with the cable having the EMERGENCY STOP switch^{*1} is disconnected during operation, an instantaneous stop will be made and released. Therefore, equipment in operation such as the actuator will stop. Do not disconnect the Touch Panel Display connected with the cable having the EMERGENCY STOP switch^{*1} during operation.

^{*1}: Optional cable (CB-RCM-PM-SIO030-EB), etc.

Caution: In the case of the PCON, ACON or ERC2 controller not having the AUTO/MANU switch, set the Operation Mode to "Monitor 2" before disconnecting the Touch Panel Display from the controller. (Refer to "4.6 TP Operation Mode.")

In the case of ERC2 or when controller setting is made by connecting the Touch Panel Display to the gateway unit or SIO converter:

- If the Touch Panel Display is disconnected while the setting of "Teach 1" or "Teach 2" remains, I/O will become invalid and control from PLC will become impossible.
- If the Touch Panel Display is disconnected while the setting of "Monitor 1" remains, the maximum speed will become the safety speed set for the parameters regardless of a command from PLC.

(1) Positioner (PCON-PL/PO, ACON-PL/PO and SCON: Mode other than the Pulse Train Mode)

Figure 1-1: IAI Servo Motor Parameter Setting Flowchart

The flowchart illustrates the sequence of operations for setting parameters on an IAI servo motor. It begins with the 'Power ON' step, followed by the 'Title Display' (IAI logo). The user then enters the 'TP 'MANU' Mode' (Teach 1, Teach 2, Monitor 1, Monitor 2). The 'Axis Select' step allows the user to choose the axis to be set (Axis No. 00). The 'MENU' and 'MENU2' steps provide options for 'Select Monitor', 'Alarm Monitor', 'PosEdit', 'Move', 'Para Display', and 'PosEdit'.

The 'EDIT' process is detailed for various parameters:


- Position:** Set Position, Velocity, Accelerate, Decelerate, Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Velocity:** Set Velocity, Accelerate, Decelerate, Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Acceleration:** Set Accelerate, Decelerate, Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Deceleration:** Set Decelerate, Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Push:** Set Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Post band:** Set Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- Push:** Set Push, Post band, Push, PosZonet, Incremental specification, and AccDd Mode.
- PosZonet:** Set PosZonet, Incremental specification, and AccDd Mode.
- Incremental specification:** Set Incremental specification, and AccDd Mode.
- AccDd Mode:** Set AccDd Mode.

The flowchart also includes an 'Error' handling section and a 'To EDIT' step. A legend at the bottom right explains the color coding for alarm status:


- Standard: White
- Alarm occurring: Pink
- Emergency stop status: Red



4. Operation: Mode Flow Chart



The total picture of operations performed with the Touch Panel Display has the tree structure as shown below.







4.1 Initial Screen upon Power-on, Japanese/English Select Screen and TP “MANU” Mode Screen

When the Touch Panel Display is connected to the controller, power is supplied to the Touch Panel Display and operation starts.

Upon power-on, the Touch Panel operation display screen (hereinafter described as the “operation screen”) displays the logo of IAI and then displays the Japanese/English select screen.



Fig. 4.1




Fig. 4.2

The screen will change to the TP "MANU" mode screen.




Fig. 4.3

Select and touch a TP operation mode. Then, touch **OK**.

The screen will move to the Axis Select screen.

Select a TP operation mode from the following 4 modes:

- Teach 1 (PIO Non., Safety ON)
 - PIO Non.: Enables writing of position data, parameters, etc., in the controller and commands of the actuator movement system.
 - Safety ON: Keeps the maximum speed at the safety speed set for the parameters regardless of position data.
- Teach 2 (PIO Non., Safety OFF)
 - PIO Non.: Enables writing of position data, parameters, etc., in the controller and commands of the actuator movement system.
 - Safety OFF: Enables movement at the speed registered in position data.
- Monitor 1 (PIO Ena., Safety ON)
 - PIO Ena.: Enables monitoring only. Writing of position data, parameters, etc., in the controller and commands of the actuator movement system are disabled.
 - Safety ON: Keeps the maximum speed at the safety speed set for the parameters regardless of position data.
- Monitor 2 (PIO Ena., Safety OFF)
 - PIO Ena.: Enables monitoring only. Writing of position data, parameters, etc., in the controller and commands of the actuator movement system are disabled.
 - Safety OFF: Enables movement at the speed registered in position data.

4.2 Axis (Controller) Select (upon Power-on)

On the Axis Select screen, connected axes (controllers) are displayed.
(Only the powered controller(s) will be detected when power is present for the Touch Panel Display.)

Axis Select				RGW	Refresh
00	PCON	04		08	ERC2 12
01	ACON	05	SCON	09	
02	----	06		10	
03		07		11	PCON 15
					ACON

Fig. 4.4

If you touch an axis (controller) to operate, the screen will move to the MENU1 screen.

If you touch **RGW**, the screen will move to the GATEWAY MENU.
Refer to "5. GATEWAY MENU."

* This screen will be displayed even if the gateway unit is not connected.

The content explained hereinafter will be based on operation in response to the selected axis (controller).

*  indicates that a controller not supported by the Touch Panel Display is detected.

4.3 Menu Select

If you select a controller on the Axis Select screen, the MENU1 screen will be displayed.




Fig. 4.5

On the MENU1 screen, select and touch one of 5 options as it appears in Fig. 4.5.

The screen will move to the touched menu.

If you touch MENU2, the screen will move to the "MENU2" screen, which is the next menu select screen.

Categories of MENU1

- (1) Select : Axis (controller) select (Refer to 4.4)
- (2) Monitor : Controller status display (Refer to 4.5)
- (3) TPmode : Operation mode setting (Refer to 4.6)
- (4) Alarm : Alarm content detailed display (Refer to 4.7)
- (5) PosEdit : Teach and Edit function for positioned table (Refer to 4.8)

Caution: In the case of PCON-PL/PO, ACON-PL/PO or SCON (pulse train mode), the screen will not move to the EDIT menu even if you touch "PosEdit."

If you touch “MENU2” on the MENU1 screen, the MENU2 screen will be displayed.




Fig. 4.6

On the MENU2 screen, select and touch one of 5 options as it appears in Fig. 4.6.

The screen will move to the touched menu.

If you touch MENU1, the screen will return to the “MENU1” screen, which is the previous menu select screen.

Categories of MENU2

- (1) Move : Axis position move, number move, jog move (Refer to 4.9)
- (2) Param : Setting of parameters such as axis zone signal output range (Refer to 4.10)
- (3) Display : Environmental setting of setting of touch sound etc. (Refer to 4.11)
- (4) Restart : Restarting of controller (Refer to 4.12)
- (5) Version : Display of version information (Refer to 4.13)

Caution: Only some parameters can be changed.
When setting any parameter that cannot be set, use our Teaching Pendant or PC-compatible software.

4.4 Axis (Controller) select

On the Axis Select screen, connected axes (controllers) are displayed.
(Only the powered controller(s) will be detected when power is present for the Touch Panel Display.)

Axis Select				RGW	Refresh
00	PCON	04		08	ERC2 12
01	ACON	05	SCON	09	
02	----	06		10	
03		07		11	PCON 15
					ACON

Fig. 4.7

If you touch an axis (controller) to operate, the screen will move to the MENU1 screen.

If you touch **RGW**, the screen will move to the GATEWAY MENU.
Refer to "5. GATEWAY MENU."

* This screen will be displayed even if the gateway unit is not connected.



4.5 Monitor

The current position, I/O status and current value will be displayed for the controller selected through Axis (Controller) Select.





Touch **Monitor** on the MENU1 screen.


Fig. 4.8

Monitor screens are comprised of 6 screens and can be changed using the  or  key.
If you press the **MENU** key, the screen will return to the MENU1 screen.


MONITOR1 screen

MONITOR1														MENU	
Cur Pos -9999.99mm															
Velocity -9999.99mm															
Complete Pos No															
7	6	5	4	3	2	1	0								

← Displays the axis position.
← Displays the speed of the moving axis.
← Displays the axis complete position.




MONITOR2 screen



MONITOR2														MENU																																															
IN PIO pattern 1																																																													
<table border="1"> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> <tr> <td>F</td><td>E</td><td>D</td><td>C</td><td>B</td><td>A</td><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td> </tr> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td> </tr> </table>														0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0																																														
F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																														
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0																																														
OUT																																																													


Displays the PIO pattern No. set with the parameter.

Displays the IN/OUT status of the PIO pattern. The ON status is displayed as ■ and the OFF status as □.



MONITOR3 screen

MONITOR3														MENU	
Servo OFF					HOME										
ORG Sensor					AUTO										
Motor Pow					non EMG										



Servo ON/OFF : When the servo is ON, reversed characters will be displayed.

HOME : After the completion of the homing, reversed characters will be displayed.

ORG Sensor : When the origin sensor is turned ON, reversed characters will be displayed.


AUTO/MANU : Display of the AUTO/MANU status of the controller.

Motor Pow/Motor Pow OFF:
When the motor power is cut off, reversed characters will be displayed.
The entire screen will turn red.


non EMG/EMG:
When an emergency stop is made, reversed characters will be displayed.
The entire screen will turn red.

To the "Velocity" screen
on the following page:


Velocity screen




The speed of the moving axis will be displayed in graph form.
Scale will be the maximum speed of the parameter.



Current screen



The current value of the moving axis will be displayed in graph form.
Scale will be as follows:
PCON, ERC2 : Rated current
ACON, SCON : Rated current \times 3




Current screen (value/ratio)



← Displays the command current value.


← Displays the percent maximum current.



To the "MONITOR1" screen
on the previous page:

4.6 TP Operation Mode


The operation mode will be set in the manual mode (MANU).



Touch **TPmode** on the MENU1 screen.

Fig. 4.9

The TP "MANU" mode screen will be displayed.



Select and touch a TP operation mode. Then, touch **MENU**. The screen will move to the MENU1 screen.


Fig. 4.10

Select a TP operation mode from the following 4 modes:

- Teach 1 (PIO Non., Safety ON)
 - PIO Non.: Enables writing of position data, parameters, etc., in the controller and commands of the actuator movement system.
 - Safety ON: Keeps the maximum speed at the safety speed set for the parameters regardless of position data.
- Teach 2 (PIO Non., Safety OFF)
 - PIO Non.: Enables writing of position data, parameters, etc., in the controller and commands of the actuator movement system.
 - Safety OFF: Enables movement at the speed registered in position data.
- Monitor 1 (PIO Ena., Safety ON)
 - PIO Ena.: Enables monitoring only. Writing of position data, parameters, etc., in the controller and commands of the actuator movement system are disabled.
 - Safety ON: Keeps the maximum speed at the safety speed set for the parameters regardless of position data.
- Monitor 2 (PIO Ena., Safety OFF)
 - PIO Ena.: Enables monitoring only. Writing of position data, parameters, etc., in the controller and commands of the actuator movement system are disabled.
 - Safety OFF: Enables movement at the speed registered in position data.

4.7 Alarm Display

Errors occurring after a controller's power-on will be displayed.



Touch **Alarm** on the MENU1 screen.

Fig. 4.11

The AlarmList screen will be displayed.




Fig. 4.12

Alarm detailed code

(When it's 0, all the number of the detail, the address and the time will become -.)

If you press or , the previous error descriptions can be displayed.

Up to 16 previous alarm-level errors including the last (latest) error can be displayed.

If you touch **MENU**, the screen will return to the MENU1 screen.

Time lapsed from power ON

PCON-CA, ERC3 PIO Converter displays the time of occurrence.

4.8 Edit

The contents of the position data stored in the controller will be displayed.
Execute teaching and editing of the position data.




Fig. 4.13

Touch **PosEdit** on the MENU1 screen.

The password input screen is displayed before it shifts to the edit display, except when the password is '0000'.





Fig. 4.14

Input the numerical value of password with the ten keys, and touch .

The password can be set by "Password change" of the main body environment setting.

When a correct password is set, it shifts to the edit display.
The display shifts by the movement pattern.

The EDIT screen will be displayed.




Fig. 4.15

The screen will move to the JOG screen.
Teaching by jog operation can be performed.

4.8.1 Basic Operation

(1) Change of Position No.




Fig. 4.16

Position No.

If you touch or , the position No. can be incremented or decremented.




Fig. 4.17



If you touch the numeric value of No., the ten keys will be displayed.

The position No. can also be input by directly inputting a numeric value of the position No. and touching .

When stopping input, touch the key.





If you press the key, the screen will return to the MENU1 screen.


(2) Change of Position Data Table Display

EDIT screens (position data table) are comprised of 6 screens and can be changed using the  or  key. (For details, refer to “4.8.2 Position Data Table Contents.”)




If you press the **MENU** key, the screen will return to the MENU1 screen.


Position, Velocity

EDIT			MENU
Position	100.00mm		
Velocity	600.00ms		
No.511			JOG WRT








PosZone±

EDIT			MENU
PosZone+	0.00mm		
PosZone-	10.00mm		
No.511			JOG WRT








Accelerate, Decelerate

EDIT			MENU
Accelerate	0.30G		
Decelerate	0.30G		
No.511			JOG WRT








Incremental specification, Threshold

EDIT			MENU
Incremental	0		
Threshold	50%		
No.511			JOG WRT







Pos.band, Push


EDIT			MENU
Pos.band	0.10mm		
Push	70%		
No.511			JOG WRT



To PosZone±

Acc/Dcl Mode, Stop Mode

EDIT			MENU
Acc/Dcl Mode	0		
Stop Mode	4		
No.511			JOG WRT



To Position, Velocity

(3) How to Rewrite Numeric Value

An example of target position rewriting is shown below.





Fig. 4.18



(4) JOG screen




Fig. 4.23

Touch **JOG**.



Fig. 4.24

The screen will move to the JOG screen.

JOG Screen Operation

1. **SVON** : If you touch the key when the display is SVON, the servo will be turned ON.
If you touch the key when the display is SVOG, the servo will be turned OFF.
2. **HOME** : If you touch the key during servo ON, homing will be executed.
After the completion of the homing, the display will change to **HEND**.
3. **JVEL** : Select the PIO jog speed or PIO jog speed 2.
In the case of display with shadow, the jog speed will be the PIO jog speed.
In the case of display without shadow, the jog speed will be the PIO jog speed 2.
4. **INC** : If you touch the key when the display is INC, operation will change to inching.
If you touch the key when the display is JOG, operation will change to jog.
(Note) The jog speed will be the PIO jog speed or PIO jog speed 2 set with the parameter. Select the speed using **JVEL**.
The inching distance will be the PIO Inching Distance set with the parameter.
5. **← →** : The axis will perform jog or inching movement.
6. **Teac** : Teaching of the current position will be given to the position No. displayed on the screen.
After teaching, return to the position table screen of EDIT and perform writing to the controller.
7. **ESC** : The screen will return to the previous position table screen of EDIT.

4.8.2 Position Data Table Contents

The setting items of the position data table are Position, Velocity, Accelerate, Decelerate, Pos.band, Push, PosZone+, PosZone-, Incremental, Threshold, Acc/Dcl Mode and Stop Mode. They are displayed in 6 screens.

The items of PosZone+, PosZone-, Acc/Dcl Mode and Stop Mode are enabled (ON) or disabled (OFF) according to the controller type.

List of ON/OFF of Position Table According to Model


Position Table	Zone +/-		Acc/Dcl Mode			Stop Mode	
			Trapezoid	S-shape	First-order Delay	Full Servo	Auto Servo OFF
ERC2	○	PIO pattern: 3	○	×	×	○	○
ERC2-SE	○	-	○	×	×	○	×
ERC3	○	PIO pattern: 2	○	○	○	○	○
ERC3 PIO Converter	○	PIO pattern: 0, 1, 2, 4, 5	○	○	○	○	○
PCON-C/CG/CF	○	PIO pattern: 0, 1, 2, 4, 5	○	×	×	○	○
-CA	○	PIO pattern: 0, 1, 2, 4, 5	○	○	○	○	○
-CY	○	PIO pattern: 1	○	×	×	○	○
-SE	○	-	○	×	×	○	×
ACON-C/CG	○	PIO pattern: 0, 1, 2, 4, 5	○	○	○		○
-CY	○	PIO pattern: 1	○	○	○		○
-SE	○	-	○	○	○		×
SCON positioner	○	PIO pattern: 0, 1, 2, 4, 5	○	○	○		○

(1) Position

Input the target position to move the actuator to, in [mm].

- Absolute Coordinates: Input the target location by determining the distance between the original point and target position. No negative value can be input.
- Relative Coordinates: Input the target location by determining the distance between the current position and target position. Any negative value can be input (if coordinates are in the negative direction).

- (2) Vel
 - Input the speed at which the actuator will be moved, in [mm/sec]. The initial value will depend on the actuator type.
- (3) Acc/Dcc
 - Input the acceleration/deceleration at which the actuator will be moved, in [G].
Basically, use acceleration/deceleration within the catalog rated value range.
The input range allows larger value input than the catalog rated values, on the assumption that the tact time will be reduced if the transfer mass is significantly smaller than the rated value.
Make the numeric value smaller if transfer work vibrates and causes trouble during acceleration/deceleration.




The acceleration will become sudden if the numeric value is made larger and it will become gradual if the numeric value is made smaller.

Caution: Enter appropriate values for Vel and Acc/Dec in such a way as to prevent excessive impact or vibration from being applied to the actuator in consideration of the installation conditions and the shape of transferred work by referring to the “List of Actuator Specifications” in the Appendix. Increasing such values largely relates to the transfer mass and the actuator characteristics vary depending on the model, consult IAI regarding the input-limiting values.

- (4) Range
 - The “positioning operation” and “push operation” have different meanings.
Positioning operation:
It defines the distance to the target position from a position at which the position complete signal turns ON.
The default value is 0.1 mm.


Standard type

Since increasing the positioning width value hastens the next sequence operation, it becomes a factor for tact time reduction. Set the optimum value by considering the balance of the entire equipment.



However, it defines the width of the position complete signal to turn ON for the 3-point type of PCON-C/CG, ACON-C/CG and SCON and the proximity switch type of PCON-CY and ACON-CY.


3-point type and proximity switch type



Push operation:

It defines the maximum push amount from the target position in the push operation.

Set the positioning width in such a way as to prevent positioning completion before the actuator contacts work by considering mechanical variations of work.



(5) Push

- Select the positioning operation or push operation.

The default value is "0."

0 : Normal positioning operation

Other than 0 : Indicates the current-limiting value and indicates the push operation.


Caution: Always specify absolute coordinates for the 3-point type of PCON-C/CG, ACON-C/CG and SCON-C and the proximity switch type of PCON-CY and ACON-CY.
If you specify relative coordinates, a position data error will occur.
In the above case, if you specify "Push," push completion cannot be judged.

- (6) Pos Zone +/- • It defines the zone where the zone output signal of the standard type turns ON.
Individual setting is available for each target position to give flexibility.


[Setting example]

No.	Position [mm]	Pos Zone+ [mm]	Pos Zone- [mm]	Comment
0	5.00	100.00	0.00	Backward end
1	380.00	400.00	300.00	Forward end
2	200.00	250.00	150.00	Midpoint


Movement command to backward end



Movement command to forward end




Movement command to midpoint



- (7) Incremental
- Select the absolute coordinate specification or relative coordinate specification.
0: Absolute coordinate specification
1: Relative coordinate specification
- (8) LoTh
- In the case of the PCON-CF controller, the load output signal (PIO) will be output if the command torque exceeds the value (%) set to "LoTh."
Set the test range with "Pos Zone+/-".
Use it to judge whether push has been performed normally.
* For details, refer to the Operating Manual of PCON-C/CG/CF Controller.
- (9) Acc/Dcl Mode
- It defines the acceleration/deceleration characteristics.
The default value is 0.
0: Trapezoid pattern
1: S-shaped motion
2: First-order delay filter

Trapezoid pattern




* Set the acceleration and deceleration in the "Acc" and "Dcl" fields of the position table.

S-shaped motion

A curve, which is gradual at the beginning of acceleration but rises sharply halfway, is drawn.

Use it in the applications for which you want to set the acceleration/deceleration high due to tact time requirement but desire a gradual curve at the beginning of movement or immediately before stop.



- * Set the degree of the S-shaped motion with the parameter No. 56 [S-shaped motion ratio setting]. The setting unit is % and the setting range is between 0 and 100.

(The above is the image graph when 100% setting is made.)

If "0" is set, the S-shaped motion becomes invalid.


However, it will not be reflected in jogging/increment movement by PC or Teaching Pendant operation. Set the parameter with the Teaching Pendant or PC-compatible software.

(Note) It cannot be set for the ERC2 or PCON controller. The parameter No. 56 is reserved.

First-order delay filter

More gradual acceleration/deceleration curves are drawn than the linear acceleration/deceleration (trapezoid pattern).

Use this in the applications by giving micro vibrations to work during acceleration/deceleration not desired.



- * Set the degree of the first-order lag with the parameter No. 55 (constant for the position command first-order filtering). The setting unit is 0.1msec. and the setting range is between 0.0 to 100.0.

If "0" is set, the first-lag filter will become invalid.

However, it will not be reflected in jogging/increment movement by PC or Teaching Pendant operation. Set the parameter with the Teaching Pendant or PC-compatible software.

(Note) It cannot be set for the ERC2 or PCON controller. The parameter No. 55 is reserved.

- (10) Stop Mode • It defines the power saving method on standby after completion of positioning to the target position set in the "Position" field of the position number.
- 0: Invalid power saving method * The default setting is 0 (invalid).
 - 1: Auto servo OFF method. Delay time defined with the parameter No. 36
 - 2: Auto servo OFF method. Delay time defined with the parameter No. 37
 - 3: Auto servo OFF method. Delay time defined with the parameter No. 38
 - 4: Full servo control method


* Set the parameters for delay time with the Teaching Pendant or PC-compatible software.

Full servo control method

The holding current can be reduced by servo-controlling the pulse motor. The degree of reduction varies depending on the actuator model, load condition, etc., but the holding current decreases approximately by a factor of 2 to 4. No displacement occurs since this method maintains the servo ON status. The actual holding current can be checked on the monitoring screen.

Auto servo OFF method

When a given length of time has elapsed after completion of positioning, the servo OFF status is automatically entered.
(Since the holding current does not flow, the power consumption can be saved by the same amount.)
When a movement command is subsequently given from PLC, the status returns to the servo ON and the actuator starts to move.



4.8.3 Data New Input






The following 4 ways to input new position data exist:

- | | |
|-------------------|---|
| (1) Numeric Input | • Numerically input the position data directly from the ten keys at the EDIT screen. |
| (2) Direct Teach | • Turn the servo controller OFF, manually move the slider to match the desired location and read and command that location (current position) into the position table. |
| (3) Jog | • Use the arrow key to jog move and match the desired location and read that location (current position) into the position table. If you continue pressing the arrow key, the actuator will move at a specified speed (PIO jog speed, PIO jog speed 2 (parameter)). However, only the maximum speed will be gained if the maximum speed is slower than the specified speed. |
| (4) Increment | • Use the arrow key to incrementally move and match the desired location and read that location (current position) into the position table.
If you press the arrow key once, the actuator will move by a specified pitch (PIO inching distance (parameter)). |

Examples of each operation will be explained as follows.






Caution: When input position data is performed first after power-on or method of (2), (3) or (4), it is required to perform home return in advance. (Increment specification)
: Jog and Increment movement prior to homing incomplete status is possible up to the slider end. Visually, perform the interference check.








1) Homing

	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Touch JOG on the EDIT screen.		
4.	When the servo is OFF, touch SVON to put into the servo ON status.		
5.	Touch HOME .		Homing will automatically be executed.






2) Numeric Input

Example 1: 2 point continuous loop move 30mm ↔ 250mm, Speed 300mm/sec






	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Move the cursor to the position where you want to input using ↓ or ↑. Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.		
4.	Touch the numeric value of Position. The ten keys will be displayed.		For any unregistered data, the display will show "*".
5.	Touch 30 and touch ↵ .		To stop during numeric input, touch ESC . Example) With the left operation, by pressing ESC immediately after inputting 30 , the status will return to the "*" display.







	Operation	Screen	Reference
6.			<p>During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input.</p> <p>In the left screen, the initial value is set as 100mm/sec.</p>
7.	<p>Touch the numeric value of Velocity.</p> <p>The ten keys will be displayed.</p>		
8.	<p>Here, touch 3 0 0 and touch .</p>		
9.	Touch WRT .		
10.	Touch YES .		To stop rewriting, touch NO .
11.	Touch ESC .		







	Operation	Screen	Reference
12.	Match to the next position (No. 1) using	<p>Position No.</p>	
13.	Touch the numeric value of Position. The ten keys will be displayed.		
14.	Touch and touch .		To stop during numeric input, touch .
15.			<p>During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input.</p> <p>In the left screen, the initial value is set as 100mm/sec.</p>
16.	Touch the numeric value of Velocity. The ten keys will be displayed.		






	Operation	Screen	Reference
17.	Here, touch 300 and touch ↵ .		
18.	Touch WRT .		
19.	Touch YES .		
20.	Touch ESC .		
21.			

Example 2:	2 point continuous loop move	Push operation 10mm position ↔ 80mm position (Push range 5mm)
------------	------------------------------	--






	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Move the cursor to the position where you want to input using ↓ or ↑ . Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.		
4.	Touch the numeric value of Position. The ten keys will be displayed.		For any unregistered data, the display will show "*".
5.	Touch 10 and touch ↵ .		To stop during numeric input, touch ESC . Example) With the left operation, by pressing ESC immediately after inputting 10 , the status will return to the "*" display.







	Operation	Screen	Reference
6.			<p>During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input.</p> <p>In the left screen, the initial value is set as 100mm/sec.</p>
7.	Touch WRT .		
8.	Touch YES .		To stop rewriting, touch NO .
9.	Touch ESC .		
10.	Match to the next position (No. 1) using ↑ .		
11.	Touch the numeric value of Position. The ten keys will be displayed.		







	Operation	Screen	Reference
12.	Touch 80 and touch ↵ .		To stop during numeric input, touch ESC .
13.			During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input. In the left screen, the initial value is set as 100mm/sec.
14.	Touch → twice to display the Push setting screen.		
15.	Touch the numeric value of Pos.band. The ten keys will be displayed.		
16.	Input a maximum push range during push into Pos.band. In this example, input 5mm. Touch 5 and touch ↵ .		
17.	Touch the numeric value of Push. The ten keys will be displayed.		




	Operation	Screen	Reference
18.	Input the current value during push. In this example, input 30%. Touch 3 0 and touch ↵ .		
19.	Touch WRT .		
20.	Touch YES .		To stop rewriting, touch NO .
21.	Touch ESC .		
22.			

Example 3: Relative Coordinates pitch movement 30 mm → 40 mm → 50 mm....

	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Move the cursor to the position where you want to input using ↓ or ↑ . Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.	 Position No.	
4.	Touch the numeric value of Position. The ten keys will be displayed.		For any unregistered data, the display will show "*".
5.	Touch 30 and touch ↵ .		To stop during numeric input, touch ESC . Example) With the left operation, by pressing ESC immediately after inputting 30 , the status will return to the "*" display.

	Operation	Screen	Reference
6.			<p>During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input.</p> <p>In the left screen, the initial value is set as 100mm/sec.</p>
7.	Touch WRT .		
8.	Touch YES .		To stop rewriting, touch NO .
9.	Touch ESC .		
10.	Match to the next position (No. 1) using ↑ .		
11.	Touch the numeric value of Position. The ten keys will be displayed.		






	Operation	Screen	Reference
12.	Touch 10 and touch ↵ .		To stop during numeric input, touch ESC .
13.			During new position data registration, the initial values set with the user parameters for Velocity, Accelerate, Decelerate, etc., will automatically be input. In the left screen, the initial value is set as 100mm/sec.
14.	Touch → four times to display the Incremental setting screen.		
15.	Touch the numeric value of Incremental. The ten keys will be displayed.		
16.	Touch 1 and touch ↵ .		
17.	Touch WRT .		







	Operation	Screen	Reference
18.	Touch YES .		To stop rewriting, touch NO .
19.	Touch ESC .		
20.			







3) Direct Teach (Method: Manually moving the actuator, matching to the desired position and teaching that position into the position table)





When direct teach operation is performed first after power-on, it is required to perform homing operation in advance. (Refer to page 47.) (In the case of increment specification)

Example: 2 point continuous loop Point A → Point B, speed 300mm/sec

	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Move the cursor to the position where you want to input using ↓ or ↑ . Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.	 Position No.	
4.	Touch JOG .		
5.	When the servo is ON, touch SVOF to put into the servo OFF status.		

	Operation	Screen	Reference
6.	Manually move the slider and match to the desired position.		
7.	Touch Teac .		
8.	Touch ESC .		
9.	Touch WRT .		<p>The Position on the EDIT screen will be the position to which teaching is given.</p> <p>As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)</p>
10.	Touch YES .		To stop rewriting, touch NO .
11.	Touch ESC .		






	Operation	Screen	Reference
12.	Match to the next position (No. 1) using  .		
13.	Touch JOG .		
14.	Manually move the slider and match to the desired position.		
15.	Touch Teac .		
16.	Touch ESC .		






	Operation	Screen	Reference
17.	Touch WRT .		<p>The Position on the EDIT screen will be the position to which teaching is given.</p> <p>As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)</p>
18.	Touch YES .		To stop rewriting, touch NO .
19.	Touch ESC .		
20.			







- 4) Jog (Method: Jogging the actuator with the direction arrow key (← or →), matching to the desired position and teaching that position [current position] into the position table)
 If you continue touching the direction arrow key (← or →), the actuator will move at a specified speed (PIO jog speed or PIO jog speed 2).
 However, only the maximum speed will be gained if the maximum speed is slower than the specified speed.





When jog operation is performed first after power-on, it is required to perform home return operation in advance. (Refer to page 47.) (Increment specification)

Example: 2 point continuous loop Point A → Point B, speed 300mm/sec

Operation	Screen	Reference
1. Touch PosEdit on the MENU1 screen.		
2. The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3. Move the cursor to the position where you want to input using ↓ or ↑. Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.		
4. Touch JOG .		
5. When the servo is OFF, touch SVON to put into the servo ON status.		

	Operation	Screen	Reference
6.	Select the speed with JVEL . Move the slider with ← or → and match to the desired position. ← : Positive direction of the displayed coordinates → : Negative direction of the displayed coordinates		JVEL : Selection of speed Display with shadow: PIO jog speed (parameter) Display without shadow: PIO jog speed 2 (parameter)
7.	Touch Teac .		
8.	Touch ESC .		
9.	Touch WRT .		The Position on the EDIT screen will be the position to which teaching is given. As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)
10.	Touch YES .		To stop rewriting, touch NO .






	Operation	Screen	Reference
11.	Touch ESC .		
12.	Match to the next position (No. 1) using ↑ .		
13.	Touch JOG .		
14.	Move the slider with ← or → and match to the next desired position.		
15.	Touch Teac .		
16.	Touch ESC .		











	Operation	Screen	Reference
17.	Touch WRT .		<p>The Position on the EDIT screen will be the position to which teaching is given.</p> <p>As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)</p>
18.	Touch YES .		To stop rewriting, touch NO .
19.	Touch ESC .		
20.			






- 5) Inching (Method: Inching the actuator with the direction arrow key (← or →), matching to the desired position and teaching that position [current position] into the position table)
If you touch the direction arrow key (← or →), the actuator will move by a specified distance (PIO Inching Distance). Finer movement than jogging is possible.






When inching movement is performed first after power-on, it is required to perform home return operation in advance. (Refer to page 47.) (Increment specification)

Example: 2 point continuous loop Point A → Point B, speed 300mm/sec

	Operation	Screen	Reference
1.	Touch PosEdit on the MENU1 screen.		
2.	The password input screen will be displayed if the password is set to other than '0000'. Input the password.		The password of the edit can be set by "Password change" of the main body environment setting.
3.	Move the cursor to the position where you want to input using ↓ or ↑. Alternatively, touch the position No. The ten keys will be displayed and you can also set the position No. directly.		
4.	Touch JOG .		
5.	When the servo is OFF, touch SVON to put into the servo ON status.		

	Operation	Screen	Reference
6.	Touch INC to change to inching operation.		
7.	Move the slider with  or  and match to the desired position.  : Positive direction of the displayed coordinates  : Negative direction of the displayed coordinates		Inching Distance: PIO Inching Distance (parameter)
8.	Touch Teac .		
9.	Touch ESC .		
10.	Touch WRT .		The Position on the EDIT screen will be the position to which teaching is given. As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)
11.	Touch YES .		To stop rewriting, touch NO .

	Operation	Screen	Reference
12.	Touch ESC .		
13.	Match to the next position (No. 1) using ↑ .		
14.	Touch JOG .		
15.	Move the slider with ← or → and match to the next desired position.		
16.	Touch Teac .		

	Operation	Screen	Reference
17.	Touch ESC .		
18.	Touch WRT .		<p>The Position on the EDIT screen will be the position to which teaching is given.</p> <p>As for the Velocity, Accelerate, Decelerate, etc., the initial value set with the user parameter will automatically be input. In the example at the left, the initial value is 300mm/sec. (Only during position data input)</p>
19.	Touch YES .		To stop rewriting, touch NO .
20.	Touch ESC .		
21.			

4.8.4 Data Modification

You may write over all of the position data.

Similar to new input, the following 4 cases exist:

- | | |
|-------------------|--|
| (1) Numeric Input | : Manually enter the position data directly from Touch Panel Display ten keys. |
| (2) Direct Teach | : Turns the servo OFF, manually move the slider to the desired location and read that location (current position) into the position table. |
| (3) Jog | : Use the arrow keys to jog to the desired location and read that location (current position) into the position table. |
| (4) Increment | : Use the arrow keys to incrementally move and read that location (current position) into the position table. |


Caution during data modification:

- * As for manual input, the data entered will erase the old data.
- * The position will be updated only when the Return key is pressed to read in the current location (direct teach, jog, increment). It does not influence speed and others.
- * Once the position data is cleared, the previous data will no longer remain anywhere. Therefore, when the next position data is registered, any data other than position will be default values. When clearing to re-set the push assign position data, be sure to confirm all items of the position data to input required data.

4.9 Move

Movement toward a position registered in the position data table, movement by directly setting a position to move to and jog movement are possible.

4.9.1 Basic Operation



Touch **Move** on the MENU2 screen.

Fig. 4.25

(1) Pos (Position) Move

The actuator will move to a position registered in the position data table.




Fig. 4.26

Touch **Pos**.




Fig. 4.27

Touch **Pos-** or **Pos+** and set the No. of the target position to move to (PosNo.).




Fig. 4.28

If you touch **START**, the actuator will move to the set target position.
To stop during movement, touch **STOP**.

Caution: Always turn the servo ON (SVOF display) and perform homing (after completion, HEND will be displayed) before movement.

If you touch **MENU**, the screen will return to the MoveMenu.

* Pos (Position) Move Speed

The actuator will move at a speed set in the position table.

The speed can be changed by changing OVRD (speed override ratio).

Caution: The maximum speed will be the safety speed set for the parameter if the TP operation mode is set to Teach 1 (Safety: ON).

Caution: The controller which decides the position and outputs completion outputs the completion position after positioning is completed, and turns ON the positioning completion output.
However, positioning completion ON is not done when missing in the pressing mode.

Other Operations




Fig. 4.29

1. SVON : If you touch the key when SVON is displayed, the servo will be turned ON.
If you touch the key when SVOF is displayed, the servo will be turned OFF.
2. HOME : If you touch the key when the servo is ON, homing will be performed.
After the completion of the homing, the display will change to HEND.
3. OVRD : Set the speed override ratio.
If you touch OVRD xxx%, the ten keys will be displayed.
Input a numeric value and touch . The ratio (%) will be set.

(2) Num Move

The actuator will move through direct setting of a position to move to.




Fig. 4.30

Touch **Num**.




Fig. 4.31

Touch the numeric value of Tar Pos.





Fig. 4.32

Input the target position to move to and touch .

The target position will be input.




Fig. 4.33

If you touch **START**, the actuator will move to the set target position.
To stop during movement, touch **STOP**.

Caution: Always turn the servo ON (SVON display) and perform homing (after completion, HEND will be displayed) before movement.

If you touch **MENU**, the screen will return to the MoveMenu screen.

Caution: The controller which decides the position and outputs completion outputs the completion position after positioning is completed, and turns ON the positioning completion output.
However, positioning completion ON is not done when missing in the pressing mode.

Other Operations

Num	MOVE	etc.	MENU
Cur Pos	200.00 mm		
Tar Pos	200.00 mm		
HEND	SVOF	START	STOP

Fig. 4.34

1. SVON : If you touch the key when SVON is displayed, the servo will be turned ON.
If you touch the key when SVOF is displayed, the servo will be turned OFF.
2. HOME : If you touch the key when the servo is ON, homing will be performed.
After the completion of the homing, the display will change to HEND.
3. etc. : Set Velocity, Accelerate and Decelerate when performing direct move.

MOVE etc Screen

MOVE etc	ESC
Velocity	600.00 ms
Accelerate	0.30 G
Decelerate	0.30 G


Fig. 4.35

(3) Jog Move

The actuator will move by jogging.


However, teaching of a position cannot be given to the position data.

To perform jog move for teaching operation, execute jog operation by touching JOG on EDIT.



Touch **Jog**.

Fig. 4.36









The JOG screen will be displayed.



Fig. 4.37

JOG Screen Operation

1. SVON : If you touch the key when SVON is displayed, the servo will be turned ON.
If you touch the key when SVOF is displayed, the servo will be turned OFF.
2. HOME : If you touch the key when the servo is ON, homing will be performed.
After homing, the display will change to HEND.
3. JVEL : Select the PIO jog speed or PIO jog speed 2.
In the case of display with shadow, the jog speed will be the PIO jog speed.
In the case of display without shadow, the jog speed will be the PIO jog speed 2.
4. INC : If you touch the key when the display is INC, operation will change to inching.
If you touch the key when the display is JOG, operation will change to jog.
(Note) The jog speed will be the PIO jog speed or PIO jog speed 2 set with the parameter. Select the speed using JVEL.
The inching distance will be the PIO Inching Distance set with the parameter.
5. ← → : The axis will perform jog or inching movement.
6. MENU : The screen will return to the MoveMENU screen.








1) Pos (Operation: Registered position data number assigned move)





Example:	Current position → Move towards position number 2, 3		
	Operation	Screen	Reference
1.	Touch Move on the MENU2 screen.		
2.	Touch Pos on the MoveMENU edit screen.		
3.	When the servo is OFF, touch SVON to put into the servo ON status.		
4.	If homing has not been executed, touch HOME to perform homing.		
5.	Assign PosNo. (position No.) with Pos- or Pos+ . In this example, set position No. 2.		
6.	If you touch START , the actuator will move from the current position to the location of position No. 2. When stopping during movement, touch STOP .		<p>The move speed can be changed by touching “OVRDxxx%” and changing the override value.</p> <p>(Note) The maximum speed will be the safety speed set for the parameter if the TP operation mode is set to Teach 1 (Safety: ON).</p>

	Operation	Screen	Reference
7.	When moving towards No. 3 position continuously, assign 3 to PosNo. with Pos- or Pos+ .		
8.	If you touch START , the actuator will move from the current position to position No. 3. When stopping during movement, touch STOP .		If you touch MENU , the screen will return to the MoveMENU screen.






Caution: When moving towards position in push mode
 After the actuator pushes the work and position complete output turns ON, the actuator is in a state of continuously pressing the work.
 Be extremely careful about handling at this time.

2) Num (Operation: Target position directly-assigned move)







Example:	Current position → Move towards target position 100mm (Num)		
	Operation	Screen	Reference
1.	Touch Move on the MENU2 screen.		
2.	Touch Num on the MoveMENU edit screen.		
3.	When the servo is OFF, touch SVON to put into the servo ON status.		
4.	If homing has not been executed, touch HOME to perform homing.		
5.	Touch the numeric value of Tar Pos. The ten keys will be displayed.		
6.	Touch 100 for Tar Pos and touch  .		

	Operation	Screen	Reference
7.	Touch etc. to display the MOVE etc screen.		
8.	<p>Touch the numeric value of the item to change from among Velocity, Accelerate and Decelerate.</p> <p>The ten keys will be displayed.</p> <p>Input a numeric value with the ten keys and touch .</p> <p>After setting the numeric value, touch ESC.</p>		In the left screen, 600 is set as Velocity.
9.	<p>If you touch START, the actuator will move from the current position to the target position.</p> <p>When stopping during movement, touch STOP.</p>		(Note) The maximum speed will be the safety speed set for the parameter if the TP operation mode is set to Teach 1 (Safety: ON).

- 3) Jog (Move) Move the actuator by jogging with the direction arrow key (← or →). However, no teaching can be given to the position table.
 If you continue touching the direction arrow key (← or →), the actuator will move at a specified speed (PIO jog speed or PIO jog speed 2).
 However, only the maximum speed will be gained if the maximum speed is slower than the specified speed.

	Operation	Screen	Reference
1.	Touch Move on the MENU2 screen.		
2.	Touch Jog on the MoveMENU edit screen.		
3.	When the servo is OFF, touch SVON to put into the servo ON status.		
4.	If homing has not been executed, touch HOME to perform homing.		
5.	Select the speed with JVEL . Move the slider with ← or → and match to the desired position. ←: Positive direction of the displayed coordinates →: Negative direction of the displayed coordinates		JVEL : Selection of speed Display with shadow: PIO jog speed (parameter) Display without shadow: PIO jog speed 2 (parameter)


- 4) Inching (Move) Move the actuator by inching with the direction arrow key (← or →). However, no teaching can be given to the position table.
If you touch the direction arrow key (← or →), the actuator will move by a specified distance (PIO Inching Distance). Finer movement than jogging is possible.

	Operation	Screen	Reference
1.	Touch Move on the MENU2 screen.		
2.	Touch Jog on the MoveMENU edit screen.		
3.	When the servo is OFF, touch SVON to put into the servo ON status.		
4.	If homing has not been executed, touch HOME to perform homing.		
5.	Touch INC to change to inching operation.		
6.	Move the slider with ← or → and match to the desired position. ←: Positive direction of the displayed coordinates →: Negative direction of the displayed coordinates		Inching Distance: PIO Inching Distance (parameter)

4.10 Parameters

Parameters will be displayed and edited.


Caution: In contrast to the Teaching Pendant and PC-compatible software, only some parameters can be displayed and edited.




Touch **Param** on the MENU2 screen.

Fig. 4.38

The password input screen is displayed before it shifts to the parameter setting display, except when the password is "0000".



Input the numerical value of password with the ten keys, and touch .

The password can be set by "Password change" of the main body environment setting.

Fig. 4.39

When a correct password is set, it shifts to the edit display. The display shifts by the movement pattern.

(1) Setting of Parameter Value




Fig. 4.40

If you touch a numeric value, the ten keys will be displayed.




Fig. 4.41

Input a numeric value and touch . When stopping input, touch the ESC key.




Fig. 4.42

Touch **WRT**.




Fig. 4.43

Touch **YES**.
(When stopping rewriting, touch **NO**.)






Fig. 4.44

Touch **YES**.
The controller will restart and the parameter will be changed.
(When stopping restart, touch **NO**.)



Caution: The changed parameter will become valid by restoring the power or resetting software.


(2) Parameter Display Change

Parameter screens are comprised of 13 screens and can be changed with the  or  key. Parameters which can be rewritten with this Touch Panel Display are only 13 items shown below.



If you touch **MENU**, the screen will return to the MENU1 screen.


Zone Output Pos. (1) +

Parameter			MENU
Zone Output Pos.(1) +			
150.30mm			
ParaNo. 01			WRT






Soft Limit -

Parameter			MENU
Soft limit -			
-0.30mm			
ParaNo. 04			WRT






Zone Output Pos. (1) -

Parameter			MENU
Zone Output Pos.(1) -			
-0.30mm			
ParaNo. 02			WRT






Zone Output Pos (2) +

Parameter			MENU
Zone Output Pos.(2) +			
150.30mm			
ParaNo. 23			WRT






Soft Limit +

Parameter			MENU
Soft limit +			
150.30mm			
ParaNo. 03			WRT



Zone Output Pos. (2) -

Parameter			MENU
Zone Output Pos.(2) -			
-0.30mm			
ParaNo. 24			WRT




To Soft Limit -

To PIO pattern select
(To the next page)


PIO pattern select

Parameter	←	→	MENU
PIO pattern select			
1			
ParaNo. 25			WRT




PIO Jog speed 2

Parameter	←	→	MENU
PIO Jog speed 2			
10.00 mm/sec			
ParaNo. 47			WRT




PIO Jog speed

Parameter	←	→	MENU
PIO Jog speed			
100.00 mm/sec			
ParaNo. 26			WRT




PIO Inching Distance

Parameter	←	→	MENU
PIO Inching Distance			
1.00 mm			
ParaNo. 48			WRT




Push speed

Parameter	←	→	MENU
Push speed			
20.00 mm/sec			
ParaNo. 34			WRT




PIO Inching Distance 2

Parameter	←	→	MENU
PIO Inching Distance2			
1.00 mm			
ParaNo. 49			WRT



Safety speed

Parameter	←	→	MENU
Safety speed			
10.00 mm/sec			
ParaNo. 35			WRT



To PIO Jog speed 2


To Zone Output (1) +
(To the previous page)

- When soft limit is modified at the customer site, please set a value which extends 0.3mm outside of the effective area.

Example: When setting the effective area between 0mm to 80mm

Soft limit + side: 80.3

Soft limit - side: -0.3



Caution: Please restore the controller power after making parameter changes. Alternatively, reset software in the case of any model which supports the software reset function.

* Regarding parameter, please refer to the Controller Operating Manual.

4.11 Display

Screen contrast and brightness can be adjusted.




Fig. 4.45

Touch **Display** on the MENU2 screen.




Fig. 4.46

Select one of **Sound**, **Display**, **Language**, or **Password** and touch it.

- Sound Setting : Set whether or not the touch sound is output or not.




Fig. 4.47

- Language Set : Select either Japanese or English for the display language.




Fig. 4.48

- Display Setting : In this screen, the contrast or brightness is adjusted.



Fig. 4.49

[1] Basic Operation [Sound Setting]




Fig. 4.50

Touching **ON** outputs the touch sound.
Touching **OFF** turns OFF the touch sound.

Touching **OK**, the setting is stored and the Environment Setup screen for the main machine is returned.




Fig. 4.51

[Language Set]




Fig. 4.52

Touching **Japanese** sets the language to Japanese.

Touching **English** sets the language to English.

Touching **OK**, the setting is stored and the Environment Setup screen for the main machine is returned.




Fig. 4.53

[Display Setting]



Fig. 4.54

When the contrast in the figure is to be adjusted, touch **Contrast**.

When the brightness in the screen is to be adjusted, touch **Brightness**.

The adjustment screen corresponding to the touched button item is displayed.

Touching **ESC** returns to the Machine Setup screen for the main machine is returned.




Fig. 4.55

- Contrast Adjustment




Fig. 4.56

Adjust the contrast in the screen by means of touching **-** or **+**.

- Brightness Adjustment




Fig. 4.57

Adjust the contrast in the screen by means of touching **-** or **+**.

Touching **ESC** returns to the Display Setting screen.



Fig. 4.58

[Change Sys-Pass]

Using this function, the operation is performed to change the password for the position editing and parameter editing.





Fig. 4.59

Enter the value and touch .





Fig. 4.60

Enter the value and touch .





Fig. 4.61

The system password will be changed.

Touching  returns to the Parameter Menu screen.




Fig. 4.62

4.12 Restart

The controller will be restarted.




Fig. 4.63

Touch **Restart** on the MENU2 screen.




Fig. 4.64

Touch **YES**.

The controller will restart.

(When stopping restart, touch **NO**.)

4.13 Version

You can confirm the controller type, version information and writing count into the flash ROM.




Fig. 4.65

Touch **Version** on the MENU2 screen.




Fig. 4.66

VersionInfo 1 will be displayed.

If you touch **ESC**, the screen will return to the MENU2 screen.





Fig. 4.67

VersionInfo 2 will be displayed.

If you touch **ESC**, the screen will return to the MENU2 screen.




Fig. 4.68


ManuInfo will be displayed.

If you touch **ESC**, the screen will return to the MENU2 screen.

5. GATEWAY MENU


Up to 16 axes can be monitored simultaneously by connecting to the ROBONET GATEWAY.

Axis Select Screen



Touch **RGW**.

Fig. 5.1



Touch an item to monitor on the ROBONET GATEWAY MENU screen.

Fig. 5.2

(1) Axis Select

This is the screen to select axes.

When axes are selected, only the selected axes can be monitored.




Fig. 5.3

(2) Cur Pos

The current position of each axis will be displayed. Four axes can be monitored simultaneously.

Cur Pos		←	→	MENU
AxisNo00	1290.00 mm			
AxisNo01	312.58 mm			
AxisNo02	0.00 mm			
AxisNo03	-0.10 mm			

Fig. 5.4

You can change to the next screen with ← or →.

If you touch **ESC**, the screen will return to the ROBONET GATEWAY MENU screen.

(3) All Alarm

Alarms currently occurring in each axis can be checked.

All Alarm				MENU
00 D8 04	08	12		
01 81 05	09	13		
02	06	10	14	
03	07	11	15	

Fig. 5.5

If you touch **ESC**, the screen will return to the ROBONET GATEWAY MENU screen.

(4) Velocity

The current speed of each axis will be displayed. Four axes can be monitored simultaneously.

Velocity		←	→	MENU
AxisNo00	210.00 ms			
AxisNo01	312.58 ms			
AxisNo02	0.00 ms			
AxisNo03	-0.10 ms			

Fig. 5.6

You can change to the next screen with ← or →.

If you touch **ESC**, the screen will return to the ROBONET GATEWAY MENU screen.

(5) Current

The current value of each axis will be displayed. Eight axes can be monitored simultaneously.

Current	←	→	MENU
00 0.823A	04 0.003A		
01 0.002A	05 1.398A		
02 0.094A	06 0.067A		
03 0.253A	07 4.500A		

Fig. 5.7

You can change to the next screen with ← or →.




Fig. 5.8

If you touch ← or →, the current values of all axes can be displayed in graph form.

If you touch **ESC**, the screen will return to the ROBONET GATEWAY MENU screen.

(6) VersionInfo

The gateway module version and fieldbus setting status will be displayed.

VersionInfo	STAT	ESC
Version	0001	
Address	0002	
Baudrate · Occ	0024	
Network Type	FF91	
IAI CC-Link V2		

Fig. 5.9

If you touch **STAT**, the screen will return to the GWstatus screen.

GWstatus	Info	ESC
T.ERR	C.ERR	MANU
ENBinvalid	ENB OFF	
StopLink	non EMG	

Fig. 5.10

The gateway status can be checked.

If you touch **Info**, the screen will return to the ROBONET GATEWAY MENU screen.

If you touch **ESC**, the screen will return to the ROBONET GATEWAY MENU screen.

6. Message Area

In the message screen, content during error and warning will be displayed.

Code No.	Error Label	Error Reset	Reference
080 to 0FF	Controller Error	Note	Error inside the controller


Note) Refer to "6.2 Controller Error."

6.1 Touch Panel Display Message Level Error

Touch Panel Display Operational Mistake:

When you attempt to input an incorrect value, the message label error will occur.

For example, if you input an excessive numeric value into Position and write it into the controller, the following message will be displayed:



6.2 Controller Error

An alarm detected from the controller side can be displayed.

When an alarm occurs, the Touch Panel backlight will turn pink.

This is a critical error due to an abnormality related to servo control and electricity. Please read through the RC Controller Operating Manual carefully for error compliance.

If any errors of the code numbers listed below occur, it is required to perform error reset of the controller (press the **RES** key on the screen where the alarm is displayed) to reset it in the case of a movement release error. It is required to perform the reset of the controller software in the case of a cold start level error. (Refer to 4.12.)

Code No : 0A1h, 0A2h, 0B0h, 0B1h, 0B8h, 0B9h, 0BAh, 0BBh, 0BCh, 0BDh, 0BEh, 0C0h, 0C1h, 0C9h, 0CAh, 0CCh, 0CEh, 0D0h, 0D1h, 0D8h, 0E0h, 0E8h, 0E9h, 0EAh, 0F4h, 0F5h, 0F6h, 0F8h, 0FAh, etc.

For details of error codes, refer to the operating manual of the controller you use.

7. Warranty

7.1 Warranty Period

One of the following periods, whichever is shorter:

- 18 months after our shipment
- 12 months after delivery to the place designated by you

7.2 Scope of Warranty

Our products are covered by warranty when all of the following conditions are met. Faulty products covered by warranty will be replaced or repaired free of charge:

- (1) The breakdown or problem in question pertains to our product as delivered by us or our authorized dealer.
- (2) The breakdown or problem in question occurred during the warranty period.
- (3) The breakdown or problem in question occurred while the product was in use for an appropriate purpose under the conditions and environment of use specified in the operation manual and catalog.
- (4) The breakdown or problem in question was caused by a specification defect or problem, or by the poor quality of our product.

Note that breakdowns due to any of the following reasons are excluded from the scope of warranty:

- [1] Anything other than our product
- [2] Modification or repair performed by a party other than us (unless we have approved such modification or repair)
- [3] Anything that could not be easily predicted with the level of science and technology available at the time of shipment from our company
- [4] A natural disaster, man-made disaster, incident or accident for which we are not liable
- [5] Natural fading of paint or other symptoms of aging
- [6] Wear, depletion or other expected result of use
- [7] Operation noise, vibration or other subjective sensation not affecting function or maintenance

Note that the warranty only covers our product as delivered and that any secondary loss arising from a breakdown of our product is excluded from the scope of warranty.

7.3 Honoring Warranty

As a rule, the product must be brought to us for repair under warranty.

7.4 Limited Liability

- (1) We shall assume no liability for any special damage, consequential loss or passive loss such as a loss of expected profit arising from or in connection with our product.
- (2) We shall not be liable for any program or control method created by the customer to operate our product or for the result of such program or control method.

7.5 Conditions of Conformance with Applicable Standards/Regulations, Etc., and Applications

- (1) If our product is combined with another product or any system, device, etc., used by the customer, the customer must first check the applicable standards, regulations and/or rules. The customer is also responsible for confirming that such combination with our product conforms to the applicable standards, etc. In such a case we will not be liable for the conformance of our product with the applicable standards, etc.
- (2) Our product is for general industrial use. It is not intended or designed for the applications specified below, which require a high level of safety. Accordingly, as a rule our product cannot be used in these applications. Contact us if you must use our product for any of these applications:
 - [1] Medical equipment pertaining to maintenance or management of human life or health
 - [2] A mechanism or mechanical equipment intended to move or transport people (such as a vehicle, railway facility or aviation facility)
 - [3] Important safety parts of mechanical equipment (such as safety devices)
 - [4] Equipment used to handle cultural assets, art or other irreplaceable items
- (3) Contact us at the earliest opportunity if our product is to be used in any condition or environment that differs from what is specified in the catalog or operation manual.

7.6 Other Items Excluded from Warranty

The price of the product delivered to you does not include expenses associated with programming, the dispatch of engineers, etc. Accordingly, a separate fee will be charged in the following cases even during the warranty period:

- [1] Guidance for installation/adjustment and witnessing of test operation
- [2] Maintenance and inspection
- [3] Technical guidance and education on operating/wiring methods, etc.
- [4] Technical guidance and education on programming and other items related to programs

* Appendix

Touch Panel Display Error Message

A message will be displayed in cases where you input an excessive numeric value into Position and write it to the controller etc.

Confirm that the input numeric value is correct and reset it again.

For the controller errors, refer to the operating manual of each controller.

Error Message

Position No. error
Position data input error
Velocity input too large
Accelerate input too large
Decelerate input too large
Pos.band input error
PosZone input error
Acc/Dcl mode input error
Command mode input error
Stop mode input error

Warning message

Non MANU Teach mode data edit prohibit	Warning when editing is performed with the Touch Panel Display during AUTO
Non MANU Teach mode axis operation prohibit	Warning when axis operation is performed with the Touch Panel Display during AUTO

Change History

Revision Date	Revision Description
November 2011	<p>Third Edition</p> <ul style="list-style-type: none"> • Please Read Before Use added • 1. Foreword and 2. Before You Begin deleted • Safety Precautions changed to Safety Guide • Caution in Handling added • ERC3 and PCON-CA are added in Support Models • Pg. 40 ERC3 and PCON-CA are added in List • Pg. 18, 19, 22, 35, 47, 48, 52, 56, 60, 64, 68, 85 Password setting added • Pg. 18, 21, 34 Alarm List screen changed • Pg. 90 to 93 Sound Setting, Language Set and Display Setting are added in 4.11 Display • Pg. 19, 22, 95 VersionInfo and ManuInfo are added • Contents changed in 7. Warranty



IAI Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan
TEL +81-54-364-5105 FAX +81-54-364-2589
website: www.iai-robot.co.jp/

Technical Support available in USA, Europe and China

IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505
TEL (310) 891-6015 FAX (310) 891-0815
Chicago Office: 110 East State Parkway, Schaumburg, IL 60173
TEL (847) 908-1400 FAX (847) 908-1399
Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066
TEL (678) 354-9470 FAX (678) 354-9471
website: www.intelligentactuator.com

IAI Industrieroboter GmbH

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany
TEL 06196-88950 FAX 06196-889524

IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China
TEL 021-6448-4753 FAX 021-6448-3992
website: www.iai-robot.com