



**IAI**  
Quality and Innovation

Applicable to Fieldbus

# Table Top Type Robot TT

## First Step Guide First Edition

Thank you for purchasing our product.

Make sure to read the Safety Guide and detailed Instruction Manual (CD) included with the product in addition to this First Step Guide to ensure correct use.

This Instruction Manual is original.

**Warning :** Operation of this equipment requires detailed installation and operation instructions which are provided on the CD Manual included in the box this device was packaged in. It should be retained with this device at all times.  
A copy of the CD Manual can be requested by contacting your nearest IAI Sales Office listed at the back cover of the Instruction Manual or on the First Step Guide.

- Using or copying all or part of this Instruction Manual without permission is prohibited.
- The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.

## Product Check

This product is comprised of the following parts if it is of standard configuration.

If you find any fault in the contained model or any missing parts, contact us or our distributor.

### 1. Parts

No.	Part Name	Model	Reference
1	Controller Main Body (with a built-in controller)	Refer to "How to read the model plate", "How to read the model No."	
Accessories			
2	Power Supply Plug	AP-400-C (Supplier : Yamate Electric Co., Ltd.)	
3	Fieldbus Connector	DeviceNet type SMSTB2.5/5-ST-5.08AU (Supplier : PHOENIX CONTACT)	
		CC-Link type	
		PROFIBUS-DP type	Prepare Dsub 9-pin (female) connector.
4	Fieldbus Terminal Resistance	DeviceNet type	Prepare it if the controller is terminating device
		CC-Link type	130Ω1/2W, 110Ω1/2W enclosed one unit each
		PROFIBUS-DP type	
5	First Step Guide		
6	Instruction Manual (CD)		
7	Safety Guide		

### 2. Optional Components

No.	Part Name	Model
1	Main Body Mounting Bracket (with set bolts and nuts)	TT-FT

### 3. Teaching Tool (Option)

The personal computer application software or teaching pendant is required for the operations including program creation and setup such as position setting and parameter setting with teaching. Use either of them.


No.	Part Name	Model	Remarks
1	PC Software (with RS232C Cable + Emergency Stop Box)	IA-101-X-MW	RS232C→RS232C <sup>*1</sup>
2	PC Software (USB conversion adapter + RS232C cable + Cable and Emergency Stop Box)	IA-101-X-USBMW	USB→RS232C <sup>*1</sup>
3	PC Software (with USB Cable + Dummy Plug)	IA-101-TT-USB	USB→USB <sup>*1</sup>
4	Teaching pendant	SEL-T	—
5	Teaching pendant (with deadman switch)	SEL-TD	—
6	Teaching pendant (with deadman switch + TP Adapter (IA-LB-TG))	SEL-TG	—
7	Teaching pendant	IA-T-X	—
8	Teaching pendant (with deadman switch)	IA-T-XD	—

<sup>\*1</sup> The communication port on the left is for the personal computer and on the right is for the TT.

### 4. Instruction Manuals related to this product, which are contained in the CD.

No.	Name	Manual No.
1	Table Top Type Robot TT Instruction Manual	ME0149
2	PC software IA-101-X-MW Instruction Manual	ME0154
3	Teaching pendant SEL-T/TD Instruction Manual	ME0183
4	Teaching pendant IA-T-X/XD Instruction Manual	ME0160
5	DeviceNet Instruction Manual	ME0124
6	CC-Link Instruction Manual	ME0123
7	PROFIBUS-DP Instruction Manual	ME0153

### 5. How to read the model plate



### 6. How to read the model No.

Model No. Example

**TT - A3 - ! - 2020 - 05B - DV**  
1) 2) 3) 4) 5) 6)

1) Series	2) Type	3) Encoder type	4) XY Stroke	5) Z Stroke	6) Option
TT (Normal)	A2 : Gate Type with 2-axis	I: Incremental	2020 200 × 200mm	-	DV : DeviceNet Type
	C2 : Cantilever Type with 2-axis				CC : CC-Link Type
	A3 : Gate Type with 3-axis		4040 400 × 400mm		PR : PROFIBUS Type
	C3 : Cantilever Type with 2-axis				ET : Ethernet Type
					FT : Main Body Mounting Bracket included
				05B 50mm	P : I/O PNP Type
				10B 100mm	Not Specified : I/O NPN Type

## Basic Specifications

### [Common Specifications]

Item	Specifications
Surrounding air temperature/humidity	0 to 40°C, Room Humidity 20 to 85% or less
Motor Type	Pulse Motor (Servo Control)
Position detection method	Incremental Encoder
Driving System	Ball Screw (φ10mm, Rolled C10), Ball Screw Lead 6mm
Positioning Repeatability	±0.02mm
Backlash	0.1mm or less
Guide	Direct Driven Infinite Circulation Type
Allowable Load Moment <sup>Note 1</sup>	Ma : 6·5N·m Mb : 9·3N·m Mc : 16·4N·m

<sup>Note 1</sup> Value found on the assumption of the life of 5000km run

### [Individual Mechanism Specifications]

Type		Stroke [mm]			Max. Speed for each axes [mm/sec]			Acceleration/Deceleration [G]	Max. Load Capacity [kg] <sup>Note 1</sup>			Weight [kg]	Model	
		X Axis	Y Axis	Z Axis	X Axis	Y Axis	Z Axis		X Axis	Y Axis	Z Axis			
Gate Type with	2-axis	200	200	-	300			0.3	10	5	-	14.8	TT-A2-I-2020	
		400	400	-								33	TT-A2-I-4040	
	3-axis	200	200	50	300	280	0.3	10	-	2	16.5	TT-A3-I-2020-05B		
			100	300							35	TT-A3-I-2020-10B		
		400	400	50	300	280								
			100	300										
Cantilever Type with	2-axis	200	200	-	300			0.2	-	4	-	16.3	TT-C2-I-2020	
		400	400	-								35	TT-C2-I-4040	
	3-axis	200	200	50	300	280	0.2	-	-	2	18	TT-C3-I-2020-05B		
			100	300										
		400	400	50	300	280							37	TT-C3-I-4040-05B
			100	300									37	TT-C3-I-4040-10B

<sup>Note 1</sup> The load capacity in the case of rated acceleration is shown (Gate Type: 0.3G, Cantilever Type: 0.2G)

### [Controller Specifications]

Item	Specifications	
Number of axes	2-axis	3-axis
Supply voltage	Single-phase 100 to 115V AC, 200 to 230V AC ±10%	
Power frequency	50Hz/60Hz	
Power-source capacity	100V AC	210VA
	200V AC	215VA
Maximum Current <sup>Note 1</sup>	3A (100V AC), 1.6A (200V AC)	4.2A (100V AC), 2.2A (200V AC)
Rush Current <sup>Note 2</sup>	15A (100V AC), 30A (200V AC)	
Leakage Current	0.75mA	
Insulation Strength	2000V AC for 1min.	
Momentary Power Interruption Tolerance	500μs or more	
Speed Setting	1 to 300mm/s	
Acceleration Setting	0.01 to 0.3G	
Program language	SEL language	
Number of programs (Number of multitask programs)	64 programs (16 programs)	
Number of program steps	6000 steps (Total)	
Number of positions	3000 positions (Total)	
Program Startup	Special Digital Switch + Special Start Switch	
Data storage device	Flash ROM + SRAM <sup>Note 3</sup>	
Standard I/O Board	16 Input Points / 16 Output Points	
Applicable Field Bus	DeviceNet/CC-Link/PROFIBUS/Ethernet	
Protective functions	Over-voltage, motor over current, motor overload, driver temperature error, encoder error, etc.	


<sup>Note 1</sup> The current reaches its maximum level when the servo-motor exciting phase is detected which is to be performed in the first servo-motor turning ON processing after the power injection. (Normal: Approx. 1 to 2sec, Max.: 10sec)

<sup>Note 2</sup> Rush current at the power connection continues for about 20ms. Consider the safety rate at the time when rush current passes. The rush current value varies depending on the impedance of the power line.

<sup>Note 3</sup> The SRAM data is not battery backed up. Accordingly, when the power is turned off, the data of flags and variables used in the program, are not saved. Take the greatest care. The same procedure is applied when the program or position data is not written on the Flash ROM.

## External Dimensions


[Gate Type with 2-axis TT-A2]



<sup>\*1</sup> Fine slider adjustment (for manual tweaking of position).

Model	A	B	C	D	E	F	G	Xst	Yst
TT-A2-I-2020	369.7	330	338.5	133.3	185	240	88.2	200	200
TT-A2-I-4040	569.7	530	538.5	333.3	385	440	188.2	400	400


[Gate Type with 3-axis TT-A3]



<sup>\*1</sup> Fine slider adjustment (for manual tweaking of position).

Model	A	B	C	D	E	F	Xst	Yst	Zst
TT-A3-I-2020-05B	369.7	330	338.5	83.3	135	240	200	200	50
TT-A3-I-2020-10B	369.7	330	338.5	83.3	135	240	200	200	100
TT-A3-I-4040-05B	569.7	530	538.5	283.3	335	440	400	400	50
TT-A3-I-4040-10B	569.7	530	538.5	283.3	335	440	400	400	100


[Cantilever Type with 2-axis TT-C2]



\*1 Fine slider adjustment (for manual tweaking of position).

								(Unit mm)
Model	A	B	C	D	E	F	Xst	Yst
TT-C2-I-2020	405	320	135	120	310	42	200	200
TT-C2-I-4040	605	520	335	213.6	510	142	400	400

[Cantilever Type with 3-axis TT-C3]



(Cable Projection Length)

\*1 Fine slider adjustment (for manual tweaking of position).

Model	A	B	C	D	E	F	Xst	Yst	Zst
TT-C3-I-2020-05B	405	330.6	135	120	310	71	200	200	50
TT-C3-I-2020-10B	405	330.6	135	120	310	71	200	200	100
TT-C3-I-4040-05B	605	530.6	335	213.6	510	171	400	400	50
TT-C3-I-4040-10B	605	530.6	335	213.6	510	171	400	400	100

## Installation Environment

This product is capable for use in the environment of pollution degree 2<sup>+</sup> or equivalent.

\*1 Pollution Degree 2 : Environment that may cause non-conductive pollution or transient conductive pollution by frost. (IEC60664-1)

## 1. Installation Environment

Do not use this product in the following environment.

- Location where the surrounding air temperature exceeds the range of 0 to 40°C
- Location where condensation occurs due to abrupt temperature changes
- Location where relative humidity exceeds 85%RH
- Location exposed to corrosive gases or combustible gases
- Location exposed to significant amount of dust, salt or iron powder
- Location subject to direct vibration or impact
- Location exposed to direct sunlight
- Location where the product may come in contact with water, oil or chemical droplets
- Environment that blocks the air vent [Refer to Installation and Noise Elimination Section]


When using the product in any of the locations specified below, provide a sufficient shield.


- Location subject to electrostatic noise
- Location where high electrical or magnetic field is present
- Location with the mains or power lines passing nearby

## 2. Storage and Preservation Environment


The storage and preservation environment should comply with the same standards as those for the installation environment. In particular, when the machine is to be stored for a long time, pay close attention to environmental conditions so that no condensation forms. Unless specially specified, moisture absorbency protection is not included in the package when the machine is delivered. In the case that the machine is to be stored and preserved in an environment where condensation is anticipated, take the condensation preventive measures from outside of the entire package, or directly after opening the package.

## Installation and Noise Elimination

1. There is a cooling vent hole on the main body's rear panel section. Do not close the vent hole when the main body is installed.
2. When it required to fix the main body, fix it as follows using the optional mounting brackets (Model TT-FT: 4 sets with secure bolts and nuts).  
 User supplied bolts to secure the brackets to the mounting surface or table.  




### 3. Protective Ground




#### 4. Noise Elimination Grounding (Frame Ground)

Connect it using a soft copper wire with the diameter of 1.6 mm or more to the frame ground on the main body (Refer to the above figure).

Do not share the ground wire with or connect to other equipment. Ground each controller.

The same procedure is applied for the protective ground.




### 5. Precautions Regarding wiring Method

Separate the I/O cable, communication line and power / driving cable each other.

## 6. Noise Sources and Elimination


Carry out noise elimination measures for power devices on the same power path and in the same equipment. The following are examples of measures to eliminate noise sources:

- 1) AC solenoid valves, magnet switches and relays  
[Measure] Install a Surge Absorber parallel with the coil.
- 2) DC solenoid valves, magnet switches and relays  
[Measure] Install a diode parallel with the coil. Use a DC relay with a built-in diode.




## Wiring Diagram

### Front Panel Section



### Rear Panel Section



\*1 For the selection of the circuit breaker, perform it according to the following items.

Breaker Teaching pendant Value > Power Capacity / AC Input Voltage

(Refer to the item for the controller specifications for the power capacity).

- The current reaches the maximum level when the servo-motor is turned on and the servo-motor exciting phase is detected. Select a circuit breaker with rated current that does not trip the TT's current.
  - Select the circuit breaker that does not trip with the rush current described in the controller specifications. (Refer to the operating characteristic curve described in the manufacturer's catalog.)
  - For the rated breaking current for the circuit breaker, select the breaking current value with which the current can be securely broken down even when short-circuit current passes.
- Rated Breaking Current > Short-circuit Current = Primary Power Supply Capacity / Power Voltage.**
- Select the breaking current value for the circuit breaker leaving some margin.


When the leakage breaker is to be installed, it is required to select it with the purpose clarified such as protection from fire or human body protection.

Measure the leakage current at the location where the leakage breaker has been installed. Use the "applicable to higher harmonics type" leakage breaker.



## I/O Port for TT Fieldbus

Fieldbus I/O port is a place where the data inside the master unit and TT is sent and received.  
1 port can handle data of 1 contact (1 bit).  
Data is transferred via Fieldbus.



### I/O Mapping

Listed below are the I/O port numbers for TT.

[Please refer to the "Table Top Type Robot TT Instruction Manual" for the details.]

	Port No.	Function		Port No.	Function	
Internal DI	000	Start	Internal DI	300	ALM (Front Panel LED)	
	001	(Software Reset)		301	RDY (Front Panel LED)	
	002	(Servo ON)		302	EMG (Front Panel LED)	
	003	(Automatic Start Start-up)		303	In Automatic Operation	
	004	(Soft Interlock)		304	HPS (Front Panel LED)	
	005	(Pause Release)		305		
	006	(Pause)		306	System Reservation	
	007	Program No. appointment For digital switch of one's digit		307		
	008				308	To switch ON/OFF internal DI – No.001
	009				309	To switch ON/OFF internal DI – No.002
	010	Program No. appointment For digital switch of ten's digit		310	To switch ON/OFF internal DI – No.003	
	011				311	To switch ON/OFF internal DI – No.004
	012				312	To switch ON/OFF internal DI – No.005
	013				313	To switch ON/OFF internal DI – No.006
	014			(Driving Power Cancellation Input)	314	To switch ON/OFF internal DI – No.014
015	(Home Return etc.)	315	To switch ON/OFF internal DI – No.015			
External DI	016 to 031	General-purpose Input (Rear Panel I/O Connector)	External DI	316 to 331	General-purpose Output (Rear Panel I/O Connector)	
Internal DI	032	System Reservation	Internal DI	332	To specify 7-segment display digits	
	033			333		
	034			334		
	035			335	System Reservation	
	036			336		
	037			337	To refresh 7-segment display	
	038			338	To alternately display 7-segment user and system	
	039			339	To specify 7-segment user display	
	040			340	DT0 (7-segment user display bit)	
	041			341	DT1 (7-segment user display bit)	
	042			342	DT2 (7-segment user display bit)	
	043			343	DT3 (7-segment user display bit)	
	044			344	DT4 (7-segment user display bit)	
	045			345	DT5 (7-segment user display bit)	
	046			346	DT6 (7-segment user display bit)	
047		347	System Reservation			
External DI	048 to 287	For field network	External DI	348 to 587	For field network	

External DI	048 to 287	For field network	External DI	348 to 587	For field network
-------------	------------	-------------------	-------------	------------	-------------------

## Setting (I/O parameter)

No.	Parameter Name	Initial Value (Reference)	Input Range	Reference
1	I/O Port Allocation Type	1	0, 1	0: Fixed Allocation 1: Automatic Allocation (Order of Priority : Field Bus Port →Standard I/O Board (Slot 1))
6	Extension I/O 1 Input Port Start Number at Fixed Allocation	48	–1 to 599	0+ (Multiples of 8) (Unavailable when it is negative figure)
7	Extension I/O 1 Output Port Start Number at Fixed Allocation	348	–1 to 599	300+ (Multiples of 8) (Unavailable when it is negative figure)
12	Extension I/O 1 Error Monitor	1	0 to 5	0: Non Monitoring 1: Monitoring * There are some exceptions
14	Network I/F Module Fix-Allocated Input Port Start No.	64	0 to 240	Multiples of 16
15	Network I/F Module Fix-Allocated Output Port Start No.	64	0 to 240	Multiples of 16

For TT, The number of the used ports can be changed with the parameter settings.

I/O Port Start Numbers are already determined.

Set the number of ports to use in Parameters No. 14 and 15.

Input Port Start No.48

Output Port Start No.348

The occupied address area on the PLC side is determined by the number of used inputs and outputs.

Refer to Instruction Manual (CD) or the instruction manual of the master unit for the details.

## DeviceNet

### • Specification



Item	Specification			
Communication Protocol	DeviceNet2.0 (Certified Interface)			
For Communication	Master/Slave Connection		Bit Strobe	
			Polling	
			Cyclic	
Baud Rate	500k/250k/125kbps			
Communication Cable Length <sup>(Note1)</sup>	Baud Rate	Max. Network Length	Max. Branch Line Length	Total Branch Line Length
	500kbps	100m	6m	39m
	250kbps	250m		78m
	125kbps	500m		156m
	(Note) When DeviceNet dedicated thick cable is used			
No. of Occupied Nodes	1 node			
Communication Power Supply	Voltage 24V DC±10% Current Consumption 60mA Externally Supplied (Supplied from DeviceNet communication cable side)			
Communication Cable	Dedicated cable for DeviceNet			

Note 1 Refer to the instruction manuals for the master unit and the mounted programmable logic controller (stated as PLC from now on) when a T-junction communication is to be conducted.

### • Wiring

For details, refer to the Instruction Manuals of the master unit and PLC in which in the master unit is installed.

The connection connector is enclosed as a standard option.  
Connector : SMSTB2.5/5-ST-5.08AU  
(Supplier : PHOENIX CONTACT)



### • Dip Switch Setting

With the dip switches, it is possible to perform (1) Node Address Setting and (2) Baud Rate Setting.  
(Note) Make sure the power supply to TT is turned off when changing the settings on the dip switches.

#### (1) Node Addresses (MAC ID) Setting

Set the node addresses (MAC IDs) by using hexadecimal numbers following the table below:

Node Addresses (MAC ID)	Dip Switch					
	NA32	NA16	NA8	NA4	NA2	NA1
0	0	0	0	0	0	0
1	0	0	0	0	0	1
2	0	0	0	0	1	0
3	0	0	0	0	1	1
:	:	:	:	:	:	:
60	1	1	1	1	0	0
61	1	1	1	1	0	1
62	1	1	1	1	1	0
63	1	1	1	1	1	1

(Note) The node addresses comply with PLC remote I/O addresses. On this DeviceNet card, it is able to set 240 ports of input and 240 ports of output at maximum. Therefore, on the PLC, the number of node addresses that corresponds to the number of input and output ports is occupied.  
Exercise caution to avoid node address duplication. [Refer to the PLC Instruction Manual for the details]

#### (2) Baud Rate Setting

Set the baud rate following the table below:

Baud Rate	Dip Switch	
	DR1	DR0
125kbps	0	0
250kbps	0	1
500kbps	1	0
Setting Prohibited	1	1

## CC-Link

### • Specification

Item	Specification					
Communication Protocol	CC-Link Ver1.10					
Baud Rate	10M/5M/2.5M/625k/156kbps					
Communication System	Broadcast Polling System					
Synchronization System	Frame synchronization system					
Transmission Path Format	Bus format (EIA RS485 conformance 3-line type)					
Error Control System	CRC (X <sup>16</sup> + X <sup>12</sup> + X <sup>5</sup> + 1) <sup>*1</sup>					
No. of Occupied Stations	Remote Device Station [Refer to Field Network Wirings and Settings Section]					
Communication Cable Length <sup>(Note1)</sup>	Baud Rate	10Mbps	5Mbps	2.5Mbps	625kbps	156kbps
	Total Cable Length	100m	160m	400m	900m	1200m
Communication Cable	Dedicated cable for CC-Link					


Note 1 Refer to the instruction manuals for the master unit and the mounted programmable logic controller (stated as PLC from now on) when a T-junction communication is to be conducted.

\*1 CRC : Cyclic Redundancy Check: It is a data error detection method often used for the synchronous transmission

### • Wiring

For details, refer to the Instruction Manuals of the master unit and PLC in which in the master unit is installed.

The connection connector is enclosed as a standard option.  
Connector : SMSTB2.5/5-ST-5.08AU  
(Supplier : PHOENIX CONTACT)



- Rotary Switch  
With the rotary switches, it is possible to perform (1) Station Number Setting and (2) Baud Rate Setting.

- (1) Station No. Setting  
For CC-Link, it is able to connect up to 64 stations at maximum.  
Set the station numbers in the values from 1 to 64 by using the two rotary switches.  
SA × 10 ..... Set the number of ten's place  
SA × 1 ..... Set the number of one's place

Selected Number on Rotary Switch	Station No.	
	SA × 10	SA × 1
0	0	0
1	10	1
2	20	2
3	30	3
4	40	4
5	50	5
6	60	6
7	—	7
8	—	8
9	—	9

(Example) If you want to set the station number to 12, you need to set;  
Rotary Switch SA × 10 to "1", and  
Rotary Switch SA × 1 to "2".

- (Note) The PLC's CC-Link head I/O address is decided depending on the master unit installation position and the number of I/O points occupied by the unit installed before it.  
The I/O addresses in PLC will be assigned in the order of the station number with this head I/O address as the top number.  
Also, for the details of the Station No. setting and I/O address setting in PLC, refer to the Instruction Manuals for the master unit and loaded PLC.

- (2) Baud Rate Setting  
The baud rate can be set with Rotary Switch BR.

Selected Number on Rotary Switch	Baud Rate
0	156kbps
1	625kbps
2	2.5Mbps
3	5Mbps
4	10Mbps
Prohibited to set to 5 or above	Error


## PROFIBUS-DP

- Specification

Item	Specification					
Communication Protocol	PROFIBUS-DP (RS485 conformance)					
Communication System	Hybrid System (Master-Slave System or Token Passing System)					
Baud Rate	9.6k to 12Mbps (Automatically follows the master)					
Communication Cable Length (Type A Cable)	Baud Rate	12/6/3Mbps	1.5Mbps	500kbps	187.5kbps	93.75/45.45/19.2/9.6kbps
	Total Cable Length	100m	200m	400m	1000m	1500m
No. of Occupied Nodes	1 node					
Communication Cable	Type A Cable for PROFIBUS-DP (Standard EN50170)					


- Wiring  
For details, refer to the Instruction Manuals of the master unit and PLC in which in the master unit is installed.

Picture of PROFIBUS-DP Board Panel




Pin No.	Signal Name	Detail
1	NC	Unconnected
2	NC	Unconnected
3	B-Line	Communication line B (Positive side)
4	NC	Unconnected
5	GND	Signal grounding
6	+5V	+5V output
7	NC	Unconnected
8	A-Line	Communication line A (Negative side)
9	NC	Unconnected
Housing	Shield	Cable Shield

Use the type A cable for PROFIBUS-DP (EN5017).



Use D-Sub 9-pin (female) type of PROFIBUS-DP Standard (recommended for EN5017) for the connector.



- Node Addresses Setting  
Settings of PROFIBUS-DP Slave Station Addresses can be done with × 1 on the left and × 10 on the right of the address setting dials.  
They are the rotary switches to set the node addresses for this controller.  
The controller is equipped with two switches, and both of them can select from 0 to 9.  
To set the address, Node Address Number = (Address Setting Dial × 10) + (Address Setting Dial × 1).  
Example)

Desired Station Number	Examples of Rotary Switch Setting	
	Setting of × 10	Setting of × 1
9	0	9
12	1	2

Note 1) For the PROFIBUS-DP station number settings, PROFIBUS-DP master station number is always set to 0. Thus the slave stations can be set to the numbers from 1 to 99.

Note 2) The node address setting shown above cannot be performed during a communication with the master.

- Bus Termination Setting

Termination Switch ON	Termination activated (Be careful not to turn it ON when the device is not connected to the ends since turning this switch ON may cause a bad influence or communication error to the bus communication.)
Termination Switch OFF	Termination not activated

- Network Type Setting  
The I/O Parameter No. 225 "Network I/F Module Control" has been set to "3<sub>H</sub>" (PROFIBUS) when the unit is delivered. (Therefore, the setting is not necessary.)


- Node Addresses  
Station number is set with parameter.  
Set the node address to I/O Parameter No. 226 "Network I/F Module Communication Attribute 1". The setting range is from 0 to 125. (Set in delivery : 1)  
(Note) "D75: Fieldbus Parameter Error" would occur if the set address is out of the allowable range.

- Baud Rate Setting  
There is no need to set the baud rate since it automatically follows the master setting.

(Note) Make sure to reboot the controller after the parameter setting is complete, and do not forget to turn the mode changeover switch to "AUTO" side.

## Starting Procedures

When using this product for the first time, pursue work while making sure to avoid omission and incorrect wiring by referring to the procedure below.



## Troubleshooting

If an error has occurred, it is possible to check the operation condition on the status LEDs on the front panel.

- In the case of DeviceNet:

LED Indicators for Monitoring				Condition	Treatment
MS		NS			
GN	OR	GN	OR		
Illuminating	□	Illuminating	□	In normal operation	
Illuminating	□	OFF	OFF	Waiting for the completion of the node address duplication check on the master side	<ul style="list-style-type: none"><li>• Check if the communication speed of the master is the same as that for all the slave units.</li><li>• Correct the setting and re-start the machine.</li><li>• Check if the connector is connected correctly.</li></ul>
Illuminating	□	Flashing	□	Waiting for the establishment of the connection with the master	<ul style="list-style-type: none"><li>• Check if the master is operated normally.</li><li>• Check if it has been registered in the master's scanning list.</li></ul>
□	Illuminating	OFF	OFF	A hardware error occurred.	<ul style="list-style-type: none"><li>• Contact our company.</li></ul>
□	Flashing	OFF	OFF	Dip Switch Setting Error	<ul style="list-style-type: none"><li>• Check if the communication speed of this unit is the same as that of the master.</li><li>• Check if the configuration has been set correctly.</li></ul>
Illuminating	□	□	Illuminating	Duplicated node address or Busoff (Communication stop due to frequent data error) detection	<ul style="list-style-type: none"><li>• Correct the node address and restart the machine.</li><li>• Check if there is any noise source close to the unit or the communication cable is not arranged parallel to the power line, and check for the influence of the noise.</li></ul>
Illuminating	□	□	Flashing	Communication Time-out	<ul style="list-style-type: none"><li>• Check if the communication speed of this unit is the same as that of the master.</li></ul>
In NS, green light is turned ON and flashes repeatedly or red light and green light flash repeatedly.				Communication Error	<ul style="list-style-type: none"><li>• Check if it has been registered in the master's scanning list.</li><li>• Check if the I/O area is not duplicated with that of the other slave unit.</li><li>• Check if the I/O area does not exceed the area permitted by the master unit. (in the case of fixed allocation)</li></ul>

- In the case of CC-Link

STATUS1	STATUS0	Condition
Illuminating	Illuminating	Impossible condition
Illuminating	OFF	• An error occurs. (CRC Error, Station Setting Error or Communication Speed Setting Error) • Since turning the power ON or software reset till completion of CC-Link initialization
OFF	Illuminating	Normal Communication Status
OFF	OFF	Power Failure: Remote station power unit breakdown or communication cable breakage
Flashing	Illuminating	Impossible condition
Flashing	OFF	The station number setting or the baud rate setting is changed during the communication

- In the case of PROFIBUS-DP

LED	Color	Illumination Status	Indication Description (Meaning)
STATUS 1	GN	Illuminating	Online from fieldbus and communication in normal condition.
		Flashing	Offline from fieldbus.
	OR	Flashing	Communication error is occurred.
STATUS 0	GN	Illuminating	In normal operation.
		Flashing	Getting ready for operation.
	OR	Illuminating	An error detected on communication-related hardware during preparing for operation.

## Troubleshooting

The following alarm displays are frequently generated at the start-up operation.

Deal with each of them referring to the following table.

Status display	Status contents	Cause and Remedy
	During Emergency-stop	It is not an alarm. • It is caused when the emergency stop button is not cleared on the front panel. Clear it. • It is generated when the emergency stop switch in the teaching pendant or the personal computer application software is not cancelled. In such case, cancel it. • It is generated when the personal computer cable is not connected to the emergency stop box.
	Deadman switch OFF	It is not an alarm. • It generated when the AUTO/MANU switch has been set to "MANU" and the personal computer or the teaching pendant is not connected. Connect the personal computer or the teaching pendant or set the AUTO/MANU switch to "AUTO". • When the actuator is to be started up, hold the deadman switch on the teaching pendant to turn it on.
	AC Power Interruption Momentary Power Failure Power Voltage Drop	It is generated when the power voltage is not supplied. Check the power supply.
	24V I/O Error	It is generated when the +24V power for I/O is not supplied. Check the power supply. (Procedure for starting up I/O 24V power unit without connection) Set both the I/O parameter No. 10 and No. 12 to "0". In this case, the I/O connection is invalid.
	Field Bus Error	It is generated when the field bus link connection is not established. Check the link cable connection, I/O parameter and PLC parameter settings. (How to start up the controller without connecting the field bus) Set both the I/O parameter No. 10 and No. 12 to "0".



## ***IAI Corporation***

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan  
TEL +81-54-364-5105 FAX +81-54-364-2589  
website: [www.iai-robot.co.jp/](http://www.iai-robot.co.jp/)

Technical Support available in USA, Europe and China

## ***IAI America, Inc.***

Head Office: 2690 W. 237th Street, Torrance, CA 90505  
TEL (310) 891-6015 FAX (310) 891-0815  
Chicago Office: 110 East State Parkway, Schaumburg, IL 60173  
TEL(847) 908-1400 FAX (847) 908-1399  
Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066  
TEL (678) 354-9470 FAX (678) 354-9471  
website: [www.intelligentactuator.com](http://www.intelligentactuator.com)

## ***IAI Industrieroboter GmbH***

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany  
TEL 06196-88950 FAX 06196-889524

## ***IAI (Shanghai) Co.,Ltd.***

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China  
TEL 021-6448-4753 FAX 021-6448-3992  
website: [www.iai-robot.com](http://www.iai-robot.com)

## ***IAI Robot (Thailand) Co.,Ltd.***

825 PhairojKijja Tower 12th Floor, Bangna-Trad RD., Bangna, Bangkok 10260, Thailand  
TEL +66-2-361-4458 FAX +66-2-361-4456

Manual No.: ME0276-1B