# IAI SCON2 First Step Guide First Edition

Thank you for purchasing our product. Make sure to read the Safety Guide and detailed Instruction Manual as well as this First Step Guide to ensure correct use This Instruction Manual is original.

- Warning : Read the instruction manual carefully and follow the instruction manual when handling this equipment. Please downloaded the user's manual from our website. You can download it free of change. User registration is required for first time users. URL:www.iai-robot.co.jp/data\_dl/CAD\_MANUAL/ Keep a printout of the introduction manual near the equipment in which this product is installed so that it can be checked at all times, or display it on your computer, tablet terminal, etc. so that you con product is impediately. can check it immediately If you need a bound copy of the instruction manual, order it from the nearest sales office listed in the First Step Guide or at the end of the instruction manual. It will be provided for a fee.
- Using or copying all or part of this Instruction Manual without permission is prohibited The company names, names of products and trademarks of each company shown in the sentences are registered trademarks.
- Installation Environment, Storage Environment
- This product is capable for use in the environment of pollution degree 2'<sup>1</sup> or equivalent. \*1 Pollution Degree 2: Environment that may cause non-conductive pollution or transient conductive pollution by frost (IEC60664-1)
- 1. Installation Environment
- Do not use this product in the following environment
  - Location where the surrounding air temperature exceeds the range of 0 to 60°C
  - · Location where condensation occurs due to abrupt temperature changes
  - Location where relative humidity is out of the range between 5%RH and 85%RH
     Location exposed to corrosive gases or combustible gases

  - Location exposed to significant amount of dust, salt or iron powder Location subject to direct vibration or impact
  - Location exposed to direct sunlight
  - Location where the product may come in contact with water, oil or chemical droplets
- Environment that blocks the air vent Refer to [Installation and Noise Elimination]
   When using the product in any of the locations specified below, provide a sufficient shield.
  - Location subject to electrostatic noise Location where high electrical or magnetic field is present
- Location with the mains or power lines passing nearby

2. Storage Environment Storage environment follows the installation environment. Especially in a long-term storage,

consider to avoid condensation of surrounding air. Unless specially specified, moisture absorbency protection is not included in the package when the machine is delivered. In the case that the machine is to be stored in an environment where dew condensation is anticipated, take the condensation preventive measures from outside of the entire package, or directly after opening the package.

# Product Check

This product is comprised of the following parts if it is of standard configuration. If you find any fault in the contained model or any missing parts, contact us or our distributor.

Parts

No.	Part Name	Model	Reference				
1	Controller Main Body	Refer to "How to read the model plate", "How to read the model"					
Access	sories						
2	I/O Flat Cable	CB-PAC-PIO***	*** shows the cable length				
3	System I/O Plug	B2CF 3.50/08/180 SN BK BX (Supplier: Weidmüller)	Applicable Cable Size 1.25mm <sup>2</sup> to 0.5mm <sup>2</sup> (AWG16 to 20)				
4	AC Power Supply plug	MPS 7S/05 S F3 TN B B (Supplier: Weidmüller)	Applicable Cable Size Controller: 0.75mm <sup>2</sup> (AWG18) Motor: 2.0mm <sup>2</sup> (AWG14)				
5	Absolute Battery	AB-5	Enclosed in Absolute Type (Excluded for battery-less absolute)				
6	Dummy plug	DP-5					
7	Dummy plug	DP-6					
8	CC-Link Connector	MSTB2.5/5-STF-5.08 AU (Manufactured by PHOENIX CONTACT)	Enclosed in CC-Link Type Enclosed with Terminal Register (1pc each of 130Ω/110Ω) Recommended cable size 0.3mm <sup>2</sup> (AWG22)				
9	DeviceNet Connector	MSTB2.5/5-STF-5.08 AU M (Manufactured by PHOENIX CONTACT)	Enclosed in DeviceNet Type Recommended cable size 0.3mm <sup>2</sup> (AWG22)				
10	Connection Cable (Between R-Unit and SCON, Between SCON and SCON)	CB-RE-CTL002	Enclosed for R-Unit Connection Type				
11	First Step Guide	ME0468	This Manual				
12	Safety Guide	M0194					
Option	Option (To be prepared separately)						
13	Multi Function Connector Cable	CB-SC2-MFC***	*** shows the cable length				
	(2) I/O Flat Cable (3) System I/O Plug						







(5) Absolute Batter











# **Basic Specifications**

. LISLO	of Specifica	ations					
Item			SCON2-CG				
Corresponding Motor Capacity			Power Supply Voltage 100V AC: 60 to 200W, 200V AC: 60 to 750W				
Power-supply Voltage		e	Single-Phase 100 to 115V AC Single-Phase 200 to 230V AC (Power supply Elucitation+10% or less)				
Rush Power-supply Voltage 100V AC Power-supply Voltage 200V AC			Controller side: 30A (to 25°C), 70A (to 60°C) <sup>(*1)</sup> Drive side: 30A (to 25°C), 80A (to 60°C) <sup>(*1)</sup>				
a als Cum	voltage ze		3.5mA				
eak Cur	rent -		Primary side when noise filter is connected to power supply line				
oad Cap	oacity, Heat	Generation	Refer to Power Capacity and Heat Generation				
Power Su	upply Frequ	ency	50/60Hz				
PIO Powe	er Supply 3		24V DC±10%				
Electroma For actual	agnetic Brai	ke with brake)	24V DC±10% 1A (MAX.) (Supplied from external equipment)				
Transient Durability	Power Cut	off	20ms (50Hz), 16ms (60Hz)				
Notor Co	ntrol Syster	n	Incremental Serial     Absolute Serial				
Correspo	nding Enco	der	ABZ (UVW) Parallel     Battery-less Absolute				
Encoder I	Resolution		Battery-less Absolute (ISB): 131072 pulse/rev     Battery-less Absolute (RCS2/3): 16384 pulse/rev     In any models other than above, refer to instruction manual of each actuator.				
Actuator (	Cable Leng	th	MAX. 20m				
Serial Communi	icati RS-4	185	1CH based on Modbus Protocol RTU/ASCII Speed : 9.6 to 230.4Kbps Control available with serial communication in the modes other than the pulse train				
on Interfa	PIO	port	Communication System: USB2.0 Baud Rate: 12Mbps				
External nterface	Spec	cifications	output 16 ports max.				
Each the dedicated	e Field d Spec	l network cifications	CC-Link, CC-Link IE Field, DeviceNet, EtherCAT, EtherNet/IP, PROFINET IO, MECHATROLINK-III				
controller	) Othe	er	R-Unit Connection Type				
	PIO Spec	cifications	MAX. 10m				
Cable	RS4	85	Total cable length 100m or less.				
engun	Field	l network	Refer to each Field network specification				
Other		er	R-Unit Connection Type: 3m Max. Between Devices, Total Cable Length 10m Max.				
Data Setting and Input		ut	PC Teaching Software, Touch Panel Teaching Pendant				
Data Retention Memory		iory	Saves position data and parameters to non-volatile memory (There is no limitation in number of writing)				
Operatior	n Mode		Positioner Mode/Pulse Train Control Mode/Press Program/Motion				
Number o	of Positione	r Mode	Standard 64 points, MAX. 384 points (PIO Type, Field network Type)				
ositions	Servo Press S	Specifications)	(Note) Number of positions differs depending on the selection in PIO pattern and Field network operation mode.				
Pulse Tra Pulse Fre	ain Control	Mode Input	Differential System (Line Driver System): MAX. 2.5Mpps Open Collector Type: MAX. 200Kpps (under condition AK-04 is used) Command Pulse Multiplying Factor (Electronic Gear: A/B) Setting Range for A and B. (Set to Parameter): 1 to 90090909				
eedback	k Pulse		Differential System (Line Driver System): MAX. 2.5Mpps				
Dedicated	d for PIO Sp	ecifications)	Open Collector Type: MAX. 500Kpps (under condition JM-08 is used) 1system (load data)				
Analog O	utput		4 to 20mA Current Output (±1%) Load resistance 10 to 600Ω				
LED Dis Mounted	play I on Front P	anel)	PWR (Green): Controller in normal condition, SV (Green): Servo ON, ALM (Orange): Alarm generated, STOP (Red): During Stop, SAFE (Red): During Safety Stop, WRG (Orange): Warning generated				
Electroma Compulso mounted	agnetic Bral ory Release I on Front P	ke e Switch 'anel)	Switching NOM (standard)/BK RLS (compulsory release)				
nsulation	Resistance	e	500V DC 10MΩ or more				
nsulation	n Durability		1,500V AC for 1 min. (Note) Withstand voltage of force control loadcell is 50V DC				
	Environme	ent of Use	Pollution Degree 2				
	Surroundi Temperatu	ng Air ure	0 to 60°C (0 to 55°C when absolute battery to be connected)				
	Surroundir	ng Humidity	5%RH to 85%RH (Should be no-condensing or freezing)				
Environ nent	Surrounding		Refer to [Installation Environment]				
	Temperatu	ure ng Storage	-20 to 70°C (Should be no-condensing or freezing)				
	Humidity		5%RH to 85%RH (Should be no-condensing or freezing)				
	Vibration I	Durability	Frequency 10 to 57Hz / Swing width: 0.035mm (continuous), 0.075mm (intermittent) Frequency 57 to 150Hz / Acceleration: 4.9m/s <sup>2</sup> (continuous), 9.8m/s <sup>2</sup> (intermittent) XYZ directions Sweep time: 10 minutes Number of sweep: 10 times				
Nass			Approx. 800g				
Cooling Method			Forced Air Cooling				
		(mm)	40Wx160Hx143D				

In-rush current will flow for approximately 20ms after the power is turned on (at 60°C).

The value of in-rush current differs depending on the impedance of the power supply line

- \*2 Leak current varies depending on the capacity of connected motor, cable length and the surrounding environment. Measure the leak current at the point where a ground fault circuit interrupter is to be installed when leakage protection is conducted. A ground fault circuit interrupter needs to be selected carefully considering the purposes of prevention of fire and protection of human.
- Use the harmonic type (for inverter) for the ground fault circuit interrupter. \*3 It is not necessary to supply power to PIO when operating with using Gateway Unit or SIO Converter without using PIO. In this case, set the parameter No. 74 (PIO Power Supply Monitor) to "1" (Invalid). It will generate the error code No. 0CF (I/O 24V Power Supply Error) if the setting is not done.

A tea that	aching tool is necessary when performing the setup such as the positio requires teaching. Prepare either of the following teaching tools.			
No.	Part Name			
1	PC Teaching Software (software only)			
2	PC Teaching Software (USB converter adapter, USB cable and external equipmer communication cable are included)			
3	Touch Panel Teaching Pendant TB-02 (Standard/with dead-man switch)			
4	Touch Panel Teaching Pendant TB-03			
Instr	ruction manuals related to this product			
No.	Name			
1	SCON2 Controller Instruction Manual			
2	SCON2 Controller Servo Pressing Function Instruction Manual			
3	SCON2 Field Network Instruction Manual Remote I/O Edit			
4	SCON2 Motion Field Network Instruction Manual MECHATROLINK-II Edit			
5	SCON2 Motion Field Network Instruction Manual EtherCAT Edit			
6	R-Unit System Instruction Manual			
7	PC Teaching Software IA-OS First Step Guide			
3	Iouch Panel leaching Pendant IB-02 Applicable for Position Controller Instruct Manual			
9	Touch Panel Teaching Pendant TB-03 Wired Link Applicable for Position Contro			
How	/ to read the model plate			
	Model MODEL :SCON2-CG-S			
s	erial number			
	INPUT :1¢,100-115V,50/60Hz,1.8A			
	OUTPUT :Φ3 ,0-230V ,0-333Hz ,1.1A			
Co	nnected Axis Actuator Type :			
Mo	RC54-SA4C-WA-60-16-200-T2-S			
How	<i>i</i> to read controller model			
	SCON2-CG-S -NP.			
orion>				
siles>				
pe>-	afaty Catagony Compliant Type (Note 1)			
. 3	arety Category Compliant Type (******			
otor T : 20	Type> DOV AC servo motor (Note 2)			
ardwa	are Option>			
Indica Note 3)	ation : With no option			
/				
eature	e Option>			
	: Press Program			
Note 4)	: Motion NP : NPN Specification (Si			
te 1 H	For Safety Category complied types only The wattage of the applicable motor should be 60W to 750W CC : CC-Link Connection 1			
ote 3 \$	Select this when necessary to conduct pulse train control			
ote 4 S	Selectable when I/O type is either "EC" or "ML3" EF . EnerCAI Connection t should be the remote I/O type when "no description" ML3: MECHATROLINK-II (			
	or the pressing program "F" is selected in the feature option,			
	and should be the motion type when the motion "M" is R-Unit Connection Ty			

Power Capacity and Heat Generation Rated Power Capacity = Motor Power Capacity + Control Power Capacity

eek max. Fower Cap	Jacity - F
Actuator Motor Type	Motor Capa (V.
30R (for RS)	13
60	13
60 (RCS3-CTZ5)	19
100	23
100S (LSA)	28
150	32
200	42
200 (DD/DDA)	50
200S (LSA excluding LSA-N15H)	48
200S (LSA-N15H)	77
300S (LSA)	66
400	92
400 (RCS3-CT8)	12
600	11
600 (DD/DDA)	14
750 750S	15

- Selection of Circuit Breaker
- catalog])

× Safety Margin (reference 1.2 to 1.4 times)

(6) Dummy plug (DP-5)





#### 2. Teaching Tool (to be purchased separately)

on setting and parameter setting

repare elaier el ale lelle ling teating teele.	
Part Name	Model
re (software only)	IA-OS
re (USB converter adapter, USB cable and external equipment e are included)	IA-OS-C
g Pendant TB-02 (Standard/with dead-man switch)	TB-02/TB-02D
g Pendant TB-03	TB-03
ated to this product	
Name	Manual No.
struction Manual	ME0458
ervo Pressing Function Instruction Manual	ME0470
rk Instruction Manual Remote I/O Edit	ME0469
Network Instruction Manual MECHATROLINK-II Edit	ME0471
Network Instruction Manual EtherCAT Edit	ME0472
ction Manual	ME0384
re IA-OS First Step Guide	ME0391
g Pendant TB-02 Applicable for Position Controller Instruction	ME0355

ollei ME0376







and should be the motion type when the motion "M" is

n Type Connection Type (Note 5) ection Type

Peek Max. Motor Power Capacity + Control Power Capacity Power Peek Max. Rated Power Control Power Peek Max. Heat Capacity (VA) Capacity (VA) acity Motor Powe Powe eneratio Capacity (VA) (W) Capacity (VA) 186 33 414 462 414 186 462 33 32 591 245 639 702 282 750 35 851 331 36 899 37 1032 984 376 38 1263 469 1311 1509 551 1557 36 6 1458 48 534 1506 38 2319 821 2367 56 1986 710 2034 40 2760 968 2808 45 3690 1278 3738 47 2376 56 64 2328 1212 49 4386 1510 4434 62 3042 3090 58 521 1569 4563 4611

RS: Rotary Shaft LSA: Linear Actuator DD: Direct Drive Motor

• 3 times of the rated current may flow to the controller during the acceleration/deceleration. Select an interrupter that does not trip with this value of current. If a trip occurs, select an interrupter that possesses the rated current of one grade higher. (Refer to the loperation characteristics curves in the product catalog).

Select an interrupter that does not trip with the in-rush current. (Refer to the [operation characteristics curves in the product

Consider the current that enables to cutoff the current even when a short circuit current is flown for the rated cutoff current. Rated Interrupting Current > Short Circuit Current = Primary Power Capacity / Power Voltage Consider margin for the rated current on the circuit breaker

Rated Current for Circuit Interrupter > (Rated Motor Power Capacity (VA) + Control Power Capacity (VA)) / AC Input Voltage

# **External Dimensions**



## **Connection Diagram**

Refer to [R-Unit System Instruction Manual (ME0384)] for R-Unit Connection Type. Standard



# Installation and Noise Elimination

1. Noise Elimination Grounding (Frame Ground)

۲ , Ground Screw on Main Unit Controller . Use a copper conductor cable in green/yellow with its rated temperature at 60°C or more and its wire width 2.0mm<sup>2</sup> (AWG14) or more Earth Terminal

Class D grounding (Formerly Class-III grounding: Grounding resistance at  $100\Omega$  or less

2. Precautions regarding wiring method

- 1) Wire is to be twisted for the 24V DC power supply. 2) Separate the signal and encoder lines from the power supply and power lines.
- 3. Noise Sources and Elimination
- Carry out noise elimination measures for power devices on the same power path and in the same equipment. The following are examples of measures to eliminate noise sources.
- 1) AC solenoid valves, magnet switches and relays [Measure] Install a Surge absorber parallel with the coil.
- 2) DC solenoid valves, magnet switches and relays [Measure] Mount the windings and diodes in parallel. Select a diode built-in type for the DC relay

4. Heat Radiation and Installation

Design and Build the system considering the size of the controller box, location of the controller and cooling factors to keep the ambient temperature around the controller below 40°C. Apply screws sized M4 × 10mm when attaching the product with screws.



# **Power Supply and Emergency Stop Circuit**

• Wiring for Power Supply (to be prepared by customer)



Power consumption varies depending on the connected actuator, etc. Select the circuit breaker that suits to the specification. Refer to [Basic Specifications]

A ground fault circuit interrupter needs to be selected carefully considering the purposes of prevention of fire and protection of human. Use the "harmonic type" for the ground fault circuit interrupter. Also, check the leak current at the set points.

₹⊕

Refer to the instruction manual for the recommended models for the noise filter and surge absorber. • Wiring for Emergency Stop Input

The following diagram shows an example of how the emergency stop switch for the teaching pendant may be included in the emergency stop circuit you may construct.

SCON2 Teaching Pendant Stop Switch (Note 1) S1 S2 24V (Note 2) STOP+ Stop Detection Circuit STOP-Enable Switch 24V (Note 2) CPU ENB+ Enable Detection ENB-Circuit (Driving Source Interruption L1 (へ) L2

Note 1 SCON2 is not equipped with a relay to enable to automatically identify a teaching tool was inserted and switch the wiring layout.

(It does not get short-circuited between S1 and S2 terminals even if not connected.) Connect the dummy plug DP-5 when a teaching tool is not connected.

Note 2 For STOP-/ENB- terminals, make sure to construct a circuit using the built-in 24V (STOP+/ENB+ terminals) outputs.

# **PIO Specification**

#### Explanation of I/O Signal Functions

al for not described signals and details

10101	to instruction manual for not described signals and details.				
ategory	Signal Abbreviation	Signal Name	Function Description		
	CSTR	Start Signal (PTP Strobe)	Starts moving toward the position set in Command Position No.		
nput	PC1 to PC256	Command Position No.	To input position No. desired to move (binary input)		
	SON	Servo ON	Turn the signal ON to servo ON, turn the OFF to Servo OFF.		
	HOME	Home return	Perform the home-return operation with the signal rising edge (OFF $\rightarrow$ ON).		
	ST0 to ST6	Start Signal 0 to 6	The actuator moves to the commanded position with this signal ON during the electromagnetic valve mode. (CSTR signal is not required)		
	<b>RSTR</b> <sup>*</sup>	Datum Position Movement Command	Movement is made to the position set in Parameter No. 167 when the signal is turned ON.		

Category	Signal Abbreviation	Signal Name	Function Description	
	PEND/INP	Position Completion	Turns ON in the positioning band range after actuator operation. PEND signal will not turn OFF once it turns ON until the next operation even if the actuator goes OFF the range of positioning band. INP will turn OFF. PEND and INP can be switched over by the parameter.	
	PM1 to PM256	Completion Position No.	Outputs (binary output) the position No. that is reached at the same time the positioning is complete.	
	PZONE Position Zone		Turns ON when the current actuator position gets into the range set to the position data during the move towards the position. It can be utilized together with ZONE 1, however, PZONE is effective only when moving towards the set position.	
Out put	*EMGS	Emergency Stop Output	Turns ON when the controller emergency stop is cancelled, and OFF during the emergency stop (regardless of alarms).	
	PE0 to PE6	Current Position Number	Turns ON when moving to the target position is complete in Electromagnetic Valve Mode.	
	LS0 to LS2	Limit Switch Output	Turns ON when the current actuator position is within the range of positioning band (±) of the target position. It is output even before the movement command and the servo is OFF if the home-return operation is completed.	
	*ALML	Light Error Alarm	This turns OFF when any of the absolute battery alarm, overload alarm or message level alarm is occurred.	
	REND*	Datum Position Movement Complete	Turns ON when movement to the datum position set in Parameter No. 167 is finished.	
* Use	* Used in Pulse Train Control PIO Pattern 1			





Use the	Use the multi function connector cable in the option.					
Pulse T	rain Input and	Output Interface				
Category Abbreviated Code Signal Name		Signal Name	Contents of Functions			
	PP, /PP	Command Pulse	Inputs the command pulse train.			
Input	NP, /NP	Input	Input pulse frequency differs depending on the type. Refer to [Basic Specifications]			
	AFB, /AFB		Outputs the feedback pulse train.			
Output	BFB, /BFB	Feedback Pulse	Input pulse frequency differs depending on the type.			
	ZFB. /ZFB	Output	Refer to [Basic Specifications]			

_	Pulse Tr	ain Input and	Output Interface		
	Category Abbreviated Code Signal Name		Signal Name	Contents of Functions	
		PP, /PP	Command Pulse Input	nputs the command pulse train.	
Inp	Input	NP, /NP		Input pulse frequency differs depending on the type. Refer to [Basic Specifications]	
ĺ		AFB, /AFB		Outputs the feedback pulse train.	
С	Output	BFB, /BFB	Peedback Pulse	Input pulse frequency differs depending on the type.	
		ZFB, /ZFB		Refer to [Basic Specifications]	

• When Host Unit is Differential System





Do not share the ground wire with or connect to other equipment. Ground each controller.





nput section	Output section		
/ DC±10%	Load voltage	24V DC	
A 1 circuit :	Peak load electric current	50mA 1 circuit :	
Voltage MIN. 18V DC F voltage MAX. 6V DC	Leak Current	MAX.0.1mA/1 point	
Controller Power strang 5.6kQ	Controller P24 P24 Power Semal Power Supply Couput Terminal + Power Supply 24 V DC 210%		
	المعالم المعالم Power Supply	Controller P24 100 Output Terminal Output Terminal N Load	

# Pulso Train Control Type

Class D grounding (Formerly Class-III grounding: Grounding resistance at 100 $\Omega$  or less)

#### • When Host Unit is Open Collector System

AK-04 (option) is required for pulse train input. JM-08 (option) is required for pulse train output.



# **Multi Function Connector** (Pulse Train Control / Dedicated for Servo Press Type)

Lay out the multi function connector cable (model code: CB-SC2-MFC***) to the host controller.					
Wiring	Color	Signal	No.	Contents	
	Orange/Red1	IOUT	1	Output leadeall lead data as applied data (surrent 4 to 20mA)	
	Orange/Black1	GND	2	Output loaden load data as allalog data (current 4 to 2011A)	
	Light gray/Red1	PP	3	Command Pulse Train Input (PP)	
	Light gray/Black1	PG	4	Command Pulse Train Input (PG)	
	White/Red1	NP	5	Command Pulse Train Input (NP)	
	White/Black1	NG	6	Command Pulse Train Input (NG)	
414/009	Yellow/Red1	AFB	7	Feedback pulse (+A)	
AWG20	Yellow/Black1	/AFB	8	Feedback pulse (-A)	
	Pink/Red1	BFB	9	Feedback pulse (+B)	
	Pink/Black1	/BFB	10	Feedback pulse (-B)	
	Orange/Red2	ZFB	11	Feedback pulse (+Z)	
	Orange/Black2	/ZFB	12	Feedback pulse (-Z)	
	Light gray/Red2	GND	13	0)/	
	Light gray/Black2	GND	14	υv	

# **CC-Link**

#### Specification

Refer to the [SCON2 Field Network Instruction Manual (ME0469)]

Connector

#### Interface Area

Status LED



• Station Number Setting (Pay attention not to duplicate) Station number is set with parameter. Set Parameter No. 85 "Fieldbus Node Address" with using the PC teaching software.

Available range for Setting : 1 to 64 (setting at delivery : 1) Baud Rate Setting

Set Parameter No. 86 "Fieldbus Baud Rate Setting" with using the PC teaching software.

Setting Value	Baud Rate
0 (at the delivery)	156kbps
1	625kbps
2	2.5Mbps
3	5Mbps
4	10Mbps

(Note) After the parameter setting, cycle the control power, and return the mode toggle switch on the front of the controller to "AUTO" side. • Operation Mode Setting and Address Assignment

Please refer to the [SCON2 Field Network Instruction Manual (ME0469)]

	LED	Color	Illumination Status	Contents of display (Detailed Explanation)
	STATUS 1	Orange	Steady Light	<ul> <li>An error occurred (CRC Error, Station Number Switch Setting Error, Baud Rate Switch Setting Error)</li> <li>Since turning the power on or software reset till completion of CC-Link initialization</li> </ul>
E	:KK		Off	Communication in normal condition
				Blinking
:	STATUS 0	Green	Steady Light	Communicating
I	RUN		Off	Not in communication

## Wiring



### **CC-Link IE Field**

Connector

Name

 Specification Refer to the [SCON2 Field Network Instruction Manual (ME0469)]





R	Cable Side Controller Side		Ethernet Category modular (RJ-45)	ANSI/TIA/E 5e and abo plug equipp	IA-568-B ove 8P8C ed with shield	It is to be prepared by the custome
К			Ethernet ANSI/TIA/EIA-568-B Category 5e and above 8P8C modular Jack equipped with shield (RJ-45)			
					Applicat	
	Pin No.	Sign	al Name	Contents	dian	neter
	1	TP0+		Data 0+		
	2	TP0-		Data 0-		
	3	TP1+		Data 1+	It is recommer	ided to
	4	TP2+		Data 2+	prepare a strai	ght STP cable
	5	TP2-		Data 2-	in Category 5e or above fo the Ethernet cable.	
	6	TP1-		Data 1-		
	7	TP3+		Data 3+		
	8	TP3-		Data 3-		

CC-Link IE Field Connector

Remarks

• Status	Status LED				
LED	ED Color Illumination Status		Explanation		
		Steady Light	Cyclic transmission in process		
	Green: D I INK	Blinking	Cyclic transmission paused		
NS	Green. D LINK	Off	Cyclic transmission not conducted, parallel off, Power not supplied		
		Steady Light	Received data in error		
	Red: L ERR	Off	Received data in normal conditions, Power not supplied		
	Croop: BUN	Steady Light	Operation in normal conditions		
	Gleen. Kun	Off	Hardware error occurred, Power not supplied		
MS	Red: ERR	Steady Light	Error being occurred (Node Error / Station Number Setting Error)		
		Off	Operation in normal conditions, Power not supplied		
	Croon	Steady Light	Linkup in process		
LINK	Green	Off	Link-down in process, Power not supplied		
	Orango	Steady Light	Received data in error		
L.ER	Orange	Off	Received data in normal conditions, Power not supplied		

• Wiring







Double shielded cable braided with aluminum foil recommended (Note) Terminal resistance is not required

• Station Number Setting (Pay attention not to duplicate)

Slave Unit

Station number is set with parameter. Set Parameter No. 85 "Fieldbus Node Address" with using the PC teaching software. Available range for Setting : 1 to 120 (setting at delivery : 1) • Operation Mode Setting and Address Assignment

The operation mode is set using the parameters.

Set the parameter No.84 "Fieldbus Operation Mode" using the Teaching tool. Refer to [SCON2 Field Network Instruction Manual (ME0469)] for details.

(Note) Reboot the power supply to the controller after parameter setting, and make sure to set the mode toggle switch on the front panel of the controller to the AUTO side.













(ON: 50m

l ink/

Activity

• Specification

# DeviceNet

Refer to the [SCON2 Field Network Instruction Manual (ME0469)]

atus LED – NS – MS	<ul> <li>Station Number Setting (Pay attention not to duplicate) Station number is set with parameter.</li> <li>Set Parameter No. 85 "Fieldbus Node Address" with using the Teaching tool.</li> <li>Available range for Setting : 0 to 63 (setting at delivery : 63)</li> </ul>
viceNet	<ul> <li>Baud Rate Setting         The setting for the communication speed is not required because         it automatically follows the master's communication speed.     </li> <li>(Note) After the parameter setting, cycle the control power, and return the         mode toggle switch on the front of the controller to "AUTO" side.</li> </ul>
mmunicati nnector	<ul> <li>Operation Mode Setting and Address Assignment Please refer to the [SCON2 Field Network Instruction Manual (ME0469)]</li> </ul>
ion Status	Explanation

ly Light	Connection is established and the communication under normal condition.		
nking	Online but network connection is not yet established. Communication Stop. (Network is normal)		
ly Light	Node address is duplicated or Busoff is detected. Communication Unavailable.		
nking	Communication Error. (Communication Time-out Detection)		
Off	The machine is not on-line. The power to the DeviceNet is not supplied.		
ly Light	The machine is in the normal operation.		
nking	Hardware Error. It might be recovered with reconnect of the power.		
ly Light	Hardware Error. The replacement of the board is required.		
nking	It is a minor error such as a user setting error or configuration error. It can be recovered by re-setting, etc.		
Off	The DeviceNet is being initialized, or the power is not supplied.		



Refer to the [SCON2 Field Network Instruction Manual (ME0469)], [SCON2 EtherCAT Motion Instruction Manual (ME0472)]

Status	LED
—RU	N
-ER	R

l ink/ Activity

Indication Color	Explanation
OFF	Initial condition (EtherCAT® communication in "INIT" condition) or the power is OFF
Green (Illuminating)	In normal operation (EtherCAT® communication in "OPERATION" condition)
Green (Flashing) (ON: 200ms/OFF: 200ms)	(EtherCAT® communication in "PRE-OPERATION" condition)
Green (Flashing) (ON: 200ms/OFF: 1000ms)	(EtherCAT® communication in "SAFE-OPERATION" condition)
Orange (Illuminating)	Communication component (module) error
OFF	No abnormality or the power is OFF
Orange (Flashing) (ON: 200ms/OFF: 200ms)	Construction information (settings) error (Information received from the master cannot be set)
Orange (Flashing) (ON: 200ms/OFF: 1000ms)	Synchronizing Event Error For EtherCAT motion connection type only
Orange (Flashing) (ON:200ms×2 times/OFF:1000ms)	Communication section circuit error (Watchdog timer timeout)
Orange (Illuminating)	Communication component (module) error
OFF	Link status not detected or the power is OFF
Green (Illuminating)	Linked (No network congestion)
Green (Flashing) (ON: 50ms/OFF: 50ms)	Linked (Network in congestion)

• EtherCAT® Connector

	Pin No.	Signal Name	Abbreviated Code
	1	Data sending+	TD+
	2	Data sending-	TD-
	3	Data receiving+	RD+
	4	Not used	
	5	Not used	
	6	Data receiving-	RD-
RJ-45 8-pin	7	Not used	
Modular Connector	8	Not used	
(Controller Side)	Connector Hood	Security grounding	FG

 Operation Mode Setting and Address Assignment The operation mode is set using the parameters.

Set the mode change switch on the controller front panel to "MANU" side and set the parameter No. 84 "Field Bus Operation Mode" using the teaching tool. Refer to the [Instruction Manual] for the details Node address setting

The node address should be determined by setting StationAlias on the master side Baud Rate Setting

It is not necessary to do any settings because it automatically follows the communication settings applied to the master for the communication frequency.

(Note) Reboot the power supply to the controller after parameter setting, and make sure to set the mode toggle switch on the front panel of the controller to the AUTO side.

\* There is no need of setting Parameter No. 84 for the EtherCAT motion connection type.

EtherNet/IP

#### Specification

Refer to the [SCON2 Field Network Instruction Manual (ME0469)]



Status LED Displays of EtherNet/IP Type

Name	Indication Color	Explanation		
	OFF	Power is OFF or IP addresses are not set		
	Green (Illuminating)	Connection is established and the commun	nication under normal condition.	
NS	Green (Flashing)	Online but network connection is not yet established. Communication Stop (Network is normal). Check the conditions of master unit.		
NO	Orange (Illuminating)	Communication Error. Communication cannot be established due to the error detection such as IP address duplication.	Check the conditions of IP address settings, communication line, the	
	Orange (Flashing)	Communication Error. (Communication Time-out Detection)	etc.	
	OFF	Power OFF		
	Green (Illuminating)	The machine is in the normal operation. The machine is under the control of the scanner (master)		
MS	Green (Flashing)	The connection with the scanner (master) is not established. Check the construction information settings. Check if the scanner (master) is in the idle condition.		
	Orange (Illuminating)	Hardware Error. The replacement of the board is required. Please contact us.		
	Orange (Flashing)	There is an error occurred but is not critica configuration error. It can be recovered wit	l such like a user setting error or have a setting arror or have a settings.	

EherNet/IP Connector



 Operation Mode Setting and Address Assignment The operation mode is set using the parameters.

Set the mode change switch on the controller front panel to "MANU" side and set the parameter No. 84 "Field Bus Operation Mode" using the teaching tool.

Refer to the [SCON2 Field Network Instruction Manual (ME0469)] for details

#### Baud Rate Setting

The Communication speed can be set with the parameter. A special setting is not necessary since it is set to automatic negotiation when the product is delivered. However, when a fixed speed is required, change the setting to the desired speed in the parameter No. 86 "Fieldbus Communication Speed" using the teaching tool. Refer to the [SCON2 Field Network Instruction Manual (ME0469)] for details

 IP Address Setting IP Address can be set with the parameter. Set the parameter No. 140 "IP Address" using the teaching tool.

Settable Range : 0.0.0.0 to 255.255.255.255 (It is set to "192.168.0.1" when the machine is delivered from the factory.)

· Settings for Subnet Mask

Subnet Mask can be set with the parameter.

Set the parameter No. 141 "Subnet Mask" using the teaching tool. Settable Range : 0.0.0.0 to 255.255.255.255 (It is set to "255.255.255.0" when the machine is delivered from the factory.)

• Settings for Default Gateway Default Gateway can be set with the parameter.

Set the parameter No. 142 "Default Gateway" using the teaching tool.

Settable Range : 0.0.0.0 to 255.255.255.255 (It is set to "192.168.0.0" when the machine is delivered from the factory.)

(Note) Reboot the power supply to the controller after parameter setting, and make sure to set the mode toggle switch on the front panel of the controller to the AUTO side.

## MECHATROLINK-III

MECHATROLINK-III is applicable for the standard I/O profile and the standard servo profile. When the standard servo profile is to be used, select the functional option "M".

Specification

Status LED

- CON

ERR

Upstream

Connector

Connector

Downstream Side

Side

LK1

LK2

Refer to the [SCON2 Field Network Instruction Manual (ME0469)], [SCON2 MECHATROLINK-III Instruction Manual (ME0471)] Interface Area

- Node address setting
- Node address can be set with the parameter.

Set Parameter No. 85 "Fieldbus Node Address" with using the Teaching tool.

Available range for Setting : 3 to 239 [hex] (setting at delivery : 3) Data Length Setting

Establish the setting in Parameter No. 86 "Fieldbus Communication Speed" in Teaching tool considering the data length to be used.

ata I/C

• For Remote I/O			
	Setting Value	Data Length	Baud Rate
	0	16 bytes	
	1	32 bytes	100Mbps
	2 (at the delivery)	48 bytes	Toombpa

For Motion Type

· For Motion Type				
Setting Value	Data Length	Baud Rate		
0	32 bytes			
1 (at the delivery)	48 bytes	100Mbps		

Electronic Gear Ratio Setting

11

Set the electronic gear numerator in Parameter No. 65 "Electronic Gear Numerator" and the electronic gear denominator in No. 66 "Electronic Gear Denominator" in the Teaching tool. Establish the settings to satisfy the following condition:

Electronic Gear Ratio Denominator  $\leq 2^{31}$ Ball Screw Lead Length (mm) × No. of Encoder Pulses × Stroke (mm) Electronic Gear Ratio Numerator

• Pulse Count Direction Setting

Set the value in Parameter No. 62 "Pulse Count Direction" to be the same as what is set in No. 5 "Home-Return Direction" in the Teaching tool.

(Note) After the parameter setting, cycle the control power, and return the mode toggle switch on the front of the controller to "AUTO" side

<ul> <li>Status</li> </ul>	Status LED				
LED	Color	Illumination Status	Explanation		
CON	Green	Steady Light	Receiving CONNECT (connected to master)		
CON	-	Off	Connection is not established to master		
ERR	Orange	Steady Light	Illumination flashes when communication alarm or command alarm is generated (warning excepted). Illumination turned off when alarm is cancelled		
	-	Off	In normal condition (no alarm generated)		
LK1	Green	Steady Light	Illumination turns on when physically connected to another device		
LK2	Green	Steady Light	applicable for MECHATROLINK-III (for cable breakage check purpose)		

Wiring

Connect the dedicated cable for MECHATROLINK.

# **PROFINET IO**

#### Specification

Refer to the [SCON2 Field Network Instruction Manual (ME0469)]



Status LED Displays of PROFINET IO Type					
Name	Indication Color	Explanation			
	OFF	Power is OFF, or there is no connectable controller.			
NS	Green (Illuminating)	Connection has been established and proper communication is in progress. (in RUN condition) Check the condition of the master unit.			
	Green (Flashing)	Connection is established but communication is paused (in STOP condition: network in normal condition). Check the condition of the master unit.			
	OFF	The power is turned OFF.			
	Green (Illuminating)	Operation is normal.			
	Green (Flashing)	Communication under diagnosis			
MS	Orange (Illuminating)	A hardware error is present. (in EXCEPTION condition) The board must be replaced. Please contact IAI.			
IVIS	Orange (Flashing 1)	There is an error in communication setting.			
	Orange (Flashing 2)	There is an error in IP address setting.			
	Orange (Flashing 3)	A wrong station name has been applied.			
	Orange (Flashing 4)	A hardware error is present. (Critical internal error) The board must be replaced. Please contact IAI.			
Link/Activity	OFF	No link or activity			
	Green (Illuminating)	Link established			
	Crean (Fleehing)	In activity (communication)			

Orange (Flashing 1): Repeating of off for 0.75s and on for 0.25s Orange (Flashing 3): Repeating three times of pattern of off for 0.75s and on for 0.5s



(Controller Side) Operation Mode Setting and Address Assignment

- The operation mode is set using the parameters. Manual (ME0469)] for the details. Baud Rate Setting
- Node address setting

Green (Flashing) In activity (communicatio

Orange (Flashing 2): Repeating two times of pattern of off for 0.75s and on for 0.5s

Orange (Flashing 4): Repeating four times of pattern of off for 0.75s and on for 0.5s

PROFINET IO Connector

Pin No.	Signal Name	Abbreviated Code
1	Data sending+	TD+
2	Data sending-	TD-
3	Data receiving+	RD+
4	Not used	
5	Not used	
6	Data receiving-	RD-
7	Not used	
8	Not used	
Connector Hood	Security grounding	FG

Set the mode change switch on the controller front panel to "MANU" side and set the parameter No. 84 "Field Bus Operation Mode" using the teaching tool. Refer to the [SCON2 Field Network Instruction

It is not necessary to establish setting. It is fixed at 100Mbps.

It is not necessary to establish setting on the IAI controller side as it should be established on the master

Refer to the [instruction manual of the host unit that the master unit is mounted in.]

(Note) Reboot the power supply to the controller after parameter setting, and make sure to set the mode toggle switch on the front panel of the controller to the AUTO side.

## **Starting Procedures**

When using this product for the first time, make sure to avoid mistakes and incorrect wiring by referring to the procedure below. "PC" stated in this section means "IA-OS".

* Refer to instruction manuals for the servo-press type and R-Unit Connection Type for startup.	

Are there all the delivered items?	→NO	ntact the distributor.		
Initial Operation Check Connect controller and actuator. Connect a teaching tool, set the o Confirm the operation by perform	operation mode setting switch ing a home-return operation a	to "MANU" side and turn the nd jog operation in full stroke	power on. e range on the teach	ing tool.
Installation and Wiring Install and wire the actuator and t instructions described in the Instr	he controller following the uction Manual and this guide.	→ ←YES Point C • Is fram • Has th	heck Item ne ground (FG) conr ne noise countermea	nected? asure been taken?
Power Supply and Alarm Check Connect a teaching tool, turn the to "MANU" side and turn the pow Select "Teaching Mode 1 Safety Operation Invalid" in the teaching	mode changeover switch er on for each unit. Speed Activated / PIO tool.	Check Item Is the orange light "ALM" the LED status display of	r' on a ff? →NO tt tr	Connect the teaching tool ind check the content of ne alarm to have the right reatment.
Servo ON Turn the servo on with the operat teaching tool.	ion on the $\rightarrow$ t	Checking Items s the green light "SV" on he LED status display on?	→NO	If an alarm is generated, connect the teaching tool and check the content of the alarm to have the right treatment.
▲ CAUTION It may generate an alarm if the a turned on. Keep the actuator aw The slider may get slightly dropp position. Be careful not to pinch	ctuator hit the mechanical end ay from them as much as pose ed by self-weight if servo on a the hand or damage the work.	l or interfering subjects wher sible. nd off is repeatedly performe	n the servo is ed at the same ↓	YES
Safety Circuit Check Does the emergency stop circuit	: (drive cutoff circuit) work pro	perly and		
turn the servo off?		→NO	Check t	the emergency stop circuit.
turn the servo off? JYES Target Position Setting Set the target position in "Positic Have the home-return operation When moving the actuator mann Put the switch back after the set	on" Box in each position table. conducted first when the dire ally, set the Brake Release S ting is complete.	-→NO ct teaching is to be executed witch to "BL RLS" side for th	Check t I. e brake equipped ty	the emergency stop circuit.
turn the servo off? IYES Target Position Setting Set the target position in "Positic Have the home-return operation When moving the actuator man. Put the switch back after the set CAUTION Be careful not to pinch the ham self-weight when turning the br	on" Box in each position table. conducted first when the dire ally, set the Brake Release S ting is complete. d or damage the mechanical h ake release switch to "BK RLS	→NO ct teaching is to be executed witch to "BL RLS" side for the hand by the slider dropped w s" side if it is mounted vertice	Check 1 l. e brake equipped typ ith the ally.	the emergency stop circuit.
turn the servo off? ↓YES Target Position Setting Set the target position in "Positic Have the home-return operation When moving the actuator manu- Put the switch back after the set M_CAUTION Be careful not to pinch the ham self-weight when turning the br ↓ M_CAUTION To ensure safety,	on" Box in each position table. conducted first when the dire ially, set the Brake Release S ting is complete. d or damage the mechanical h ake release switch to "BK RLS it is recommended that safety	→NO ct teaching is to be executed witch to "BL RLS" side for the trand by the slider dropped w state if it is mounted vertice r speed be enabled during in	Check 1	pe.
turn the servo off? ↓YES Target Position Setting Set the target position in "Position Have the home-return operation When moving the actuator mann. Put the switch back after the set ▲CAUTION Be careful not to pinch the hann self-weight when turning the br ↓ ▲CAUTION To ensure safety, Test Run Adjustment 1 Have an operation check done w the safety velocity disabled in th teaching tool and with no workpio loaded, and then check operatio	on" Box in each position table. conducted first when the dire ally, set the Brake Release S ting is complete. d or damage the mechanical I ake release switch to "BK RLS it is recommended that safety vith ceece n	→NO	Check t I. e brake equipped typ ith the ally. itial movements. Check the actuator if condition for use is b adjust the servo <sup>4</sup> if ne	the emergency stop circuit.
turn the servo off? ↓YES Target Position Setting Set the target position in "Position Have the home-return operation When moving the actuator manu. Put the switch back after the set ACAUTION Be careful not to pinch the han self-weight when turning the br ↓ ① CAUTION To ensure safety, Test Run Adjustment 1 Have an operation check done w the safety velocity disabled in th teaching tool and with no workpi loaded, and then check operatio with a workpiece loaded.	on" Box in each position table. conducted first when the dire ally, set the Brake Release S ting is complete. d or damage the mechanical I ake release switch to "BK RLS it is recommended that safety vith Check e Check to "NO Check the Use the for	→NO ct teaching is to be executed witch to "BL RLS" side for the trand by the slider dropped w s" side if it is mounted vertica respeed be enabled during in ttem →NO C $\downarrow$ YES m →YES rec control?	Check t i. e brake equipped typ ith the ally. Check the actuator if condition for use is b adjust the servo-lif ne nitial Setting for Ford Perform the initial set allibration on the teal	the emergency stop circuit.

Action to Take When Error Occurred

It is an alarm that may occur during startup. Have an appropriate treatment following the instructions below. Please refer to the Instruction Manual for other alarms.

Error Code	Error Description	Cause and Treatment
069	Real Time Clock Operation Stop Detection	It indicates the calendar function has stopped and the current time data has lost. Have the clock settings again from the teaching tool.
0A5	Electromagnetic Brake Release Failure Error	Brake could not be released for the electromagnetic brake equipped type. Check the 24V power supply for electromagnetic brake.
0CF	I/O 24V Power Supply Error	An error is occurred in 24V power supply for PIO. Check the voltage of the 24V power supply for PIO.
0E5	Encoder Receive Error	This error code appears when the right signal was not received from the encoder side to the controller command. Check if any wire breakage on a connector and the condition of wire connections. If no error is generated under the condition that the power to all the peripheral equipment is shut and operate only this controller and the actuator, noise can be considered as the cause of the problem.
0E7	A-, B- and Z-Phases Breakage Error	It is the condition that the encoder signal is not properly detected. Check if any wire breakage on a connector and the condition of wire connections.
0EE	Absolute Encoder Error Detection 2	This error code appears when the absolute encoder PCB cannot detect the position information properly. The voltage for the absolute data battery is dropped. Check the battery alarm output on PIO, and if it is OFF, replace the battery. Perform Absolute Reset after the replacement. Check the encoder cable connection.
20A	Servo OFF While in Operation	It shows the operation command was generated in the condition that the servo is OFF. Resume the operation after turning the servo ON.

# Quality and Innovation

# **IAI** Corporation

Head Office: 577-1 Obane Shimizu-KU Shizuoka City Shizuoka 424-0103, Japan TEL +81-54-364-5105 FAX +81-54-364-2589 website: www.iai-robot.co.jp/

# IAI America, Inc.

Head Office: 2690 W. 237th Street, Torrance, CA 90505 TEL +1-310-891-6015 FAX +1-310-891-0815 Chicago Office: 110 East State Parkway, Schaumburg, IL 60173 TEL +1-847-908-1400 FAX +1-847-908-1399 Atlanta Office: 1220 Kennestone Circle, Suite 108, Marietta, GA 30066 TEL +1-678-354-9470 FAX +1-678-354-9471 website: www.intelligentactuator.com

Technical Support available in Europe

Ober der Röth 4, D-65824 Schwalbach am Taunus, Germany TEL +49(0)6196-88950 FAX +49(0)6196-889524 website:www.iai-automation.com



Duttons Way, Shadsworth Business Park, Blackburn, Lancashire, BB1 2QR, United Kingdom TEL +44(0)1254-685900 website: www.lcautomation.com

# IAI (Shanghai) Co., Ltd.

SHANGHAI JIAHUA BUSINESS CENTER A8-303, 808, Hongqiao Rd. Shanghai 200030, China TEL +86-21-6448-4753 FAX +86-21-6448-3992 website: www.iai-robot.com

# IAI Robot (Thailand) Co., Ltd.

825 PhairojKijja Tower 7th Floor, Debaratana RD., Bangna-Nuea, Bangna, Bangkok 10260, Thailand TEL +66-2-361-4458 FAX +66-2-361-4456 website:www.iai-robot.co.th

Manual No.: ME0468-1C